

ABB industrial drives

Firmware manual

ACS880 PCP/ESP control program



Power and productivity
for a better world™



List of related manuals

Drive hardware manuals

Code (English)

| | |
|--|--------------------------------|
| <i>ACS880-01 drives hardware manual</i> | 3AUA0000078093 |
| <i>ACS880-07 drives (45 to 250 kW, 60 to 300 hp) hardware manual</i> | 3AUA0000105718 |
| <i>ACS880-07 drives (560 to 2800 kW) hardware manual</i> | 3AUA0000143261 |
| <i>ACS880-104 inverter modules hardware manual</i> | 3AUA0000104271 |
| <i>ACS880-107 inverter units hardware manual</i> | 3AUA0000102519 |

Drive firmware manuals and guides

| | |
|---|---------------------------------|
| <i>ACS880 primary control program firmware manual</i> | 3AUA0000085967 |
| <i>ACS880 drives with primary control program, quick start-up guide</i> | 3AUA0000098062 |
| <i>ACS880 PCP/ESP control program firmware manual</i> | 3AXD50000016186 |

Option manuals and guides

| | |
|--|--------------------------------|
| <i>ACS-AP-x assistant control panels user's manual</i> | 3AUA0000085685 |
| <i>Drive composer Start-up and maintenance PC tool User's manual</i> | 3AUA0000094606 |

Manuals and quick guides for I/O extension modules, fieldbus adapters, encoder interfaces, etc.

You can find manuals and other product documents in PDF format on the Internet. See section [Document library on the Internet](#) on the inside of the back cover. For manuals not available in the Document library, contact your local ABB representative.



[ACS880-01 manuals](#)



[ACS880-07 manuals](#)

Firmware manual

ACS880 PCP/ESP control program

Table of contents



2. Quick start-up guide for ACS880 drives



3. PCP/ESP control start-up



Table of contents

| | |
|-------------------------------|---|
| List of related manuals | 2 |
|-------------------------------|---|

1. Introduction

| | |
|--------------------------------|----|
| Contents of this chapter | 11 |
| Applicability | 11 |
| Safety instructions | 11 |
| Target audience | 12 |
| Contents of the manual | 12 |
| Related documents | 12 |
| Terms and abbreviations | 13 |

2. Quick start-up guide for ACS880 drives

| | |
|------------------------|----|
| About this guide | 15 |
| Before you start | 15 |
| Safety | 15 |
| Start-up | 17 |



3. PCP/ESP control start-up

| | |
|--------------------------------|----|
| Contents of this chapter | 23 |
| PCP/ESP control start-up | 23 |

4. Using the control panel

5. PCP/ESP program features

| | |
|---|----|
| Contents of this chapter | 31 |
| Overview of PCP/ESP control program | 31 |
| Construction of PCP/ESP system | 32 |
| Progressive cavity pump (PCP) | 32 |
| Electric submersible pump (ESP) | 33 |
| Pump starting speed | 33 |
| Settings | 34 |
| Pump level control | 34 |
| Timing diagram | 34 |
| Sleep and wake up function | 35 |
| Pump pressure protection | 40 |
| Timing diagram | 41 |
| Settings | 41 |
| Pump torque protection | 41 |
| Rod torque 1 function | 42 |
| Rod torque 2 function | 43 |
| Pump underload protection | 44 |
| Timing diagram | 45 |
| Settings | 45 |

6 Table of contents

| | |
|-----------------------------|----|
| Pump temperature protection | 45 |
| Timing diagram | 45 |
| Settings | 46 |
| Shutdown procedure | 47 |
| Pump backspin control | 47 |
| Start delay | 49 |
| Brake confirmation | 50 |

6. Standard programposi features

| | |
|---|----|
| Contents of this chapter | 51 |
| Local control vs. external control | 51 |
| Local control | 52 |
| External control | 53 |
| Operating modes of the drive | 53 |
| Speed control mode | 54 |
| Frequency control mode | 54 |
| Drive configuration and programming | 54 |
| Programming through parameters | 54 |
| Application programming | 55 |
| Control interfaces | 55 |
| Programmable analog inputs | 55 |
| Programmable analog outputs | 55 |
| Programmable digital inputs and outputs | 55 |
| Programmable relay outputs | 56 |
| Programmable I/O extensions | 56 |
| Fieldbus control | 57 |
| Motor control | 57 |
| Direct torque control (DTC) | 57 |
| Reference ramping | 58 |
| Critical speeds (frequencies) | 59 |
| Speed controller autotune | 59 |
| Oscillation damping | 62 |
| Rush control | 62 |
| Encoder support | 63 |
| Position counter | 66 |
| Jogging | 69 |
| Position latching | 71 |
| Scalar motor control | 71 |
| Autophasing | 73 |
| Flux braking | 75 |
| DC magnetization | 77 |
| Application control | 78 |
| Motor potentiometer | 78 |
| DC voltage control | 79 |
| Overvoltage control | 79 |
| Undervoltage control | 79 |
| Voltage control and trip limits | 81 |
| Brake chopper | 82 |
| Safety and protections | 82 |
| Emergency stop | 82 |



| | |
|---|----|
| Motor thermal protection | 83 |
| Thermal protection of motor cable | 86 |
| Other programmable protection functions | 86 |
| Automatic fault resets | 89 |
| Diagnostics | 89 |
| Signal supervision | 89 |
| Maintenance timers and counters | 89 |
| Energy savings calculator | 90 |
| Load analyzer | 90 |
| Miscellaneous | 92 |
| User parameter sets | 92 |
| Data storage parameters | 92 |
| du/dt filter support | 93 |
| Sine filter support | 93 |

7. Default control connections

| | |
|--|----|
| Contents of this chapter | 95 |
| PCP/ESP I/O control connections | 96 |
| Sensor connection examples | 97 |
| Application control PCP/ESP | 98 |
| Default parameter settings for the PCP/ESP | 98 |



8. Parameters

| | |
|---------------------------------|-----|
| Contents of this chapter | 101 |
| Terms and abbreviations | 101 |
| Summary of parameter groups | 103 |
| Parameter listing | 105 |
| 01 Actual values | 105 |
| 03 Input references | 108 |
| 04 Warnings and faults | 109 |
| 05 Diagnostics | 115 |
| 06 Control and status words | 116 |
| 07 System info | 124 |
| 09 Pump actuals | 125 |
| 10 Standard DI, RO | 128 |
| 11 Standard DIO, FI, FO | 134 |
| 12 Standard AI | 140 |
| 13 Standard AO | 144 |
| 14 I/O extension module 1 | 149 |
| 15 I/O extension module 2 | 171 |
| 16 I/O extension module 3 | 174 |
| 19 Operation mode | 178 |
| 20 Start/stop/direction | 180 |
| 21 Start/stop mode | 189 |
| 22 Speed reference selection | 195 |
| 23 Speed reference ramp | 203 |
| 24 Speed reference conditioning | 210 |
| 25 Speed control | 213 |
| 26 Torque reference chain | 224 |

8 Table of contents

| | |
|--------------------------------|-----|
| 28 Frequency reference chain | 226 |
| 30 Limits | 235 |
| 31 Fault functions | 241 |
| 32 Supervision | 251 |
| 33 Generic timer & counter | 254 |
| 35 Motor thermal protection | 262 |
| 36 Load analyzer | 272 |
| 43 Brake chopper | 276 |
| 45 Energy efficiency | 277 |
| 46 Monitoring/scaling settings | 280 |
| 47 Data storage | 281 |
| 49 Panel port communication | 283 |
| 50 Fieldbus adapter (FBA) | 284 |
| 51 FBA A settings | 291 |
| 52 FBA A data in | 293 |
| 53 FBA A data out | 293 |
| 54 FBA B settings | 294 |
| 55 FBA B data in | 295 |
| 56 FBA B data out | 296 |
| 58 Embedded fieldbus | 296 |
| 74 Pump setup | 303 |
| 75 Pump level control | 307 |
| 76 Pump pressure protection | 310 |
| 77 Pump torque protection | 311 |
| 78 Pump underload protection | 314 |
| 79 Pump temperature protection | 315 |
| 80 Pump backspin control | 316 |
| 90 Feedback selection | 318 |
| 91 Encoder module settings | 327 |
| 92 Encoder 1 configuration | 330 |
| 93 Encoder 2 configuration | 336 |
| 95 HW configuration | 338 |
| 96 System | 342 |
| 97 Motor control | 348 |
| 98 User motor parameters | 351 |
| 99 Motor data | 353 |
| 200 Safety | 359 |

9. Additional parameter data

| | |
|--------------------------|-----|
| Contents of this chapter | 361 |
| Terms and abbreviations | 361 |
| Fieldbus addresses | 362 |
| Parameter groups 1...9 | 363 |
| Parameter groups 10...99 | 367 |

10. Fault tracing

| | |
|--------------------------|-----|
| Contents of this chapter | 405 |
| Safety | 405 |
| Indications | 405 |



| | |
|---|-----|
| How to reset faults | 406 |
| Warning/fault history | 406 |
| Event logs | 406 |
| Parameters warning/fault information | 406 |
| QR code generation for mobile service application | 407 |
| Warning messages | 408 |
| Fault messages | 421 |

11. Fieldbus control through the embedded fieldbus interface (EFB)

| | |
|--|-----|
| What this chapter contains | 437 |
| System overview | 437 |
| Connecting the fieldbus to the drive | 438 |
| Setting up the embedded fieldbus interface | 439 |
| Setting the drive control parameters | 440 |
| Basics of the embedded fieldbus interface | 442 |
| Control word and Status word | 443 |
| References | 443 |
| Actual values | 443 |
| Data input/outputs | 443 |
| Register addressing | 445 |
| About the control profiles | 446 |
| The ABB Drives profile | 447 |
| Control Word | 447 |
| Status Word | 449 |
| State transition diagram | 450 |
| References | 451 |
| Actual values | 452 |
| Modbus holding register addresses | 453 |
| The Transparent profile | 454 |
| Modbus function codes | 455 |
| Exception codes | 456 |
| Coils (0xxxx reference set) | 457 |
| Discrete inputs (1xxxx reference set) | 458 |
| Error code registers (holding registers 400090...400100) | 460 |



12. Fieldbus control through a fieldbus adapter

| | |
|---|-----|
| Contents of this chapter | 461 |
| System overview | 462 |
| Basics of fieldbus control interface | 464 |
| Control word and Status word | 465 |
| References | 465 |
| Actual values | 466 |
| Contents of fieldbus Control word | 467 |
| Contents of the fieldbus Status word | 468 |
| The state diagram | 470 |
| Setting up the drive for fieldbus control | 471 |
| Parameter setting example: FPBA (PROFIBUS DP) | 471 |
| Parameter setting example: Using PCP/ESP application through FPBA | 473 |

13. Control chain diagrams

| | |
|--|-----|
| Contents of this chapter | 475 |
| Speed reference source selection for application | 476 |
| Speed reference source selection I | 477 |
| Speed reference source selection II | 478 |
| Speed reference ramping and shaping | 479 |
| Motor feedback configuration | 480 |
| Load feedback and position counter configuration | 481 |
| Speed error calculation | 482 |
| Speed controller | 483 |
| Frequency reference selection | 484 |
| Frequency reference modification | 485 |

14. Appendix: ESP with step-up transformer and sine filter

| | |
|--|-----|
| Contents of this chapter | 487 |
| ESP with step-up transformer and sine filter | 487 |
| Block digram | 487 |
| Current calculation | 488 |
| Primary and secondary voltage calculation | 488 |
| Example | 490 |



Further information

| | |
|--|-----|
| Product and service inquiries | 493 |
| Product training | 493 |
| Providing feedback on ABB Drives manuals | 493 |
| Document library on the Internet | 493 |



Introduction

Contents of this chapter

This chapter describes the compatibility, safety instructions, intended audience and contents of this manual. It also contains a list of terms and abbreviations used in this manual.

Applicability

This manual applies to the ACS880 PCP/ESP control program (version 2.12 or later).

The firmware version of the control program is visible in parameter [07.05 Firmware version](#), or the **System info** in the main menu on the control panel.

The application version of the control is visible in the **System info** in the main menu on the control panel.

Safety instructions

Obey all safety instructions for the drive.

- Read the **complete safety instructions** before you install, commission, or use the drive. The complete safety instructions are delivered with the drive as either part of the *Hardware manual*, or, in the case of ACS880 multidrives, as a separate document.
 - Read the **firmware function-specific warnings and notes** before changing parameter values. These warnings and notes are included in the parameter descriptions presented in chapter [Parameters](#).
-

Target audience

This manual is intended for people who design, commission, or operate the drive system.

Contents of the manual

This manual contains the following chapters:

- [Quick start-up guide for ACS880 drives](#) (page 15) describes the start-up sequence of the pump control program.
- [PCP/ESP control start-up](#) (page 23) describes the start-up sequence of the pump control program.
- [Using the control panel](#) (page 29) refers to the instructions for using the control panel.
- [PCP/ESP program features](#) (page 31) describes the program features specific to the progressive cavity pump (PCP)/Electric submersible pump (ESP) applications.
- [Standard program features](#) (page 51) describes the control locations and operation modes as well as the program features that are not specific to PCP/ESP applications.
- [Default control connections](#) (page 95) presents the default connection diagram of the PCP/ESP control application.
- [Parameters](#) (page 101) describes the parameters of the drive.
- [Additional parameter data](#) (page 361) contains further information on the parameters.
- [Fault tracing](#) (page 405) lists the warning and fault messages with possible causes and remedies.
- [Fieldbus control through the embedded fieldbus interface \(EFB\)](#) (page 437) describes the communication to and from a fieldbus network using the embedded fieldbus interface of the drive.
- [Fieldbus control through a fieldbus adapter](#) (page 461) describes the communication to and from a fieldbus network using an optional fieldbus adapter module.
- [Control chain diagrams](#) (page 475) shows the parameter structure within the drive.
- [Appendix: ESP with step-up transformer and sine filter](#) (page 487) provides an overview of ESP with step-up transformer and sine filter.

Related documents

A list of related manuals is printed on the inside of the front cover.

Terms and abbreviations

| Term/abbreviation | Definition |
|-------------------|---|
| AC 800M | Type of programmable controller manufactured by ABB. |
| ACS-AP-I | Type of control panel used with ACS880 drives |
| AI | Analog input; interface for analog input signals |
| AO | Analog output; interface for analog output signals |
| BCU | Type of control unit used in ACS880 drives, primarily those with parallel-connected inverter or supply modules. |
| DC link | DC circuit between rectifier and inverter |
| DI | Digital input; interface for digital input signals |
| DIO | Digital input/output; interface that can be used as a digital input or output |
| DO | Digital output; interface for digital output signals |
| Drive | Frequency converter for controlling AC motors. The drive consists of a rectifier and an inverter connected together by the DC link. In drives up to approximately 500 kW, these are integrated into a single module (drive module). Larger drives typically consist of separate supply and inverter units. The ACS880 PCP/ESP control program is used to control the inverter part of the drive. |
| DriveBus | A communication link used by, for example, ABB controllers. ACS880 drives can be connected to the DriveBus link of the controller. |
| DTC | Direct torque control. See page 57 . |
| EFB | Embedded fieldbus |
| ESP | Electric submersible pump. See also Electric submersible pump (ESP) on page 33 . |
| FBA | Fieldbus adapter |
| FEN-01 | Optional TTL encoder interface module |
| FEN-11 | Optional absolute encoder interface module |
| FEN-21 | Optional resolver interface module |
| FEN-31 | Optional HTL encoder interface module |
| FEX-01 | Optional temperature measurement module for potentially explosive atmospheres. Not released for sales at the time of publication. |
| FIO-01 | Optional digital I/O extension module |
| FIO-11 | Optional analog I/O extension module |
| FCAN-01 | Optional CANopen adapter |
| FCNA-01 | Optional ControlNet adapter |
| FDNA-01 | Optional DeviceNet adapter |
| FECA-01 | Optional EtherCAT® adapter |
| FENA-11 | Optional Ethernet/IP, Modbus/TCP and PROFINET IO adapter |
| FENA-21 | Optional dual-port Ethernet/IP, Modbus/TCP and PROFINET IO adapter |
| FEX-01 | Optional temperature measurement module for potentially explosive atmospheres. Not released for sales at the time of publication. |
| FEPL-02 | Optional POWERLINK adapter |
| FPBA-01 | Optional PROFIBUS DP adapter |
| FPTC-01 | Optional temperature measurement module. Not released for sales at the time of publication. |
| FSCA-01 | Optional Modbus/RTU adapter |

| Term/abbreviation | Definition |
|-------------------|--|
| FSO-xx | Optional safety functions module |
| HTL | High-threshold logic |
| IGBT | Insulated gate bipolar transistor; a voltage-controlled semiconductor type widely used in inverters due to their easy controllability and high switching frequency |
| I/O | Input/Output |
| ID run | Motor identification run. During the identification run, the drive will identify the characteristics of the motor for optimum motor control. |
| LSB | Least significant bit |
| LSW | Least significant word |
| ModuleBus | A communication link used by, for example, ABB controllers. ACS880 drives can be connected to the optical ModuleBus link of the controller. |
| MSB | Most significant bit |
| MSW | Most significant word |
| Network control | With fieldbus protocols based on the Common Industrial Protocol (CIP™), such as DeviceNet and Ethernet/IP, denotes the control of the drive using the Net Ctrl and Net Ref objects of the ODVA AC/DC Drive Profile. For more information, see www.odva.org , and the following manuals: FDNA-01 DeviceNet adapter module User's manual (3AFE68573360 [English]), and FENA-01/-11 Ethernet adapter module User's manual (3AUA0000093568 [English]). |
| Parameter | User-adjustable operation instruction to the drive, or signal measured or calculated by the drive |
| PCP | Progressive cavity pump. See also Progressive cavity pump (PCP) on page 32. |
| PID controller | Proportional–integral–derivative controller. Drive speed control is based on PID algorithm. |
| PLC | Programmable logic controller |
| Power unit | Contains the power electronics and connections of the drive. The drive control unit is connected to the power unit. |
| Prpm | Pump rpm, units for pump speed. |
| PTC | Positive temperature coefficient |
| RFG | Ramp function generator. |
| RO | Relay output; interface for a digital output signal. Implemented with a relay. |
| SSI | Synchronous serial interface |
| STO | Safe torque off |
| TTL | Transistor–transistor logic |
| UPS | Uninterrupted power supply; power supply equipment with battery to maintain output voltage during power failure |
| ZCON | Type of control board used in ACS880 drives. The board is either integrated into the drive or fitted in a plastic housing. See ZCU . |
| ZCU | Type of control unit used in ACS880 drives that consists of a ZCON board built into a plastic housing. The control unit may be fitted onto the drive/inverter module, or installed separately. |

2

Quick start-up guide for ACS880 drives

About this guide

This guide describes the basic start-up sequence of an ACS880 drive. Complete documentation of the drive firmware can be found in *Firmware manual* (see list of manuals on the inside of the front cover).

In this guide, the drive is set up using the start-up assistant on the ACS-AP-I control panel. The start-up assistant guides the user through the essential drive settings.

The start-up assistant is not available in the Drive composer PC tool as such, but the same settings (apart from those related to the control panel itself) can also be made through drive parameters using Drive composer. For more information, refer to *Drive composer Start-up and maintenance PC tool User's manual* (3AUA0000094606 [English]).

Before you start

Ensure that the drive has been mechanically and electrically installed as described in the appropriate *Quick installation guide* and/or *Hardware manual*.

The data presented on the rating plate of the motor is needed during the start-up.

Safety











WARNING! All electrical installation and maintenance work on the drive should be carried out by qualified electricians only.






















Never work on the drive, the braking chopper circuit, the motor cable or the motor when power is applied to the drive. Always ensure by measuring that no voltage is actually present.












































Start-up

| Safety | |
|---|--|
|  | The start-up may only be carried out by a qualified electrician. The safety instructions must be followed during the start-up procedure. See the safety instructions on the first pages of the appropriate <i>Hardware manual</i> . |
| <input type="checkbox"/> | Check the installation. See the installation checklist in the appropriate <i>Hardware manual</i> . |
| <input type="checkbox"/> | Check that the starting of the motor does not cause any danger. De-couple the driven machine if <ul style="list-style-type: none"> • there is a risk of damage in case of an incorrect direction of rotation, or • a Normal ID run is required during the drive start-up, when the load torque is higher than 20% or the machinery is not able to withstand the nominal torque transient during the ID run. |
| 1 – Power-up, language, date and time settings | |
| <input type="checkbox"/> | Power up the drive. The language selection menu appears. |
| |  |
| <input type="checkbox"/> | Wait until the loading finishes and the Home view appears. Note: During the start-up, it is normal that warning messages are displayed either in the top or main pane of the display. The messages can be ignored at this point. To hide any warnings displayed in the main pane, press  (Hide). The two commands at the bottom of the display (in this case, Options and Menu), show the functions of the two softkeys  and  located below the display. The commands assigned to the softkeys vary depending on the context. |
| |  |
| <input type="checkbox"/> | In the Home view, press  (Menu). The main Menu appears. |
| |  |







| | | |
|--------------------------|--|---|
| <input type="checkbox"/> | <p>Highlight Assistants on the menu using  and  and press  (Select). A listing of available assistants appears.</p> |  |
| <input type="checkbox"/> | <p>Highlight Basic setup on the menu using  and  and press  (Select). The first setting of the assistant appears. At any point, use  to return to the previous setting (and ultimately cancel the assistant). During the assistant, a progress bar shows how much of the assistant has been completed.</p> |  |
| <input type="checkbox"/> | <p>Highlight the desired language on the list using  and  and then press  (Next). The default units settings appear.</p> |  |
| <input type="checkbox"/> | <p>Highlight the desired unit on the list using  and  and then press  (Next). The Units settings appear.</p> |  |
| <input type="checkbox"/> | <p>To change any of the unit settings, highlight it on the list using  and  and then press . As an example, the changing of unit is shown on the right.</p> |  |


























| | | |
|---|--|---|
| <input type="checkbox"/> | <p>Highlight the desired unit on the list using  and  and then press  (Next).</p> <p>The date and time settings appear.</p> |  <p>Remote  ACS880 0.0 rpm</p> <p>Date & Time </p> <p>Please enter the current date and time.</p> <p>Date 23.01.2015 </p> <p>Time 10:59:25 </p> <p>Show date as day.month.year </p> <p>Show time as 24-hour </p> <p>Back 10:59 Next</p> |
| <input type="checkbox"/> | <p>To change any of the settings, highlight it on the list using  and  and then press .</p> <p>As an example, the adjustment of date is shown on the right.</p> |  <p>Remote  ACS880 0.0 rpm</p> <p>96.16 Unit selection</p> <p>0   Power unit =kW</p> <p>2   Temperature unit =°C</p> <p>4   Torque unit =Nm</p> <p>Cancel 11:33 Save *</p> |
| <input type="checkbox"/> | <p>To set the correct date:</p> <ul style="list-style-type: none"> • Use  and  to move the cursor left and right. • Use  and  to change the value. • Press  (Save) to accept the new date and return to the date and time settings. |  <p>Remote  ACS880 0.0 rpm</p> <p>Date & Time </p> <p>Please enter the current date and time.</p> <p>Date 27.01.2015 </p> <p>Time 10:47:50 </p> <p>Show date as day.month.year </p> <p>Show time as 24-hour </p> <p>Back 10:48 Next</p> |
| <input type="checkbox"/> | <p>Make the necessary changes in the other date and time settings and press  (Next).</p> <p>The screen for selecting the supply voltage appears.</p> |  <p>Remote  ACS880 0.0 rpm</p> <p>Supply voltage </p> <p>Set supply voltage.</p> <p>Supply voltage Not given </p> <p>Back 11:42 Next</p> |
| <h2>2 – Supply voltage and motor data settings</h2> | | |
| <input type="checkbox"/> | <p>To define the supply voltage, press .</p> <p>The adjustment screen for parameter 95.01 appears.</p> <p>Note: The list of selections available in this parameter depends on the drive hardware.</p> |  <p>Remote  ACS880 0.0 rpm</p> <p>95.01 Supply voltage</p> <p>[0] Not given</p> <p>[2] 380...415 V</p> <p>Cancel 11:00 Save</p> |













| | | |
|--------------------------|---|---|
| <input type="checkbox"/> | <p>Highlight the correct setting on the list and press (Save) to return to the previous screen.</p> |  |
| <input type="checkbox"/> | <p>Press (Next). The motor data screen appears.</p> |  |
| <input type="checkbox"/> | <p>Use to enter the adjustment screen for each motor value.</p> <p>Notes:</p> <ul style="list-style-type: none"> Enter the values <u>exactly</u> as shown on the motor nameplate (examples shown below). With permanent magnet motors, the nominal voltage is the BackEMF voltage at nominal speed. If the voltage is given in volt/rpm (eg. 60 V per 1000 rpm), the voltage at a nominal speed of 3000 rpm is $3 \times 60 \text{ V} = 180 \text{ V}$. Note that nominal voltage is not the same as equivalent DC motor voltage (EDCM) given by some manufacturers. The nominal voltage can be calculated by dividing the EDCM voltage by 1.7 (or square root of 3). With permanent magnet motors, if the nominal frequency is not shown on the nameplate, it can be calculated using the following formula: $f = n \times p / 60$ where n = nominal motor speed, p = number of pole pairs. If the nominal power is not known, leave the setting at 0, and specify nominal torque in the advanced motor settings screen (the next stage). | |
| | <p>Example of a nameplate of an asynchronous (induction) motor:</p>  | <p>Example of a nameplate of a permanent magnet motor:</p>  |



| | |
|--|--|
| <p><input type="checkbox"/> After setting the values, press  (Next). The advanced motor settings screen appears. These values are not obligatory, but improve the accuracy of motor control if set correctly.</p> <p>Notes:</p> <ul style="list-style-type: none"> • The cos phi value is especially useful with asynchronous motors that cannot be de-coupled from the machinery for the identification run (see further below). • Enter the nominal torque only if the nominal power is not known and could not be specified in the previous screen. • The DTC motor control mode is suitable for most cases. Scalar mode is recommended if <ul style="list-style-type: none"> • the nominal current of the motor is less than 1/6 of the nominal current of the drive, • the drive is used for test purposes with no motor connected, or • the drive controls multiple motors and the number of motors connected is variable. |  <p>Remote  ACS880 0.0 rpm</p> <p>Advanced motor setti...</p> <p>If available, these settings can improve accuracy.</p> <p>Motor nominal cos φ 0.00 ▶</p> <p>Motor nominal torque 0.000 Nm ▶</p> <p>Motor control mode DTC ▶</p> <p>Back 11:52 Next</p> |
| <p><input type="checkbox"/> After setting the values, press  (Next). The limit settings screen appears. Check the limits, and adjust if necessary.</p> |  <p>Remote  ACS880 0.0 rpm</p> <p>Limits</p> <p>Minimum speed -1500.00 rpm ▶</p> <p>Maximum speed 1500.00 rpm ▶</p> <p>Maximum current 4.59 A ▶</p> <p>Minimum torque 1 -300.0 % ▶</p> <p>Maximum torque 1 300.0 % ▶</p> <p>Back 11:00 Next</p> |
| <p><input type="checkbox"/> After setting the limits, press  (Next). The drive name screen appears.</p> |  <p>Remote  ACS880 0.0 rpm</p> <p>Naming the drive</p> <p>The name will show at the top of the panel screen, making it easier to see which motor this drive controls.</p> <p>Drive name ACS880 ▶</p> <p>Back 11:00 Next</p> |
| <p><input type="checkbox"/> To rename the drive, press . (To skip, press  (Next).)</p> <p>In the drive name screen,</p> <ul style="list-style-type: none"> • Use  and  to move the cursor left and right. The maximum length of the drive name is 15 characters. • Use  and  to select a character. <ul style="list-style-type: none"> • When the character  is highlighted, you can switch between character sets (lowercase, uppercase, numerals, special characters) using  and . • Press  and  to apply selection. • Press  (Save) to accept the new name. |  <p>Remote  ACS880 0.0 rpm</p> <p>Naming the drive</p> <p>The name will show at the top of the panel screen, making it easier to see which motor this drive controls.</p> <p>Drive name ACS880 ▶</p> <p>Back 11:00 Next</p> |



| | | |
|--|--|---|
| <input type="checkbox"/> | <p>Switch to local control to ensure that external control is disabled by pressing the  key. Local control is indicated by the text "Local" in the top pane.</p> |  |
| <input type="checkbox"/> | <p>Highlight Parameters and press  (Select).</p> |  |
| <input type="checkbox"/> | <p>Highlight Complete list using  and  and press  (Select). A listing of parameter groups is displayed.</p> |  |
| <p>Make the following parameter settings in the same manner.</p> | | |
| <input type="checkbox"/> | <p>99.13 Identification run request This parameter selects the mode of the identification run (DTC motor control mode only).  WARNING! The identification run modes marked thus * will run the motor in the forward direction (see below for details). Make sure it is safe to run the motor before choosing any of these modes. *Normal mode should be selected whenever possible. The driven machinery must be de-coupled from the motor if</p> <ul style="list-style-type: none"> • the load torque is higher than 20%, or • the machinery is not able to withstand the nominal torque transient during the identification run. <p>*Reduced mode should be selected if the mechanical losses are higher than 20%, ie. the load cannot be de-coupled, or full flux is required to keep the motor brake open (eg. with conical motors). The Standstill mode should be selected if neither the *Normal or *Reduced mode can be used. Notes:</p> <ul style="list-style-type: none"> • This mode cannot be used with a permanent magnet motor if the load torque is higher than 20% of nominal. • Mechanical brake is not opened by the logic for the identification run. | |
| <input type="checkbox"/> | <p>Ensure that the Safe torque off and emergency stop circuits (if present) are closed.</p> | |
| <input type="checkbox"/> | <p>Start the identification run by pressing the  (Start) button.</p> | <p>A warning will indicate that the identification run is in progress.</p> |





3

PCP/ESP control start-up

Contents of this chapter

This chapter contains the start-up sequence of the PCP/ESP control program.

PCP/ESP control start-up

This section contains the following alternative control schemes for starting up the drive with the control program:

- High pressure switch set up
- Optional speed reduction at maximum torque

In addition, this section describes how to configure the following program features:




The checklist for PCP/ESP control start up is given below:

| I/O wiring | |
|-------------------------------|--|
| <input type="checkbox"/> | Connect the digital and analog I/Os according to the wiring diagram shown in page 96. |
| I/O wiring parameter settings | |
| <input type="checkbox"/> | Select the source of the start for external control location 1 (EXT1). <i>20.01 Ext1 commands</i> |
| <input type="checkbox"/> | Select the level-triggered signal type. <i>20.02 Ext1 start trigger type</i> |
| <input type="checkbox"/> | Select the start signal. By default, the drive starts/stops according to the status of digital input DI1 (0 = Stop, 1 = Start). <i>20.03 Ext1 in1 source</i> |



| | | |
|--------------------------|--|--|
| <input type="checkbox"/> | Select the way motor is stopped when the run enable signal switches off. | 20.11 Run enable stop mode |
| <input type="checkbox"/> | Select the source of the external run enable signal. If the run enable signal is switched off, the drive will not start. | 20.12 Run enable 1 source |
| <input type="checkbox"/> | Select the way motor is stopped when an emergency stop command is received. | 21.04 Emergency stop mode |
| <input type="checkbox"/> | Select the source of the emergency stop signal. | 21.05 Emergency stop source |
| <input type="checkbox"/> | Select the source of an external fault reset signal. The signal resets the drive after a fault trip if the cause of the fault no longer exists. | 31.11 Fault reset selection |
| Basic pump set up | | |
| | <p>The following information is required to complete the set up:</p> $\text{Gear reduction ratio} = \frac{\text{pump sheave diameter} * \text{gear box ratio}}{\text{motor sheave diameter}}$ <p>Maximum rod torque in lbft or Nm.</p> | |
| <input type="checkbox"/> | Enable the pump functions. | 74.01 Pump enable |
| <input type="checkbox"/> | Define the transmission reduction ratio. Note: Not applicable for ESP. | 74.03 Gear reduction ratio |
| <input type="checkbox"/> | Select the reference type between motor speed or pump speed. Note: Not applicable for ESP. | 74.04 Speed ref type |
| <input type="checkbox"/> | Select the source for the speed reference. Note: If parameter 74.05 Speed ref source is selected as <i>AI1 scaled</i> , set the minimum and maximum values of AI1. | 74.05 Speed ref source 12.19 AI1 scaled at AI1 min 12.20 AI1 scaled at AI1 max |
| <input type="checkbox"/> | Set the speed reference if parameter 74.05 Speed ref source is selected as <i>Constant ref</i> (Prpm, rpm or Hz). | 74.06 Speed ref |



| | | |
|----------------------------|--|--|
| <input type="checkbox"/> | Define the minimum allowed rod/pump speed.  Warning! This value must not be higher than <i>74.06 Speed ref</i> (Prpm, rpm or Hz). | <i>74.07 Minimum rod speed</i> |
| <input type="checkbox"/> | Define the maximum allowed rod/pump speed.  Warning! This value must not be lower than <i>74.07 Minimum rod speed</i> (Prpm, rpm or Hz). | <i>74.08 Maximum rod speed</i> |
| <input type="checkbox"/> | Define maximum allowed torque reference (Nm or lbft). | <i>74.19 Maximum rod torq ref</i> |
| <input type="checkbox"/> | Define the acceleration time for rod/pump: from zero to <i>74.08 Maximum rod speed</i> (s). | <i>74.10 Rod acc time</i> |
| <input type="checkbox"/> | Define the deceleration time for rod/pump: from <i>74.08 Maximum rod speed</i> to zero speed. | <i>74.11 Rod dec time</i> |
| <input type="checkbox"/> | Activate Backspin function to control the reverse rotation of pump caused by back flow. | <i>80.01 Backspin enable</i> |
| <input type="checkbox"/> | Define the reference speed/frequency limit for the Backspin function (Prpm, rpm or Hz).  Warning! If <i>80.02 Backspin ref limit</i> is set to 0, the <i>Pump backspin control</i> function is not effective. | <i>80.02 Backspin ref limit</i> |
| <input type="checkbox"/> | Define the acceleration time for the Backspin function: from zero to <i>80.02 Backspin ref limit</i> (s). | <i>80.03 Backspin acc time</i> |
| <input type="checkbox"/> | Define a torque limit for the Backspin function. When the actual torque is below the limit, Backspin function is complete and it gives coast to stop command to the drive (Nm or lbft). | <i>80.04 Backspin stop torque</i> |
| <input type="checkbox"/> | Set the speed reference regulation range for the Backspin function. Note: Default = 0% is recommended because it is the safe range for backspin operation to avoid rod damages and drive overvoltage. | <i>80.05 Backspin speed range trim</i> |
| Check pump rotation | | |



| | | |
|---|--|--|
| | Set a small speed reference. Start the drive. The motor rotates at a slow rate. Check that the rotation is correct for the pump. If the rotation is not correct, power down the drive and swap two of the motor cables (V2 and W2) at the drive terminal block. Re-apply power and check the rotation again. | |
| | Set back speed reference as required. | |
| High pressure switch set up | | |
| | If high pressure switch is present, wire the switch between the +24 V (XD24:2 or XD24:4) on I/O control board and required DI (XDI:1-6). | |
| <input type="checkbox"/> | Enable pump pressure protection function. | 76.01 Pressure protection function |
| <input type="checkbox"/> | Define the latching type for pump pressure protection. | 76.02 Pressure protection latching |
| <input type="checkbox"/> | Enable the source of digital feedback for high pressure protection. | 76.03 Digital feedback source enable |
| <input type="checkbox"/> | Select the source of digital feedback for high pressure protection. | 76.04 Digital feedback source |
| Optional speed reduction at maximum torque | | |
| | If it is desired to reduce the speed at maximum torque in a situation as the sand entering into the pump, the following parameters need to be set. If pump is unable to overcome the high torque situation (the solids cannot pass through the pump), the parameters setting causes the drive to trip. | |
| <input type="checkbox"/> | Select the display type to view the Rod torque limit for pump torque protection. | 77.01 Rod torq limit display |
| <input type="checkbox"/> | Enable the Rod torque 1 function for pump torque protection. | 77.02 Rod torq1 function |
| <input type="checkbox"/> | Select the Rod torque 1 limit type of the fault condition in 77.04 Rod torq1 limit . Note: The warning D204 Rod torque 1 limit is displayed during the shutdown process. | 77.03 Rod torq1 limit type |
| <input type="checkbox"/> | Define the torque limit for Rod torque 1 function in engineering units (Nm, lbft or A). | 77.04 Rod torq1 limit |
| <input type="checkbox"/> | Define the speed limit for rod torque 1 functionality in engineering units (Prpm, rpm or Hz). | 77.05 Rod torq1 speed |



| | | |
|--------------------------|---|--|
| <input type="checkbox"/> | Define the time period for confirming the high torque 1 condition(s). | 77.06 Rod torq1 delay time |
|--------------------------|---|--|

For more information on ESP with step-up transformer and sine filter, see [Appendix: ESP with step-up transformer and sine filter](#) (page 487).







4

Using the control panel

Refer to *ACS-AP-x assistant control panels user's manual* ([3AUA0000085685](#) [English]).



PCP/ESP program features

Contents of this chapter

This chapter describes the functions within the control program that are specific to PCP/ESP applications, how to use them and how to program them to operate.

Overview of PCP/ESP control program

The Progressive cavity pumping (PCP)/ Electric submersible pumping (ESP) control program is a drive application program used in oil pump stations and other related areas that require pumping of viscous liquids. The control program includes functions for protection of the pump and optimization of production rates.

- **Protection** is provided by monitoring selectable input signals. The control program can shut down the pump during conditions that could harm the equipment.
- **Optimization** is performed through automatic pump speed adjustments based on control set points and limits.

The PCP application uses *Direct torque control (DTC)* with speed reference in rpm or Prpm. The ESP application uses scalar control with the speed reference in Hz.

The PCP/ESP control program also features an automatic backspin control feature that prevents the unit from uncontrolled reverse rotation caused by back flow of fluid.


See *Pump backspin control* (page 47).

Construction of PCP/ESP system

ABB industrial drive modules with the pump control program can be used to control the following pump types:

- *Progressive cavity pump (PCP)*
- *Electric submersible pump (ESP)*


■ Progressive cavity pump (PCP)



The PCP system consists of a surface drive, a drive string and a down hole PC pump. The PC pump comprises of a single helical-shaped rotor that turns inside a double helical elastomer-lined stator. The stator is attached to the production tubing string and remains stationary during pumping.

In most cases the rotor is attached to a sucker rod string which is suspended and rotated by the surface drive.

■ Electric submersible pump (ESP)




The ESP system incorporates an electric motor and centrifugal pump unit running on a production string. The system is connected back to the surface control mechanism and transformer unit through an electric power cable.

Pump starting speed

The pump starting speed function allows the user to define a starting speed and acceleration time to run the pump according to requirements. For example, a faster start up acceleration time can be used for cleaning purposes and slower acceleration time can be used for equipment protection. The user can enable this function using parameter [74.12 Starting speed enable](#). The pump runs at starting speed in the starting speed acceleration time and then releases control to run the pump at reference speed in the normal acceleration time.

Timing diagram

At start, the pump starting speed function controls the pump to run in the start acceleration time. After a defined delay time is passed, the function releases control and the pumps shifts to normal acceleration time to reach the reference speed.



Settings

Parameters: [74.12 Starting speed enable](#), [74.13 Starting speed](#), [74.14 Starting speed acc time](#) and [74.15 Starting speed time delay](#).

Signals: [09.06 Motor speed reference](#) and [09.14 Pump status word](#) (Bit 14)

Warnings: -

Faults: -

Pump level control

The pump level control is a fluid level PI regulator for maintaining fluid level at a certain set point. The pump speed is adjusted based on the requirements during the working process. The actual fluid level value comes through a dedicated input, that reads the signal from one or several sensors. The fluid level is maintained through continuous speed adjustment in PI regulator. The user can enable this function in the parameter [75.01 Level control enable](#).


Note: The pump level control provides fluid level data even if the level control is disabled. It is also possible to check the fluid level through pressure data, since the values are in direct relation.

Timing diagram

Non-inverted level control


When feedback from fluid level source is higher than fluid level set point, the PI regulator output decreases, causing the speed reference to decrease. The grey

shaded areas indicate fluid level maintained through continuous PI adjustment to speed.



Inverted level control

When feedback from fluid level source is higher than fluid level set point, the PI regulator output increases, causing the speed reference to increase. The grey shaded areas indicate fluid level maintained through continuous PI adjustment to speed.



Settings

Parameters: [75.01](#) to [75.09](#).

Signals: [09.08 Fluid level](#)

Warnings: -

Faults: -

■ Sleep and wake up function

The sleep and wake up function reduces energy consumption by running the pump only when it is required. If start command is given then sleep function constantly monitor [09.15 Sleep feedback value](#) and generates start and stop commands according to sleep and wake up levels. When condition for sleep mode is triggered (see timing diagram), then sleep function generates a stop command for the drive.

The pump goes to backspin mode, if backspin function [80.01 Backspin enable](#) is enabled. See [Pump backspin control, 47](#)). After this, the drive goes to sleep mode. If condition to wake up is triggered (see timing diagrams) then wake up function generates a start command for the drive. Sleep time is limited by parameter [75.20 Maximum sleep time](#). Wake up function generates start command if parameter [09.16 Sleep time](#) exceeds maximum sleep time. To skip this function, set value of parameter [75.20 Maximum sleep time](#) to 0.

Note: The sleep command is deactivated by the wake up command. The wake up level has higher priority than the sleep level.


The user can enable this function in the parameter [75.10 Sleep control enable](#). The user can also define the sleep level and delay time parameters according to process requirements. The user also defines the sleep limit type (parameter [75.12](#)): whether sleep starts after [09.15 Sleep feedback value](#) goes below the sleep limit (Low limit) or exceeds it (High limit).

The timing diagrams below illustrate the operation of the function:

- with the limit type selection as Low and High
- when the sleep limit is lower than the wake-up limit and vice versa.


Timing diagram 1

This diagram depicts the sleep region for sleep limit type as Low. In this limit type, sleep starts only after the sleep feedback value is below sleep level and wake up level. The sleep function is activated when the sleep feedback value reaches sleep level (see diagram, *Sleep level* < *Wakeup level*). The drive shifts to sleep mode after sleep delay time is passed. The sleep function is active until the sleep feedback value reaches the wakeup level (see diagram, *Sleep level* > *Wakeup level*). The wakeup function is activated when the sleep feedback value reaches wakeup level. The drive shifts to wakeup mode after wakeup delay time is passed.



Timing diagram 2

This diagram depicts the sleep region for sleep limit type as High. In this limit type, sleep starts only after the sleep feedback value is more than sleep level and wake up level. The sleep function is activated when the sleep feedback value reaches sleep level (see diagram, *Sleep level > Wakeup level*). The drive shifts to sleep mode after sleep delay time is passed. The sleep function is active until the sleep feedback value reaches wakeup level (see diagram, *Sleep level < Wakeup level*). The wakeup function is activated when the sleep feedback value reaches the wakeup level. The drive shifts to wakeup mode after the wakeup delay time is passed.



Settings

Parameters: [75.10](#) to [75.20](#).

Signals: [09.14 Pump status word](#) (Bit 10), [09.15 Sleep feedback value](#) and [09.16 Sleep time](#).

Warnings: [D207 Sleep mode](#)

Faults: -

Pump pressure protection

The pump pressure protection function protects the pump from high pressure. The user can enable this function in the parameter [76.01 Pressure protection function](#). Pressure is monitored through analog or digital signals. In high pressure conditions, the pump pressure protection generates a stop command for the drive. The pump goes to backspin mode, if backspin function ([80.01](#)) is enabled.


As soon as the safe condition is stabilized, the drive ramps up again or remains stopped according to the selected option: Non latching type (pump starts automatically after clearing the high pressure condition), Latching type (pump trips instead of auto restarting), Latch zero speed (enables Non latching type if speed is below zero or enables Latching type if speed is above zero).

The user can also select the notification for high pump pressure reaction: Warning, Fault or a selection between them depending on the pump speed.

Note: The pump pressure protection function provides pressure data even when pressure protection is disabled.

■ Timing diagram

The pump pressure function is activated when the measured pressure reaches the pressure limit. The pump goes to backspin mode after the delay time is passed and thereafter stops.



■ Settings

Parameter group: [76 Pump pressure protection](#) on page [310](#).

Signals: [09.09 Pressure](#) and [09.14 Pump status word](#) (Bits 3, 4 and 5)

Warnings: [D201 Pressure](#)

Faults: [D101 Pressure fault](#)

Pump torque protection

The pump torque protection function protects the pump from overload or under load condition and triggers warnings and faults. This function is activated when the measured rod torque exceeds the defined torque limit and when the measured speed exceeds the defined speed limit. The rod torque protection is based on the measurement of rod torque value. This function also enables pump protection with motor current. The user can select this option in parameter [77.01 Rod torq limit display](#).

- If [Torque](#) is selected, there is rod torque protection.
- If [Current](#) is selected, there is motor current protection.

The rod torque function operates in two different modes: Rod torque 1 and Rod torque 2.

- In Rod torque 1, the function maintains torque constant and controls speed.
- In Rod torque 2, the function maintains speed constant and controls torque.

The user can select the Rod torque limit type as Low or High, based on the rod torque value at lower or higher side of the predefined limit.


- For limit type low, a hysteresis (of Rod torque * 5%) is present in the comparator meaning, once the condition is set, it latches until the Rod torque increases to a value of [Rod torq1 limit + (Rod torque * 0.05)].
- For limit type high, a hysteresis (of Rod torque * 5%) is present in the comparator meaning, once the condition is set, it latches until the Rod torque decreases to a value of [Rod torq1 limit - (Rod torque * 0.05)].

■ Rod torque 1 function

This function monitors the actual torque and speed values. If the torque and speed values exceed the defined Rod torque1 limits, the drive stops the motor and notifies a warning (*D204*). The user can enable this function in the parameter *77.02 Rod torq1 function*. For under load protection, user can define the limit as low or high in parameter *77.03 Rod torq1 limit type*.

Timing diagram

The Rod torque 1 function is activated after the pump torque signal reaches the defined torque and speed limit. The pump torque is maintained constant, while the pump speed drops to zero in the defined delay time. After the delay time is passed, the drive shifts to backspin control.



Settings

Parameters: [77.02 Rod torq1 function](#), [77.03 Rod torq1 limit type](#), [77.04 Rod torq1 limit](#), [77.05 Rod torq1 speed](#) and [77.06 Rod torq1 delay time](#).

Signals: [09.01 Rod torque](#), [09.02 Maximum rod torque](#), [09.05 Rod speed](#) and [09.14 Pump status word](#) (Bit 7).

Warnings: [D204 Rod torque 1 limit](#)

Faults: [D103 Rod torque 1 limit fault](#)

■ Rod torque 2 function

This function monitors the actual torque and speed values. If the torque and speed values exceed the defined Rod torque2 limits, the function adds an additional speed reference to maintain constant speed before the drive shifts to backspin control. The user can enable this function in the parameter [77.07 Rod torq2 function](#). For under load protection, user can define the limit as low or high in parameter [77.08 Rod torq2 limit type](#).


Low limit: The control program triggers the Torque pressure protection function when measured torque and speed are less than or equal to defined Torque2 limits for a period of time greater than the Rod torque2 delay time.

High limit: The control program triggers the Torque pressure protection function when measured torque and speed are greater than or equal to defined Torque2 limits for a period of time greater than Rod torque2 delay time.

Timing diagram

This timing diagram depicts the Rod torque2 function with limit type as Low. The Rod torque 2 function is activated after the pump torque signal reaches the defined torque and speed limit. The pump speed is maintained constant, while the pump torque is

lowered below the limit in the defined delay time. After the delay time is passed, the drive shifts to backspin control.



Settings

Parameters, [77.07 Rod torq2 function](#), [77.08 Rod torq2 limit type](#), [77.09 Rod torq2 limit](#), [77.10 Rod torq2 delay time](#), [77.11 Rod torq2 additive speed ref](#), [77.12 Rod torq2 speed delay time](#), [77.13 Rod torq2 limit counter](#) and [77.14 Rod torq2 time window](#).

Signals: [09.01 Rod torque](#), [09.02 Maximum rod torque](#), [09.05 Rod speed](#) and [09.14 Pump status word](#) (Bits 8 and 15).

Warnings: [D205 Rod torque 2 speed](#) and [D206 Rod torque 2 limit](#).

Faults: [D104 Rod torque 2 limit fault](#)

Pump underload protection

This function supervises the load condition of the pump. For example, fluid with gas, lack of fluid in the well or a broken rod. User can define the monitoring curve for the normal load if the function is speed (load points). If the load goes below the curve, the function detects an underload condition.


The pump underload protection is based on the measurement of rod torque value. This function also enables pump protection with motor current. The user can select this option in parameter [78.01 Underload limit display](#).

- If [Torque](#) is selected, there is rod torque protection.
- If [Current](#) is selected, there is motor current protection.

User can also select the reaction for the pump underload condition ([78.02](#)): Warning, Fault or no reaction. This function is based on linear interpolation method.

■ Timing diagram

The points (X1, Y1), (X2, Y2) and (X3, Y3) on the user defined monitoring curve are taken as reference to calculate the underload condition. The actual rod torque is compared with the interpolated points on the curve. If the value lies below the curve, it is interpreted as underload condition. The pump underload protection function is active after the delay time is passed.



■ Settings

Parameter group: [78 Pump underload protection](#)

Signals: [09.01 Rod torque](#), [09.05 Rod speed](#) and [09.14 Pump status word](#) (Bit 6).

Warnings: [D202 Underload](#)

Faults: [D102 Underload fault](#)


Pump temperature protection

This function protects the pump from overheating. User can select the reaction on overheating condition: Warning, Fault or no reaction. The temperature feedback comes through analog input (PT-100) or digital input (Klixon), or both the sources can be connected and used simultaneously. The pump temperature protection function provides temperature data through analog sensor even if temperature protection is disabled.

■ Timing diagram

The measured temperature is compared against the defined fault and warning temperature limits. When the measured value reaches the warning limit, the temperature protection function is activated. After the delay time in 5 seconds, a warning message is triggered. The temperature protection function is still active. After

the fault limit is reached, temperature monitoring continues. After the delay time in 5 seconds, the pump temperature protection generates a stop command for the drive. The pump goes to backspin mode, if backspin function (80.01) is enabled.



■ Settings

Parameter group: [79 Pump temperature protection](#) on page 315

Signals: [09.10 Measured temperature](#) and [09.14 Pump status word](#) (Bits 0, 1 and 2)

Warnings: [D200 Overtemperature](#)

Faults: [D100 Overtemperature fault](#)

Shutdown procedure

There are two ways to stop the drive: by coast stop or backspin control. If Backspin control is disabled, then the drive performs normal coast stop.

■ Pump backspin control

Pump backspin control protects the pump during shutdown process. Backspin control may be performed by two different function: backspin function and start delay function.

Backspin function eliminates the effect of uncontrollable rotation of the pump in opposite direction, that is caused by the back flow of fluid. Backspin function allows to keep this reverse rotation below the defined speed limit. This sequence can be performed with any stop command. User can enable this function using parameter [80.01 Backspin enable](#).

When zero speed is reached, the drive begins ramping to the backspin speed reference with an acceleration time in parameter [80.03 Backspin acc time](#). If the torque in the pump is driving the motor in the reverse direction, then the actual backspin speed is equal to the backspin speed reference. If torque in the pump is not driving the motor in reverse, the actual speed is not equal to backspin speed reference.

Backspin speed reference is based on actual torque.


$$\text{Backspin Speed Ref} = \text{Backspin Limit} - \frac{\text{Actual Torque Filtered}}{\text{Max Torque}} * \text{Backspin Limit} * \text{Backspin Speed Range}$$

As torque decreases, backspin speed reference increases. If torque is constant, backspin speed range increases with the decrease in backspin speed reference.

The following procedure and time scheme describes the operation of backspin function:

1. The Drive receives an external stop command and starts to decelerate the pump down along the defined ramp ([74.11 Rod dec time](#)).
 2. At zero speed, the fluid starts flowing back from the pipe. The function keeps the drive operational (delaying the internal stop command).
 3. Backward flow accelerates the pump in reverse direction. The Backspin function keeps the acceleration rate under the acceleration level ([80.03 Backspin acc time](#)).
 4. The Backspin function keeps the reverse speed under the Backspin speed limit ([80.05 Backspin speed range trim](#)) until the back flow starts running out and the torque starts decreasing.
 5. When the actual torque goes below the limit ([80.04 Backspin stop torque](#)), the function stops and initiates the Coast to stop command to the drive.
-

Timing diagram



Settings

Parameters: **80.01 Backspin enable**, **80.02 Backspin ref limit**, **80.03 Backspin acc time**, **80.04 Backspin stop torque** and **80.05 Backspin speed range trim**.

Signals: **09.11 Backspin speed reference** and **09.13 Backspin status word** (bits 0, 1 and 2).

Warnings: *D208 Backspin limit* and *D209 Backspin active*

Faults: -

Start delay

Start delay function blocks any start command when stop command is given. User can enable this function using parameter *80.11 Start delay enable*. Pump will not be able to make start during defined time period *80.12 Start delay time*. This delay time has to be equal or longer than time period needed to complete shutdown process.

Time remained to allow drive to start is indicating in actual signal *09.12 Start delay remain*.

If drive is stopped due to power failure and then after power supply is retained, the stopped time period will be deducted from start delay time. In case, if battery of ZCU board is empty, time will not be deducted from start delay time in case of power failure.

Settings

Parameters: *80.11 Start delay enable* and *80.12 Start delay time*.


Signals: *09.12 Start delay remain*, *09.13 Backspin status word* (bits 10 and 11).

Warnings: *D20C Start delay active*.

Faults: -

Brake confirmation

The brake confirmation function is optional. This function controls the operation of the mechanical brake. If a pressure feedback is available from the mechanical brake then this function can be used to detect the failure of the brake before starting the pump. If the mechanical brake is defective, this function generates a fault and also forbids the start command.



Settings

Parameters: [74.21 Brake confirmation enable](#), [74.22 Brake confirmation source](#), [74.23 Brake confirmation limit](#), [74.24 Brake confirmation speed](#) and [74.25 Brake confirmation time](#).

Signals: [09.14 Pump status word](#) (Bit 13)

Warnings: [D20A Brake confirmation active](#)

Faults: [D105 Brake confirmation fault](#)



Standard programposi features


Contents of this chapter

This chapter describes the control locations and operating modes supported by the control program.

Local control vs. external control

The ACS880 has two main control locations.

- External control
 - Internal control
-



1) Extra inputs/outputs can be added by installing optional I/O extension modules (FIO-xx) in drive slots.

2) Encoder or resolver interface module(s) (FEN-xx) installed in drive slots.

The control location is selected with the Loc/Rem key on the control panel or in the PC tool.

Local control

The control commands are given from the control panel keypad or from a PC equipped with Drive composer when the drive is in local control. Speed control mode is available for local control and frequency mode is available when scalar motor control mode is used. See parameter [19.16 Local control mode](#) (page 179).

Local control is mainly used during commissioning and maintenance. The control panel always overrides the external control signal sources when used in local control. Changing the control location to local can be prevented by parameter [19.17 Local control disable](#) (page 179).

Select the parameter [49.05 Communication loss action](#) (page 284) and check how the drive reacts to a control panel or PC tool communication break (the parameter has no effect in external control).

External control

When the drive is in external control, control commands are given through the


- I/O terminals (digital and analog inputs), or optional I/O extension modules
- embedded fieldbus interface or an optional fieldbus adapter module.

Two external control locations, EXT1 and EXT2 are available. The user can select the sources of start and stop commands separately for each location using parameters [20.01...20.10](#). Select the operating mode separately for each location (in parameter group [19 Operation mode](#)), which enables quick switching between different operating modes. For example, speed control. Selection between EXT1 and EXT2 is done through any binary source such as a digital input or fieldbus control word (see parameter [19.11 Ext1/Ext2 selection](#) (page [178](#))). The source of reference is selectable for each operating mode separately.

Operating modes of the drive

The drive operates in several operating modes with different types of reference. The mode is selectable for each control location (Local, EXT1 and EXT2) in parameter group [19 Operation mode](#).

The following is a general representation of the reference types and control chains. The page numbers refer to detailed diagrams in chapter [Control chain diagrams](#).



■ Speed control mode

The motor follows a speed reference given to the drive. This mode is used either with estimated speed used as feedback, or with an encoder or resolver for better speed control accuracy.

Speed control mode is available in both local and external control. It is also available both in DTC (Direct Torque Control) and scalar motor control modes.


■ Frequency control mode

The motor follows a frequency reference given to the drive. Frequency control is only available for scalar motor control.

Drive configuration and programming

The drive control program is divided into two parts:

- Application program and
- Firmware program.



The firmware program performs the main control functions, including speed control, drive logic (start/stop), I/O, feedback, communication and protection functions. Firmware functions are configured and programmed with parameters, and can be extended by application programming.

■ Programming through parameters

Parameters configure all standard drive operations and can be set through

- the control panel, as described in chapter [Using the control panel](#)
- the Drive composer PC tool, as described in *Drive composer user's manual* (3AUA0000094606 [English]), or
- the fieldbus interface, as described in chapters [Fieldbus control through the embedded fieldbus interface \(EFB\)](#) and [Fieldbus control through a fieldbus adapter](#).

All parameter settings are stored automatically to the permanent memory of the drive. However, if an external +24 V DC power supply is used for the drive control unit, it is highly recommended to force a save by using parameter [96.07 Parameter save manually](#) before powering down the control unit after any parameter changes have been made.

If necessary, the default parameter values can be restored by parameter [96.06 Parameter restore](#).

■ Application programming

The functions of the firmware program can be extended with application programming. (A standard drive delivery does not include an application program.) Application programs can be built with function blocks based on the IEC 61131-3 standard using a PC tool available separately.

For more information, see *Programming manual: Drive application programming (IEC 61131-3)* (3AUA0000127808 [English]).

Control interfaces

■ Programmable analog inputs

The control unit has two programmable analog inputs. Each of the inputs can be independently set as a voltage (0/2...10 V or -10...10 V) or current (0/4...20 mA) input by a jumper or switch on the control unit. Each input can be filtered, inverted and scaled. The number of analog inputs are increased by installing FIO-11 or FAIO-01 I/O extensions (see [Programmable I/O extensions](#)).

Settings

See parameter group [12 Standard AI](#) (page [140](#)).

■ Programmable analog outputs

The control unit has two current (0...20 mA) analog outputs. Each output is filtered, inverted and scaled. The number of analog outputs are increased using FIO-xx I/O extensions. See [Programmable I/O extensions](#) (page [56](#)).

Settings

See parameter group [13 Standard AO](#).

■ Programmable digital inputs and outputs

The control unit has six digital inputs, a digital start interlock input, and two digital input/outputs.

One digital input (DI6) doubles as a PTC thermistor input. See section [Motor thermal protection](#) (page [83](#)).

Digital input/output DIO1 is used as a frequency input, DIO2 as a frequency output.

The number of digital inputs/outputs are increased using FIO-xx I/O extensions. See [Programmable I/O extensions](#) (page 56).

Settings

See parameter groups

- [10 Standard DI, RO](#)
- [11 Standard DIO, FI, FO](#)

■ Programmable relay outputs

The control unit has three relay outputs. The signal is indicated by the outputs are selected using parameters.

Relay outputs are added using FIO-0x I/O extensions.

Settings

See parameter group [10 Standard DI, RO](#) (page 128).

■ Programmable I/O extensions

Inputs and outputs are added using FIO-xx I/O extension modules. One to three modules are mounted on the slots of the control unit.

The table below shows the number of I/O on the control unit as well as optional FIO-xx I/O extension modules.

| Location | Digital inputs (DI) | Digital I/Os (DIO) | Analog inputs (AI) | Analog outputs (AO) | Relay outputs (RO) |
|--------------|---------------------|--------------------|--------------------|---------------------|--------------------|
| Control unit | 7 | 2 | 2 | 2 | 3 |
| FIO-01 | - | 4 | - | - | 2 |
| FIO-11 | - | 2 | 3 | 1 | - |

Three I/O extension modules are activated and configured using parameter groups 14...16.

Note: Each configuration parameter group contains parameters that display the values of the inputs on that particular extension module. These parameters are the only way of utilizing the inputs on I/O extension modules as signal sources. To connect to an input, choose the setting *Other* in the source selector parameter, then specify the appropriate value parameter (and bit, for digital signals) in group 14, 15 or 16.

Settings

See parameter groups:

- [14 I/O extension module 1](#)
- [15 I/O extension module 2](#)
- [16 I/O extension module 3](#)

■ Fieldbus control

The drive is connected to several different automation systems through its fieldbus interfaces. See chapter [Fieldbus control through a fieldbus adapter](#) (page 461) and [Fieldbus control through a fieldbus adapter](#) (page 461).

Settings

See parameter groups

- [50 Fieldbus adapter \(FBA\)](#)
- [51 FBA A settings](#)
- [52 FBA A data in](#)
- [53 FBA A data out](#)
- [54 FBA B settings](#)
- [55 FBA B data in](#)
- [56 FBA B data out](#)
- [58 Embedded fieldbus](#)

Motor control

■ Direct torque control (DTC)

The motor control of the ACS880 is based on direct torque control (DTC). The switching of the output semiconductors is controlled to achieve the required stator flux and motor torque. The switching frequency is changed only if the actual torque and stator flux values differ from their reference values by more than the allowed hysteresis. The reference value for the torque controller comes from the speed controller or directly from an external torque reference source.

Motor control requires measurement of DC voltage and two motor phase currents. Stator flux is calculated by integrating the motor voltage in vector space. Motor torque is calculated as a cross product of the stator flux and the rotor current. By utilizing the identified motor model, the stator flux estimate is improved. Actual motor shaft speed is not needed for motor control.

The main difference between traditional control and DTC is that torque control has the same time level as the power switch control. There is no separate voltage and frequency controlled PWM modulator. The output stage switching is based on the electromagnetic state of the motor.

The best motor control accuracy is achieved by activating a separate motor identification run (ID run).

See also section [Scalar motor control](#) (page 71).

Settings

See parameters

- [99.04 Motor ctrl mode](#)
- [99.13 ID run requested](#)

■ Reference ramping

Acceleration and deceleration ramping times can be set individually for speed and frequency reference.

With a speed or frequency reference, the ramps are defined as the time it takes for the drive to accelerate or decelerate between zero speed or frequency and the value defined by parameter [46.01 Speed scaling](#) or [46.02 Frequency scaling](#). The user can switch between two preset ramp sets using a binary source such as a digital input. For speed reference, the shape of the ramp can be controlled.

Special acceleration/deceleration ramps

The acceleration/deceleration times for the jogging function can be defined separately; see section [Jogging](#) (page 69).

The change rate of the motor potentiometer function (page 78) is adjustable. The same rate applies in both directions.

A deceleration ramp can be defined for emergency stop (“Off3” mode).

Settings

- Speed reference ramping: Parameters [23.11...23.19](#) and [46.01](#) (pages [204](#) and [280](#)).
 - Frequency reference ramping: Parameters [28.71...28.75](#) and [46.02](#) (pages [232](#) and [280](#)).
 - Jogging: Parameters [23.20](#) and [23.21](#) (page [207](#)).
 - Motor potentiometer: Parameter [22.75](#) (page [202](#)).
 - Emergency stop (“Off3” mode): Parameter [23.23 Emergency stop time](#) (page [207](#)).
-

■ Critical speeds (frequencies)


A critical speed function is available for applications where it is necessary to avoid certain problems in motor speeds or speed ranges, for example, mechanical resonance problems.

A similar function is available for scalar motor control with a frequency reference.

Example

A fan has vibrations in the range of 540 to 690 rpm and 1380 to 1560 rpm. To make the drive jump over these speed ranges,

- enable the critical speeds function by turning on bit 0 of parameter [22.51 Critical speed function](#), and
- set the critical speed ranges as shown in the figure below.



Settings

See parameter groups

- Critical speeds: parameters [22.51...22.57](#)
- Critical frequencies: parameters [28.51...28.57](#)

■ Speed controller autotune


The speed controller of the drive can be automatically adjusted using the autotune function. Autotuning is based on an estimation of the mechanical time constant (inertia) of the motor and machine.

The autotune routine will run the motor through a series of acceleration/deceleration cycles, the number of which can be adjusted by parameter [25.40 Autotune repeat times](#). Higher values will produce more accurate results, especially if the difference between initial and maximum speeds is small.

The maximum torque reference used during autotuning will be the initial torque (ie. torque when the routine is activated) plus [25.38 Autotune torque step](#), unless limited by the maximum torque limit (parameter group [30 Limits](#)) or the nominal motor torque

(*99 Motor data*). The calculated maximum speed during the routine is the initial speed (ie. speed when the routine is activated) + *25.39 Autotune speed step*, unless limited by *30.12 Maximum speed* or *99.09 Motor nominal speed*.

The diagram below shows the behavior of speed and torque during the autotune routine. In this example, *25.40 Autotune repeat times* is set to 2.



Notes:

- If the drive cannot produce the requested braking power during the routine, the results will be based on the acceleration stages only, and not as accurate as with full braking power.
- The motor will exceed the calculated maximum speed slightly at the end of each acceleration stage.

Before activating the autotune routine


The prerequisites for performing the autotune routine are:

- The motor identification run (ID run) has been successfully completed
- Speed and torque limits (parameter group *30 Limits*) have been set
- The speed feedback has been monitored for noise, vibrations and other disturbances caused by the mechanics of the system, and
 - speed feedback filtering (parameter group *90 Feedback selection*)
 - speed error filtering (*24 Speed reference conditioning*) and
 - zero speed (parameters *21.06* and *21.07*) have been set to eliminate these disturbances.
- The drive has been started and is running in speed control mode.

After these conditions have been fulfilled, autotuning can be activated by parameter *25.33 Speed controller autotune* (or the signal source selected by it).

Autotune modes

Autotuning can be performed in three different ways depending on the setting of parameter [25.34 Speed controller autotune mode](#). The selections *Smooth*, *Normal* and *Tight* define how the drive torque reference should react to a speed reference step after tuning. The selection *Smooth* will produce a slow but robust response; *Tight* will produce a fast response but possibly too high gain values for some applications. The figure below shows speed responses at a speed reference step (typically 1...20%).



- A: Undercompensated
- B: Normally tuned (autotuning)
- C: Normally tuned (manually). Better dynamic performance than with B
- D: Overcompensated speed controller


Autotune results

At the end of a successful autotune routine, its results are automatically transferred into parameters

- [25.02 Speed proportional gain](#) (proportional gain of the speed controller)
- [25.03 Speed integration time](#) (integration time of the speed controller)
- [25.37 Mechanical time constant](#)(mechanical time constant of the motor and machine).

Nevertheless, it is still possible to manually adjust the controller gain, integration time and derivation time.

The figure below is a simplified block diagram of the speed controller. The controller output is the reference for the torque controller.



Warning indications

A warning message, [AF90 Speed controller autotuning](#), will be generated if the autotune routine does not complete successfully. See chapter [Fault tracing](#) (page [405](#)) for further information.

Settings

Parameters [25.33...25.40](#) (page [222](#)).


■ Oscillation damping

The oscillation damping function can be used to cancel out oscillations caused by mechanics or an oscillating DC voltage. The input – a signal reflecting the oscillation – is selected by parameter [26.53 Oscillation compensation input](#). The oscillation damping function outputs a sine wave ([26.58 Oscillation damping output](#)) which can be summed with the torque reference with a suitable gain ([26.57 Oscillation damping gain](#)) and phase shift ([26.56 Oscillation damping phase](#)).

The oscillation damping algorithm can be activated without connecting the output to the reference chain, which makes it possible to compare the input and output of the function and make further adjustments before applying the result.

■ Rush control

In torque control, the motor could potentially rush if the load were suddenly lost. The control program has a rush control function that decreases the torque reference whenever the motor speed exceeds [30.11 Minimum speed](#) or [30.12 Maximum speed](#).



The function is based on a PI controller. The proportional gain and integration time can be defined by parameters. Setting these to zero disables rush control.

Settings

See parameters

- [26.81 Rush control gain](#)
- [26.82 Rush control integration time](#)

Encoder support

The control program supports two single-turn or multi turn encoders (or resolvers). The following optional interface modules are available:

- TTL encoder interface FEN-01—two TTL inputs, TTL output (for encoder emulation and echo) and two digital inputs for position latching
- Absolute encoder interface FEN-11—absolute encoder input, TTL input, TTL output (for encoder emulation and echo) and two digital inputs for position latching
- Resolver interface FEN-21—resolver input, TTL input, TTL output (for encoder emulation and echo) and two digital inputs for position latching
- HTL encoder interface FEN-31—HTL encoder input, TTL output (for encoder emulation and echo) and two digital inputs for position latching.
- HTL/TTL encoder interface FSE-31 (for use with an FSO-xx safety functions module): Two HTL/TTL encoder inputs.

The interface module is installed onto any optional slot on the drive control unit. The module (except FSE-31) can also be installed onto an FEA-0x extension adapter.

Encoder echo and emulation

Both encoder echo and emulation are supported by the above-mentioned FEN-xx interfaces.

Encoder echo is available with TTL, TTL+ and HTL encoders. The signal received from the encoder is relayed to the TTL output unchanged. This enables the connection of one encoder to several drives.

Encoder emulation also relays the encoder signal to the output, but the signal is either scaled, or position data converted to pulses. Emulation can be used when absolute encoder or resolver position needs to be converted to TTL pulses, or when the signal must be converted to a different pulse number than the original.

Quick configuration of HTL encoder feedback

1. Specify the type of encoder interface module (parameter [91.11 Module 1 type](#) = [FEN-31](#)) and slot in which the module is installed ([91.12 Module 1 location](#)).
 2. Specify the type of encoder ([92.01 Encoder 1 type](#) = [HTL](#)). The parameter listing is re-read from the drive after the value is changed.
 3. Specify the interface module to which the encoder is connected to ([92.02 Encoder 1 source](#) = [Module 1](#)).
 4. Set the number of pulses according to encoder nameplate ([92.10 Pulses/revolution](#)).
 5. If the encoder rotates at a different speed to the motor (that is, not mounted directly on the motor shaft), enter the gear ratio in [90.43 Motor gear numerator](#) and [90.44 Motor gear denominator](#).
 6. Set parameter [91.10 Encoder parameter refresh](#) to [Refresh](#) to apply the new parameter settings. The parameter automatically reverts to [Done](#).
 7. Check that [91.02 Module 1 status](#) is showing the correct interface module type ([FEN-31](#)). Also check the status of the module. Both LEDs should be glowing green.
 8. Start the motor with a reference. For example, 400 rpm.
 9. Compare the estimated speed ([01.02 Motor speed estimated](#)) with the measured speed ([01.04 Encoder 1 speed filtered](#)). If the values are the same, set the encoder as the feedback source ([90.41 Motor feedback selection](#) = [Encoder 1](#)).
 10. Specify the action taken in case the feedback signal is lost ([90.45 Motor feedback fault](#)).
-


Settings

See parameter groups

- [90 Feedback selection](#)
 - [91 Encoder module settings](#)
 - [92 Encoder 1 configuration](#)
 - [93 Encoder 2 configuration](#)
-

■ Position counter


The control program contains a position counter feature that can be used to indicate the position of a load, eg. the position of a conveyor belt or the height of the load on a crane. The output of the counter function, parameter [90.07 Load position scaled int](#), indicates the scaled number of revolutions read from an encoder through either encoder interface. A position estimate calculated internally by the motor control can be used instead of encoder feedback. (The estimate is also used until next stop if the selected feedback is lost and its monitoring parameter is set to warning instead of fault.)



The source of the measurement is selected by [90.51 Load feedback selection](#). Any gear ratio between the encoder and load is defined by [90.53 Load gear numerator](#) and [90.54 Load gear denominator](#). In case the internal position estimate is chosen as the source, the gear between the motor and load must be defined in [90.61 Gear numerator](#) and [90.62 Gear denominator](#).

The relation between revolutions of the motor shaft and the translatory movement of the load (in any given unit of distance) is defined by parameters [90.63 Feed constant numerator](#) and [90.64 Feed constant denominator](#).

By default, all of the ratios mentioned above are 1:1.



The position counter is initialized by setting a known physical position of the load into the control program. The initial position (for example, the home/zero position, or the distance from it) can be entered manually in a parameter ([90.58 Pos counter init value int](#)), or taken from another parameter. This position is set as the value of the position counter ([90.07 Load position scaled int](#)) when the source selected by [90.67 Pos counter init cmd source](#), such as a proximity switch connected to a digital input, is activated. A successful initialization is indicated by bit 4 of [90.35 Pos counter status](#).

Any subsequent initialization of the counter must first be enabled by [90.69 Reset pos counter init ready](#). To define a time window for initializations, [90.68 Disable pos counter initialization](#) can be used to inhibit the signal from the proximity switch. An active fault in the drive will also prevent counter initialization.

See also the block diagram on page [481](#).

Reading/writing position counter values through fieldbus

The parameters of the position counter function, such as [90.07 Load position scaled int](#) and [90.58 Pos counter init value int](#), can be accessed from an upper-level control system in the following formats:

- 16-bit integer (if 16 bits are sufficient for the application)
- 32-bit integer (can be accessed as two consequent 16-bit words)

For example, to read parameter [90.07 Load position scaled int](#) through fieldbus, set the selection parameter of the desired dataset (in group 52) to *Other – 90.07*, and

select the format. If you select a 32-bit format, the subsequent data word is also automatically reserved.

Example 2: Transmitting a 32-bit integer over fieldbus

Parameters [90.05 Load position scaled](#) and [90.65 Pos counter init value](#) are real-type numbers.

In this example, 123456.78 is to be used as the initial value sent from the PLC. To send the number as an integer over the fieldbus, multiply the value by 100 and select it to be transmitted as two data words:

- $12345678 = \text{BC614Eh}$
- $614\text{Eh} = 24910$
- $\text{BCh} = 188$
- $\text{FBA data out } x = 188$
- $\text{FBA data out } (x + 1) = 24910$.

The drive will thus receive a 32-bit integer. To restore the original two decimal places, set parameter [90.38 Pos counter decimals](#) to 2. This will divide the integer by 100 before it is written into [90.65 Pos counter init value](#). Parameter [90.05 Load position scaled](#) will also be scaled, so when read by the PLC, it will still appear as an integer (12345678).

[90.38 Pos counter decimals](#) = 2

[90.65 Pos counter init value](#) = 123456.78

Example 3: Transmitting a 32-bit floating point number over fieldbus

In this example, 66770.125 is used as the initial value sent from the PLC. To transmit a 32-bit floating-point value, split it into two 16-bit words.

According to IEEE 754, the value 66770.125 converts to 47826910h including the sign, exponent and significand.

High word: $4782\text{h} = 18306$

Low word: $6910\text{h} = 26896$

For eg. PROFIBUS, these values can be set as

$\text{FBA data out } x = 18306$

$\text{FBA data out } (x + 1) = 26896$.

For ABB Automation using DDCS communication, the two words can be transmitted as eg. data words 12.1 and 12.2 respectively.

When configuring the data selection parameters, select the 32-bit floating-point number format for parameters [90.65 Pos counter init value](#) and [90.05 Load position scaled](#).

As a result, parameter [90.65 Pos counter init value](#) will be set to 66770.125.

Jogging

The jogging function enables the use of a momentary switch to briefly rotate the motor. The jogging function is typically used during servicing or commissioning to control the machinery locally.


Two jogging functions (1 and 2) are available, each with their own activation sources and references. The signal sources are selected by parameters [20.26 Jogging 1 start source](#) and [20.27 Jogging 2 start source](#). When jogging is activated, the drive starts and accelerates to the defined jogging speed ([22.42 Jogging 1 ref](#) or [22.43 Jogging 2 ref](#)) along the defined jogging acceleration ramp ([23.20 Acc time jogging](#)). After the activation signal switches off, the drive decelerates to a stop along the defined jogging deceleration ramp ([23.21 Dec time jogging](#)).

The figure and table below provide an example of how the drive operates during jogging. In the example, the ramp stop mode is used (see parameter [21.03 Stop mode](#)).

Jog cmd = State of source set by [20.26 Jogging 1 start source](#) or [20.27 Jogging 2 start source](#)

Jog enable = State of source set by [20.25 Jogging enable](#)

Start cmd = State of drive start command.



| Phase | Jog cmd | Jog enable | Start cmd | Description |
|-------|---------|------------|-----------|---|
| 1-2 | 1 | 1 | 0 | Drive accelerates to the jogging speed along the acceleration ramp of the jogging function. |
| 2-3 | 1 | 1 | 0 | Drive follows the jog reference. |
| 3-4 | 0 | 1 | 0 | Drive decelerates to zero speed along the deceleration ramp of the jogging function. |

| Phase | Jog cmd | Jog enable | Start cmd | Description |
|-------|---------|------------|-----------|--|
| 4-5 | 0 | 1 | 0 | Drive is stopped. |
| 5-6 | 1 | 1 | 0 | Drive accelerates to the jogging speed along the acceleration ramp of the jogging function. |
| 6-7 | 1 | 1 | 0 | Drive follows the jog reference. |
| 7-8 | 0 | 1 | 0 | Drive decelerates to zero speed along the deceleration ramp of the jogging function. |
| 8-9 | 0 | 1->0 | 0 | Drive is stopped. As long as the jog enable signal is on, start commands are ignored. After jog enable switches off, a fresh start command is required. |
| 9-10 | x | 0 | 1 | Drive accelerates to the speed reference along the selected acceleration ramp (parameters 23.11 ... 23.19). |
| 10-11 | x | 0 | 1 | Drive follows the speed reference. |
| 11-12 | x | 0 | 0 | Drive decelerates to zero speed along the selected deceleration ramp (parameters 23.11 ... 23.19). |
| 12-13 | x | 0 | 0 | Drive is stopped. |
| 13-14 | x | 0 | 1 | Drive accelerates to the speed reference along the selected acceleration ramp (parameters 23.11 ... 23.19). |
| 14-15 | x | 0->1 | 1 | Drive follows the speed reference. As long as the start command is on, the jog enable signal is ignored. If the jog enable signal is on when the start command switches off, jogging is enabled immediately. |
| 15-16 | 0->1 | 1 | 0 | Start command switches off. The drive starts to decelerate along the selected deceleration ramp (parameters 23.11 ... 23.19). When the jog command switches on, the decelerating drive adopts the deceleration ramp of the jogging function. |
| 16-17 | 1 | 1 | 0 | Drive follows the jog reference. |
| 17-18 | 0 | 1->0 | 0 | Drive decelerates to zero speed along the deceleration ramp of the jogging function. |

See also the block diagram on page [479](#).

Notes:

- Jogging is not available when the drive is in local control.
- Jogging cannot be enabled when the drive start command is on, or the drive started when jogging is enabled. Starting the drive after the jog enable switches off requires a fresh start command.



WARNING! If jogging is enabled and activated while the start command is on, jogging will activate as soon as the start command switches off.

- If both jogging functions are activated, the one that was activated first has priority.
- Jogging uses the speed control mode.
- Ramp shape times (parameters [23.16](#)...[23.19](#)) do not apply to jogging acceleration/deceleration ramps.
- The inching functions activated through fieldbus (see [06.01 Main control word](#), bits 8...9) use the references and ramp times defined for jogging, but do not require the jog enable signal.

Settings

See parameters below:

[20.25 Jogging enable](#)

[20.26 Jogging 1 start source](#)

[20.27 Jogging 2 start source](#)

[22.42 Jogging 1 ref](#)

[22.43 Jogging 2 ref](#)

[23.20 Acc time jogging](#) and

[23.21 Dec time jogging](#).

■ Position latching

The FEN-xx encoder interface modules listed above support position latching. Position latching stores the position of the motor or machine at the instant a latch signal, eg. from a limit switch, is received.

Each FEN-xx module has two digital inputs that can be used for latching. Latching can alternatively be triggered by the Z-pulse signal received from the encoder.

The control program has two position latching functions that can be configured separately. The stored positions can be read by a PLC and used for position control when the loop is closed in the PLC. The positions can also be used as initial positions – see section [Position counter](#) (page [66](#)).

■ Scalar motor control

Scalar control is the motor control method used instead of DTC (Direct Torque Control). In scalar control mode, the drive is controlled with a speed or frequency reference. However, the outstanding performance of DTC is not achieved in scalar control.

It is recommended to activate scalar motor control mode in the following situations:

- In multi motor drives:
 - if the load is not equally shared between the motors
 - if the motors are of different sizes or
 - if the motors are changed after motor identification (ID run)
- If the nominal current of the motor is less than 1/6 of the nominal output current of the drive
- If the drive is used without a motor connected (for example, for test purposes)
- If the drive runs a medium-voltage motor through a step-up transformer


In scalar control, some standard features are not available.

IR compensation for scalar motor control

IR compensation (also known as voltage boost) is available only when the motor control mode is scalar. When IR compensation is activated, the drive gives an extra voltage boost to the motor at low speeds. IR compensation is useful in applications that require a high break-away torque. In step-up applications, voltage cannot be fed through the transformer at 0 Hz, so an additional breakpoint is available for defining the compensation near zero frequency.

In Direct Torque Control (DTC), no IR compensation is possible or needed as it is applied automatically.

Motor voltage



Settings


See parameter group [28 Frequency reference chain](#) (page 226) and below parameters:

- [19.20 Scalar control reference unit](#)
 - [97.12 IR comp step-up frequency](#)
 - [97.13 IR compensation](#)
 - [99.04 Motor ctrl mode](#)
-

■ Autophasing

Autophasing is an automatic measurement routine to determine the angular position of the magnetic flux of a permanent magnet synchronous motor or the magnetic axis of a synchronous reluctance motor. The motor control requires the absolute position of the rotor flux for accurate control of motor torque.

Sensors like absolute encoders and resolvers indicate the rotor position at all times after the offset between the zero angle of rotor and that of the sensor are established. On the other hand, a standard pulse encoder determines the rotor position when it rotates but the initial position is not known. However, a pulse encoder can be used as an absolute encoder if it is equipped with Hall sensors, albeit with coarse initial position accuracy. The Hall sensors generate commutation pulses that change their state six times during one revolution. It is only known within which 60° sector of a complete revolution the initial position is.



The autophasing routine is performed with permanent magnet synchronous motors and synchronous reluctance motors in the following cases:

1. One-time measurement of the rotor and encoder position difference when an absolute encoder, a resolver, or an encoder with commutation signal is used
2. At every power-up when an incremental encoder is used
3. With open-loop motor control, repetitive measurement of the rotor position at every start
4. When the position of the zero pulse must be measured before the first start after power-up.

Note: In closed-loop control, autophasing is performed automatically after the motor identification run (ID run). Autophasing is also performed automatically before starting when necessary.

Several autophasing modes are available (see parameter [21.13 Autophasing mode](#)).

The turning mode is recommended especially with case 1 as it is the most robust and accurate method. In turning mode, the motor shaft is turned back and forward ($\pm 360/\text{polepairs}$)° to determine the rotor position. In case 3 (open-loop control), the shaft is turned only in one direction and the angle is smaller.

The standstill modes can be used if the motor cannot be turned (for example, when the load is connected). As the characteristics of motors and loads differ, testing is done to find out the most suitable standstill mode.

A rotor position offset used in motor control can also be given by the user. See parameter [98.15 Position offset user](#). Note that the autophasing routine also writes its result into this parameter. The results are updated even if user settings are not enabled by [98.01 User motor model mode](#).

The drive is capable of determining the rotor position when started to a running motor in open loop or closed loop modes. In this situation, the setting of [21.13 Autophasing mode](#) has no effect.

Note: In open-loop control, the motor always turns when it is started as the shaft is turned towards the remanence flux.

Autophasing modes

Several autophasing modes are available (see parameter [21.13 Autophasing mode](#)).

The turning mode (*Turning*) is recommended especially with case 1 (see the list above) as it is the most robust and accurate method. In turning mode, the motor shaft is turned back and forward ($\pm 360/\text{polepairs}$)° in order to determine the rotor position. In case 3 (open-loop control), the shaft is turned only in one direction and the angle is smaller.

Another turning mode, *Turning with Z-pulse*, can be used if there is difficulty using the normal turning mode, for example, because of significant friction. With this mode, the rotor is turned slowly until a zero pulse is detected from the encoder. When the zero pulse is detected for the first time, its position is stored into parameter [98.15 Position offset user](#), which can be edited for fine-tuning. Note that it is not mandatory to use this mode with a zero pulse encoder. In open-loop control, the two turning modes are identical.

The standstill modes (*Standstill 1*, *Standstill 2*) can be used if the motor cannot be turned (for example, when the load is connected). As the characteristics of motors and loads differ, testing must be done to find out the most suitable standstill mode.

The drive is capable of determining the rotor position when started into a running motor in open-loop or closed-loop control. In this situation, the setting of [21.13 Autophasing mode](#) has no effect.

The autophasing routine can fail and therefore it is recommended to perform the routine several times and check the value of parameter [98.15 Position offset user](#).

An autophasing fault ([3385 Autophasing](#)) can occur with a running motor if the estimated angle of the motor differs too much from the measured angle. This could be caused by, for example, the following:

- The encoder is slipping on the motor shaft
- An incorrect value has been entered into [98.15 Position offset user](#)
- The motor is already turning before the autophasing routine is started
- [Turning](#) mode is selected in [21.13 Autophasing mode](#) but the motor shaft is locked
- [Turning with Z-pulse](#) mode is selected in [21.13 Autophasing mode](#) but no zero pulse is detected within a revolution of the motor
- The wrong motor type is selected in [99.03 Motor type](#)
- Motor ID run has failed.


Settings

See parameters

- [21.13 Autophasing mode](#)
- [98.15 Position offset user](#)
- [99.13 ID run requested](#)

Flux braking

The drive can provide greater deceleration by raising the level of magnetization in the motor. By increasing the motor flux, the energy generated by the motor during braking can be converted to motor thermal energy.



During flux braking, the drive monitors the motor status continuously. Therefore, flux braking is used both for stopping the motor and for changing the speed. The other benefits of flux braking are:

- The braking starts immediately after a stop command is given. The function does not need to wait for the flux reduction before it can start the braking.

- The cooling of the induction motor is efficient. The stator current of the motor increases during flux braking, not the rotor current. The stator cools much more efficiently than the rotor.
- Flux braking is used with induction motors and permanent magnet synchronous motors.

Two braking power levels are available:

- Moderate braking provides faster deceleration compared to a situation where flux braking is disabled. The flux level of the motor is limited to prevent excessive heating of the motor.
- Full braking exploits almost all available current to convert the mechanical braking energy to motor thermal energy. Braking time is shorter compared to moderate braking. In cyclic use, motor heating may be significant.

Settings

See parameter [97.05 Flux braking](#)

■ DC magnetization


DC magnetization can be applied to the motor to lock the rotor at or near zero speed.

Pre-magnetization

Pre-magnetization refers to DC magnetization of the motor before start. Depending on the selected start mode ([21.01 Start mode](#)), pre-magnetization is applied to guarantee the highest possible breakaway torque, up to 200% of the nominal torque of the motor. By adjusting the pre-magnetization time ([21.02 Magnetization time](#)), it is possible to synchronize the motor start.

DC hold

The function makes it possible to lock the rotor at or near zero speed in the middle of normal operation. DC hold is activated by parameter [21.08 DC current control](#). When both the reference and motor speed drop below a certain level (parameter [21.09 DC hold speed](#)), the drive stops generating sinusoidal current and starts to inject DC into the motor. The current is set by parameter [21.10 DC current reference](#). When the reference exceeds parameter [21.09 DC hold speed](#), normal drive operation continues.



Note:

- DC hold is only available in speed control.
- The function applies the DC current to one phase only, depending on the position of the rotor. The return current will be shared between the other phases.

Post-magnetization

This feature keeps the motor magnetized for a certain period (parameter [21.11 Post magnetization time](#)) after stopping to prevent the machinery from moving under load. Post-magnetization is activated by parameter [21.08 DC current control](#). The magnetization current is set by parameter [21.10 DC current reference](#).

Note: Post-magnetization is only available when ramping is the selected stop mode (see parameter [21.03 Stop mode](#)).

Continuous magnetization

A digital signal, such as a user bit in the fieldbus control word, can be selected to activate continuous magnetization. This can be especially useful in processes requiring motors to be stopped (for example, to stand by until new material is processed), then quickly started without magnetizing them first.

Note: Continuous magnetization is only available in speed control in DTC motor control mode (see page [53](#)), and only when ramping is the selected stop mode (see parameter [21.03 Stop mode](#)).



WARNING: The motor must be designed to absorb or dissipate the thermal energy generated by continuous magnetization, for example by forced ventilation.

Settings

Parameters [21.01 Start mode](#), [21.02 Magnetization time](#) and [21.08...21.12](#) (page [193](#)).

Application control

See chapter [Default control connections](#) (page [95](#)).

■ Motor potentiometer


The motor potentiometer is, in effect, a counter whose value can be adjusted up and down using two digital signals selected by parameters [22.73 Motor potentiometer up source](#) and [22.74 Motor potentiometer down source](#). Note that these signals have no effect when the drive is stopped.

When enabled by [22.71 Motor potentiometer function](#), the motor potentiometer assumes the value set by [22.72 Motor potentiometer initial value](#). Depending on the mode selected in [22.71](#), the motor potentiometer value is either retained or reset over a stop or a power cycle.

The change rate is defined in [22.75 Motor potentiometer ramp time](#) as the time it would take for the value to change from the minimum ([22.76 Motor potentiometer min value](#)) to the maximum ([22.77 Motor potentiometer max value](#)) or vice versa. If the up and down signals are simultaneously on, the motor potentiometer value does not change.

The output of the function is shown by [22.80 Motor potentiometer ref act](#), which can directly be set as the source of any selector parameter such as [22.11 Speed ref1 source](#).

The following example shows the behavior of the motor potentiometer value.



Settings

Parameters [22.71...22.80](#) (page [201](#)).

DC voltage control


Overvoltage control

Overvoltage control of the intermediate DC link is typically needed when the motor is in generating mode. To prevent the DC voltage from exceeding the overvoltage control limit, the overvoltage controller automatically decreases the generating torque when the limit is reached.

Undervoltage control

If the incoming supply voltage is cut off, the drive will continue to operate by utilizing the kinetic energy of the rotating motor. The drive will be fully operational as long as the motor rotates and generates energy to the drive. The drive can continue operation after the break if the main contactor (if present) remained closed.

Note: Units equipped with a main contactor must be equipped with a hold circuit (example UPS) to keep the contactor control circuit closed during a short supply break.



U_{DC} = intermediate circuit voltage of the drive, f_{out} = output frequency of the drive, T_M = motor torque
 Loss of supply voltage at nominal load ($f_{out} = 40$ Hz). The intermediate circuit DC voltage drops to the minimum limit. The controller keeps the voltage steady as long as the mains is switched off. The drive runs the motor in generator mode. The motor speed falls but the drive is operational as long as the motor has enough kinetic energy.

Automatic restart

It is possible to restart the drive automatically after a short (maximum 5 seconds) power supply failure by using the Automatic restart function provided that the drive is allowed to run for 5 seconds without the cooling fans operating.

When enabled, the function takes the following actions upon a supply failure to enable a successful restart:

- The undervoltage fault is suppressed (but a warning is generated)
- Modulation and cooling is stopped to conserve any remaining energy
- DC circuit pre-charging is enabled.

If the DC voltage is restored before the expiration of the period defined by parameter [21.18 Auto restart time](#) and the start signal is still on, normal operation will continue. However, if the DC voltage remains too low at that point, the drive trips on a fault, [3280 Standby timeout](#).



WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a supply break.

■ Voltage control and trip limits

The control and trip limits of the intermediate DC voltage regulator are relative to the supply voltage as well as drive/inverter type. The DC voltage is approximately 1.35 times the line-to-line supply voltage, and is displayed by parameter [01.11 DC voltage](#).

The following table shows the values of selected DC voltage levels in volts. All voltages are relative to the supply voltage range selected in parameter [95.01 Supply voltage](#).

| Level | Supply voltage range [V] (see 95.01 Supply voltage) | | | | | |
|---|--|-----------|-----------|-----|-----------|-----------|
| | 208...240 | 380...415 | 440...480 | 500 | 525...600 | 660...690 |
| Overvoltage fault limit | 489/440* | 800 | 878 | 880 | 1113 | 1218 |
| Overvoltage control limit | 389 | 700 | 778 | 810 | 1013 | 1118 |
| Internal brake chopper at 100% pulse width | 403 | 697 | 806 | 806 | 1008 | 1159 |
| Internal brake chopper at 0% pulse width | 375 | 648 | 749 | 780 | 936 | 1077 |
| Overvoltage warning limit | 373 | 644 | 745 | 776 | 932 | 1071 |
| DC voltage at upper bound of supply voltage range (U_{DCmax}) | 324 | 560 | 648 | 675 | 810 | 932 |
| DC voltage at lower bound of supply voltage range | 281 | 513 | 594 | 675 | 709 | 891 |
| Undervoltage control and warning limit | 239 | 436 | 505 | 574 | 602 | 757 |
| Charging activation/standby limit | 225 | 410 | 475 | 540 | 567 | 713 |
| Undervoltage fault limit | 168 | 308 | 356 | 405 | 425 | 535 |

*489 V with frames R1...R3, 440 V with frames R4...R8.

Settings

See parameters

- [01.11 DC voltage](#) (page 105)
- [30.30 Overvoltage control](#) (page 240)
- [30.31 Undervoltage control](#) (page 241)
- [95.01 Supply voltage](#) (page 338) and
- [95.02 Adaptive voltage limits](#) (page 338)

■ Brake chopper

A brake chopper can be used to handle the energy generated by a decelerating motor. When the DC voltage rises high enough, the chopper connects the DC circuit to an external brake resistor. The chopper operates on the pulse width modulation principle.

The internal brake choppers of ACS880 drives start conducting when the DC link voltage reaches $1.156 \times U_{DCmax}$. 100% pulse width is reached at approximately $1.2 \times U_{DCmax}$, depending on supply voltage range. See table under [Voltage control and trip limits](#) (page 81). (U_{DCmax} is the DC voltage corresponding to the maximum of the AC supply voltage range.)

For information on external brake choppers, refer to their documentation.

Settings

See parameter [01.11 DC voltage](#) (page 105) and parameter group [43 Brake chopper](#) (page 276).

Safety and protections

■ Emergency stop

The emergency stop signal is connected to the input selected by parameter [21.05 Emergency stop source](#). An emergency stop can also be generated through fieldbus (parameter [06.01 Main control word](#), bits 0...2).

The mode of the emergency stop is selected by parameter [21.04 Emergency stop mode](#). The following modes are available:

- Off1: Stop along the standard deceleration ramp defined for the particular reference type in use
- Off2: Stop by coasting
- Off3: Stop by the emergency stop ramp defined by parameter [23.23 Emergency stop time](#).

With Off1 or Off3 emergency stop modes, the ramp-down of the motor speed can be supervised by parameters [31.32 Emergency ramp supervision](#) and [31.33 Emergency ramp supervision delay](#).

Notes:

- For SIL 3 / PL e-level emergency stop functions, the drive can be fitted with a TÜV-certified FSO-xx safety options module. The module can then be incorporated into certified safety systems.
 - The installer of the equipment is responsible for installing the emergency stop devices and all additional devices needed for the emergency stop function to fulfill
-

the required emergency stop categories. For more information, contact your local ABB representative.

- After an emergency stop signal is detected, the emergency stop function cannot be canceled even though the signal is canceled.
- If the minimum (or maximum) torque limit is set to 0%, the emergency stop function may not be able to stop the drive.

Settings

Parameters [06.17 Drive status word 2](#) (page 118), [06.18 Start inhibit status word](#) (page 119), [21.04 Emergency stop mode](#) (page 191), [21.05 Emergency stop source](#) (page 191), [23.23 Emergency stop time](#) (page 207), [25.13 Min torq sp ctrl em stop](#) (page 219), [25.14 Max torq sp ctrl em stop](#) (page 219), [25.15 Proportional gain em stop](#) (page 219), [31.32 Emergency ramp supervision](#) (page 248) and [31.33 Emergency ramp supervision delay](#) (page 248).

■ Motor thermal protection

The control program features two separate motor temperature monitoring functions. The temperature data sources and warning/trip limits can be set up independently for each function.

The motor temperature can be monitored using

- the motor thermal protection model (estimated temperature derived internally inside the drive), or
- sensors installed in the windings. This will result in a more accurate motor model.

In addition to temperature monitoring, a protection function is available for 'Ex' motors installed in a potentially explosive atmosphere.

Motor thermal protection model


The drive calculates the temperature of the motor on the basis of the following assumptions:

1. When power is applied to the drive for the first time, the motor is assumed to be at ambient temperature (defined by parameter [35.50 Motor ambient temperature](#)). After this, when power is applied to the drive, the motor is assumed to be at the estimated temperature.
2. Motor temperature is calculated using the user-adjustable motor thermal time and motor load curve. The load curve should be adjusted in case the ambient temperature exceeds 30 °C.

Note: The motor thermal model can be used when only one motor is connected to the inverter.

Temperature monitoring using PTC sensors

One PTC sensor can be connected to digital input DI6. FEN-xx encoder interfaces (optional) also have a connection for one PTC sensor.




The resistance of the PTC sensor increases when its temperature rises. The increasing resistance of the sensor decreases the voltage at the input, and eventually its state switches from 1 to 0, indicating overtemperature.

1...3 PTC sensors can also be connected in series to an analog input and an analog output. The analog output feeds a constant excitation current of 1.6 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function calculates the resistance of the sensor and generates an indication if overtemperature is detected.

For wiring of the sensor, refer to the Hardware Manual of the drive.

The figure below shows typical PTC sensor resistance values as a function of temperature.



In addition to the above, optional FEN-xx encoder interfaces, and FEX-01 and FPTC-01 modules have connections for PTC sensors. Refer to the module-specific documentation for more information.

Temperature monitoring using Pt100 or Pt1000 sensors

1...3 Pt100 or Pt 1000 sensors can be connected in series to an analog input and an analog output.

The analog output feeds a constant excitation current of 9.1 mA (Pt100) or 1 mA (1000) through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

The warning and fault limits can be adjusted by parameters.

For the wiring of the sensor, refer to the *Hardware Manual* of the drive.


Temperature monitoring using KTY84 sensors

One KTY84 sensor can be connected to an analog input and an analog output on the control unit.

The analog output feeds a constant excitation current of 2.0 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

FEN-xx encoder interfaces (optional) also have a connection for one KTY84 sensor.

The figure and table below show typical KTY84 sensor resistance values as a function of the motor operating temperature.



The warning and fault limits can be adjusted by parameters.

For the wiring of the sensor, refer to the *Hardware Manual* of the drive.

Motor fan control logic (parameters [35.100...35.106](#))

If the motor has an external cooling fan, it is possible to use a drive signal (for example, running/stopped) to control the starter of the fan via a relay or digital output. A digital input can be selected for fan feedback. A loss of the feedback signal will optionally cause a warning or a fault.

Start and stop delays can be defined for the fan. In addition, a feedback delay can be set to define the time within which feedback must be received after the fan starts.

Ex motor support (parameter [95.15](#), bit 0)

The control program has a temperature protection function for Ex motors located in a potentially explosive atmosphere. The protection is enabled by setting bit 0 of parameter [95.15 Special HW settings](#).

Settings

Parameter groups [35 Motor thermal protection](#) (page [262](#)) and [91 Encoder module settings](#) (page [327](#)); parameter [95.15 Special HW settings](#) (page [340](#)).

■ Thermal protection of motor cable

The control program contains a thermal protection function for the motor cable. This function should be used, for example, when the nominal current of the drive exceeds the current-carrying capacity of the motor cable.

The program calculates the temperature of the cable on the basis of the following data:

- Measured output current (parameter [01.07 Motor current](#))
- Nominal continuous current rating of the cable, specified by [35.61 Cable nominal current](#), and
- Thermal time constant of the cable, specified by [35.62 Cable thermal rise time](#).

When the calculated temperature of the cable reaches 102% of the rated maximum, a warning ([A480 Motor cable overload](#)) is given. The drive trips on a fault ([4000 Motor cable overload](#)) when 106% is reached.

Settings

Parameters [35.60...35.62](#) (page [270](#)).

■ Other programmable protection functions

External events (parameters [31.01...31.10](#))

Five different event signals from the process can be connected to selectable inputs to generate trips and warnings for the driven equipment. When the signal is lost, an external event (fault, warning, or a mere log entry) is generated. The contents of the

messages can be edited on the control panel by selecting **Menu - Settings - Edit texts**.

Motor phase loss detection (parameter 31.19)

The parameter selects how the drive reacts whenever a motor phase loss is detected.

Earth (Ground) fault detection (parameter 31.20)

The earth fault detection function is based on sum current measurement. Note that

- an earth fault in the supply cable does not activate the protection
- in a grounded supply, the protection activates within 2 milliseconds
- in an ungrounded supply, the supply capacitance must be 1 microfarad or more
- the capacitive currents caused by shielded motor cables up to 300 meters will not activate the protection
- the protection is deactivated when the drive is stopped.

Supply phase loss detection (parameter 31.21)

The parameter selects how the drive reacts whenever a supply phase loss is detected.

Safe torque off detection (parameter 31.22)

The drive monitors the status of the Safe torque off input, and this parameter selects which indications are given when the signals are lost. (The parameter does not affect the operation of the Safe torque off function itself). For more information on the Safe torque off function, see the *Hardware manual*.

Swapped supply and motor cabling (parameter 31.23)

The drive can detect if the supply and motor cables have accidentally been swapped (for example, if the supply is connected to the motor connection of the drive). The parameter selects if a fault is generated or not. Note that the protection should be disabled in drive/inverter hardware supplied from a common DC bus.

Stall protection (parameters 31.24...31.28)

The drive protects the motor in a stall situation. It is possible to adjust the supervision limits (current, frequency and time) and choose how the drive reacts to a motor stall condition.

Overspeed protection (parameter 31.30)

The user can set overspeed limits by specifying a margin that is added to the currently-used maximum and minimum speed limits.

Ramp stop supervision (parameters [31.32](#), [31.33](#), [31.37](#) and [31.38](#))

The control program has a supervision function for both the normal and emergency stop ramps. The user can either define a maximum time for stopping, or a maximum deviation from the expected deceleration rate. If the drive fails to stop in the expected manner, a fault is generated and the drive coasts to a stop.

Custom motor current fault limit (parameter [31.42](#))

The control program sets a motor current limit based on drive hardware. In most cases, the default value is appropriate. However, a lower limit can be manually set by the user, for example, to protect a permanent magnet motor from demagnetization.

Local control loss detection (parameter [49.05](#))

The parameter selects how the drive reacts to a control panel or PC tool communication break.

■ Automatic fault resets

The drive can automatically reset itself after overcurrent, overvoltage, undervoltage and external faults. The user can also specify a fault that is automatically reset.

By default, automatic resets are off and must be specifically activated by the user.



WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function resets the drive automatically and continues operation after a fault.

Settings

Parameters [31.12...31.16](#) (page [243](#)).

Diagnostics

■ Signal supervision

Three signals can be selected to be supervised by this function. Whenever a supervised signal exceeds or falls below predefined limits, a bit in [32.01 Supervision status](#) is activated, and a warning or fault generated. The contents of the message can be edited on the control panel by selecting **Settings - Edit texts**.

The supervised signal is low-pass filtered.

Settings

See parameter group [32 Supervision](#) (page [251](#)).

■ Maintenance timers and counters

The program has six different maintenance timers or counters that can be configured to generate a warning when a pre-defined limit is reached. The contents of the message can be edited on the control panel by selecting **Settings - Edit texts**.

The timer/counter can be set to monitor any parameter. This feature is especially useful as a service reminder.

There are three types of counters:

- On time timers. Measures the time a binary source (for example, a bit in a status word) is on.
 - Signal edge counters. The counter is incremented whenever the monitored binary source changes state.
 - Value counters measures, by integration, the monitored parameter. An warning is given when the calculated area below the signal peak exceeds a user-defined limit.
-

Settings

See parameter group [33 Generic timer & counter](#) (page 254).

■ Energy savings calculator

This feature consists of the following functionalities:

- An energy optimizer that adjusts the motor flux in such a way that the total efficiency is maximized
- A counter that monitors used and saved energy by the motor and displays them in kWh, currency or volume of CO₂ emissions, and
- A load analyzer showing the load profile of the drive (see separate section on page 90).

Note: The accuracy of the energy savings calculation is directly dependent on the accuracy of the reference motor power given in parameter [45.19 Comparison power](#).

Settings

See parameter group [45 Energy efficiency](#) (page 277).

■ Load analyzer

Peak value logger


The user can select a signal to be monitored by a peak value logger. The logger records the peak value of the signal along with the time the peak occurred, as well as motor current, DC voltage and motor speed at the time of the peak.

Amplitude loggers

The control program has two amplitude loggers.

For amplitude logger 2, the user can select a signal to be sampled at 200 ms intervals when the drive is running, and specify a value that corresponds to 100%. The collected samples are sorted into 10 read-only parameters according to their

amplitude. Each parameter represents an amplitude range 10 percentage points wide, and displays the percentage of the collected samples that fall within that range.



Amplitude logger 1 is fixed to monitor motor current, and cannot be reset. With amplitude logger 1, 100% corresponds to the maximum output current of the drive (I_{\max} , as given in the hardware manual). The distribution of samples is shown by parameters [36.20](#)...[36.29](#).

Settings

See parameter group [36 Load analyzer](#) (page [272](#)).

Miscellaneous

■ User parameter sets

The drive supports four user parameter sets that can be saved to the permanent memory and recalled using drive parameters. It is also possible to use digital inputs to switch between user parameter sets.

A user parameter set contains all editable values in parameter groups 10...99 except

- forced I/O values such as parameters [10.03 DI force selection](#) and [10.04 DI force data](#)
- I/O extension module settings (groups 14...16)
- data storage parameters (group 47)
- fieldbus adapter-specific settings (groups 51...56 and 58), and
- encoder configuration settings (groups 92...93).

As the motor settings are included in the user parameter sets, make sure the settings correspond to the motor used in the application before recalling a user set. In an application where different motors are used with the drive, the motor ID run needs to be performed with each motor and the results saved to different user sets. The appropriate set can be recalled when the motor is switched.

Settings

See parameters [96.10...96.13](#) (page [344](#)).

■ Data storage parameters

Twenty four (sixteen 32-bit, eight 16-bit) parameters are reserved for data storage. These parameters are unconnected by default and can be used for eg. linking, testing and commissioning purposes. They can be written to and read from using other parameters' source or target selections.

Note that "[Analog src](#)" type parameters (see page [361](#)) expect a 32-bit real (floating point) source – in other words, parameters [47.01...47.08](#) can be used as a value source of other parameters while [47.11...47.28](#) cannot.

Settings

See parameter group [47 Data storage](#) (page [281](#)).

■ du/dt filter support

With an external du/dt filter connected to the output of the drive, bit 13 of [95.20 HW options word 1](#) must be switched on. The setting enables an overtemperature protection for the filter. Note that the setting is not to be activated with inverter modules with internal du/dt filters.

Settings

Parameter [95.20 HW options word 1](#) (page [341](#)).

■ Sine filter support

The control program has a setting that enables the use of ABB sine filters (available separately). With a sine filter connected to the output of the drive, bit 1 of [95.15 Special HW settings](#) must be switched on. The setting forces the drive to use the scalar motor control mode, and limits the switching and output frequencies to

- prevent the drive from operating at filter resonance frequencies, and
- protect the filter from overheating.

Please contact your local ABB representative before connecting a sine filter from another manufacturer.

Settings

Parameter [95.15 Special HW settings](#) (page [340](#)).



Default control connections


Contents of this chapter

This chapter describes the default control connections of the PCP/ESP control application.




PCP/ESP I/O control connections

| | | |
|---|--------|--|
| | | XPOW External power input |
| 1 | +24Vl | 24 V DC, 2 A |
| 2 | GND | |
| | | XAI Reference voltage and analog inputs |
| 1 | +VREF | 10 V DC, R_L 1...10 kohm |
| 2 | -VREF | -10 V DC, R_L 1...10 kohm |
| 3 | AGND | Ground |
| 4 | AI1+ | Analog input 1 Speed reference 0(2)...10V, R_{in} > 200 kohm |
| 5 | AI1- | |
| 6 | AI2+ | Analog input 2 0(4)...20 mA, R_{in} > 100 ohm By default, not in use. |
| 7 | AI2- | |
| | | XAO Analog outputs |
| 1 | AO1 | Motor speed rpm |
| 2 | AGND | 0...20 mA, R_L < 500 ohm |
| 3 | AO2 | Motor current |
| 4 | AGND | 0...20 mA, R_L < 500 ohm |
| | | XD2D Drive-to-drive link |
| 1 | B | Drive-to-drive link |
| 2 | A | |
| 3 | BGND | |
| | | XRO1, XRO2, XRO3 Relay outputs |
| 1 | NC | Relay out 1 250 V AC / 30 VDC, 2 A Ready run |
| 2 | COM | |
| 3 | NO | |
| 1 | NC | Relay output 2 250 V AC / 30 VDC, 2 A Running |
| 2 | COM | |
| 3 | NO | |
| 1 | NC | Relay output 3 250 V AC / 30 VDC, 2 A Fault (-1) |
| 2 | COM | |
| 3 | NO | |
| | | XD24 Digital interlock |
| 1 | DIIL | Run enable |
| 2 | +24VD | +24 V DC 200 mA |
| 3 | DTCOM | Digital input ground |
| 4 | +24VD | +24 V DC 200 mA |
| 5 | DIOGND | Digital input/output ground |
| | | XDIO Digital input/outputs |
| 1 | DIO1 | Output: Ready |
| 2 | DIO2 | Output: Running |
| | | XDI Digital inputs |
| 1 | DI1 | Stop (0) / Start (1) |
| 2 | DI2 | By default, not in use. |
| 3 | DI3 | By default, not in use. |
| 4 | DI4 | By default, not in use. |
| 5 | DI5 | By default, not in use. |
| 6 | DI6 | By default, not in use. |
| | | XSTO Safe torque off circuits must be closed for the drive to start. See <i>Hardware manual</i> of drive. |
| | | X12 Safety options connection |
| | | X13 Control panel connection |
| | | X205 Memory unit connection |

Sensor connection examples



Note: The sensor must be powered externally.



Application control PCP/ESP

This default connection scheme is used for PCP/ESP application. Pump speed reference is constant and selectable through parameter [74.05 Speed ref source](#).

The application works through Ext1 and Ext 2 control locations.

The start/stop signal is connected to digital input DI1. The reset is determined by digital input DI2. Klixon temperature sensor is connected to input DI3. Input DI4 is responsible for pressure protection. Pressure limits and temperature limits are set through corresponding parameters, as well as protection modes.

PT100 source feedback goes through input AI1 scaled. AO2 is used for feeding excitation current. Pressure feedback source goes through AI2 scaled as a current signal in the range of 020 mA.

■ Default parameter settings for the PCP/ESP

Below is a listing of default parameter values that differ from those listed for the factory macro in [Parameter listing](#) (page 105).

| Parameter | | PCP/ESP control default |
|-----------------------|---|---------------------------------|
| No. | Name | |
| 20.01 | Ext1 commands | In1 Start |
| 20.06 | Ext2 commands | Not selected |
| 74.01 | Pump enable | Enable |
| 74.02 | Run-time hours reset source | No |
| 74.05 | Speed ref source | AI1 scaled |
| 76.01 | Pressure protection function | Disable |
| 76.02 | Pressure protection latching | Non latching |
| 76.03 | Digital feedback source enable | FALSE |
| 76.04 | Digital feedback source | FALSE |
| 76.05 | Analog feedback source enable | FALSE |
| 76.06 | Analog feedback source | Zero |
| 76.07 | Analog feedback limit | 0.00 kPa or psi |
| 76.08 | Analog feedback limit delay time | 0.000 s |
| 79.01 | Temperature protection function | No |
| 79.02 | Temperature protection device | Klixon |
| 79.03 | Klixon signal source | FALSE |
| 79.04 | PT100 source | Zero |
| 79.05 | PT100 excitation source | Zero |
| 79.06 | PT100 internal selection | 9.10 mA |
| 79.07 | Number of PT100 sensors in series | 1 |

| Parameter | | PCP/ESP control default |
|-----------|----------------------------------|-------------------------|
| No. | Name | |
| 79.08 | <i>Warning temperature limit</i> | 0.00 °C |
| 79.09 | <i>Fault temperature limit</i> | 0.00 °C |

8

Parameters

Contents of this chapter

The chapter describes the parameters, including actual signals, of the control program.

Terms and abbreviations

| Term | Definition |
|---------------|--|
| Actual signal | Type of <i>parameter</i> that is the result of a measurement or calculation by the drive, or contains status information. Most actual signals are read-only, but some (especially counter-type actual signals) can be reset. |
| Def | (In the following table, shown on the same row as the parameter name). The default value of a <i>parameter</i> when used in the Factory macro. For information on other macro-specific parameter values, see chapter <i>Application macros</i> in See <i>ACS880 primary control program firmware manual (3AUA0000085967[English])</i> . Note: Certain configurations or optional equipment may require specific default values. These are labeled as follows: (95.20 bx) = Default changed or write-protected by parameter 95.20, bit x. |
| FbEq16 | (In the following table, shown on the same row as the parameter range, or for each selection) 16-bit fieldbus equivalent: The scaling between the value shown on the panel and the integer used in communication when a 16-bit value is selected for transmission to an external system. A dash (-) indicates that the parameter is not accessible in 16-bit format. The corresponding 32-bit scalings are listed in chapter <i>Additional parameter data</i> (page 361). |
| Other | The value is taken from another parameter. Choosing "Other" displays a parameter list in which the user can specify the source parameter. Note: The source parameter must be a 32-bit real (floating point) number. To use a 16-bit integer (for example, received from an external device in data sets) as the source, data storage parameters 47.01...47.08 (page 281) can be used. |
| Other [bit] | The value is taken from a specific bit in another parameter. Choosing "Other" displays a parameter list in which the user can specify the source parameter and bit. |

102 Parameters

| Term | Definition |
|-----------|--|
| Parameter | Either a user-adjustable operating instruction for the drive, or an <i>actual signal</i> . |
| p.u. | Per unit |

Summary of parameter groups

| Group | Contents | Page |
|---|---|---------------------|
| 01 Actual values | Basic signals for monitoring the drive. | 105 |
| 03 Input references | Values of references received from various sources. | 108 |
| 04 Warnings and faults | Information on warnings and faults that occurred last. | 109 |
| 05 Diagnostics | Various run-time-type counters and measurements related to drive maintenance. | 115 |
| 06 Control and status words | Drive control and status words. | 116 |
| 07 System info | Drive hardware and firmware information. | 124 |
| 09 Pump actuals | Basic signals for monitoring the application. | 125 |
| 10 Standard DI, RO | Configuration of digital inputs and relay outputs. | 128 |
| 11 Standard DIO, FI, FO | Configuration of digital input/outputs and frequency inputs/outputs. | 134 |
| 12 Standard AI | Configuration of standard analog inputs. | 140 |
| 13 Standard AO | Configuration of standard analog outputs. | 144 |
| 14 I/O extension module 1 | Configuration of I/O extension module 1. | 149 |
| 15 I/O extension module 2 | Configuration of I/O extension module 2. | 171 |
| 16 I/O extension module 3 | Configuration of I/O extension module 3. | 174 |
| 19 Operation mode | Selection of local and external control location sources and operating modes. | 178 |
| 20 Start/stop/direction | Start/stop/direction and run/start/jog enable signal source selection; positive/negative reference enable signal source selection. | 180 |
| 21 Start/stop mode | Start and stop modes; emergency stop mode and signal source selection; DC magnetization settings; autophasing mode selection. | 189 |
| 22 Speed reference selection | Speed reference selection settings; motor potentiometer settings. | 195 |
| 23 Speed reference ramp | Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive). | 203 |
| 24 Speed reference conditioning | Speed error calculation; speed error window control configuration; speed error step. | 210 |
| 25 Speed control | Speed controller settings. | 213 |
| 26 Torque reference chain | Settings for the torque reference chain. | 224 |
| 28 Frequency reference chain | Settings for the frequency reference chain. | 226 |
| 30 Limits | Drive operation limits. | 235 |
| 31 Fault functions | Configuration of external events; selection of behavior of the drive upon fault situations. | 241 |
| 32 Supervision | Configuration of signal supervision functions 1...3. | 251 |
| 33 Generic timer & counter | Configuration of maintenance timers/counters. | 254 |
| 35 Motor thermal protection | Motor thermal protection settings such as temperature measurement configuration, load curve definition and motor fan control configuration. | 262 |
| 36 Load analyzer | Peak value and amplitude logger settings. | 272 |
| 43 Brake chopper | Settings for the internal brake chopper. | 276 |
| 45 Energy efficiency | Settings for the energy saving calculators. | 277 |

| Group | Contents | Page |
|--|---|---------------------|
| 46 Monitoring/scaling settings | Speed supervision settings; actual signal filtering; general scaling settings. | 280 |
| 47 Data storage | Data storage parameters that can be written to and read from using other parameters' source and target settings. | 281 |
| 49 Panel port communication | Communication settings for the control panel port on the drive. | 283 |
| 50 Fieldbus adapter (FBA) | Fieldbus communication configuration. | 284 |
| 51 FBA A settings | Fieldbus adapter A configuration. | 291 |
| 52 FBA A data in | Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter A. | 293 |
| 53 FBA A data out | Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter A. | 293 |
| 54 FBA B settings | Fieldbus adapter B configuration. | 294 |
| 55 FBA B data in | Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter B. | 295 |
| 56 FBA B data out | Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter B. | 296 |
| 58 Embedded fieldbus | Configuration of the embedded fieldbus (EFB) interface. | 296 |
| 74 Pump setup | Basic functions of applications. | 303 |
| 75 Pump level control | Pump level control function. | 307 |
| 76 Pump pressure protection | Pump pressure protection function. | 310 |
| 77 Pump torque protection | Pump torque protection function. | 311 |
| 78 Pump underload protection | Pump underload protection function. | 314 |
| 79 Pump temperature protection | Pump temperature protection function. | 315 |
| 80 Pump backspin control | Basic functions of applications. | 316 |
| 90 Feedback selection | Motor and load feedback configuration. | 318 |
| 91 Encoder module settings | Configuration of encoder interface modules. | 327 |
| 92 Encoder 1 configuration | Settings for encoder 1. | 330 |
| 93 Encoder 2 configuration | Settings for encoder 2. | 336 |
| 95 HW configuration | Various hardware-related settings. | 338 |
| 96 System | Language selection; access levels; macro selection; parameter save and restore; control unit reboot; user parameter sets; unit selection. | 342 |
| 97 Motor control | Motor model settings. | 348 |
| 98 User motor parameters | Motor values supplied by the user that are used in the motor model. | 351 |
| 99 Motor data | Motor configuration settings. | 353 |
| 200 Safety | FSO-xx settings. | 359 |

Parameter listing

| No. | Name/Value | Description | Def/ FbEq16 |
|-------------------------|---------------------------------|---|--------------------------------|
| 01 Actual values | | Basic signals for monitoring the drive. All parameters in this group are read-only unless otherwise noted. | |
| 01.01 | Motor speed used | Measured or estimated motor speed depending on which type of feedback is used (see parameter 90.41 Motor feedback selection). A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed . | - |
| | -30000.00 ...30000.00 rpm | Measured or estimated motor speed. | See par. 46.01 |
| 01.02 | Motor speed estimated | Estimated motor speed in rpm. A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed . | - |
| | -30000.00 ...30000.00 rpm | Estimated motor speed. | See par. 46.01 |
| 01.03 | Motor speed % | Shows the value of 01.01 Motor speed used in percent of the synchronous speed of the motor. | 10 = 1% |
| | -1000.00 ... 1000.00% | Measured or estimated motor speed. | See par. 46.01 |
| 01.04 | Encoder 1 speed filtered | Speed of encoder 1 in rpm. A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed . | - |
| | -30000.00 ...30000.00 rpm | Encoder 1 speed. | See par. 46.01 |
| 01.05 | Encoder 2 speed filtered | Speed of encoder 2 in rpm. A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed . | - |
| | -30000.00 ...30000.00 rpm | Encoder 2 speed. | See par. 46.01 |
| 01.06 | Output frequency | Estimated drive output frequency in Hz. A filter time constant for this signal can be defined by parameter 46.12 Filter time output frequency . | - |
| | -500.00 ...500.00 Hz | Estimated output frequency. | See par. 46.02 |
| 01.07 | Motor current | Measured (absolute) motor current in A. | - |
| | 0.00...30000.00 A | Motor current. | See par. 46.05 |
| 01.10 | Motor torque | Motor torque in percent of the nominal motor torque. See also parameter 01.30 Nominal torque scale . A filter time constant for this signal can be defined by parameter 46.13 Filter time motor torque . | - |
| | -1600.0...1600.0% | Motor torque. | See par. 46.03 |
| 01.11 | DC voltage | Measured DC link voltage. | - |
| | 0.00...2000.00 V | DC link voltage. | 10 = 1 V |
| 01.13 | Output voltage | Calculated motor voltage in V AC. | - |
| | 0...2000 V | Motor voltage. | 1 = 1 V |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------|---|---|----------------|
| 01.14 | Output power | Drive output power. The unit is selected by parameter 96.16 Unit selection . A filter time constant for this signal can be defined by parameter 46.14 Filter time power out . | - |
| | -32768.00 ...32767.00 kW or hp | Output power. | 1 = 1 unit |
| 01.15 | Output power % of motor nom | Shows the value of 01.14 Output power in percent of the nominal power of the motor. | - |
| | -300.00 ... 300.00% | Output power. | 1 = 1% |
| 01.17 | Motor shaft power | Estimated mechanical power at motor shaft. The unit is selected by parameter 96.16 Unit selection . | - |
| | -32768.00 ... 32767.00 kW or hp | Motor shaft power. | 1 = 1 unit |
| 01.18 | Inverter GWh motoring | Amount of energy that has passed through the drive (towards the motor) in full gigawatt-hours. The minimum value is zero. | - |
| | 0...32767 GWh | Motoring energy in GWh. | 1 = 1 GWh |
| 01.19 | Inverter MWh motoring | Amount of energy that has passed through the drive (towards the motor) in full megawatt-hours. Whenever the counter rolls over, 01.18 Inverter GWh motoring is incremented. The minimum value is zero. | - |
| | 0...1000 MWh | Motoring energy in MWh. | 1 = 1 MWh |
| 01.20 | Inverter kWh motoring | Amount of energy that has passed through the drive (towards the motor) in full kilowatt-hours. Whenever the counter rolls over, 01.19 Inverter MWh motoring is incremented. The minimum value is zero. | - |
| | 0...1000 kWh | Motoring energy in kWh. | 10 = 1 kWh |
| 01.21 | U-phase current | Measured U-phase current. | - |
| | -30000.00 ... 30000.00 A | U-phase current. | - |
| 01.22 | V-phase current | Measured V-phase current. | - |
| | -30000.00 ... 30000.00 A | V-phase current. | - |
| 01.23 | W-phase current | Measured W-phase current. | - |
| | -30000.00 ... 30000.00 A | W-phase current. | - |
| 01.24 | Flux actual % | Used flux reference in percent of nominal flux of motor. | - |
| | 0...200% | Flux reference. | 1 = 1% |
| 01.29 | Speed change rate | Rate of actual speed change. Positive values indicate acceleration, negative values indicate deceleration. See also parameters 31.32 Emergency ramp supervision , 31.33 Emergency ramp supervision delay , 31.37 Ramp stop supervision and 31.38 Ramp stop supervision delay . | - |
| | -15000...15000 rpm/s | Rate of speed change. | 1 = 1 rpm/s |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------------|--|--------------------------------|
| 01.30 | <i>Nominal torque scale</i> | Torque that corresponds to 100% of nominal motor torque. The unit is selected by parameter 96.16 Unit selection Note: This value is copied from parameter 99.12 Motor nominal torque if entered. Otherwise the value is calculated from other motor data. | 0.000 N·m or lb·ft |
| | 0.000...4000000.000 N·m or lb·ft | Nominal torque. | 1 = 100 unit |
| 01.31 | <i>Ambient temperature</i> | Measured temperature of incoming cooling air. The unit is selected by parameter 96.16 Unit selection . | - |
| | -40...120 °C or °F | Cooling air temperature. | 1 = 1° |
| 01.32 | <i>Inverter GWh regenerating</i> | Amount of energy that has passed through the drive (towards the supply) in full gigawatt-hours. The minimum value is zero. | - |
| | 0...32767 GWh | Motoring energy in GWh. | 1 = 1 GWh |
| 01.33 | <i>Inverter MWh regenerating</i> | Amount of energy that has passed through the drive (towards the supply) in full megawatt-hours. Whenever the counter rolls over, 01.32 Inverter GWh regenerating is incremented. The minimum value is zero. | - |
| | 0...1000 MWh | Motoring energy in MWh. | 1 = 1 MWh |
| 01.34 | <i>Inverter kWh regenerating</i> | Amount of energy that has passed through the drive (towards the supply) in full kilowatt-hours. Whenever the counter rolls over, 01.33 Inverter MWh regenerating is incremented. The minimum value is zero. | - |
| | 0...1000 kWh | Motoring energy in kWh. | 10 = 1 kWh |
| 01.35 | <i>Mot - regen energy GWh</i> | Amount of net energy (motoring energy - regenerating energy) that has passed through the drive in full gigawatt-hours. | - |
| | -32768...32767 GWh | Motoring energy in GWh. | 1 = 1 GWh |
| 01.36 | <i>Mot - regen energy MWh</i> | Amount of net energy (motoring energy - regenerating energy) that has passed through the drive in full megawatt-hours. Whenever the counter rolls over, 01.35 Mot - regen energy GWh is incremented or decremented. | - |
| | -1000...1000 MWh | Motoring energy in MWh. | 1 = 1 MWh |
| 01.37 | <i>Mot - regen energy kWh</i> | Amount of energy (motoring energy - regenerating energy) that has passed through the drive in full kilowatt-hours. Whenever the counter rolls over, 01.36 Mot - regen energy MWh is incremented or decremented. | - |
| | -1000...1000 kWh | Motoring energy in kWh. | 10 = 1 kWh |
| 01.61 | <i>Abs motor speed used</i> | Absolute value of 01.01 Motor speed used . | - |
| | 0.00 ... 30000.00 rpm | Measured or estimated motor speed. | See par. 46.01 |
| 01.62 | <i>Abs motor speed %</i> | Absolute value of 01.03 Motor speed % . | - |
| | 0.00 ... 1000.00% | Measured or estimated motor speed. | See par. 46.01 |
| 01.63 | <i>Abs output frequency</i> | Absolute value of 01.06 Output frequency . | - |
| | 0.00 ... 500.00 Hz | Estimated output frequency. | See par. 46.02 |

| No. | Name/Value | Description | Def/ FbEq16 |
|----------------------------|--|--|----------------|
| 01.64 | Abs motor torque | Absolute value of 01.10 Motor torque . | - |
| | 0.0 ... 1600.0% | Motor torque. | - |
| 01.65 | Abs output power | Absolute value of 01.14 Output power . | - |
| | 0.00 ... 32767.00 kW or hp | Output power. | 1 = 1 unit |
| 01.66 | Abs output power % motor nom | Absolute value of 01.15 Output power % of motor nom . | - |
| | 0.00 ... 300.00% | Output power. | 1 = 1% |
| 01.68 | Abs motor shaft power | Absolute value of 01.17 Motor shaft power . | - |
| | 0.00 ... 32767.00 kW or hp | Motor shaft power. | 1 = 1 unit |
| 03 Input references | | Values of references received from various sources. All parameters in this group are read-only unless otherwise noted. | |
| 03.01 | Panel reference | Reference given from the control panel or PC tool. | - |
| | -100000.00 ...100000.00 | Control panel or PC tool reference. | 1 = 10 |
| 03.05 | FB A reference 1 | Reference 1 received through fieldbus adapter A. See also chapter Fieldbus control through a fieldbus adapter (page 461). | - |
| | -100000.00 ...100000.00 | Reference 1 from fieldbus adapter A. | 1 = 10 |
| 03.06 | FB A reference 2 | Reference 2 received through fieldbus adapter A. | - |
| | -100000.00 ...100000.00 | Reference 2 from fieldbus adapter A. | 1 = 10 |
| 03.07 | FB B reference 1 | Reference 1 received through fieldbus adapter B. | - |
| | -100000.00 ...100000.00 | Reference 1 from fieldbus adapter B. | 1 = 10 |
| 03.08 | FB B reference 2 | Reference 2 received through fieldbus adapter B. | - |
| | -100000.00 ...100000.00 | Reference 2 from fieldbus adapter B. | 1 = 10 |
| 03.09 | EFB reference 1 | Scaled reference 1 received through the embedded fieldbus interface. | 1 = 10 |
| | -30000.00 ... 30000.00 | Reference 1 received through the embedded fieldbus interface. | 1 = 10 |
| 03.10 | EFB reference 2 | Scaled reference 2 received through the embedded fieldbus interface. | 1 = 10 |
| | -30000.00 ... 30000.00 | Reference 2 received through the embedded fieldbus interface. | 1 = 10 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------------------------------|---------------------------|---|----------------|
| 04 Warnings and faults | | Information on warnings and faults that occurred last. For explanations of individual warning and fault codes, see chapter Fault tracing . All parameters in this group are read-only unless otherwise noted. | |
| 04.01 | <i>Tripping fault</i> | Code of the 1st active fault (the fault that caused the current trip). | - |
| | 0000h...FFFFh | 1st active fault. | 1 = 1 |
| 04.02 | <i>Active fault 2</i> | Code of the 2nd active fault. | - |
| | 0000h...FFFFh | 2nd active fault. | 1 = 1 |
| 04.03 | <i>Active fault 3</i> | Code of the 3rd active fault. | - |
| | 0000h...FFFFh | 3rd active fault. | 1 = 1 |
| 04.04 | <i>Active fault 4</i> | Code of the 4th active fault. | - |
| | 0000h...FFFFh | 4th active fault. | 1 = 1 |
| 04.05 | <i>Active fault 5</i> | Code of the 5th active fault. | - |
| | 0000h...FFFFh | 5th active fault. | 1 = 1 |
| 04.06 | <i>Active warning 1</i> | Code of the 1st active warning. | - |
| | 0000h...FFFFh | 1st active warning. | 1 = 1 |
| 04.07 | <i>Active warning 2</i> | Code of the 2nd active warning. | - |
| | 0000h...FFFFh | 2nd active warning. | 1 = 1 |
| 04.08 | <i>Active warning 3</i> | Code of the 3rd active warning. | - |
| | 0000h...FFFFh | 3rd active warning. | 1 = 1 |
| 04.09 | <i>Active warning 4</i> | Code of the 4th active warning. | - |
| | 0000h...FFFFh | 4th active warning. | 1 = 1 |
| 04.10 | <i>Active warning 5</i> | Code of the 5th active warning. | - |
| | 0000h...FFFFh | 5th active warning. | 1 = 1 |
| 04.11 | <i>Latest fault</i> | Code of the 1st stored (non-active) fault. | - |
| | 0000h...FFFFh | 1st stored fault. | 1 = 1 |
| 04.12 | <i>2nd latest fault</i> | Code of the 2nd stored (non-active) fault. | - |
| | 0000h...FFFFh | 2nd stored fault. | 1 = 1 |
| 04.13 | <i>3rd latest fault</i> | Code of the 3rd stored (non-active) fault. | - |
| | 0000h...FFFFh | 3rd stored fault. | 1 = 1 |
| 04.14 | <i>4th latest fault</i> | Code of the 4th stored (non-active) fault. | - |
| | 0000h...FFFFh | 4th stored fault. | 1 = 1 |
| 04.15 | <i>5th latest fault</i> | Code of the 5th stored (non-active) fault. | - |
| | 0000h...FFFFh | 5th stored fault. | 1 = 1 |
| 04.16 | <i>Latest warning</i> | Code of the 1st stored (non-active) warning. | - |
| | 0000h...FFFFh | 1st stored warning. | 1 = 1 |
| 04.17 | <i>2nd latest warning</i> | Code of the 2nd stored (non-active) warning. | - |
| | 0000h...FFFFh | 2nd stored warning. | 1 = 1 |

110 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------|------------------------------------|---|----------------|
| 04.18 | 3rd latest warning | Code of the 3rd stored (non-active) warning. | - |
| | 0000h...FFFFh | 3rd stored warning. | 1 = 1 |
| 04.19 | 4th latest warning | Code of the 4th stored (non-active) warning. | - |
| | 0000h...FFFFh | 4th stored warning. | 1 = 1 |
| 04.20 | 5th latest warning | Code of the 5th stored (non-active) warning. | - |
| | 0000h...FFFFh | 5th stored warning. | 1 = 1 |
| 04.21 | Fault word 1 | <p>ACS800-compatible fault word 1.</p> <p>The bit assignments of this word correspond to FAULT WORD 1 in the ACS800. Parameter 04.120 Fault/Warning word compatibility determines whether the bit assignments are according to the ACS800 Standard or ACS800 System control program.</p> <p>Each bit can indicate several ACS880 events as listed below.</p> <p>This parameter is read-only.</p> | - |

| Bit | ACS800 fault name | | ACS880 events indicated by this bit (see Fault tracing , page 405) |
|-----|---|---|--|
| | (04.120 = ACS800 Standard ctrl program) | (04.120 = ACS800 System ctrl program) | |
| 0 | SHORT CIRC | SHORT CIRC | 2340 |
| 1 | OVERCURRENT | OVERCURRENT | 2310 |
| 2 | DC OVERVOLT | DC OVERVOLT | 3210 |
| 3 | ACS800 TEMP | ACS800 TEMP | 2381 , 4210 , 4290 , 42F1 , 4310 , 4380 |
| 4 | EARTH FAULT | EARTH FAULT | 2330 , 2392 , 3181 |
| 5 | THERMISTOR | MOTOR TEMP M | 4981 |
| 6 | MOTOR TEMP | MOTOR TEMP | 4982 |
| 7 | SYSTEM_FAULT | SYSTEM_FAULT | 6481 , 6487 , 64A1 , 64A2 , 64A3 , 64B1 , 64E1 , 6881 , 6882 , 6883 , 6885 |
| 8 | UNDERLOAD | UNDERLOAD | - |
| 9 | OVERFREQ | OVERFREQ | 7310 |
| 10 | Reserved | MPROT SWITCH | 9081 |
| 11 | Reserved | CH2 COMM LOSS | - |
| 12 | Reserved | SC (INU1) | 2340 (XXYY YY01) |
| 13 | Reserved | SC (INU2) | 2340 (XXYY YY02) |
| 14 | Reserved | SC (INU3) | 2340 (XXYY YY03) |
| 15 | Reserved | SC (INU4) | 2340 (XXYY YY04) |

| | | |
|---------------|---------------------------------|-------|
| 0000h...FFFFh | ACS800-compatible fault word 1. | 1 = 1 |
|---------------|---------------------------------|-------|

| No. | Name/Value | Description | Def/ FbEq16 |
|--------------------------|---|--|---|
| 04.22 | <i>Fault word 2</i> | <p>ACS800-compatible fault word 2.</p> <p>The bit assignments of this word correspond to FAULT WORD 2 in the ACS800. Parameter 04.120 Fault/Warning word compatibility determines whether the bit assignments are according to the ACS800 Standard or ACS800 System control program.</p> <p>Each may indicate several ACS880 events as listed below.</p> <p>This parameter is read-only.</p> | - |
| ACS800 fault name | | | |
| Bit | (04.120 = ACS800 Standard ctrl program) | (04.120 = ACS800 System ctrl program) | ACS880 events indicated by this bit (see Fault tracing , page 405) |
| 0 | SUPPLY PHASE | SUPPLY PHASE | 3130 |
| 1 | NO MOT DATA | NO MOTOR DATA | - |
| 2 | DC UNDERVOLT | DC UNDERVOLT | 3220 |
| 3 | Reserved | CABLE TEMP | 4000 |
| 4 | RUN ENABLE | RUN DISABLE | AFEB |
| 5 | ENCODER ERR | ENCODER ERR | 7301, 7380, 7381, 73A0, 73A1 |
| 6 | I/O COMM | IO COMM ERR | 7080, 7082 |
| 7 | CTRL B TEMP | CTRL B TEMP | - |
| 8 | EXTERNAL FLT | SELECTABLE | 9082 |
| 9 | OVER SWFREQ | OVER SWFREQ | - |
| 10 | AI < MIN FUNC | AI<MIN FUNC | 80A0 |
| 11 | PPCC LINK | PPCC LINK | 5681, 5682, 5690, 5691, 5692, 5693, 5694 |
| 12 | COMM MODULE | COMM MODULE | 6681, 7510, 7520 |
| 13 | PANEL LOSS | PANEL LOSS | 7081 |
| 14 | MOTOR STALL | MOTOR STALL | 7121 |
| 15 | MOTOR PHASE | MOTOR PHASE | 3381 |
| 0000h...FFFFh | | ACS800-compatible fault word 2. | 1 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|--|---|-----|-------------------|--|--|---|---------------------------------------|---|---------------|--------------|----------------------|---|----------|---------|---|---|------------|--------------|----------------------|---|------------|------------|----------------------|---|-------------|-------------|---|---|-------------|-------------|---|---|------------|-------------|---|---|----------|------------|---|---|----------|-----------|---|---|----------|----------------|---|----|----------|---------------|--|----|----------|---------------|----------------------|----|-------------|--------------|----------------------|----|----------|-------------|---|----|-------------|-------------|----------------------|----|----------|--------------|----------------------|
| 04.31 | <i>Warning word 1</i> | <p>ACS800-compatible warning (alarm) word 1.</p> <p>The bit assignments of this word correspond to ALARM WORD 1 in the ACS800. Parameter 04.120 Fault/Warning word compatibility determines whether the assignments are according to the ACS800 Standard or ACS800 System control program.</p> <p>Each may indicate several ACS880 warnings as listed below.</p> <p>This parameter is read-only.</p> | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th rowspan="2">Bit</th> <th colspan="2">ACS800 alarm name</th> <th rowspan="2">ACS880 events indicated by this bit (see <i>Fault tracing</i>, page 405)</th> </tr> <tr> <th>(04.120 = ACS800 Standard ctrl program)</th> <th>(04.120 = ACS800 System ctrl program)</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>START INHIBIT</td> <td>START INHIBI</td> <td>B5A0</td> </tr> <tr> <td>1</td> <td>Reserved</td> <td>EM STOP</td> <td>AFE1, AFE2</td> </tr> <tr> <td>2</td> <td>THERMISTOR</td> <td>MOTOR TEMP M</td> <td>A491</td> </tr> <tr> <td>3</td> <td>MOTOR TEMP</td> <td>MOTOR TEMP</td> <td>A492</td> </tr> <tr> <td>4</td> <td>ACS800 TEMP</td> <td>ACS800 TEMP</td> <td>A2BA, A4A1, A4A9, A4B0, A4B1, A4F6</td> </tr> <tr> <td>5</td> <td>ENCODER ERR</td> <td>ENCODER ERR</td> <td>A797, A7B0, A7B1, A7E1</td> </tr> <tr> <td>6</td> <td>T MEAS ALM</td> <td>T MEAS CIRC</td> <td>A490, A5EA, A782, A8A0</td> </tr> <tr> <td>7</td> <td>Reserved</td> <td>DIGITAL IO</td> <td>-</td> </tr> <tr> <td>8</td> <td>Reserved</td> <td>ANALOG IO</td> <td>-</td> </tr> <tr> <td>9</td> <td>Reserved</td> <td>EXT DIGITAL IO</td> <td>-</td> </tr> <tr> <td>10</td> <td>Reserved</td> <td>EXT ANALOG IO</td> <td>A6E5, A7AA, A7AB</td> </tr> <tr> <td>11</td> <td>Reserved</td> <td>CH2 COMM LOSS</td> <td>A7CE</td> </tr> <tr> <td>12</td> <td>COMM MODULE</td> <td>MPROT SWITCH</td> <td>A981</td> </tr> <tr> <td>13</td> <td>Reserved</td> <td>EM STOP DEC</td> <td>-</td> </tr> <tr> <td>14</td> <td>EARTH FAULT</td> <td>EARTH FAULT</td> <td>A2B3</td> </tr> <tr> <td>15</td> <td>Reserved</td> <td>SAFETY SWITC</td> <td>A983</td> </tr> </tbody> </table> | | | | Bit | ACS800 alarm name | | ACS880 events indicated by this bit (see <i>Fault tracing</i> , page 405) | (04.120 = ACS800 Standard ctrl program) | (04.120 = ACS800 System ctrl program) | 0 | START INHIBIT | START INHIBI | B5A0 | 1 | Reserved | EM STOP | AFE1 , AFE2 | 2 | THERMISTOR | MOTOR TEMP M | A491 | 3 | MOTOR TEMP | MOTOR TEMP | A492 | 4 | ACS800 TEMP | ACS800 TEMP | A2BA , A4A1 , A4A9 , A4B0 , A4B1 , A4F6 | 5 | ENCODER ERR | ENCODER ERR | A797 , A7B0 , A7B1 , A7E1 | 6 | T MEAS ALM | T MEAS CIRC | A490 , A5EA , A782 , A8A0 | 7 | Reserved | DIGITAL IO | - | 8 | Reserved | ANALOG IO | - | 9 | Reserved | EXT DIGITAL IO | - | 10 | Reserved | EXT ANALOG IO | A6E5 , A7AA , A7AB | 11 | Reserved | CH2 COMM LOSS | A7CE | 12 | COMM MODULE | MPROT SWITCH | A981 | 13 | Reserved | EM STOP DEC | - | 14 | EARTH FAULT | EARTH FAULT | A2B3 | 15 | Reserved | SAFETY SWITC | A983 |
| Bit | ACS800 alarm name | | ACS880 events indicated by this bit (see <i>Fault tracing</i> , page 405) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | (04.120 = ACS800 Standard ctrl program) | (04.120 = ACS800 System ctrl program) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | START INHIBIT | START INHIBI | B5A0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Reserved | EM STOP | AFE1 , AFE2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | THERMISTOR | MOTOR TEMP M | A491 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | MOTOR TEMP | MOTOR TEMP | A492 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | ACS800 TEMP | ACS800 TEMP | A2BA , A4A1 , A4A9 , A4B0 , A4B1 , A4F6 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | ENCODER ERR | ENCODER ERR | A797 , A7B0 , A7B1 , A7E1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | T MEAS ALM | T MEAS CIRC | A490 , A5EA , A782 , A8A0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Reserved | DIGITAL IO | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Reserved | ANALOG IO | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Reserved | EXT DIGITAL IO | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Reserved | EXT ANALOG IO | A6E5 , A7AA , A7AB | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | Reserved | CH2 COMM LOSS | A7CE | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | COMM MODULE | MPROT SWITCH | A981 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | Reserved | EM STOP DEC | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | EARTH FAULT | EARTH FAULT | A2B3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | Reserved | SAFETY SWITC | A983 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0000h...FFFFh | ACS800-compatible warning (alarm) word 1. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|--|---|-----|-------------------|-------------|---|---|---|---|------------|---|----------------------|-----|-----------|-----------|-------------|---|----------|--------------|---|---|----------|------------|----------------------|---|---------|--------------|---|---|----------|--------------|----------------------|---|----------|----------|---|---|--------------|--------------|---|---|-------------|--------------|---|---|-------------|-------------|----------------------|----|---------------|-------------|----------------------|----|----------|-------------|--|----|----------|--------------|---|----|------------|------------|----------------------|----|----------|--------------|----------------------|----|----------|-----------|---|
| 04.32 | Warning word 2 | <p>ACS800-compatible warning (alarm) word 2.</p> <p>The bit assignments of this word correspond to ALARM WORD 2 in the ACS800. Parameter 04.120 Fault/Warning word compatibility determines whether the bit assignments are according to the ACS800 Standard or ACS800 System control program.</p> <p>Each may indicate several ACS880 warnings as listed below.</p> <p>This parameter is read-only.</p> | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th rowspan="2">Bit</th> <th colspan="2">ACS800 alarm name</th> <th rowspan="2">ACS880 events indicated by this bit (see Fault tracing, page 405)</th> </tr> <tr> <th>(04.120 = ACS800 Standard ctrl program)</th> <th>(04.120 = ACS800 System ctrl program)</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Reserved</td> <td>MOTOR FAN</td> <td>A781</td> </tr> <tr> <td>1</td> <td>UNDERLOAD</td> <td>UNDERLOAD</td> <td>-</td> </tr> <tr> <td>2</td> <td>Reserved</td> <td>INV OVERLOAD</td> <td>-</td> </tr> <tr> <td>3</td> <td>Reserved</td> <td>CABLE TEMP</td> <td>A480</td> </tr> <tr> <td>4</td> <td>ENCODER</td> <td>ENCODER A<>B</td> <td>-</td> </tr> <tr> <td>5</td> <td>Reserved</td> <td>FAN OVERTEMP</td> <td>A984</td> </tr> <tr> <td>6</td> <td>Reserved</td> <td>Reserved</td> <td>-</td> </tr> <tr> <td>7</td> <td>POWFAIL FILE</td> <td>POWFAIL FILE</td> <td>-</td> </tr> <tr> <td>8</td> <td>ALM (OS_17)</td> <td>POWDOWN FILE</td> <td>-</td> </tr> <tr> <td>9</td> <td>MOTOR STALL</td> <td>MOTOR STALL</td> <td>A780</td> </tr> <tr> <td>10</td> <td>AI < MIN FUNC</td> <td>AI<MIN FUNC</td> <td>A8A0</td> </tr> <tr> <td>11</td> <td>Reserved</td> <td>COMM MODULE</td> <td>A6D1, A6D2, A7C1, A7C2, A7CE</td> </tr> <tr> <td>12</td> <td>Reserved</td> <td>BATT FAILURE</td> <td>-</td> </tr> <tr> <td>13</td> <td>PANEL LOSS</td> <td>PANEL LOSS</td> <td>A7EE</td> </tr> <tr> <td>14</td> <td>Reserved</td> <td>DC UNDERVOLT</td> <td>A3A2</td> </tr> <tr> <td>15</td> <td>Reserved</td> <td>RESTARTED</td> <td>-</td> </tr> </tbody> </table> | | | | Bit | ACS800 alarm name | | ACS880 events indicated by this bit (see Fault tracing , page 405) | (04.120 = ACS800 Standard ctrl program) | (04.120 = ACS800 System ctrl program) | 0 | Reserved | MOTOR FAN | A781 | 1 | UNDERLOAD | UNDERLOAD | - | 2 | Reserved | INV OVERLOAD | - | 3 | Reserved | CABLE TEMP | A480 | 4 | ENCODER | ENCODER A<>B | - | 5 | Reserved | FAN OVERTEMP | A984 | 6 | Reserved | Reserved | - | 7 | POWFAIL FILE | POWFAIL FILE | - | 8 | ALM (OS_17) | POWDOWN FILE | - | 9 | MOTOR STALL | MOTOR STALL | A780 | 10 | AI < MIN FUNC | AI<MIN FUNC | A8A0 | 11 | Reserved | COMM MODULE | A6D1, A6D2, A7C1, A7C2, A7CE | 12 | Reserved | BATT FAILURE | - | 13 | PANEL LOSS | PANEL LOSS | A7EE | 14 | Reserved | DC UNDERVOLT | A3A2 | 15 | Reserved | RESTARTED | - |
| Bit | ACS800 alarm name | | ACS880 events indicated by this bit (see Fault tracing , page 405) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | (04.120 = ACS800 Standard ctrl program) | (04.120 = ACS800 System ctrl program) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Reserved | MOTOR FAN | A781 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | UNDERLOAD | UNDERLOAD | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Reserved | INV OVERLOAD | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Reserved | CABLE TEMP | A480 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | ENCODER | ENCODER A<>B | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Reserved | FAN OVERTEMP | A984 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Reserved | Reserved | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | POWFAIL FILE | POWFAIL FILE | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | ALM (OS_17) | POWDOWN FILE | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | MOTOR STALL | MOTOR STALL | A780 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | AI < MIN FUNC | AI<MIN FUNC | A8A0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | Reserved | COMM MODULE | A6D1, A6D2, A7C1, A7C2, A7CE | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | Reserved | BATT FAILURE | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | PANEL LOSS | PANEL LOSS | A7EE | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | Reserved | DC UNDERVOLT | A3A2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | Reserved | RESTARTED | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | ACS800-compatible warning (alarm) word 2. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 04.40 | Event word 1 | <p>User-defined event word. This word collects the status of the events (warnings, faults or pure events) selected by parameters 04.41...04.72.</p> <p>For each event, an auxiliary code can optionally be specified for filtering.</p> <p>This parameter is read-only.</p> | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>User bit 0</td> <td>1 = Event selected by parameters 04.41 (and 04.42) is active</td> </tr> <tr> <td>1</td> <td>User bit 1</td> <td>1 = Event selected by parameters 04.43 (and 04.44) is active</td> </tr> <tr> <td>...</td> <td>...</td> <td>...</td> </tr> <tr> <td>15</td> <td>User bit 15</td> <td>1 = Event selected by parameters 04.71 (and 04.72) is active</td> </tr> </tbody> </table> | | | | Bit | Name | Description | 0 | User bit 0 | 1 = Event selected by parameters 04.41 (and 04.42) is active | 1 | User bit 1 | 1 = Event selected by parameters 04.43 (and 04.44) is active | ... | ... | ... | 15 | User bit 15 | 1 = Event selected by parameters 04.71 (and 04.72) is active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | User bit 0 | 1 = Event selected by parameters 04.41 (and 04.42) is active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | User bit 1 | 1 = Event selected by parameters 04.43 (and 04.44) is active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ... | ... | ... | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | User bit 15 | 1 = Event selected by parameters 04.71 (and 04.72) is active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | User-defined event word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|--------|---|---|----------------|
| 04.41 | <i>Event word 1 bit 0 code</i> | Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 0 of 04.40 Event word 1 . The event codes are listed in chapter Fault tracing (page 405). | 0000h |
| | 0000h...FFFFh | Code of event. | 1 = 1 |
| 04.42 | <i>Event word 1 bit 0 aux code</i> | Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code. | 0000 0000h |
| | 0000 0000h ... FFFF FFFFh | Code of warning, fault or pure event. | 1 = 1 |
| 04.43 | <i>Event word 1 bit 1 code</i> | Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 1 of 04.40 Event word 1 . The event codes are listed in chapter Fault tracing (page 405). | 0000h |
| | 0000h...FFFFh | Code of event. | 1 = 1 |
| 04.44 | <i>Event word 1 bit 1 aux code</i> | Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code. | 0000 0000h |
| | 0000 0000h ... FFFF FFFFh | Code of warning, fault or pure event. | 1 = 1 |
| ... | ... | ... | ... |
| 04.71 | <i>Event word 1 bit 15 code</i> | Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 15 of 04.40 Event word 1 . The event codes are listed in chapter Fault tracing (page 405). | 0000h |
| | 0000h...FFFFh | Code of event. | 1 = 1 |
| 04.72 | <i>Event word 1 bit 15 aux code</i> | Specifies an auxiliary code for the event selected by the previous parameter. The selected event is indicated by the event word only if its auxiliary code matches the value of this parameter. With a value of 0000 0000h, the event word will indicate the event regardless of the auxiliary code. | 0000 0000h |
| | 0000 0000h ... FFFF FFFFh | Code of warning, fault or pure event. | 1 = 1 |
| 04.120 | <i>Fault/Warning word compatibility</i> | Selects whether the bit assignments of parameters 04.21...04.32 correspond to the ACS800 Standard control program or the ACS800 System control program. | <i>FALSE</i> |
| | ACS800 Standard ctrl program | The bit assignments of parameters 04.21...04.32 correspond to the ACS800 Standard control program as follows: 04.21 Fault word 1 : 03.05 FAULT WORD 1 04.22 Fault word 2 : 03.06 FAULT WORD 2 04.31 Warning word 1 : 03.08 ALARM WORD 1 04.32 Warning word 2 : 03.09 ALARM WORD 2 | 0 |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | |
|-----------------------|--|--|----------------|------|-------|--------|----------|--|----|-------------|--|----|---------------------|---|---------|----------|--|--|
| | ACS800 System ctrl program | The bit assignments of parameters 04.21...04.32 correspond to the ACS800 System control program as follows: 04.21 Fault word 1 : 09.01 FAULT WORD 1 04.22 Fault word 2 : 09.02 FAULT WORD 2 04.31 Warning word 1 : 09.04 ALARM WORD 1 04.32 Warning word 2 : 09.05 ALARM WORD 2 | 1 | | | | | | | | | | | | | | | |
| 05 Diagnostics | | Various run-time-type counters and measurements related to drive maintenance. All parameters in this group are read-only unless otherwise noted. | | | | | | | | | | | | | | | | |
| 05.01 | On-time counter | On-time counter. The counter runs when the drive is powered. | - | | | | | | | | | | | | | | | |
| | 0...65535 d | On-time counter. | 1 = 1 d | | | | | | | | | | | | | | | |
| 05.02 | Run-time counter | Motor run-time counter. The counter runs when the inverter modulates. | - | | | | | | | | | | | | | | | |
| | 0...65535 d | Motor run-time counter. | 1 = 1 d | | | | | | | | | | | | | | | |
| 05.04 | Fan on-time counter | Running time of the drive cooling fan. Can be reset from the control panel by keeping Reset depressed for over 3 seconds. | - | | | | | | | | | | | | | | | |
| | 0...65535 d | Cooling fan run-time counter. | 1 = 1 d | | | | | | | | | | | | | | | |
| 05.11 | Inverter temperature | Estimated drive temperature in percent of fault limit. The fault limit varies according to the type of the drive. 0.0% = 0 °C (32 °F) 100.0% = Fault limit | - | | | | | | | | | | | | | | | |
| | -40.0...160.0% | Drive temperature in percent. | 1 = 1% | | | | | | | | | | | | | | | |
| 05.22 | Diagnostic word 3 | Diagnostic word 3. | - | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0...10</td> <td>Reserved</td> <td></td> </tr> <tr> <td>11</td> <td>Fan command</td> <td>1 = Drive fan is rotating above idle speed</td> </tr> <tr> <td>12</td> <td>Fan service counter</td> <td>1 = Drive fan service counter has reached its limit</td> </tr> <tr> <td>13...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | Bit | Name | Value | 0...10 | Reserved | | 11 | Fan command | 1 = Drive fan is rotating above idle speed | 12 | Fan service counter | 1 = Drive fan service counter has reached its limit | 13...15 | Reserved | | |
| Bit | Name | Value | | | | | | | | | | | | | | | | |
| 0...10 | Reserved | | | | | | | | | | | | | | | | | |
| 11 | Fan command | 1 = Drive fan is rotating above idle speed | | | | | | | | | | | | | | | | |
| 12 | Fan service counter | 1 = Drive fan service counter has reached its limit | | | | | | | | | | | | | | | | |
| 13...15 | Reserved | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Diagnostic word 3. | 1 = 1 | | | | | | | | | | | | | | | |
| 05.41 | Main fan service counter | Displays the age of the main cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (A8C0 Fan service counter) is generated. Can be reset from the control panel by keeping Reset depressed for over 3 seconds. | - | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|------------------------------------|---------------------------------------|---|----------------|
| | 0...150% | Main cooling fan age. | 1 = 1% |
| 05.42 | <i>Aux. fan service counter</i> | Displays the age of the auxiliary cooling fan as a percentage of its estimated lifetime. The estimate is based on the duty, operating conditions and other operating parameters of the fan. When the counter reaches 100%, a warning (<i>A8C0 Fan service counter</i>) is generated. Can be reset from the control panel by keeping Reset depressed for over 3 seconds. | - |
| | 0...150% | Auxiliary cooling fan age. | 1 = 1% |
| | 0000h...FFFFh | Main control word. | 1 = 1 |
| 06 Control and status words | | Drive control and status words. | |
| 06.01 | <i>Main control word</i> | The main control word of the drive. This parameter shows the control signals as received from the selected sources (such as digital inputs, the fieldbus interfaces and the application program). The bit assignments of the word are as described on page 467. The related status word and state diagram are presented on pages 468 respectively. Note: Bits 12...15 can be used to carry additional control data, and used as a signal source by any binary-source selector parameter. This parameter is read-only. | - |
| | 0000h...FFFFh | Main control word. | 1 = 1 |
| 06.02 | <i>Application control word</i> | The drive control word received from the application program (if any). The bit assignments are described on page 467. This parameter is read-only. | - |
| | 0000h...FFFFh | Application program control word. | 1 = 1 |
| 06.03 | <i>FBA A transparent control word</i> | The unaltered control word received from the PLC through fieldbus adapter A. This parameter is read-only. | - |
| | 00000000h ...FFFFFFFFh | Control word received through fieldbus adapter A. | - |
| 06.04 | <i>FBA B transparent control word</i> | The unaltered control word received from the PLC through fieldbus adapter B. This parameter is read-only. | - |
| | 00000000h ...FFFFFFFFh | Control word received through fieldbus adapter B. | 1 = 1 |
| 06.05 | <i>EFB transparent control word</i> | The unaltered control word received from the PLC through the embedded fieldbus interface. This parameter is read-only. | - |
| | 00000000h ... FFFFFFFFh | Control word received through the embedded fieldbus interface. | 1 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------|----------------------------|--|----------------|------|-------------|---|---------|---|---|-----------|--|---|------------|---------------------------------|---|----------------|---|---|---------------------|--|---|---------|----------------------------|---|------------|--|---|----------|---|---|---------------|-------------------------------|---|--------------|--|----|-------------|----------------------------------|----|-------------|----------------------------------|----|----------|--|----|---------------|---------------------|---------|----------|--|--|
| 06.11 | <i>Main status word</i> | Main status word of the drive. The bit assignments are described on page 468. The related control word and state diagram are presented on pages 467 and 470 respectively. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Main status word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 06.16 | <i>Drive status word 1</i> | Drive status word 1. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Enabled</td> <td>1 = Both run enable (see par. 20.12) and start enable (20.19) signals are present. Note: This bit is not affected by the presence of a fault.</td> </tr> <tr> <td>1</td> <td>Inhibited</td> <td>1 = Start inhibited. See parameters 06.18 for the source of the inhibiting signal.</td> </tr> <tr> <td>2</td> <td>DC charged</td> <td>1 = DC circuit has been charged</td> </tr> <tr> <td>3</td> <td>Ready to start</td> <td>1 = Drive is ready to receive a start command</td> </tr> <tr> <td>4</td> <td>Following reference</td> <td>1 = Drive is ready to follow given reference</td> </tr> <tr> <td>5</td> <td>Started</td> <td>1 = Drive has been started</td> </tr> <tr> <td>6</td> <td>Modulating</td> <td>1 = Drive is modulating (output stage is being controlled)</td> </tr> <tr> <td>7</td> <td>Limiting</td> <td>1 = Any operating limit (speed, torque, etc.) is active</td> </tr> <tr> <td>8</td> <td>Local control</td> <td>1 = Drive is in local control</td> </tr> <tr> <td>9</td> <td>Network ctrl</td> <td>1 = Drive is in <i>network control</i> (see page 14)</td> </tr> <tr> <td>10</td> <td>Ext1 active</td> <td>1 = Control location EXT1 active</td> </tr> <tr> <td>11</td> <td>Ext2 active</td> <td>1 = Control location EXT2 active</td> </tr> <tr> <td>12</td> <td>Reserved</td> <td></td> </tr> <tr> <td>13</td> <td>Start request</td> <td>1 = Start requested</td> </tr> <tr> <td>14...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | Bit | Name | Description | 0 | Enabled | 1 = Both run enable (see par. 20.12) and start enable (20.19) signals are present. Note: This bit is not affected by the presence of a fault. | 1 | Inhibited | 1 = Start inhibited. See parameters 06.18 for the source of the inhibiting signal. | 2 | DC charged | 1 = DC circuit has been charged | 3 | Ready to start | 1 = Drive is ready to receive a start command | 4 | Following reference | 1 = Drive is ready to follow given reference | 5 | Started | 1 = Drive has been started | 6 | Modulating | 1 = Drive is modulating (output stage is being controlled) | 7 | Limiting | 1 = Any operating limit (speed, torque, etc.) is active | 8 | Local control | 1 = Drive is in local control | 9 | Network ctrl | 1 = Drive is in <i>network control</i> (see page 14) | 10 | Ext1 active | 1 = Control location EXT1 active | 11 | Ext2 active | 1 = Control location EXT2 active | 12 | Reserved | | 13 | Start request | 1 = Start requested | 14...15 | Reserved | | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Enabled | 1 = Both run enable (see par. 20.12) and start enable (20.19) signals are present. Note: This bit is not affected by the presence of a fault. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Inhibited | 1 = Start inhibited. See parameters 06.18 for the source of the inhibiting signal. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | DC charged | 1 = DC circuit has been charged | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Ready to start | 1 = Drive is ready to receive a start command | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Following reference | 1 = Drive is ready to follow given reference | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Started | 1 = Drive has been started | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Modulating | 1 = Drive is modulating (output stage is being controlled) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Limiting | 1 = Any operating limit (speed, torque, etc.) is active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Local control | 1 = Drive is in local control | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Network ctrl | 1 = Drive is in <i>network control</i> (see page 14) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Ext1 active | 1 = Control location EXT1 active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | Ext2 active | 1 = Control location EXT2 active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | Start request | 1 = Start requested | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Drive status word 1. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|----------------------------|---|----------------|-----|------|-------------|---|-------------------------|--|---|------------|-----------------------------------|---|----------------|--------------------------------|---|---------------|-------------------------------|---|---------------|-------------------------------|---|-----------------------|---|---|-------------------|---|---|-------------------|---------------------------|---|-----------------------|---|---|----------------|---------------------------------|----|-------------|---|----|-----------------------|---|----|-------------|---|----|----------|--|----|-------------|---|----|----------|--|
| 06.17 | <i>Drive status word 2</i> | Drive status word 2. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Identification run done</td> <td>1 = Motor identification (ID) run has been performed</td> </tr> <tr> <td>1</td> <td>Magnetized</td> <td>1 = The motor has been magnetized</td> </tr> <tr> <td>2</td> <td>Torque control</td> <td>1 = Torque control mode active</td> </tr> <tr> <td>3</td> <td>Speed control</td> <td>1 = Speed control mode active</td> </tr> <tr> <td>4</td> <td>Power control</td> <td>1 = Power control mode active</td> </tr> <tr> <td>5</td> <td>Safe reference active</td> <td>1 = A "safe" reference is being applied by functions such as parameters 49.05 and 50.02</td> </tr> <tr> <td>6</td> <td>Last speed active</td> <td>1 = A "last speed" reference is being applied by functions such as parameters 49.05 and 50.02</td> </tr> <tr> <td>7</td> <td>Loss of reference</td> <td>1 = Reference signal lost</td> </tr> <tr> <td>8</td> <td>Emergency stop failed</td> <td>1 = Emergency stop failed (see parameters 31.32 and 31.33)</td> </tr> <tr> <td>9</td> <td>Jogging active</td> <td>1 = Jogging enable signal is on</td> </tr> <tr> <td>10</td> <td>Above limit</td> <td>1 = Actual speed, frequency or torque equals or exceeds limit (defined by parameters 46.31...46.33). Valid in both directions of rotation.</td> </tr> <tr> <td>11</td> <td>Emergency stop active</td> <td>1 = An emergency stop command signal is active, or the drive is stopping after receiving an emergency stop command.</td> </tr> <tr> <td>12</td> <td>Reduced run</td> <td>1 = Reduced run active (see section See parameter group 47 Data storage (page 281), on page 92)</td> </tr> <tr> <td>13</td> <td>Reserved</td> <td></td> </tr> <tr> <td>14</td> <td>Stop failed</td> <td>1 = Stopping failed (see parameter 31.37 and 31.38).</td> </tr> <tr> <td>15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | | | | Bit | Name | Description | 0 | Identification run done | 1 = Motor identification (ID) run has been performed | 1 | Magnetized | 1 = The motor has been magnetized | 2 | Torque control | 1 = Torque control mode active | 3 | Speed control | 1 = Speed control mode active | 4 | Power control | 1 = Power control mode active | 5 | Safe reference active | 1 = A "safe" reference is being applied by functions such as parameters 49.05 and 50.02 | 6 | Last speed active | 1 = A "last speed" reference is being applied by functions such as parameters 49.05 and 50.02 | 7 | Loss of reference | 1 = Reference signal lost | 8 | Emergency stop failed | 1 = Emergency stop failed (see parameters 31.32 and 31.33) | 9 | Jogging active | 1 = Jogging enable signal is on | 10 | Above limit | 1 = Actual speed, frequency or torque equals or exceeds limit (defined by parameters 46.31 ... 46.33). Valid in both directions of rotation. | 11 | Emergency stop active | 1 = An emergency stop command signal is active, or the drive is stopping after receiving an emergency stop command. | 12 | Reduced run | 1 = Reduced run active (see section See parameter group 47 Data storage (page 281) , on page 92) | 13 | Reserved | | 14 | Stop failed | 1 = Stopping failed (see parameter 31.37 and 31.38). | 15 | Reserved | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Identification run done | 1 = Motor identification (ID) run has been performed | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Magnetized | 1 = The motor has been magnetized | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Torque control | 1 = Torque control mode active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Speed control | 1 = Speed control mode active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Power control | 1 = Power control mode active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Safe reference active | 1 = A "safe" reference is being applied by functions such as parameters 49.05 and 50.02 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Last speed active | 1 = A "last speed" reference is being applied by functions such as parameters 49.05 and 50.02 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Loss of reference | 1 = Reference signal lost | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Emergency stop failed | 1 = Emergency stop failed (see parameters 31.32 and 31.33) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Jogging active | 1 = Jogging enable signal is on | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Above limit | 1 = Actual speed, frequency or torque equals or exceeds limit (defined by parameters 46.31 ... 46.33). Valid in both directions of rotation. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | Emergency stop active | 1 = An emergency stop command signal is active, or the drive is stopping after receiving an emergency stop command. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | Reduced run | 1 = Reduced run active (see section See parameter group 47 Data storage (page 281) , on page 92) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | Stop failed | 1 = Stopping failed (see parameter 31.37 and 31.38). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0000h...FFFFh | | Drive status word 2. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------|----------------------------------|---|----------------|------|-------------|---|---------------|---|---|-----------------------|------------------------------------|---|-------------|--|---|-------------|------------------------------|---|-------------------|---------------------------------|---|-----------------|-------------------------------|---|-------------|---|---|-----|----------------------------|---|---------------------------|--|---|--------------|---|----|------------------|--|----|---------|---------------------------------------|----|---------|---------------------------------------|----|---------|---------------------------------------|----|--------------------|--|----|----------------|---|--|
| 06.18 | <i>Start inhibit status word</i> | <p>Start inhibit status word. This word specifies the source of the inhibiting signal that is preventing the drive from starting.</p> <p>The conditions marked with an asterisk (*) only require that the start command is cycled. In all other instances, the inhibiting condition must be removed first.</p> <p>See also parameter <i>06.16 Drive status word 1</i>, bit 1.</p> <p>This parameter is read-only.</p> | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Not ready run</td> <td>1 = DC voltage is missing or drive has not been parametrized correctly. Check the parameters in groups 95 and 99.</td> </tr> <tr> <td>1</td> <td>Ctrl location changed</td> <td>* 1 = Control location has changed</td> </tr> <tr> <td>2</td> <td>SSW inhibit</td> <td>1 = Control program is keeping itself in inhibited state</td> </tr> <tr> <td>3</td> <td>Fault reset</td> <td>* 1 = A fault has been reset</td> </tr> <tr> <td>4</td> <td>Lost start enable</td> <td>1 = Start enable signal missing</td> </tr> <tr> <td>5</td> <td>Lost run enable</td> <td>1 = Run enable signal missing</td> </tr> <tr> <td>6</td> <td>FSO inhibit</td> <td>1 = Operation prevented by FSO-xx safety functions module</td> </tr> <tr> <td>7</td> <td>STO</td> <td>1 = Safe torque off active</td> </tr> <tr> <td>8</td> <td>Current calibration ended</td> <td>* 1 = Current calibration routine has finished</td> </tr> <tr> <td>9</td> <td>ID run ended</td> <td>* 1 = Motor identification run has finished</td> </tr> <tr> <td>10</td> <td>Auto phase ended</td> <td>* 1 = Autophasing routine has finished</td> </tr> <tr> <td>11</td> <td>Em Off1</td> <td>1 = Emergency stop signal (mode off1)</td> </tr> <tr> <td>12</td> <td>Em Off2</td> <td>1 = Emergency stop signal (mode off2)</td> </tr> <tr> <td>13</td> <td>Em Off3</td> <td>1 = Emergency stop signal (mode off3)</td> </tr> <tr> <td>14</td> <td>Auto reset inhibit</td> <td>1 = The autoreset function is inhibiting operation</td> </tr> <tr> <td>15</td> <td>Jogging active</td> <td>1 = The jogging enable signal is inhibiting operation</td> </tr> </tbody> </table> | Bit | Name | Description | 0 | Not ready run | 1 = DC voltage is missing or drive has not been parametrized correctly. Check the parameters in groups 95 and 99. | 1 | Ctrl location changed | * 1 = Control location has changed | 2 | SSW inhibit | 1 = Control program is keeping itself in inhibited state | 3 | Fault reset | * 1 = A fault has been reset | 4 | Lost start enable | 1 = Start enable signal missing | 5 | Lost run enable | 1 = Run enable signal missing | 6 | FSO inhibit | 1 = Operation prevented by FSO-xx safety functions module | 7 | STO | 1 = Safe torque off active | 8 | Current calibration ended | * 1 = Current calibration routine has finished | 9 | ID run ended | * 1 = Motor identification run has finished | 10 | Auto phase ended | * 1 = Autophasing routine has finished | 11 | Em Off1 | 1 = Emergency stop signal (mode off1) | 12 | Em Off2 | 1 = Emergency stop signal (mode off2) | 13 | Em Off3 | 1 = Emergency stop signal (mode off3) | 14 | Auto reset inhibit | 1 = The autoreset function is inhibiting operation | 15 | Jogging active | 1 = The jogging enable signal is inhibiting operation | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Not ready run | 1 = DC voltage is missing or drive has not been parametrized correctly. Check the parameters in groups 95 and 99. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Ctrl location changed | * 1 = Control location has changed | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | SSW inhibit | 1 = Control program is keeping itself in inhibited state | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Fault reset | * 1 = A fault has been reset | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Lost start enable | 1 = Start enable signal missing | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Lost run enable | 1 = Run enable signal missing | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | FSO inhibit | 1 = Operation prevented by FSO-xx safety functions module | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | STO | 1 = Safe torque off active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Current calibration ended | * 1 = Current calibration routine has finished | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | ID run ended | * 1 = Motor identification run has finished | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Auto phase ended | * 1 = Autophasing routine has finished | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | Em Off1 | 1 = Emergency stop signal (mode off1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | Em Off2 | 1 = Emergency stop signal (mode off2) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | Em Off3 | 1 = Emergency stop signal (mode off3) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | Auto reset inhibit | 1 = The autoreset function is inhibiting operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | Jogging active | 1 = The jogging enable signal is inhibiting operation | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Start inhibit status word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---------|----------------------------------|---|-----------------------|------|-------------|---|------------|------------------------------------|---|---------|---|---|---------|---|---|---------------|--|---|-------------------------|--|---|--------------------|---|---|--------------------|---|---|----------------------------|--|---|-----------------------------|---|---|-----------------------------|---|---------|----------|--|--|
| 06.19 | <i>Speed control status word</i> | Speed control status word. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Zero speed</td> <td>1 = Drive is running at zero speed</td> </tr> <tr> <td>1</td> <td>Forward</td> <td>1 = Drive is running in forward direction above zero speed limit (par. 21.06)</td> </tr> <tr> <td>2</td> <td>Reverse</td> <td>1 = Drive is running in reverse direction above zero speed limit (par. 21.06)</td> </tr> <tr> <td>3</td> <td>Out of window</td> <td>1 = Speed error window control active (see par. 24.41)</td> </tr> <tr> <td>4</td> <td>Internal speed feedback</td> <td>1 = Estimated speed feedback used in motor control, ie. estimated speed is selected by par. 90.41 or 90.46, or selected encoder has faulted (par. 90.45) 0 = Encoder 1 or 2 is used for speed feedback.</td> </tr> <tr> <td>5</td> <td>Encoder 1 feedback</td> <td>1 = Encoder 1 used for speed feedback in motor control 0 = Encoder 1 faulted or not selected as source of speed feedback (see par. 90.41 and 90.46).</td> </tr> <tr> <td>6</td> <td>Encoder 2 feedback</td> <td>1 = Encoder 2 used for speed feedback in motor control 0 = Encoder 2 faulted or not selected as source of speed feedback (see par. 90.41 and 90.46).</td> </tr> <tr> <td>7</td> <td>Any constant speed request</td> <td>1 = A constant speed or frequency has been selected; see par. 06.20.</td> </tr> <tr> <td>8</td> <td>Follower speed corr min lim</td> <td>1 = Minimum limit of speed correction (in a speed-controlled follower) has been reached (see par. 23.39...23.41).</td> </tr> <tr> <td>9</td> <td>Follower speed corr max lim</td> <td>1 = Maximum limit of speed correction (in a speed-controlled follower) has been reached (see par. 23.39...23.41).</td> </tr> <tr> <td>10...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | Bit | Name | Description | 0 | Zero speed | 1 = Drive is running at zero speed | 1 | Forward | 1 = Drive is running in forward direction above zero speed limit (par. 21.06) | 2 | Reverse | 1 = Drive is running in reverse direction above zero speed limit (par. 21.06) | 3 | Out of window | 1 = Speed error window control active (see par. 24.41) | 4 | Internal speed feedback | 1 = Estimated speed feedback used in motor control, ie. estimated speed is selected by par. 90.41 or 90.46, or selected encoder has faulted (par. 90.45) 0 = Encoder 1 or 2 is used for speed feedback. | 5 | Encoder 1 feedback | 1 = Encoder 1 used for speed feedback in motor control 0 = Encoder 1 faulted or not selected as source of speed feedback (see par. 90.41 and 90.46). | 6 | Encoder 2 feedback | 1 = Encoder 2 used for speed feedback in motor control 0 = Encoder 2 faulted or not selected as source of speed feedback (see par. 90.41 and 90.46). | 7 | Any constant speed request | 1 = A constant speed or frequency has been selected; see par. 06.20. | 8 | Follower speed corr min lim | 1 = Minimum limit of speed correction (in a speed-controlled follower) has been reached (see par. 23.39...23.41). | 9 | Follower speed corr max lim | 1 = Maximum limit of speed correction (in a speed-controlled follower) has been reached (see par. 23.39...23.41). | 10...15 | Reserved | | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Zero speed | 1 = Drive is running at zero speed | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Forward | 1 = Drive is running in forward direction above zero speed limit (par. 21.06) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Reverse | 1 = Drive is running in reverse direction above zero speed limit (par. 21.06) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Out of window | 1 = Speed error window control active (see par. 24.41) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Internal speed feedback | 1 = Estimated speed feedback used in motor control, ie. estimated speed is selected by par. 90.41 or 90.46, or selected encoder has faulted (par. 90.45) 0 = Encoder 1 or 2 is used for speed feedback. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Encoder 1 feedback | 1 = Encoder 1 used for speed feedback in motor control 0 = Encoder 1 faulted or not selected as source of speed feedback (see par. 90.41 and 90.46). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Encoder 2 feedback | 1 = Encoder 2 used for speed feedback in motor control 0 = Encoder 2 faulted or not selected as source of speed feedback (see par. 90.41 and 90.46). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Any constant speed request | 1 = A constant speed or frequency has been selected; see par. 06.20. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Follower speed corr min lim | 1 = Minimum limit of speed correction (in a speed-controlled follower) has been reached (see par. 23.39...23.41). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Follower speed corr max lim | 1 = Maximum limit of speed correction (in a speed-controlled follower) has been reached (see par. 23.39...23.41). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Speed control status word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 06.29 | <i>MSW bit 10 sel</i> | Selects a binary source whose status is transmitted as bit 10 of 06.11 Main status word. | <i>Above limit</i> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | FALSE | 0. | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | True | 1. | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Above limit | Bit 10 of 06.17 Drive status word 2 (see page 118). | 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 06.30 | <i>MSW bit 11 sel</i> | Selects a binary source whose status is transmitted as bit 11 of 06.11 Main status word. | <i>Ext ctrl loc</i> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | FALSE | 0. | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | True | 1. | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Ext ctrl loc | Bit 11 of 06.01 Main control word (see page 117). | 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 06.31 | <i>MSW bit 12 sel</i> | Selects a binary source whose status is transmitted as bit 12 of 06.11 Main status word. | <i>Ext run enable</i> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | FALSE | 0. | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | True | 1. | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | |
|--|-------------------------------------|---|------------------------------|-----|------|-------------|---|-------------------|---|---|-------------------|---|-----|-----|-----|----|--------------------|---|
| | Ext run enable | Inverted bit 5 of <i>06.18 Start inhibit status word</i> (see page 119). | 2 | | | | | | | | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - | | | | | | | | | | | | | | | |
| <i>06.32</i> | <i>MSW bit 13 sel</i> | Selects a binary source whose status is transmitted as bit 13 of <i>06.11 Main status word</i> . | <i>FALSE</i> | | | | | | | | | | | | | | | |
| | FALSE | 0. | 0 | | | | | | | | | | | | | | | |
| | True | 1. | 1 | | | | | | | | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - | | | | | | | | | | | | | | | |
| <i>06.33</i> | <i>MSW bit 14 sel</i> | Selects a binary source whose status is transmitted as bit 14 of <i>06.11 Main status word</i> . | <i>FALSE</i> | | | | | | | | | | | | | | | |
| | FALSE | 0. | 0 | | | | | | | | | | | | | | | |
| | True | 1. | 1 | | | | | | | | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - | | | | | | | | | | | | | | | |
| <i>06.50</i> | <i>User status word 1</i> | User-defined status word. This word shows the status of the binary sources selected by parameters <i>06.60...06.75</i> . This parameter is read-only. | - | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>User status bit 0</td> <td>Status of source selected by parameter <i>06.60</i></td> </tr> <tr> <td>1</td> <td>User status bit 1</td> <td>Status of source selected by parameter <i>06.61</i></td> </tr> <tr> <td>...</td> <td>...</td> <td>...</td> </tr> <tr> <td>15</td> <td>User status bit 15</td> <td>Status of source selected by parameter <i>06.75</i></td> </tr> </tbody> </table> | | | | Bit | Name | Description | 0 | User status bit 0 | Status of source selected by parameter <i>06.60</i> | 1 | User status bit 1 | Status of source selected by parameter <i>06.61</i> | ... | ... | ... | 15 | User status bit 15 | Status of source selected by parameter <i>06.75</i> |
| Bit | Name | Description | | | | | | | | | | | | | | | | |
| 0 | User status bit 0 | Status of source selected by parameter <i>06.60</i> | | | | | | | | | | | | | | | | |
| 1 | User status bit 1 | Status of source selected by parameter <i>06.61</i> | | | | | | | | | | | | | | | | |
| ... | ... | ... | | | | | | | | | | | | | | | | |
| 15 | User status bit 15 | Status of source selected by parameter <i>06.75</i> | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | User-defined status word. | 1 = 1 | | | | | | | | | | | | | | | |
| <i>06.60</i> | <i>User status word 1 bit 0 sel</i> | Selects a binary source whose status is shown as bit 0 of <i>06.50 User status word 1</i> . | <i>FALSE</i> | | | | | | | | | | | | | | | |
| | FALSE | 0. | 0 | | | | | | | | | | | | | | | |
| | True | 1. | 1 | | | | | | | | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - | | | | | | | | | | | | | | | |
| <i>06.61</i> | <i>User status word 1 bit 1 sel</i> | Selects a binary source whose status is shown as bit 1 of <i>06.50 User status word 1</i> . | <i>Out of window</i> | | | | | | | | | | | | | | | |
| | FALSE | 0. | 0 | | | | | | | | | | | | | | | |
| | True | 1. | 1 | | | | | | | | | | | | | | | |
| | Out of window | Bit 3 of <i>06.19 Speed control status word</i> (see page 120). | 2 | | | | | | | | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - | | | | | | | | | | | | | | | |
| <i>06.62</i> | <i>User status word 1 bit 2 sel</i> | Selects a binary source whose status is shown as bit 2 of <i>06.50 User status word 1</i> . | <i>Emergency stop failed</i> | | | | | | | | | | | | | | | |
| | FALSE | 0. | 0 | | | | | | | | | | | | | | | |
| | True | 1. | 1 | | | | | | | | | | | | | | | |
| | Emergency stop failed | Bit 8 of <i>06.17 Drive status word 2</i> (see page 118). | 2 | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------------|---|--------------------------------|
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 06.63 | <i>User status word 1 bit 3 sel</i> | Selects a binary source whose status is shown as bit 3 of 06.50 <i>User status word 1</i> . | <i>Magnetized</i> |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | Magnetized | Bit 1 of 06.17 <i>Drive status word 2</i> (see page 118). | 2 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 06.64 | <i>User status word 1 bit 4 sel</i> | Selects a binary source whose status is shown as bit 4 of 06.50 <i>User status word 1</i> . | <i>Run disable</i> |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | Run disable | Bit 5 of 06.18 <i>Start inhibit status word</i> (see page 119). | 2 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 06.65 | <i>User status word 1 bit 5 sel</i> | Selects a binary source whose status is shown as bit 5 of 06.50 <i>User status word 1</i> . | <i>FALSE</i> |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 06.66 | <i>User status word 1 bit 6 sel</i> | Selects a binary source whose status is shown as bit 6 of 06.50 <i>User status word 1</i> . | <i>FALSE</i> |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 06.67 | <i>User status word 1 bit 7 sel</i> | Selects a binary source whose status is shown as bit 7 of 06.50 <i>User status word 1</i> . | <i>Identification run done</i> |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | Identification run done | Bit 0 of 06.17 <i>Drive status word 2</i> (see page 118). | 2 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 06.68 | <i>User status word 1 bit 8 sel</i> | Selects a binary source whose status is shown as bit 8 of 06.50 <i>User status word 1</i> . | <i>Start inhibition</i> |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | Start inhibition | Bit 7 of 06.18 <i>Start inhibit status word</i> (see page 119). | 2 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------------|--|--------------------------------|
| 06.69 | <i>User status word 1 bit 9 sel</i> | Selects a binary source whose status is shown as bit 9 of <i>06.50 User status word 1</i> . | <i>Limiting</i> |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | Limiting | Bit 7 of <i>06.16 Drive status word 1</i> (see page 117). | 2 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 06.70 | <i>User status word 1 bit 10 sel</i> | Selects a binary source whose status is shown as bit 10 of <i>06.50 User status word 1</i> . | <i>Torque control</i> |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | Torque control | Bit 2 of <i>06.17 Drive status word 2</i> (see page 118). | 2 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 06.71 | <i>User status word 1 bit 11 sel</i> | Selects a binary source whose status is shown as bit 11 of <i>06.50 User status word 1</i> . | <i>Zero speed</i> |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | Zero speed | Bit 0 of <i>06.19 Speed control status word</i> (see page 120). | 2 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 06.72 | <i>User status word 1 bit 12 sel</i> | Selects a binary source whose status is shown as bit 12 of <i>06.50 User status word 1</i> . | <i>Internal speed feedback</i> |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | Internal speed feedback | Bit 4 of <i>06.19 Speed control status word</i> (see page 120). | 2 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 06.73 | <i>User status word 1 bit 13 sel</i> | Selects a binary source whose status is shown as bit 13 of <i>06.50 User status word 1</i> . | <i>FALSE</i> |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 06.74 | <i>User status word 1 bit 14 sel</i> | Selects a binary source whose status is shown as bit 14 of <i>06.50 User status word 1</i> . | <i>FALSE</i> |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 06.75 | <i>User status word 1 bit 15 sel</i> | Selects a binary source whose status is shown as bit 15 of <i>06.50 User status word 1</i> . | <i>False</i> |
| | False | 0. | 0 |
| | True | 1. | 1 |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | |
|-----------------------|--------------------------------|--|----------------|------|-------------|---|---------------------------|-------------------|---|---------------------------|-------------------|-----|-----|-----|----|----------------------------|-------------------|--|
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - | | | | | | | | | | | | | | | |
| 06.100 | <i>User control word 1</i> | User-defined control word 1. This parameter is read-only. | - | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>User control word 1 bit 0</td> <td>User-defined bit.</td> </tr> <tr> <td>1</td> <td>User control word 1 bit 1</td> <td>User-defined bit.</td> </tr> <tr> <td>...</td> <td>...</td> <td>...</td> </tr> <tr> <td>15</td> <td>User control word 1 bit 15</td> <td>User-defined bit.</td> </tr> </tbody> </table> | Bit | Name | Description | 0 | User control word 1 bit 0 | User-defined bit. | 1 | User control word 1 bit 1 | User-defined bit. | ... | ... | ... | 15 | User control word 1 bit 15 | User-defined bit. | |
| Bit | Name | Description | | | | | | | | | | | | | | | | |
| 0 | User control word 1 bit 0 | User-defined bit. | | | | | | | | | | | | | | | | |
| 1 | User control word 1 bit 1 | User-defined bit. | | | | | | | | | | | | | | | | |
| ... | ... | ... | | | | | | | | | | | | | | | | |
| 15 | User control word 1 bit 15 | User-defined bit. | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | User-defined control word 1. | 1 = 1 | | | | | | | | | | | | | | | |
| 06.101 | <i>User control word 2</i> | User-defined control word 2. This parameter is read-only. | - | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>User control word 2 bit 0</td> <td>User-defined bit.</td> </tr> <tr> <td>1</td> <td>User control word 2 bit 1</td> <td>User-defined bit.</td> </tr> <tr> <td>...</td> <td>...</td> <td>...</td> </tr> <tr> <td>15</td> <td>User control word 2 bit 15</td> <td>User-defined bit.</td> </tr> </tbody> </table> | Bit | Name | Description | 0 | User control word 2 bit 0 | User-defined bit. | 1 | User control word 2 bit 1 | User-defined bit. | ... | ... | ... | 15 | User control word 2 bit 15 | User-defined bit. | |
| Bit | Name | Description | | | | | | | | | | | | | | | | |
| 0 | User control word 2 bit 0 | User-defined bit. | | | | | | | | | | | | | | | | |
| 1 | User control word 2 bit 1 | User-defined bit. | | | | | | | | | | | | | | | | |
| ... | ... | ... | | | | | | | | | | | | | | | | |
| 15 | User control word 2 bit 15 | User-defined bit. | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | User-defined control word 2. | 1 = 1 | | | | | | | | | | | | | | | |
| 07 System info | | Drive hardware and firmware information. All parameters in this group are read-only. | | | | | | | | | | | | | | | | |
| 07.03 | <i>Drive rating id</i> | Type of the drive/inverter unit. | - | | | | | | | | | | | | | | | |
| 07.04 | <i>Firmware name</i> | Firmware identification. | - | | | | | | | | | | | | | | | |
| 07.05 | <i>Firmware version</i> | Version number of the firmware. | - | | | | | | | | | | | | | | | |
| 07.06 | <i>Loading package name</i> | Name of the firmware loading package. | - | | | | | | | | | | | | | | | |
| 07.07 | <i>Loading package version</i> | Version number of the firmware loading package. | - | | | | | | | | | | | | | | | |
| 07.11 | <i>Cpu usage</i> | Microprocessor load in percent. | - | | | | | | | | | | | | | | | |
| | 0...100% | Microprocessor load. | 1 = 1% | | | | | | | | | | | | | | | |
| 07.13 | <i>PU logic version number</i> | Version number of the power unit logic. | - | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | |
|------------------------|---|--|--------------------|------|-------------|---|----------|---|---|------------|---|-----|------------|---------------------|----|------------|--|--------|----------|--|----|-----------------|-----------------------------|--|
| 07.21 | <i>Application environment status 1</i> | Shows which tasks of the application program are running. See the <i>Drive (IEC 61131-3) application programming manual</i> (3AUA0000127808 [English]). | - | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Pre task</td> <td>1 = Pre-task running.</td> </tr> <tr> <td>1</td> <td>Appl task1</td> <td>1 = Task 1 running.</td> </tr> <tr> <td>2</td> <td>Appl task2</td> <td>1 = Task 2 running.</td> </tr> <tr> <td>3</td> <td>Appl task3</td> <td>1 = Task 3 running.</td> </tr> <tr> <td>4...14</td> <td colspan="2">Reserved</td> </tr> <tr> <td>15</td> <td>Task monitoring</td> <td>1 = Task monitoring enabled</td> </tr> </tbody> </table> | Bit | Name | Description | 0 | Pre task | 1 = Pre-task running. | 1 | Appl task1 | 1 = Task 1 running. | 2 | Appl task2 | 1 = Task 2 running. | 3 | Appl task3 | 1 = Task 3 running. | 4...14 | Reserved | | 15 | Task monitoring | 1 = Task monitoring enabled | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Pre task | 1 = Pre-task running. | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Appl task1 | 1 = Task 1 running. | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Appl task2 | 1 = Task 2 running. | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Appl task3 | 1 = Task 3 running. | | | | | | | | | | | | | | | | | | | | | | |
| 4...14 | Reserved | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | Task monitoring | 1 = Task monitoring enabled | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Application program task status. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | |
| 07.22 | <i>Application environment status 2</i> | Shows the status of the openings in the application program. See the <i>Drive (IEC 61131-3) application programming manual</i> (3AUA0000127808 [English]). | - | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Opening1</td> <td>Status of opening 1 in the application program.</td> </tr> <tr> <td>1</td> <td>Opening2</td> <td>Status of opening 2 in the application program.</td> </tr> <tr> <td>...</td> <td>...</td> <td>...</td> </tr> <tr> <td>15</td> <td>Opening16</td> <td>Status of opening 16 in the application program.</td> </tr> </tbody> </table> | Bit | Name | Description | 0 | Opening1 | Status of opening 1 in the application program. | 1 | Opening2 | Status of opening 2 in the application program. | ... | ... | ... | 15 | Opening16 | Status of opening 16 in the application program. | | | | | | | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Opening1 | Status of opening 1 in the application program. | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Opening2 | Status of opening 2 in the application program. | | | | | | | | | | | | | | | | | | | | | | |
| ... | ... | ... | | | | | | | | | | | | | | | | | | | | | | |
| 15 | Opening16 | Status of opening 16 in the application program. | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Application program opening status. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | |
| 07.23 | <i>Application name</i> | First five ASCII letters of the name given to the application program in the programming tool. The full name is visible under System info on the control panel or the Drive composer PC tool. _N/A_ = None. | - | | | | | | | | | | | | | | | | | | | | | |
| 07.24 | <i>Application version</i> | Application program version number given to the application program in the programming tool. Also visible under System info on the control panel or the Drive composer PC tool. | - | | | | | | | | | | | | | | | | | | | | | |
| 07.25 | <i>Customization package name</i> | First five ASCII letters of the name given to the customization package. The full name is visible under System info on the control panel or the Drive composer PC tool. _N/A_ = None. | - | | | | | | | | | | | | | | | | | | | | | |
| 07.26 | <i>Customization package version</i> | Customization package version number. Also visible under System info on the control panel or the Drive composer PC tool. | - | | | | | | | | | | | | | | | | | | | | | |
| 09 Pump actuals | | Basic signals for monitoring the application. All parameters in this group are read-only unless otherwise noted. | | | | | | | | | | | | | | | | | | | | | | |
| 09.01 | <i>Rod torque</i> | Estimated pump torque in engineering units. | 0.00 N*m or lbft | | | | | | | | | | | | | | | | | | | | | |
| | -100000.00 ...100000.00 | Value range | 10 = 1 N*m or lbft | | | | | | | | | | | | | | | | | | | | | |



126 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------------|--|---------------------------|
| 09.02 | <i>Maximum rod torque</i> | Maximum allowed pump torque in engineering units. | 0.00 |
| | -100000.00 ...100000.00 | Value range | 10 = 1 N•m or lbft |
| 09.03 | <i>Motor torque</i> | Actual motor torque in engineering units. | 0.00 N•m or lbft |
| | -100000.00 ...100000.00 | Value range | 10 = 1 N•m or lbft |
| 09.04 | <i>Maximum motor torque</i> | Maximum allowed motor torque in engineering units. | 0.00 N•m or lbft |
| | -100000.00 ...100000.00 | Value range | 10 = 1 N•m or lbft |
| 09.05 | <i>Rod speed</i> | Pump speed in engineering units. | 0.00 Prpm, rpm or Hz |
| | -100000.00 ...100000.00 | Value range | 10 = 1 Prpm, rpm or Hz |
| 09.06 | <i>Motor speed reference</i> | Motor speed reference in engineering units. | 0.00 rpm or Hz |
| | -100000.00 ...100000.00 | Value range | 10 = 1 rpm or Hz |
| 09.07 | <i>Run-time hours</i> | Runtime of the pump in hours. | 0.00 h |
| | 0.00....100000.00 | Value range | 10 = 1 h |
| 09.08 | <i>Fluid level</i> | Measured fluid level in depth units. | 0.00 m, ft or Joints |
| | -100000.00 ...100000.00 | Value range | 10 = 1 m, ft or Joints |
| 09.09 | <i>Pressure</i> | Measured pressure in engineering units. | 0.00 kPa or psi |
| | -100000.00 ...100000.00 | Value range | 10 = 1 kPa or psi |
| 09.10 | <i>Measured temperature</i> | Measured temperature in engineering units. | 0.00 °C |
| | -100000.00 ...100000.00 | Value range | 10 = 1 °C |
| 09.11 | <i>Backspin speed reference</i> | Speed reference for controllable shutdown procedure. | 0.00 Prpm, rpm or Hz |
| | -100000.00 ...100000.00 | Value range | 10 = 1 Prpm, rpm or Hz |
| 09.12 | <i>Start delay remain</i> | Remaining start delay time. | 0.000s |
| | 0...4294967.295 | Value range | 10 = 1 s |
| 09.13 | <i>Backspin status word</i> | Pump backspin status word. | 0000h |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|--|--------------------|-----|------|-------------|---|--|--|---|--|--|---|---------------------------|--|-------|--|---|----|---|--|----|---------------------------------|--|---------|-----------------------------|--|---|---------------------|----------------------|---|---------------------|----------------------|---|--------------------------|-------------------------------------|----|-------------------|------------------------------|----|--------------------|------------------------|----|-----------------|--|----|----------------------|--------------------------|----|-----------------------|----------------------------------|----|--------------------|----------------------------------|
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Backspin enabled</td> <td>Backspin function is enabled.</td> </tr> <tr> <td>1</td> <td>Backspin operation active</td> <td>Backspin function is active.</td> </tr> <tr> <td>2</td> <td>Backspin limit active</td> <td>Backspin limit is reached.</td> </tr> <tr> <td>3...9</td> <td>Reserved</td> <td></td> </tr> <tr> <td>10</td> <td>Start delay enabled</td> <td>Start delay function is enabled.</td> </tr> <tr> <td>11</td> <td>Start delay timer active</td> <td>Start delay function is active.</td> </tr> <tr> <td>12...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | | | | Bit | Name | Description | 0 | Backspin enabled | Backspin function is enabled. | 1 | Backspin operation active | Backspin function is active. | 2 | Backspin limit active | Backspin limit is reached. | 3...9 | Reserved | | 10 | Start delay enabled | Start delay function is enabled. | 11 | Start delay timer active | Start delay function is active. | 12...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Backspin enabled | Backspin function is enabled. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Backspin operation active | Backspin function is active. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Backspin limit active | Backspin limit is reached. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3...9 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Start delay enabled | Start delay function is enabled. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | Start delay timer active | Start delay function is active. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Backspin status word | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 09.14 | <i>Pump status word</i> | Pump control program status word. | 0000h | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Thermal protection alarm level reached</td> <td>Alarm due to thermal protection failure.</td> </tr> <tr> <td>1</td> <td>Thermal protection fault level reached</td> <td>Drive tripped due to thermal protection failure.</td> </tr> <tr> <td>2</td> <td>Thermal protection active</td> <td>Actual temperature for thermal protection.</td> </tr> <tr> <td>3</td> <td>High pressure presented - digital sensor</td> <td>High pressure measured by digital sensor.</td> </tr> <tr> <td>4</td> <td>High pressure presented - analogue sensor</td> <td>High pressure measured by analog sensor.</td> </tr> <tr> <td>5</td> <td>High pressure protection active</td> <td>Actual value for high pressure protection.</td> </tr> <tr> <td>6</td> <td>Underload protection active</td> <td>Actual value for underload protection.</td> </tr> <tr> <td>7</td> <td>Rod torque 1 active</td> <td>Actual rod torque 1.</td> </tr> <tr> <td>8</td> <td>Rod torque 2 active</td> <td>Actual rod torque 2.</td> </tr> <tr> <td>9</td> <td>Torque protection active</td> <td>Actual value for torque protection.</td> </tr> <tr> <td>10</td> <td>Sleep mode active</td> <td>Actual value for sleep mode.</td> </tr> <tr> <td>11</td> <td>Fault delay active</td> <td>Fault delay is active.</td> </tr> <tr> <td>12</td> <td>Replace battery</td> <td>Battery from ZCU is needed to replace.</td> </tr> <tr> <td>13</td> <td>Brake confirm active</td> <td>Brake confirm is active.</td> </tr> <tr> <td>14</td> <td>Starting speed active</td> <td>Drive is ready for startup ramp.</td> </tr> <tr> <td>15</td> <td>Rod torque 2 speed</td> <td>Reserved for rod torque 2 speed.</td> </tr> </tbody> </table> | | | | Bit | Name | Description | 0 | Thermal protection alarm level reached | Alarm due to thermal protection failure. | 1 | Thermal protection fault level reached | Drive tripped due to thermal protection failure. | 2 | Thermal protection active | Actual temperature for thermal protection. | 3 | High pressure presented - digital sensor | High pressure measured by digital sensor. | 4 | High pressure presented - analogue sensor | High pressure measured by analog sensor. | 5 | High pressure protection active | Actual value for high pressure protection. | 6 | Underload protection active | Actual value for underload protection. | 7 | Rod torque 1 active | Actual rod torque 1. | 8 | Rod torque 2 active | Actual rod torque 2. | 9 | Torque protection active | Actual value for torque protection. | 10 | Sleep mode active | Actual value for sleep mode. | 11 | Fault delay active | Fault delay is active. | 12 | Replace battery | Battery from ZCU is needed to replace. | 13 | Brake confirm active | Brake confirm is active. | 14 | Starting speed active | Drive is ready for startup ramp. | 15 | Rod torque 2 speed | Reserved for rod torque 2 speed. |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Thermal protection alarm level reached | Alarm due to thermal protection failure. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Thermal protection fault level reached | Drive tripped due to thermal protection failure. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Thermal protection active | Actual temperature for thermal protection. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | High pressure presented - digital sensor | High pressure measured by digital sensor. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | High pressure presented - analogue sensor | High pressure measured by analog sensor. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | High pressure protection active | Actual value for high pressure protection. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Underload protection active | Actual value for underload protection. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Rod torque 1 active | Actual rod torque 1. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Rod torque 2 active | Actual rod torque 2. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Torque protection active | Actual value for torque protection. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Sleep mode active | Actual value for sleep mode. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | Fault delay active | Fault delay is active. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | Replace battery | Battery from ZCU is needed to replace. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | Brake confirm active | Brake confirm is active. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | Starting speed active | Drive is ready for startup ramp. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | Rod torque 2 speed | Reserved for rod torque 2 speed. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Pump status word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 09.15 | <i>Sleep feedback value</i> | Integrated value of sleep signal feedback from different sources 75.14 Sleep signal source 1 and 75.15 Sleep signal source 2 . | 0.00 SourceUnit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | - 100000.00...100000. 00 | Value range | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 09.16 | <i>Sleep time</i> | Period of time when pump is in sleep mode. | 0.000 s | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0...100000.000 s | Value range | 10 = 1 s | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | |
|---------------------------|--|---|----------------|-------|---|--|---|--|---|--|---|--|---|--|---|--|--------|----------|----|--|--|
| 10 Standard DI, RO | | | | | | | | | | | | | | | | | | | | | |
| 10.01 | DI status | Displays the electrical status of digital inputs DIIL and DI6...DI1. The activation/deactivation delays of the inputs (if any are specified) are ignored. A filtering time can be defined by parameter 10.51 DI filter time . Bits 0...5 reflect the status of DI1...DI6; bit 15 reflects the status of the DIIL input. Example: 100000000010011b = DIIL, DI5, DI2 and DI1 are on, DI3, DI4 and DI6 are off. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Status of digital inputs. | 1 = 1 | | | | | | | | | | | | | | | | | | |
| 10.02 | DI delayed status | Displays the status of digital inputs DIIL and DI6...DI1. This word is updated only after activation/deactivation delays (if any are specified). Bits 0...5 reflect the delayed status of DI1...DI6; bit 15 reflects the delayed status of the DIIL input. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Delayed status of digital inputs. | 1 = 1 | | | | | | | | | | | | | | | | | | |
| 10.03 | DI force selection | The electrical statuses of the digital inputs can be overridden for eg. testing purposes. A bit in parameter 10.04 DI force data is provided for each digital input, and its value is applied whenever the corresponding bit in this parameter is 1. | 0000h | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 = Force DI1 to value of bit 0 of parameter 10.04 DI force data.</td> </tr> <tr> <td>1</td> <td>1 = Force DI2 to value of bit 1 of parameter 10.04 DI force data.</td> </tr> <tr> <td>2</td> <td>1 = Force DI3 to value of bit 2 of parameter 10.04 DI force data.</td> </tr> <tr> <td>3</td> <td>1 = Force DI4 to value of bit 3 of parameter 10.04 DI force data.</td> </tr> <tr> <td>4</td> <td>1 = Force DI5 to value of bit 4 of parameter 10.04 DI force data.</td> </tr> <tr> <td>5</td> <td>1 = Force DI6 to value of bit 5 of parameter 10.04 DI force data.</td> </tr> <tr> <td>6...14</td> <td>Reserved</td> </tr> <tr> <td>15</td> <td>1 = Force DIIL to value of bit 15 of parameter 10.04 DI force data.</td> </tr> </tbody> </table> | Bit | Value | 0 | 1 = Force DI1 to value of bit 0 of parameter 10.04 DI force data . | 1 | 1 = Force DI2 to value of bit 1 of parameter 10.04 DI force data . | 2 | 1 = Force DI3 to value of bit 2 of parameter 10.04 DI force data . | 3 | 1 = Force DI4 to value of bit 3 of parameter 10.04 DI force data . | 4 | 1 = Force DI5 to value of bit 4 of parameter 10.04 DI force data . | 5 | 1 = Force DI6 to value of bit 5 of parameter 10.04 DI force data . | 6...14 | Reserved | 15 | 1 = Force DIIL to value of bit 15 of parameter 10.04 DI force data . | |
| Bit | Value | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 = Force DI1 to value of bit 0 of parameter 10.04 DI force data . | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 = Force DI2 to value of bit 1 of parameter 10.04 DI force data . | | | | | | | | | | | | | | | | | | | | |
| 2 | 1 = Force DI3 to value of bit 2 of parameter 10.04 DI force data . | | | | | | | | | | | | | | | | | | | | |
| 3 | 1 = Force DI4 to value of bit 3 of parameter 10.04 DI force data . | | | | | | | | | | | | | | | | | | | | |
| 4 | 1 = Force DI5 to value of bit 4 of parameter 10.04 DI force data . | | | | | | | | | | | | | | | | | | | | |
| 5 | 1 = Force DI6 to value of bit 5 of parameter 10.04 DI force data . | | | | | | | | | | | | | | | | | | | | |
| 6...14 | Reserved | | | | | | | | | | | | | | | | | | | | |
| 15 | 1 = Force DIIL to value of bit 15 of parameter 10.04 DI force data . | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Override selection for digital inputs. | 1 = 1 | | | | | | | | | | | | | | | | | | |
| 10.04 | DI force data | Contains the values that the digital inputs are forced to when selected by 10.03 DI force selection . Bit 0 is the forced value for DI1; bit 15 is the forced value for the DIIL input. | 0000h | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Forced values of digital inputs. | 1 = 1 | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|--|----------------|
| 10.05 | <i>DI1 ON delay</i> | Defines the activation delay for digital input DI1. | 0.0 s |
| | <p> $t_{On} = 10.05$ <i>DI1 ON delay</i> $t_{Off} = 10.06$ <i>DI1 OFF delay</i> *Electrical status of digital input. Indicated by 10.01 DI status. **Indicated by 10.02 DI delayed status. </p> | | |
| | 0.0 ... 3000.0 s | Activation delay for DI1. | 10 = 1 s |
| 10.06 | <i>DI1 OFF delay</i> | Defines the deactivation delay for digital input DI1. See parameter 10.05 DI1 ON delay . | 0.0 s |
| | 0.0 ... 3000.0 s | Deactivation delay for DI1. | 10 = 1 s |
| 10.07 | <i>DI2 ON delay</i> | Defines the activation delay for digital input DI2. | 0.0 s |
| | <p> $t_{On} = 10.07$ <i>DI2 ON delay</i> $t_{Off} = 10.08$ <i>DI2 OFF delay</i> *Electrical status of digital input. Indicated by 10.01 DI status. **Indicated by 10.02 DI delayed status. </p> | | |
| | 0.0 ... 3000.0 s | Activation delay for DI2. | 10 = 1 s |
| 10.08 | <i>DI2 OFF delay</i> | Defines the deactivation delay for digital input DI2. See parameter 10.07 DI2 ON delay . | 0.0 s |
| | 0.0 ... 3000.0 s | Deactivation delay for DI2. | 10 = 1 s |

| No. | Name/Value | Description | Def/ FbEq16 |
|---|----------------------|--|----------------|
| 10.09 | <i>DI3 ON delay</i> | Defines the activation delay for digital input DI3. | 0.0 s |
|  <p data-bbox="162 470 380 494">$t_{On} = 10.09$ <i>DI3 ON delay</i></p> <p data-bbox="162 494 386 518">$t_{Off} = 10.10$ <i>DI3 OFF delay</i></p> <p data-bbox="162 518 666 542">*Electrical status of digital input. Indicated by 10.01 DI status.</p> <p data-bbox="162 542 487 566">**Indicated by 10.02 DI delayed status.</p> | | | |
| 0.0 ... 3000.0 s | | Activation delay for DI3. | 10 = 1 s |
| 10.10 | <i>DI3 OFF delay</i> | Defines the deactivation delay for digital input DI3. See parameter 10.09 DI3 ON delay . | 0.0 s |
| 0.0 ... 3000.0 s | | Deactivation delay for DI3. | 10 = 1 s |
| 10.11 | <i>DI4 ON delay</i> | Defines the activation delay for digital input DI4. | 0.0 s |
|  <p data-bbox="162 973 380 997">$t_{On} = 10.11$ <i>DI4 ON delay</i></p> <p data-bbox="162 997 386 1021">$t_{Off} = 10.12$ <i>DI4 OFF delay</i></p> <p data-bbox="162 1021 666 1045">*Electrical status of digital input. Indicated by 10.01 DI status.</p> <p data-bbox="162 1045 487 1069">**Indicated by 10.02 DI delayed status.</p> | | | |
| 0.0 ... 3000.0 s | | Activation delay for DI4. | 10 = 1 s |
| 10.12 | <i>DI4 OFF delay</i> | Defines the deactivation delay for digital input DI4. See parameter 10.11 DI4 ON delay . | 0.0 s |
| 0.0 ... 3000.0 s | | Deactivation delay for DI4. | 10 = 1 s |

| No. | Name/Value | Description | Def/ FbEq16 |
|--|----------------------|--|----------------|
| 10.13 | <i>DI5 ON delay</i> | Defines the activation delay for digital input DI5. | 0.0 s |
| <p> $t_{On} = 10.13$ DI5 ON delay $t_{Off} = 10.14$ DI5 OFF delay *Electrical status of digital input. Indicated by 10.01 DI status. **Indicated by 10.02 DI delayed status. </p> | | | |
| | 0.0 ... 3000.0 s | Activation delay for DI5. | 10 = 1 s |
| 10.14 | <i>DI5 OFF delay</i> | Defines the deactivation delay for digital input DI5. See parameter 10.13 DI5 ON delay . | 0.0 s |
| | 0.0 ... 3000.0 s | Deactivation delay for DI5. | 10 = 1 s |
| 10.15 | <i>DI6 ON delay</i> | Defines the activation delay for digital input DI6. | 0.0 s |
| <p> $t_{On} = 10.15$ DI6 ON delay $t_{Off} = 10.16$ DI6 OFF delay *Electrical status of digital input. Indicated by 10.01 DI status. **Indicated by 10.02 DI delayed status. </p> | | | |
| | 0.0 ... 3000.0 s | Activation delay for DI6. | 10 = 1 s |
| 10.16 | <i>DI6 OFF delay</i> | Defines the deactivation delay for digital input DI6. See parameter 10.15 DI6 ON delay . | 0.0 s |
| | 0.0 ... 3000.0 s | Deactivation delay for DI6. | 10 = 1 s |
| 10.21 | <i>RO status</i> | Status of relay outputs RO8...RO1. Example: 00000001b = RO1 is energized, RO2...RO8 are de-energized. | - |
| | 0000h...FFFFh | Status of relay outputs. | 1 = 1 |


132 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------|--|--|
| 10.24 | <i>RO1 source</i> | Selects a drive signal to be connected to relay output RO1. | <i>Ready run</i> ; 10.01 b3 (-1) (95.20 b2); 35.105 b1 (95.20 b6); 06.16 b6 (95.20 b9) |
| | Not energized | Output is not energized. | 0 |
| | Energized | Output is energized. | 1 |
| | Ready run | Bit 1 of <i>06.11 Main status word</i> (see page 117). | 2 |
| | Enabled | Bit 0 of <i>06.16 Drive status word 1</i> (see page 117). | 4 |
| | Started | Bit 5 of <i>06.16 Drive status word 1</i> (see page 117). | 5 |
| | Magnetized | Bit 1 of <i>06.17 Drive status word 2</i> (see page 118). | 6 |
| | Running | Bit 6 of <i>06.16 Drive status word 1</i> (see page 117). | 7 |
| | Ready ref | Bit 2 of <i>06.11 Main status word</i> (see page 117). | 8 |
| | At setpoint | Bit 8 of <i>06.11 Main status word</i> (see page 117). | 9 |
| | Reverse | Bit 2 of <i>06.19 Speed control status word</i> (see page 120). | 10 |
| | Zero speed | Bit 0 of <i>06.19 Speed control status word</i> (see page 120). | 11 |
| | Above limit | Bit 10 of <i>06.17 Drive status word 2</i> (see page 118). | 12 |
| | Warning | Bit 7 of <i>06.11 Main status word</i> (see page 117). | 13 |
| | Fault | Bit 3 of <i>06.11 Main status word</i> (see page 117). | 14 |
| | Fault (-1) | Inverted bit 3 of <i>06.11 Main status word</i> (see page 117). | 15 |
| | Open brake command | Bit 0 of <i>44.01 Brake control status</i> . | 22 |
| | Ext2 active | Bit 11 of <i>06.16 Drive status word 1</i> (see page 117). | 23 |
| | Remote control | Bit 9 of <i>06.11 Main status word</i> (see page 117). | 24 |
| | Supervision 1 | Bit 0 of <i>32.01 Supervision status</i> (see page 251). | 33 |
| | Supervision 2 | Bit 1 of <i>32.01 Supervision status</i> (see page 251). | 34 |
| | Supervision 3 | Bit 2 of <i>32.01 Supervision status</i> (see page 251). | 35 |
| | RO/DIO control word bit0 | Bit 0 of <i>10.99 RO/DIO control word</i> (see page 134). | 40 |
| | RO/DIO control word bit1 | Bit 1 of <i>10.99 RO/DIO control word</i> (see page 134). | 41 |
| | RO/DIO control word bit2 | Bit 2 of <i>10.99 RO/DIO control word</i> (see page 134). | 42 |
| | RO/DIO control word bit8 | Bit 8 of <i>10.99 RO/DIO control word</i> (see page 134). | 43 |
| | RO/DIO control word bit9 | Bit 9 of <i>10.99 RO/DIO control word</i> (see page 134). | 44 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |


| No. | Name/Value | Description | Def/ FbEq16 |
|---|----------------------|--|------------------------------|
| 10.25 | <i>RO1 ON delay</i> | Defines the activation delay for relay output RO1. | 0.0 s |
| <p> $t_{On} = 10.25 \text{ RO1 ON delay}$ $t_{Off} = 10.26 \text{ RO1 OFF delay}$ </p> | | | |
| | 0.0 ... 3000.0 s | Activation delay for RO1. | 10 = 1 s |
| 10.26 | <i>RO1 OFF delay</i> | Defines the deactivation delay for relay output RO1. See parameter 10.25 RO1 ON delay . | 0.0 s |
| | 0.0 ... 3000.0 s | Deactivation delay for RO1. | 10 = 1 s |
| 10.27 | <i>RO2 source</i> | Selects a drive signal to be connected to relay output RO2. For the available selections, see parameter 10.24 RO1 source . | <i>Running</i> (95.20 b3) |
| 10.28 | <i>RO2 ON delay</i> | Defines the activation delay for relay output RO2. | 0.0 s (95.20 b3) |
| <p> $t_{On} = 10.28 \text{ RO2 ON delay}$ $t_{Off} = 10.29 \text{ RO2 OFF delay}$ </p> | | | |
| | 0.0 ... 3000.0 s | Activation delay for RO2. | 10 = 1 s |
| 10.29 | <i>RO2 OFF delay</i> | Defines the deactivation delay for relay output RO2. See parameter 10.28 RO2 ON delay . | 0.0 s (95.20 b3) |
| | 0.0 ... 3000.0 s | Deactivation delay for RO2. | 10 = 1 s |
| 10.30 | <i>RO3 source</i> | Selects a drive signal to be connected to relay output RO3. For the available selections, see parameter 10.24 RO1 source . | <i>Fault (-1)</i> |


| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | |
|--|----------------------------|--|----------------|-----|------|-------------|---|-----|--|---|-----|--|---|-----|--|-------|----------|--|---|------|--|---|------|--|---------|----------|--|
| 10.31 | <i>RO3 ON delay</i> | Defines the activation delay for relay output RO3. | 0.0 s | | | | | | | | | | | | | | | | | | | | | | | | |
| <p> $t_{On} = 10.31$ RO3 ON delay $t_{Off} = 10.32$ RO3 OFF delay </p> | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0.0 ... 3000.0 s | Activation delay for RO3. | 10 = 1 s | | | | | | | | | | | | | | | | | | | | | | | | |
| 10.32 | <i>RO3 OFF delay</i> | Defines the deactivation delay for relay output RO3. See parameter 10.31 RO3 ON delay . | 0.0 s | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0.0 ... 3000.0 s | Deactivation delay for RO3. | 10 = 1 s | | | | | | | | | | | | | | | | | | | | | | | | |
| 10.51 | <i>DI filter time</i> | Defines a filtering time for parameter 10.01 DI status | 10.0 ms | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0.3...100.0 ms | Filter time for 10.01 DI status . | 10 = 1 ms | | | | | | | | | | | | | | | | | | | | | | | | |
| 10.99 | <i>RO/DIO control word</i> | Storage parameter for controlling the relay outputs and digital input/outputs eg. through the embedded fieldbus interface. To control the relay outputs (RO) and the digital input/outputs (DIO) of the drive, send a control word with the bit assignments shown below as Modbus I/O data. | 0000h | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>RO1</td> <td>Source bits for relay outputs RO1...RO3 (see parameters 10.24, 10.27 and 10.30).</td> </tr> <tr> <td>1</td> <td>RO2</td> <td></td> </tr> <tr> <td>2</td> <td>RO3</td> <td></td> </tr> <tr> <td>3...7</td> <td>Reserved</td> <td></td> </tr> <tr> <td>8</td> <td>DIO1</td> <td>Source bits for digital input/outputs DIO1...DIO3 (see parameters 11.06 and 11.10).</td> </tr> <tr> <td>9</td> <td>DIO2</td> <td></td> </tr> <tr> <td>10...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | | | | Bit | Name | Description | 0 | RO1 | Source bits for relay outputs RO1...RO3 (see parameters 10.24 , 10.27 and 10.30). | 1 | RO2 | | 2 | RO3 | | 3...7 | Reserved | | 8 | DIO1 | Source bits for digital input/outputs DIO1...DIO3 (see parameters 11.06 and 11.10). | 9 | DIO2 | | 10...15 | Reserved | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | RO1 | Source bits for relay outputs RO1...RO3 (see parameters 10.24 , 10.27 and 10.30). | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | RO2 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | RO3 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3...7 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | DIO1 | Source bits for digital input/outputs DIO1...DIO3 (see parameters 11.06 and 11.10). | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | DIO2 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | RO/DIO control word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 Standard DIO, FI, FO | | Configuration of digital input/outputs and frequency inputs/outputs. | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11.01 | <i>DIO status</i> | Displays the status of digital input/outputs DIO2...DIO1. The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter 10.51 DI filter time . Example: 0010 = DIO2 is on, DIO is off. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000b...0011b | Status of digital input/outputs. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------|--|------------------|
| 11.02 | <i>DIO delayed status</i> | Displays the delayed status of digital input/outputs DIO2...DIO1. This word is updated only after activation/deactivation delays (if any are specified). Example: 0010 = DIO2 is on, DIO1 is off. This parameter is read-only. | - |
| | 0000b...0011b | Delayed status of digital input/outputs. | 1 = 1 |
| 11.05 | <i>DIO1 function</i> | Selects whether DIO1 is used as a digital output or input, or a frequency input. | <i>Output</i> |
| | Output | DIO1 is used as a digital output. | 0 |
| | Input | DIO1 is used as a digital input. | 1 |
| | Frequency | DIO1 is used as a frequency input. | 2 |
| 11.06 | <i>DIO1 output source</i> | Selects a drive signal to be connected to digital input/output DIO1 when parameter <i>11.05 DIO1 function</i> is set to <i>Output</i> . | <i>Ready run</i> |
| | Not energized | Output is off. | 0 |
| | Energized | Output is on. | 1 |
| | Ready run | Bit 1 of <i>06.11 Main status word</i> (see page 117). | 2 |
| | Enabled | Bit 0 of <i>06.16 Drive status word 1</i> (see page 117). | 4 |
| | Started | Bit 5 of <i>06.16 Drive status word 1</i> (see page 117). | 5 |
| | Magnetized | Bit 1 of <i>06.17 Drive status word 2</i> (see page 118). | 6 |
| | Running | Bit 6 of <i>06.16 Drive status word 1</i> (see page 117). | 7 |
| | Ready ref | Bit 2 of <i>06.11 Main status word</i> (see page 117). | 8 |
| | At setpoint | Bit 8 of <i>06.11 Main status word</i> (see page 117). | 9 |
| | Reverse | Bit 2 of <i>06.19 Speed control status word</i> (see page 120). | 10 |
| | Zero speed | Bit 0 of <i>06.19 Speed control status word</i> (see page 120). | 11 |
| | Above limit | Bit 10 of <i>06.17 Drive status word 2</i> (see page 118). | 12 |
| | Warning | Bit 7 of <i>06.11 Main status word</i> (see page 117). | 13 |
| | Fault | Bit 3 of <i>06.11 Main status word</i> (see page 117). | 14 |
| | Fault (-1) | Inverted bit 3 of <i>06.11 Main status word</i> (see page 117). | 15 |
| | Open brake command | Bit 0 of 44.01 Brake control status. (See ACS880 primary control program firmware manual (3AUA0000085967[English])). | 22 |
| | Ext2 active | Bit 11 of <i>06.16 Drive status word 1</i> (see page 117). | 23 |
| | Remote control | Bit 9 of <i>06.11 Main status word</i> (see page 117). | 24 |
| | Supervision 1 | Bit 0 of <i>32.01 Supervision status</i> (see page 251). | 33 |
| | Supervision 2 | Bit 1 of <i>32.01 Supervision status</i> (see page 251). | 34 |
| | Supervision 3 | Bit 2 of <i>32.01 Supervision status</i> (see page 251). | 35 |
| | RO/DIO control word bit0 | Bit 0 of <i>10.99 RO/DIO control word</i> (see page 134). | 40 |
| | RO/DIO control word bit1 | Bit 1 of <i>10.99 RO/DIO control word</i> (see page 134). | 41 |
| | RO/DIO control word bit2 | Bit 2 of <i>10.99 RO/DIO control word</i> (see page 134). | 42 |



| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|--|-------------------------|
| | RO/DIO control word bit8 | Bit 8 of 10.99 RO/DIO control word (see page 134). | 43 |
| | RO/DIO control word bit9 | Bit 9 of 10.99 RO/DIO control word (see page 134). | 44 |
| | Other [bit] | Source selection (see Terms and abbreviations on page 101). | - |
| 11.07 | DIO1 ON delay | Defines the activation delay for digital input/output DIO1 (when used as a digital output or digital input). | 0.0 s |
| |  <p data-bbox="162 663 397 687">t_{On} = 11.07 DIO1 ON delay</p> <p data-bbox="162 687 397 711">t_{Off} = 11.08 DIO1 OFF delay</p> <p data-bbox="162 711 982 751">*Electrical status of DIO (in input mode) or status of selected source (in output mode). Indicated by 11.01 DIO status.</p> <p data-bbox="162 751 498 775">**Indicated by 11.02 DIO delayed status.</p> | | |
| | 0.0 ... 3000.0 s | Activation delay for DIO1. | 10 = 1 s |
| 11.08 | DIO1 OFF delay | Defines the deactivation delay for digital input/output DIO1 (when used as a digital output or digital input). See parameter 11.07 DIO1 ON delay . | 0.0 s |
| | 0.0...3000.0 s | Deactivation delay for DIO1. | 10 = 1 s |
| 11.09 | DIO2 function | Selects whether DIO2 is used as a digital output or input, or a frequency output. | Output |
| | Output | DIO2 is used as a digital output. | 0 |
| | Input | DIO2 is used as a digital input. | 1 |
| | Frequency | DIO2 is used as a frequency output. | 2 |
| 11.10 | DIO2 output source | Selects a drive signal to be connected to digital input/output DIO2 when parameter 11.09 DIO2 function is set to Output . For the available selections, see parameter 11.06 DIO1 output source . | Running |

| No. | Name/Value | Description | Def/ FbEq16 |
|--|-------------------------------|---|----------------|
| 11.11 | <i>DIO2 ON delay</i> | Defines the activation delay for digital input/output DIO2 (when used as a digital output or digital input). | 0.0 s |
| <p>*DIO status</p> <p>**Delayed DIO status</p> <p>Time</p> <p>t_{on} t_{off} t_{on} t_{off}</p> <p>$t_{On} = 11.11$ <i>DIO2 ON delay</i> $t_{Off} = 11.12$ <i>DIO2 OFF delay</i> *Electrical status of DIO (in input mode) or status of selected source (in output mode). Indicated by 11.01 DIO status. **Indicated by 11.02 DIO delayed status.</p> | | | |
| | 0.0...3000.0 s | Activation delay for DIO2. | 10 = 1 s |
| 11.12 | <i>DIO2 OFF delay</i> | Defines the deactivation delay for digital input/output DIO2 (when used as a digital output or digital input). See parameter 11.11 DIO2 ON delay . | 0.0 s |
| | 0.0...3000.0 s | Deactivation delay for DIO2. | 10 = 1 s |
| 11.38 | <i>Freq in 1 actual value</i> | Displays the value of frequency input 1 (via DIO1 when it is used as a frequency input) before scaling. See parameter 11.42 Freq in 1 min . This parameter is read-only. | - |
| | 0...16000 Hz | Unscaled value of frequency input 1. | 1 = 1 Hz |
| 11.39 | <i>Freq in 1 scaled</i> | Displays the value of frequency input 1 (via DIO1 when it is used as a frequency input) after scaling. See parameter 11.42 Freq in 1 min . This parameter is read-only. | - |
| | -32768.000 ...32767.000 | Scaled value of frequency input 1. | 1 = 1 |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------|---|---|
| 11.42 | <i>Freq in 1 min</i> | <p>Defines the minimum for the frequency actually arriving at frequency input 1 (DIO1 when it is used as a frequency input).</p> <p>The incoming frequency signal (11.38 Freq in 1 actual value) is scaled into an internal signal (11.39 Freq in 1 scaled) by parameters 11.42...11.45 as follows:</p>  | 0 Hz |
| | 0...16000 Hz | Minimum frequency of frequency input 1 (DIO1). | 1 = 1 Hz |
| 11.43 | <i>Freq in 1 max</i> | Defines the maximum for the frequency actually arriving at frequency input 1 (DIO1 when it is used as a frequency input). See parameter 11.42 Freq in 1 min . | 16000 Hz |
| | 0...16000 Hz | Maximum frequency for frequency input 1 (DIO1). | 1 = 1 Hz |
| 11.44 | <i>Freq in 1 at scaled min</i> | Defines the value that is required to correspond internally to the minimum input frequency defined by parameter 11.42 Freq in 1 min . See diagram at parameter 11.42 Freq in 1 min . | 0.000 |
| | -32768.000 ...32767.000 | Value corresponding to minimum of frequency input 1. | 1 = 1 |
| 11.45 | <i>Freq in 1 at scaled max</i> | Defines the value that is required to correspond internally to the maximum input frequency defined by parameter 11.43 Freq in 1 max . See diagram at parameter 11.42 Freq in 1 min . | 1500.000; 1800.000 (95.20 b0) |
| | -32768.000 ...32767.000 | Value corresponding to maximum of frequency input 1. | 1 = 1 |
| 11.54 | <i>Freq out 1 actual value</i> | Displays the value of frequency output 1 after scaling. See parameter 11.58 Freq out 1 src min . This parameter is read-only. | - |
| | 0...16000 Hz | Value of frequency output 1. | 1 = 1 |
| 11.55 | <i>Freq out 1 source</i> | Selects a signal to be connected to frequency output 1. | <i>Motor speed used</i> |
| | Zero | None. | 0 |
| | Motor speed used | 01.01 Motor speed used (page 105). | 1 |
| | Output frequency | 01.06 Output frequency (page 105). | 3 |
| | Motor current | 01.07 Motor current (page 105). | 4 |
| | Motor torque | 01.10 Motor torque (page 105). | 6 |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------|---|---|
| | DC voltage | 01.11 DC voltage (page 105). | 7 |
| | Power inu out | 01.14 Output power (page 106). | 8 |
| | Speed ref ramp in | 23.01 Speed ref ramp input (page 203). | 10 |
| | Speed ref ramped | 23.02 Speed ref ramp output (page 204). | 11 |
| | Speed ref used | 24.01 Used speed reference (page 210). | 12 |
| | Torq ref used | 26.02 Torque reference used. | 13 |
| | Freq ref used | 28.02 Frequency ref ramp output (page 226). | 14 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 11.58 | <i>Freq out 1 src min</i> | <p>Defines the real value of the signal (selected by parameter 11.55 Freq out 1 source and shown by parameter 11.54 Freq out 1 actual value) that corresponds to the minimum value of frequency output 1 (defined by parameter 11.60 Freq out 1 at src min).</p>  | 0.000 |
| | -32768.000 ...32767.000 | Real signal value corresponding to minimum value of frequency output 1. | 1 = 1 |
| 11.59 | <i>Freq out 1 src max</i> | <p>Defines the real value of the signal (selected by parameter 11.55 Freq out 1 source and shown by parameter 11.54 Freq out 1 actual value) that corresponds to the maximum value of frequency output 1 (defined by parameter 11.61 Freq out 1 at src max). See parameter 11.58 Freq out 1 src min.</p> | 1500.000; 1800.000 (95.20 b0) |
| | -32768.000 ...32767.000 | Real signal value corresponding to maximum value of frequency output 1. | 1 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------------|---|----------------|
| 11.60 | <i>Freq out 1 at src min</i> | Defines the minimum value of frequency output 1. See diagrams at parameter <i>11.58 Freq out 1 src min</i> . | 0 Hz |
| | 0...16000 Hz | Minimum value of frequency output 1. | 1 = 1 Hz |
| 11.61 | <i>Freq out 1 at src max</i> | Defines the maximum value of frequency output 1. See diagrams at parameter <i>11.58 Freq out 1 src min</i> . | 16000 Hz |
| | 0...16000 Hz | Maximum value of frequency output 1. | 1 = 1 Hz |
| 11.81 | <i>DIO filter time</i> | Defines a filtering time for parameter <i>11.01 DIO status</i> . The filtering time will only affect the DIOs that are in input mode. | 10.0 ms |
| | 0.3...100 ms | Filtering time for <i>11.01</i> . | 10 = 1 ms |

| 12 Standard AI | | Configuration of standard analog inputs. | |
|-----------------------|--------------------------------|--|------------------|
| 12.01 | <i>AI tune</i> | Triggers the analog input tuning function. Connect the signal to the input and select the appropriate tuning function. | |
| | No action | AI tune is not activated. | 0 |
| | AI1 min tune | Current analog input AI1 signal value is set as minimum value of AI1 into parameter <i>12.17 AI1 min</i> . The value reverts back to <i>No action</i> automatically. | 1 |
| | AI1 max tune | Current analog input AI1 signal value is set as maximum value of AI1 into parameter <i>12.18 AI1 max</i> . The value reverts back to <i>No action</i> automatically | 2 |
| | AI2 min tune | Current analog input AI2 signal value is set as minimum value of AI2 into parameter <i>12.27 AI2 min</i> . The value reverts back to <i>No action</i> automatically | 3 |
| | AI2 max tune | Current analog input AI2 signal value is set as maximum value of AI2 into parameter <i>12.28 AI2 max</i> . The value reverts back to <i>No action</i> automatically | 4 |
| 12.03 | <i>AI supervision function</i> | Selects how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input. The inputs and the limits to be observed are selected by parameter <i>12.04 AI supervision selection</i> . | <i>No action</i> |
| | No action | No action taken. | 0 |
| | Fault | Drive trips on <i>80A0 AI supervision</i> . | 1 |
| | Warning | Drive generates an <i>A8A0 AI supervision</i> warning. | 2 |
| | Last speed | Drive generates a warning (<i>A8A0 AI supervision</i>) and freezes the speed (or frequency) to the level the drive was operating at. The speed/frequency is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 3 |
| | Speed ref safe | Drive generates a warning (<i>A8A0 AI supervision</i>) and sets the speed to the speed defined by parameter <i>22.41 Speed ref safe</i> (or <i>28.41 Frequency ref safe</i> when frequency reference is being used).  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 4 |


| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | |
|--------|---------------------------------|---|---------------------|------|-------------|---|-----------|--|---|-----------|--|---|-----------|--|---|-----------|--|--------|----------|--|--|
| 12.04 | <i>AI supervision selection</i> | Specifies the analog input limits to be supervised. See parameter 12.03 AI supervision function . | 0000b | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>AI1 < MIN</td> <td>1 = Minimum limit supervision of AI1 active.</td> </tr> <tr> <td>1</td> <td>AI1 > MAX</td> <td>1 = Maximum limit supervision of AI1 active.</td> </tr> <tr> <td>2</td> <td>AI2 < MIN</td> <td>1 = Minimum limit supervision of AI2 active.</td> </tr> <tr> <td>3</td> <td>AI2 > MAX</td> <td>1 = Maximum limit supervision of AI2 active.</td> </tr> <tr> <td>4...15</td> <td colspan="2">Reserved</td> </tr> </tbody> </table> | Bit | Name | Description | 0 | AI1 < MIN | 1 = Minimum limit supervision of AI1 active. | 1 | AI1 > MAX | 1 = Maximum limit supervision of AI1 active. | 2 | AI2 < MIN | 1 = Minimum limit supervision of AI2 active. | 3 | AI2 > MAX | 1 = Maximum limit supervision of AI2 active. | 4...15 | Reserved | | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | |
| 0 | AI1 < MIN | 1 = Minimum limit supervision of AI1 active. | | | | | | | | | | | | | | | | | | | |
| 1 | AI1 > MAX | 1 = Maximum limit supervision of AI1 active. | | | | | | | | | | | | | | | | | | | |
| 2 | AI2 < MIN | 1 = Minimum limit supervision of AI2 active. | | | | | | | | | | | | | | | | | | | |
| 3 | AI2 > MAX | 1 = Maximum limit supervision of AI2 active. | | | | | | | | | | | | | | | | | | | |
| 4...15 | Reserved | | | | | | | | | | | | | | | | | | | | |
| | 0000b...1111b | Activation of analog input supervision. | 1 = 1 | | | | | | | | | | | | | | | | | | |
| 12.11 | <i>AI1 actual value</i> | Displays the value of analog input AI1 in mA or V (depending on whether the input is set to current or voltage by a hardware setting). This parameter is read-only. | - | | | | | | | | | | | | | | | | | | |
| | -22.000... 22.000 mA or V | Value of analog input AI1. | 1000 = 1 mA or V | | | | | | | | | | | | | | | | | | |
| 12.12 | <i>AI1 scaled value</i> | Displays the value of analog input AI1 after scaling. See parameters 12.19 AI1 scaled at AI1 min and 12.20 AI1 scaled at AI1 max . This parameter is read-only. | - | | | | | | | | | | | | | | | | | | |
| | -32768.000 ...32767.000 | Scaled value of analog input AI1. | 1 = 1 | | | | | | | | | | | | | | | | | | |
| 12.15 | <i>AI1 unit selection</i> | Selects the unit for readings and settings related to analog input AI1. Note: This setting must match the corresponding hardware setting on the drive control unit (see the hardware manual of the drive). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings. | V | | | | | | | | | | | | | | | | | | |
| | V | Volts. | 2 | | | | | | | | | | | | | | | | | | |
| | mA | Milliamperes. | 10 | | | | | | | | | | | | | | | | | | |



| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|---|--------------------------|
| 12.16 | <p><i>AI1 filter time</i></p>  <p style="text-align: center;"> $O = I \times (1 - e^{-t/T})$ I = filter input (step) O = filter output t = time T = filter time constant </p> <p>Note: The signal is also filtered due to the signal interface hardware (approximately 0.25 ms time constant). This cannot be changed by any parameter.</p> | 0.100 s | |
| | 0.000...30.000 s | Filter time constant. | 1000 = 1 s |
| 12.17 | <p><i>AI1 min</i></p> | <p>Defines the minimum site value for analog input AI1. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting. See also parameter 12.01 AI tune.</p> | 0.000 mA or V |
| | -22.000 ...22.000 mA or V | Minimum value of AI1. | 1000 = 1 mA or V |
| 12.18 | <p><i>AI1 max</i></p> | <p>Defines the maximum site value for analog input AI1. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter 12.01 AI tune.</p> | 20.000 mA or 10.000 V |
| | -22.000 ...22.000 mA or V | Maximum value of AI1. | 1000 = 1 mA or V |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------------|--|--|
| 12.19 | <i>AI1 scaled at AI1 min</i> | <p>Defines the real internal value that corresponds to the minimum analog input AI1 value defined by parameter 12.17 AI1 min. (Changing the polarity settings of 12.19 and 12.20 can effectively invert the analog input.)</p>  | 0.000 |
| | -32768.000 ...32767.000 | Real value corresponding to minimum AI1 value. | 1 = 1 |
| 12.20 | <i>AI1 scaled at AI1 max</i> | <p>Defines the real internal value that corresponds to the maximum analog input AI1 value defined by parameter 12.18 AI1 max. See the drawing at parameter 12.19 AI1 scaled at AI1 min.</p> | 1500.000; 1800.000 (95.20 b0) |
| | -32768.000 ...32767.000 | Real value corresponding to maximum AI1 value. | 1 = 1 |
| 12.21 | <i>AI2 actual value</i> | <p>Displays the value of analog input AI2 in mA or V (depending on whether the input is set to current or voltage by a hardware setting). This parameter is read-only.</p> | - |
| | -22.000 ...22.000 mA or V | Value of analog input AI2. | 1000 = 1 mA or V |
| 12.22 | <i>AI2 scaled value</i> | <p>Displays the value of analog input AI2 after scaling. See parameters 12.29 AI2 scaled at AI2 min and 12.30 AI2 scaled at AI2 max. This parameter is read-only.</p> | - |
| | -32768.000 ...32767.000 | Scaled value of analog input AI2. | 1 = 1 |
| 12.25 | <i>AI2 unit selection</i> | <p>Selects the unit for readings and settings related to analog input AI2. Note: This setting must match the corresponding hardware setting on the drive control unit (see the hardware manual of the drive). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.</p> | <i>mA</i> |
| | V | Volts. | 2 |
| | mA | Milliamperes. | 10 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------|------------------------------|---|-----------------------|
| 12.26 | <i>AI2 filter time</i> | Defines the filter time constant for analog input AI2. See parameter 12.16 AI1 filter time . | 0.100 s |
| | 0.000...30.000 s | Filter time constant. | 1000 = 1 s |
| 12.27 | <i>AI2 min</i> | Defines the minimum site value for analog input AI2. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting. See also parameter 12.01 AI tune . | 0.000 mA or V |
| | -22.000 ...22.000 mA or V | Minimum value of AI2. | 1000 = 1 mA or V |
| 12.28 | <i>AI2 max</i> | Defines the maximum site value for analog input AI2. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter 12.01 AI tune . | 20.000 mA or 10.000 V |
| | -22.000 ...22.000 mA or V | Maximum value of AI2. | 1000 = 1 mA or V |
| 12.29 | <i>AI2 scaled at AI2 min</i> | Defines the real value that corresponds to the minimum analog input AI2 value defined by parameter 12.27 AI2 min . (Changing the polarity settings of 12.29 and 12.30 can effectively invert the analog input.) | 0.000 |
| | | | |
| | -32768.000 ...32767.000 | Real value corresponding to minimum AI2 value. | 1 = 1 |
| 12.30 | <i>AI2 scaled at AI2 max</i> | Defines the real value that corresponds to the maximum analog input AI2 value defined by parameter 12.28 AI2 max . See the drawing at parameter 12.29 AI2 scaled at AI2 min . | 100.000 |
| | -32768.000 ...32767.000 | Real value corresponding to maximum AI2 value. | 1 = 1 |
| 13 Standard AO | | Configuration of standard analog outputs. | |
| 13.11 | <i>AO1 actual value</i> | Displays the value of AO1 in mA. This parameter is read-only. | - |
| | 0.000...22.000 mA | Value of AO1. | 1000 = 1 mA |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------|--|-------------------------|
| 13.12 | <i>AO1 source</i> | Selects a signal to be connected to analog output AO1. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor. | <i>Motor speed used</i> |
| | Zero | None. | 0 |
| | Motor speed used | 01.01 Motor speed used (page 105). | 1 |
| | Output frequency | 01.06 Output frequency (page 105). | 3 |
| | Motor current | 01.07 Motor current (page 105). | 4 |
| | Motor torque | 01.10 Motor torque (page 105). | 6 |
| | DC voltage | 01.11 DC voltage (page 105). | 7 |
| | Power inu out | 01.14 Output power (page 106). | 8 |
| | Speed ref ramp in | 23.01 Speed ref ramp input (page 203). | 10 |
| | Speed ref ramp out | 23.02 Speed ref ramp output (page 204). | 11 |
| | Speed ref used | 24.01 Used speed reference (page 210). | 12 |
| | Torq ref used | 26.02 Torque reference used | 13 |
| | Freq ref used | 28.02 Frequency ref ramp output (page 226). | 14 |
| | Force Pt100 excitation | The output is used to feed an excitation current to 1...3 Pt100 sensors. See section Motor thermal protection (page 83). | 20 |
| | Force KTY84 excitation | The output is used to feed an excitation current to a KTY84 sensor. See section Motor thermal protection (page 83). | 21 |
| | Force PTC excitation | The output is used to feed an excitation current to 1...3 PTC sensors. See section Motor thermal protection (page 83). | 22 |
| | Force Pt1000 excitation | The output is used to feed an excitation current to 1...3 Pt1000 sensors. See section Motor thermal protection (page 83). | 23 |
| | AO1 data storage | 13.91 AO1 data storage (page 149). | 37 |
| | AO2 data storage | 13.92 AO2 data storage (page 149). | 38 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------|---|----------------|
| 13.16 | AO1 filter time | Defines the filtering time constant for analog output AO1.  $O = I \times (1 - e^{-t/T})$ <p> I = filter input (step) O = filter output t = time T = filter time constant </p> | 0.100 s |
| | 0.000...30.000 s | Filter time constant. | 1000 = 1 s |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------|---|---|
| 13.17 | <i>AO1 source min</i> | <p>Defines the real minimum value of the signal (selected by parameter 13.12 AO1 source) that corresponds to the minimum required AO1 output value (defined by parameter 13.19 AO1 out at AO1 src min).</p>  <p>Programming 13.17 as the maximum value and 13.18 as the minimum value inverts the output.</p>  | 0.0 |
| | -32768.0...32767.0 | Real signal value corresponding to minimum AO1 output value. | 1 = 1 |
| 13.18 | <i>AO1 source max</i> | Defines the real maximum value of the signal (selected by parameter 13.12 AO1 source) that corresponds to the maximum required AO1 output value (defined by parameter 13.20 AO1 out at AO1 src max). See parameter 13.17 AO1 source min . | 1500.0; 1800.0 (95.20 b0) |
| | -32768.0...32767.0 | Real signal value corresponding to maximum AO1 output value. | 1 = 1 |
| 13.19 | <i>AO1 out at AO1 src min</i> | Defines the minimum output value for analog output AO1. See also drawing at parameter 13.17 AO1 source min . | 0.000 mA |
| | 0.000...22.000 mA | Minimum AO1 output value. | 1000 = 1 mA |
| 13.20 | <i>AO1 out at AO1 src max</i> | Defines the maximum output value for analog output AO1. See also drawing at parameter 13.17 AO1 source min . | 20.000 mA |
| | 0.000...22.000 mA | Maximum AO1 output value. | 1000 = 1 mA |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------------|---|-------------------------------|
| 13.21 | AO2 actual value | Displays the value of AO2 in mA. This parameter is read-only. | - |
| | 0.000...22.000 mA | Value of AO2. | 1000 = 1 mA |
| 13.22 | AO2 source | Selects a signal to be connected to analog output AO2. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor. For the selections, see parameter 13.12 AO1 source . | Motor current |
| 13.26 | AO2 filter time | Defines the filtering time constant for analog output AO2. See parameter 13.16 AO1 filter time . | 0.100 s |
| | 0.000...30.000 s | Filter time constant. | 1000 = 1 s |
| 13.27 | AO2 source min | <p>Defines the real minimum value of the signal (selected by parameter 13.22 AO2 source) that corresponds to the minimum required AO2 output value (defined by parameter 13.29 AO2 out at AO2 src min).</p>  <p>Programming 13.27 as the maximum value and 13.28 as the minimum value inverts the output.</p> | 0.0 |
| | -32768.0...32767.0 | Real signal value corresponding to minimum AO2 output value. | 1 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|----------------------------------|-------------------------------|---|----------------|
| 13.28 | <i>AO2 source max</i> | Defines the real maximum value of the signal (selected by parameter <i>13.22 AO2 source</i>) that corresponds to the maximum required AO2 output value (defined by parameter <i>13.30 AO2 out at AO2 src max</i>). See parameter <i>13.27 AO2 source min</i> . | 100.0 |
| | -32768.0...32767.0 | Real signal value corresponding to maximum AO2 output value. | 1 = 1 |
| 13.29 | <i>AO2 out at AO2 src min</i> | Defines the minimum output value for analog output AO2. See also drawing at parameter <i>13.27 AO2 source min</i> . | 0.000 mA |
| | 0.000...22.000 mA | Minimum AO2 output value. | 1000 = 1 mA |
| 13.30 | <i>AO2 out at AO2 src max</i> | Defines the maximum output value for analog output AO2. See also drawing at parameter <i>13.27 AO2 source min</i> . | 20.000 mA |
| | 0.000...22.000 mA | Maximum AO2 output value. | 1000 = 1 mA |
| 13.91 | <i>AO1 data storage</i> | Storage parameter for controlling analog output AO1 eg. through fieldbus. In <i>13.12 AO1 source</i> , select <i>AO1 data storage</i> . Then set this parameter as the target of the incoming value data. With the embedded fieldbus interface, simply set the target selection parameter of that particular data to <i>AO1 data storage</i> . | 0.00 |
| | -327.68 ... 327.67 | Storage parameter for AO1. | 100 = 1 |
| 13.92 | <i>AO2 data storage</i> | Storage parameter for controlling analog output AO2 eg. through fieldbus. In <i>13.22 AO2 source</i> , select <i>AO2 data storage</i> . Then set this parameter as the target of the incoming value data. With the embedded fieldbus interface, simply set the target selection parameter of that particular data to <i>AO2 data storage</i> . | 0.00 |
| | -327.68 ... 327.67 | Storage parameter for AO2. | 100 = 1 |
| 14 I/O extension module 1 | | Configuration of I/O extension module 1. See also section <i>Programmable I/O extensions</i> (page 56). Note: The contents of the parameter group vary according to the selected I/O extension module type. | |
| 14.01 | <i>Module 1 type</i> | Activates (and specifies the type of) I/O extension module 1. | <i>None</i> |
| | None | Inactive. | 0 |
| | FIO-01 | FIO-01. | 1 |
| | FIO-11 | FIO-11. | 2 |
| | FAIO-01 | FAIO-01. | 4 |
| 14.02 | <i>Module 1 location</i> | Specifies the slot (1...3) on the control unit of the drive into which the I/O extension module is installed. Alternatively, specifies the node ID of the slot on an FEA-0x extension adapter. | <i>Slot 1</i> |
| | Slot 1 | Slot 1. | 1 |
| | Slot 2 | Slot 2. | 2 |
| | Slot 3 | Slot 3. | 3 |
| | 4...254 | Node ID of the slot on the FEA-0x extension adapter. | 1 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------|--|----------------------|
| 14.03 | <i>Module 1 status</i> | Displays the status of I/O extension module 1. | <i>No option</i> |
| | No option | No module detected in the specified slot. | 0 |
| | No communication | A module has been detected but cannot be communicated with. | 1 |
| | Unknown | The module type is unknown. | 2 |
| | FIO-01 | An FIO-01 module has been detected and is active. | 15 |
| | FIO-11 | An FIO-11 module has been detected and is active. | 20 |
| | FAIO-01 | An FAIO-01 module has been detected and is active. | 24 |
| 14.05 | <i>DIO status</i> | <i>(Visible when 14.01 Module 1 type = FIO-01 or FIO-11)</i> Displays the status of the digital input/outputs on the extension module. The activation/deactivation delays (if any are specified) are ignored. A filtering time (for input mode) can be defined by parameter <i>10.51 DI filter time</i> . Bit 0 indicates the status of DIO1. Note: The number of active bits in this parameter depends on the number of digital input/outputs on the extension module. Example: 1001b = DIO1 and DIO4 are on, remainder are off. This parameter is read-only. | - |
| | 0000b...1111b | Status of digital input/outputs. | 1 = 1 |
| 14.06 | <i>DIO delayed status</i> | <i>(Visible when 14.01 Module 1 type = FIO-01 or FIO-11)</i> Displays the delayed status of the digital input/outputs on the extension module. This word is updated only after activation/deactivation delays (if any are specified). Bit 0 indicates the status of DIO1. Note: The number of active bits in this parameter depends on the number of digital input/outputs on the extension module. Example: 00001001b = DIO1 and DIO4 are on, remainder are off. This parameter is read-only. | - |
| | 0000b...1111b | Delayed status of digital input/outputs. | 1 = 1 |
| 14.08 | <i>DIO filter time</i> | <i>(Visible when 14.01 Module 1 type = FIO-01 or FIO-11)</i> Defines a filtering time for parameter 14.05 DIO status. The filtering time will only affect the DIOs that are in input mode. | 10.0 ms |
| | 0.8...100.0 ms | Filtering time for <i>14.05</i> . | 10 = 1 ms |
| 14.09 | <i>DIO1 function</i> | <i>(Visible when 14.01 Module 1 type = FIO-01 or FIO-11)</i> Selects whether DIO1 of the extension module is used as a digital input or output. | <i>Input</i> |
| | Output | DIO1 is used as a digital output. | 0 |
| | Input | DIO1 is used as a digital input. | 1 |
| 14.11 | <i>DIO1 output source</i> | <i>(Visible when 14.01 Module 1 type = FIO-01 or FIO-11)</i> Selects a drive signal to be connected to digital input/output DIO1 of the extension module when parameter <i>14.09 DIO1 function</i> is set to <i>Output</i> . | <i>Not energized</i> |
| | Not energized | Output is not energized. | 0 |
| | Energized | Output is energized. | 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----|--------------------------|--|----------------|
| | Ready run | Bit 1 of 06.11 Main status word (see page 117). | 2 |
| | Enabled | Bit 0 of 06.16 Drive status word 1 (see page 117). | 4 |
| | Started | Bit 5 of 06.16 Drive status word 1 (see page 117). | 5 |
| | Magnetized | Bit 1 of 06.17 Drive status word 2 (see page 118). | 6 |
| | Running | Bit 6 of 06.16 Drive status word 1 (see page 117). | 7 |
| | Ready ref | Bit 2 of 06.11 Main status word (see page 117). | 8 |
| | At setpoint | Bit 8 of 06.11 Main status word (see page 117). | 9 |
| | Reverse | Bit 2 of 06.19 Speed control status word (see page 120). | 10 |
| | Zero speed | Bit 0 of 06.19 Speed control status word (see page 120). | 11 |
| | Above limit | Bit 10 of 06.17 Drive status word 2 (see page 118). | 12 |
| | Warning | Bit 7 of 06.11 Main status word (see page 117). | 13 |
| | Fault | Bit 3 of 06.11 Main status word (see page 117). | 14 |
| | Fault (-1) | Inverted bit 3 of 06.11 Main status word (see page 117). | 15 |
| | Open brake command | Bit 0 of 44.01 Brake control status | 22 |
| | Ext2 active | Bit 11 of 06.16 Drive status word 1 (see page 117). | 23 |
| | Remote control | Bit 9 of 06.11 Main status word (see page 117). | 24 |
| | Supervision 1 | Bit 0 of 32.01 Supervision status (see page 251). | 33 |
| | Supervision 2 | Bit 1 of 32.01 Supervision status (see page 251). | 34 |
| | Supervision 3 | Bit 2 of 32.01 Supervision status (see page 251). | 35 |
| | RO/DIO control word bit0 | Bit 0 of 10.99 RO/DIO control word (see page 134). | 40 |
| | RO/DIO control word bit1 | Bit 1 of 10.99 RO/DIO control word (see page 134). | 41 |
| | RO/DIO control word bit2 | Bit 2 of 10.99 RO/DIO control word (see page 134). | 42 |
| | RO/DIO control word bit8 | Bit 8 of 10.99 RO/DIO control word (see page 134). | 43 |
| | RO/DIO control word bit9 | Bit 9 of 10.99 RO/DIO control word (see page 134). | 44 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|--|----------------------|
| 14.12 | <i>DIO1 ON delay</i> | (Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the activation delay for digital input/output DIO1. | 0.0 s |
| | <p>*DIO status</p> <p>**Delayed DIO status</p> <p>Time</p> <p>t_{On} t_{Off} t_{On} t_{Off}</p> <p>t_{On} = 14.12 DIO1 ON delay t_{Off} = 14.13 DIO1 OFF delay</p> <p>*Electrical status of DIO (in input mode) or status of selected source (in output mode). Indicated by 14.05 DIO status. **Indicated by 14.06 DIO delayed status.</p> | | |
| | 0.0...3000.0 s | Activation delay for DIO1. | 10 = 1 s |
| 14.13 | <i>DIO1 OFF delay</i> | (Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the deactivation delay for digital input/output DIO1. See parameter 14.12 DIO1 ON delay. | 0.0 s |
| | 0.0...3000.0 s | Deactivation delay for DIO1. | 10 = 1 s |
| 14.14 | <i>DIO2 function</i> | (Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Selects whether DIO2 of the extension module is used as a digital input or output. | <i>Input</i> |
| | Output | DIO2 is used as a digital output. | 0 |
| | Input | DIO2 is used as a digital input. | 1 |
| 14.15 | <i>DIO2 filter gain</i> | (Visible when 14.01 Module 1 type = FIO-11) Determines a filtering time for DIO2 when it is used as an input. | <i>7.5 us</i> |
| | 7.5 us | 7.5 microseconds. | 0 |
| | 195 us | 195 microseconds. | 1 |
| | 780 us | 780 microseconds. | 2 |
| | 4.680 ms | 4.680 milliseconds. | 3 |
| 14.16 | <i>DIO2 output source</i> | (Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Selects a drive signal to be connected to digital input/output DIO2 when parameter 14.14 DIO2 function is set to <i>Output</i> . For the available selections, see parameter 14.11 DIO1 output source. | <i>Not energized</i> |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---|---|----------------|
| 14.17 | <i>DIO2 ON delay</i> | (Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the activation delay for digital input/output DIO2. | 0.0 s |
| | *DIO status | | |
| | **Delayed DIO status | | |
| | t_{On} = 14.17 DIO2 ON delay t_{Off} = 14.18 DIO2 OFF delay | | |
| | *Electrical status of DIO (in input mode) or status of selected source (in output mode). Indicated by 14.05 DIO status. **Indicated by 14.06 DIO delayed status. | | |
| | 0.0...3000.0 s | Activation delay for DIO2. | 10 = 1 s |
| 14.18 | <i>DIO2 OFF delay</i> | (Visible when 14.01 Module 1 type = FIO-01 or FIO-11) Defines the deactivation delay for digital input/output DIO2. See parameter 14.17 DIO2 ON delay. | 0.0 s |
| | 0.0...3000.0 s | Deactivation delay for DIO2. | 10 = 1 s |
| 14.19 | <i>DIO3 function</i> | (Visible when 14.01 Module 1 type = FIO-01) Selects whether DIO3 of the extension module is used as a digital input or output. | Input |
| | Output | DIO3 is used as a digital output. | 0 |
| | Input | DIO3 is used as a digital input. | 1 |
| 14.19 | <i>AI supervision function</i> | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Selects how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input. The inputs and the limits to be observed are selected by parameter 14.20 AI supervision selection. | No action |
| | No action | No action taken. | 0 |
| | Fault | Drive trips on 80A0 AI supervision. | 1 |
| | Warning | Drive generates an A8A0 AI supervision warning. | 2 |
| | Last speed | Drive generates a warning (A8A0 AI supervision) and freezes the speed (or frequency) to the level the drive was operating at. The speed/frequency is determined on the basis of actual speed using 850 ms low-pass filtering. WARNING! Make sure that it is safe to continue operation in case of a communication break. | 3 |
| | Speed ref safe | Drive generates a warning (A8A0 AI supervision) and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). WARNING! Make sure that it is safe to continue operation in case of a communication break. | 4 |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---------------------------------|--|----------------------|-----|------|-------------|---|-----------|--|---|-----------|--|---|-----------|--|---|-----------|--|---|-----------|--|---|-----------|--|--------|----------|--|
| 14.20 | <i>AI supervision selection</i> | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Specifies the analog input limits to be supervised. See parameter 14.19 <i>AI supervision function</i> . Note: The number of active bits in this parameters depends on the number of inputs on the extension module. | 0000 0000b | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>AI1 < MIN</td> <td>1 = Minimum limit supervision of AI1 active.</td> </tr> <tr> <td>1</td> <td>AI1 > MAX</td> <td>1 = Maximum limit supervision of AI1 active.</td> </tr> <tr> <td>2</td> <td>AI2 < MIN</td> <td>1 = Minimum limit supervision of AI2 active.</td> </tr> <tr> <td>3</td> <td>AI2 > MAX</td> <td>1 = Maximum limit supervision of AI2 active.</td> </tr> <tr> <td>4</td> <td>AI3 < MIN</td> <td>1 = Minimum limit supervision of AI3 active (FIO-11 only).</td> </tr> <tr> <td>5</td> <td>AI3 > MAX</td> <td>1 = Maximum limit supervision of AI3 active (FIO-11 only).</td> </tr> <tr> <td>6...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | | | | Bit | Name | Description | 0 | AI1 < MIN | 1 = Minimum limit supervision of AI1 active. | 1 | AI1 > MAX | 1 = Maximum limit supervision of AI1 active. | 2 | AI2 < MIN | 1 = Minimum limit supervision of AI2 active. | 3 | AI2 > MAX | 1 = Maximum limit supervision of AI2 active. | 4 | AI3 < MIN | 1 = Minimum limit supervision of AI3 active (FIO-11 only). | 5 | AI3 > MAX | 1 = Maximum limit supervision of AI3 active (FIO-11 only). | 6...15 | Reserved | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | AI1 < MIN | 1 = Minimum limit supervision of AI1 active. | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | AI1 > MAX | 1 = Maximum limit supervision of AI1 active. | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | AI2 < MIN | 1 = Minimum limit supervision of AI2 active. | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | AI2 > MAX | 1 = Maximum limit supervision of AI2 active. | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | AI3 < MIN | 1 = Minimum limit supervision of AI3 active (FIO-11 only). | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | AI3 > MAX | 1 = Maximum limit supervision of AI3 active (FIO-11 only). | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000 0000b...0011 1111b | Activation of analog input supervision. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | |
| 14.21 | <i>DIO3 output source</i> | (Visible when 14.01 Module 1 type = FIO-01) Selects a drive signal to be connected to digital input/output DIO3 when parameter 14.19 <i>DIO3 function</i> is set to <i>Output</i> . For the available selections, see parameter 14.11 <i>DIO1 output source</i> . | <i>Not energized</i> | | | | | | | | | | | | | | | | | | | | | | | | |
| 14.21 | <i>AI tune</i> | (Visible when 14.01 Module 1 type = FIO-01 or FAIO-01) Triggers the analog input tuning function, which enables the use of actual measurements as the minimum and maximum input values instead of potentially inaccurate estimates. Apply the minimum or maximum signal to the input and select the appropriate tuning function. See also the drawing at parameter 14.35 <i>AI1 scaled at AI1 min</i> . | <i>No action</i> | | | | | | | | | | | | | | | | | | | | | | | | |
| | No action | Tuning action completed or no action has been requested. The parameter automatically reverts to this value after any tuning action. | 0 | | | | | | | | | | | | | | | | | | | | | | | | |
| | AI1 min tune | The measured value of AI1 is set as the minimum value of AI1 into parameter 14.33 <i>AI1 min</i> . | 1 | | | | | | | | | | | | | | | | | | | | | | | | |
| | AI1 max tune | The measured value of AI1 is set as the maximum value of AI1 into parameter 14.34 <i>AI1 max</i> . | 2 | | | | | | | | | | | | | | | | | | | | | | | | |
| | AI2 min tune | The measured value of AI2 is set as the minimum value of AI2 into parameter 14.48 <i>AI2 min</i> . | 3 | | | | | | | | | | | | | | | | | | | | | | | | |
| | AI2 max tune | The measured value of AI2 is set as the maximum value of AI2 into parameter 14.49 <i>AI2 max</i> . | 4 | | | | | | | | | | | | | | | | | | | | | | | | |
| | AI3 min tune | (Visible when 14.01 Module 1 type = FIO-11) The measured value of AI3 is set as the minimum value of AI3 into parameter 14.63 <i>AI3 min</i> . | 5 | | | | | | | | | | | | | | | | | | | | | | | | |
| | AI3 max tune | (Visible when 14.01 Module 1 type = FIO-11) The measured value of AI3 is set as the maximum value of AI3 into parameter 14.64 <i>AI3 max</i> . | 6 | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | |
|--------|---|---|----------------|-------|---|---|---|---|---|---|--------|-----------|--|
| 14.22 | <i>DIO3 ON delay</i> | (Visible when 14.01 Module 1 type = FIO-01) Defines the activation delay for digital input/output DIO3. | 0.0 s | | | | | | | | | | |
| | *DIO status | | | | | | | | | | | | |
| | **Delayed DIO status | | | | | | | | | | | | |
| | t_{On} = 14.22 DIO3 ON delay t_{Off} = 14.23 DIO3 OFF delay | | | | | | | | | | | | |
| | *Electrical status of DIO (in input mode) or status of selected source (in output mode). Indicated by 14.05 DIO status. **Indicated by 14.06 DIO delayed status. | | | | | | | | | | | | |
| | 0.0...3000.0 s | Activation delay for DIO3. | 10 = 1 s | | | | | | | | | | |
| 14.22 | <i>AI force selection</i> | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) The true readings of the analog inputs can be overridden for eg. testing purposes. A forced value parameter is provided for each analog input, and its value is applied whenever the corresponding bit in this parameter is 1. | 0000b | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 = Force AI1 to value of parameter 14.28 AI1 force data.</td> </tr> <tr> <td>1</td> <td>1 = Force AI2 to value of parameter 14.43 AI2 force data.</td> </tr> <tr> <td>2</td> <td>1 = Force AI3 to value of parameter 14.58 AI3 force data (FIO-11 only).</td> </tr> <tr> <td>3...15</td> <td>Reserved.</td> </tr> </tbody> </table> | Bit | Value | 0 | 1 = Force AI1 to value of parameter 14.28 AI1 force data. | 1 | 1 = Force AI2 to value of parameter 14.43 AI2 force data. | 2 | 1 = Force AI3 to value of parameter 14.58 AI3 force data (FIO-11 only). | 3...15 | Reserved. | |
| Bit | Value | | | | | | | | | | | | |
| 0 | 1 = Force AI1 to value of parameter 14.28 AI1 force data. | | | | | | | | | | | | |
| 1 | 1 = Force AI2 to value of parameter 14.43 AI2 force data. | | | | | | | | | | | | |
| 2 | 1 = Force AI3 to value of parameter 14.58 AI3 force data (FIO-11 only). | | | | | | | | | | | | |
| 3...15 | Reserved. | | | | | | | | | | | | |
| | 0000b ...0111b | Forced values selector for analog inputs. | 1 = 1 | | | | | | | | | | |
| 14.23 | <i>DIO3 OFF delay</i> | (Visible when 14.01 Module 1 type = FIO-01) Defines the deactivation delay for digital input/output DIO3. See parameter 14.22 DIO3 ON delay. | 0.0 s | | | | | | | | | | |
| | 0.0...3000.0 s | Deactivation delay for DIO3. | 10 = 1 s | | | | | | | | | | |
| 14.24 | <i>DIO4 function</i> | (Visible when 14.01 Module 1 type = FIO-01) Selects whether DIO4 of the extension module is used as a digital input or output. | Input | | | | | | | | | | |
| | Output | DIO4 is used as a digital output. | 0 | | | | | | | | | | |
| | Input | DIO4 is used as a digital input. | 1 | | | | | | | | | | |
| 14.26 | <i>DIO4 output source</i> | (Visible when 14.01 Module 1 type = FIO-01) Selects a drive signal to be connected to digital input/output DIO4 when parameter 14.24 DIO4 function is set to Output. For the available selections, see parameter 14.11 DIO1 output source. | Not energized | | | | | | | | | | |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|---|---------------------|
| 14.26 | <i>AI1 actual value</i> | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays the value of analog input AI1 in mA or V (depending on whether the input is set to current or voltage). This parameter is read-only. | - |
| | -22.000 ...22.000 mA or V | Value of analog input AI1. | 1000 = 1 mA or V |
| 14.27 | <i>DIO4 ON delay</i> | (Visible when 14.01 Module 1 type = FIO-01) Defines the activation delay for digital input/output DIO4. | 0.0 s |
| | <p>*DIO status</p> <p>**Delayed DIO status</p> <p>Time</p> <p>t_{On} t_{Off} t_{On} t_{Off}</p> <p>t_{On} = 14.27 DIO4 ON delay t_{Off} = 14.28 DIO4 OFF delay</p> <p>*Electrical status of DIO (in input mode) or status of selected source (in output mode). Indicated by 14.05 DIO status. **Indicated by 14.06 DIO delayed status.</p> | | |
| | 0.0...3000.0 s | Activation delay for DIO4. | 10 = 1 s |
| 14.27 | <i>AI1 scaled value</i> | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays the value of analog input AI1 after scaling. See parameter 14.35 AI1 scaled at AI1 min. This parameter is read-only. | - |
| | -32768.000 ...32767.000 | Scaled value of analog input AI1. | 1 = 1 |
| 14.28 | <i>DIO4 OFF delay</i> | (Visible when 14.01 Module 1 type = FIO-01) Defines the deactivation delay for digital input/output DIO4. See parameter 14.27 DIO4 ON delay. | 0.0 s |
| | 0.0...3000.0 s | Deactivation delay for DIO4. | 10 = 1 s |
| 14.28 | <i>AI1 force data</i> | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Forced value that can be used instead of the true reading of the input. See parameter 14.22 AI force selection. | 0.000 mA |
| | -22.000 ...22.000 mA or V | Forced value of analog input AI1. | 1000 = 1 mA or V |
| 14.29 | <i>AI1 HW switch pos</i> | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Shows the position of the hardware current/voltage selector on the I/O extension module. Note: The setting of the current/voltage selector must match the unit selection made in parameter 14.30 AI1 unit selection. I/O module reboot either by cycling the power or through parameter 96.08 Control board boot is required to validate any changes in the hardware settings. | - |
| | V | Volts. | 2 |
| | mA | Milliamperes. | 10 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------|---|----------------|
| 14.30 | <i>AI1 unit selection</i> | (Visible when <i>14.01 Module 1 type = FIO-11 or FAIO-01</i>) Selects the unit for readings and settings related to analog input AI1. Note: This setting must match the corresponding hardware setting on the I/O extension module (see the manual of the I/O extension module). The hardware setting is shown by parameter <i>14.29 AI1 HW switch pos.</i> I/O module reboot either by cycling the power or through parameter <i>96.08 Control board boot</i> is required to validate any changes in the hardware settings. | <i>mA</i> |
| | V | Volts. | 2 |
| | mA | Milliamperes. | 10 |
| 14.31 | <i>RO status</i> | (Visible when <i>14.01 Module 1 type = FIO-01</i>) Status of relay outputs on the I/O extension module. Example: 00000001b = RO1 is energized, RO2 is de-energized. | - |
| | 0000b...1111b | Status of relay outputs. | 1 = 1 |
| 14.31 | <i>AI1 filter gain</i> | (Visible when <i>14.01 Module 1 type = FIO-11 or FAIO-01</i>) Selects a hardware filtering time for AI1. See also parameter <i>14.32 AI1 filter time.</i> | <i>1 ms</i> |
| | No filtering | No filtering. | 0 |
| | 125 us | 125 microseconds. | 1 |
| | 250 us | 250 microseconds. | 2 |
| | 500 us | 500 microseconds. | 3 |
| | 1 ms | 1 millisecond. | 4 |
| | 2 ms | 2 milliseconds. | 5 |
| | 4 ms | 4 milliseconds. | 6 |
| | 7.9375 ms | 7.9375 milliseconds. | 7 |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-----------------------------|---|----------------------|
| 14.32 | <i>AI1 filter time</i> | <p>(Visible when <i>14.01 Module 1 type = FIO-11 or FAIO-01</i>) Defines the filter time constant for analog input AI1.</p>  <p style="text-align: center;">$O = I \times (1 - e^{-t/T})$</p> <p>I = filter input (step) O = filter output t = time T = filter time constant</p> <p>Note: The signal is also filtered due to the signal interface hardware. See parameter <i>14.31 AI1 filter gain</i>.</p> | 0.100 s |
| | 0.000...30.000 s | Filter time constant. | 1000 = 1 s |
| 14.33 | <i>AI1 min</i> | <p>(Visible when <i>14.01 Module 1 type = FIO-11 or FAIO-01</i>) Defines the minimum value for analog input AI1. See also parameter <i>14.21 AI tune</i>.</p> | 0.000 mA or V |
| | -22.000...22.000 mA or V | Minimum value of AI1. | 1000 = 1 mA or V |
| 14.34 | <i>RO1 source</i> | <p>(Visible when <i>14.01 Module 1 type = FIO-01</i>) Selects a drive signal to be connected to relay output RO1. For the available selections, see parameter <i>14.11 DIO1 output source</i>.</p> | <i>Not energized</i> |
| 14.34 | <i>AI1 max</i> | <p>(Visible when <i>14.01 Module 1 type = FIO-11 or FAIO-01</i>) Defines the maximum value for analog input AI1. See also parameter <i>14.21 AI tune</i>.</p> | 10.000 mA or V |
| | -22.000...22.000 mA or V | Maximum value of AI1. | 1000 = 1 mA or V |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------|---|----------------|
| 14.35 | RO1 ON delay | (Visible when 14.01 Module 1 type = FIO-01) Defines the activation delay for relay output RO1. | 0.0 s |
| | | <p>$t_{On} = 14.35$ RO1 ON delay $t_{Off} = 14.36$ RO1 OFF delay</p> | |
| | 0.0...3000.0 s | Activation delay for RO1. | 10 = 1 s |
| 14.35 | AI1 scaled at AI1 min | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value that corresponds to the minimum analog input AI1 value defined by parameter 14.33 AI1 min. | 0.000 |
| | | | |
| | -32768.000 ...32767.000 | Real value corresponding to minimum AI1 value. | 1 = 1 |
| 14.36 | RO1 OFF delay | (Visible when 14.01 Module 1 type = FIO-01) Defines the deactivation delay for relay output RO1. See parameter 14.35 RO1 ON delay. | 0.0 s |
| | 0.0...3000.0 s | Deactivation delay for RO1. | 10 = 1 s |
| 14.36 | AI1 scaled at AI1 max | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the real value that corresponds to the maximum analog input AI1 value defined by parameter 14.34 AI1 max. See the drawing at parameter 14.35 AI1 scaled at AI1 min. | 100.000 |
| | -32768.000 ...32767.000 | Real value corresponding to maximum AI1 value. | 1 = 1 |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------|---|------------------|
| 14.37 | RO2 source | (Visible when 14.01 Module 1 type = FIO-01) Selects a drive signal to be connected to relay output RO2. For the available selections, see parameter 14.11 DIO1 output source. | Not energized |
| 14.38 | RO2 ON delay | (Visible when 14.01 Module 1 type = FIO-01) Defines the activation delay for relay output RO2. | 0.0 s |
| | | <p> $t_{On} = 14.38$ RO2 ON delay $t_{Off} = 14.39$ RO2 OFF delay </p> | |
| | 0.0...3000.0 s | Activation delay for RO2. | 10 = 1 s |
| 14.39 | RO2 OFF delay | (Visible when 14.01 Module 1 type = FIO-01) Defines the deactivation delay for relay output RO2. See parameter 14.38 RO2 ON delay. | 0.0 s |
| | 0.0...3000.0 s | Deactivation delay for RO2. | 10 = 1 s |
| 14.41 | AI2 actual value | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays the value of analog input AI2 in mA or V (depending on whether the input is set to current or voltage). This parameter is read-only. | - |
| | -22.000...22.000 mA or V | Value of analog input AI2. | 1000 = 1 mA or V |
| 14.42 | AI2 scaled value | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Displays the value of analog input AI2 after scaling. See parameter 14.50 AI2 scaled at AI2 min. This parameter is read-only. | - |
| | -32768.000 ...32767.000 | Scaled value of analog input AI2. | 1 = 1 |
| 14.43 | AI2 force data | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Forced value that can be used instead of the true reading of the input. See parameter 14.22 AI force selection. | 0.000 mA |
| | -22.000...22.000 mA or V | Forced value of analog input AI2. | 1000 = 1 mA or V |
| 14.44 | AI2 HW switch pos | (Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Shows the position of the hardware current/voltage selector on the I/O extension module. Note: The setting of the current/voltage selector must match the unit selection made in parameter 14.45 AI2 unit selection. I/O module reboot either by cycling the power or through parameter 96.08 Control board boot is required to validate any changes in the hardware settings. | - |
| | V | Volts. | 2 |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------|---|----------------|
| | mA | Milliamperes. | 10 |
| 14.45 | <i>AI2 unit selection</i> | (Visible when <i>14.01 Module 1 type = FIO-11 or FAIO-01</i>) Selects the unit for readings and settings related to analog input AI2. Note: This setting must match the corresponding hardware setting on the I/O extension module (see the manual of the I/O extension module). The hardware setting is shown by parameter <i>14.44 AI2 HW switch pos.</i> I/O module reboot either by cycling the power or through parameter <i>96.08 Control board boot</i> is required to validate any changes in the hardware settings. | <i>mA</i> |
| | V | Volts. | 2 |
| | mA | Milliamperes. | 10 |
| 14.46 | <i>AI2 filter gain</i> | (Visible when <i>14.01 Module 1 type = FIO-11 or FAIO-01</i>) Selects a hardware filtering time for AI2. See also parameter <i>14.47 AI2 filter time.</i> | <i>1 ms</i> |
| | No filtering | No filtering. | 0 |
| | 125 us | 125 microseconds. | 1 |
| | 250 us | 250 microseconds. | 2 |
| | 500 us | 500 microseconds. | 3 |
| | 1 ms | 1 millisecond. | 4 |
| | 2 ms | 2 milliseconds. | 5 |
| | 4 ms | 4 milliseconds. | 6 |
| | 7.9375 ms | 7.9375 milliseconds. | 7 |
| 14.47 | <i>AI2 filter time</i> | (Visible when <i>14.01 Module 1 type = FIO-11 or FAIO-01</i>) Defines the filter time constant for analog input AI2.  $O = I \times (1 - e^{-t/T})$ I = filter input (step) O = filter output t = time T = filter time constant Note: The signal is also filtered due to the signal interface hardware. See parameter <i>14.46 AI2 filter gain.</i> | 0.100 s |
| | 0.000...30.000 s | Filter time constant. | 1000 = 1 s |

162 Parameters


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------------|--|---------------------|
| 14.48 | <i>AI2 min</i> | (Visible when <i>14.01 Module 1 type = FIO-11 or FAIO-01</i>) Defines the minimum value for analog input AI2. See also parameter <i>14.21 AI tune</i> . | 0.000 mA or V |
| | -22.000...22.000 mA or V | Minimum value of AI2. | 1000 = 1 mA or V |
| 14.49 | <i>AI2 max</i> | (Visible when <i>14.01 Module 1 type = FIO-11 or FAIO-01</i>) Defines the maximum value for analog input AI2. See also parameter <i>14.21 AI tune</i> . | 10.000 mA or V |
| | -22.000...22.000 mA or V | Maximum value of AI2. | 1000 = 1 mA or V |
| 14.50 | <i>AI2 scaled at AI2 min</i> | (Visible when <i>14.01 Module 1 type = FIO-11 or FAIO-01</i>) Defines the real value that corresponds to the minimum analog input AI2 value defined by parameter <i>14.48 AI2 min</i> .  | 0.000 |
| | -32768.000 ...32767.000 | Real value corresponding to minimum AI2 value. | 1 = 1 |
| 14.51 | <i>AI2 scaled at AI2 max</i> | (Visible when <i>14.01 Module 1 type = FIO-11 or FAIO-01</i>) Defines the real value that corresponds to the maximum analog input AI2 value defined by parameter <i>14.49 AI2 max</i> . See the drawing at parameter <i>14.50 AI2 scaled at AI2 min</i> . | 100.000 |
| | -32768.000 ...32767.000 | Real value corresponding to maximum AI2 value. | 1 = 1 |
| 14.56 | <i>AI3 actual value</i> | (Visible when <i>14.01 Module 1 type = FIO-11</i>) Displays the value of analog input AI3 in mA or V (depending on whether the input is set to current or voltage). This parameter is read-only. | - |
| | -22.000...22.000 mA or V | Value of analog input AI3. | 1000 = 1 mA or V |
| 14.57 | <i>AI3 scaled value</i> | (Visible when <i>14.01 Module 1 type = FIO-11</i>) Displays the value of analog input AI3 after scaling. See parameter <i>14.65 AI3 scaled at AI3 min</i> . This parameter is read-only. | - |
| | -32768.000 ...32767.000 | Scaled value of analog input AI3. | 1 = 1 |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-----------------------------|---|---------------------|
| 14.58 | <i>AI3 force data</i> | (Visible when <i>14.01 Module 1 type = FIO-11</i>) Forced value that can be used instead of the true reading of the input. See parameter <i>14.22 AI force selection</i> . | 0.000 mA |
| | -22.000...22.000 mA or V | Forced value of analog input AI3. | 1000 = 1 mA or V |
| 14.59 | <i>AI3 HW switch pos</i> | (Visible when <i>14.01 Module 1 type = FIO-11</i>) Shows the position of the hardware current/voltage selector on the I/O extension module. Note: The setting of the current/voltage selector must match the unit selection made in parameter <i>14.60 AI3 unit selection</i> . I/O module reboot either by cycling the power or through parameter <i>96.08 Control board boot</i> is required to validate any changes in the hardware settings. | - |
| | V | Volts. | 2 |
| | mA | Milliamperes. | 10 |
| 14.60 | <i>AI3 unit selection</i> | (Visible when <i>14.01 Module 1 type = FIO-11</i>) Selects the unit for readings and settings related to analog input AI3. Note: This setting must match the corresponding hardware setting on the I/O extension module (see the manual of the I/O extension module). The hardware setting is shown by parameter <i>14.59 AI3 HW switch pos</i> . I/O module reboot either by cycling the power or through parameter <i>96.08 Control board boot</i> is required to validate any changes in the hardware settings. | <i>mA</i> |
| | V | Volts. | 2 |
| | mA | Milliamperes. | 10 |
| 14.61 | <i>AI3 filter gain</i> | (Visible when <i>14.01 Module 1 type = FIO-11</i>) Selects a hardware filtering time for AI3. See also parameter <i>14.62 AI3 filter time</i> . | <i>1 ms</i> |
| | No filtering | No filtering. | 0 |
| | 125 us | 125 microseconds. | 1 |
| | 250 us | 250 microseconds. | 2 |
| | 500 us | 500 microseconds. | 3 |
| | 1 ms | 1 millisecond. | 4 |
| | 2 ms | 2 milliseconds. | 5 |
| | 4 ms | 4 milliseconds. | 6 |
| | 7.9375 ms | 7.9375 milliseconds. | 7 |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-----------------------------|--|---------------------|
| 14.62 | <i>AI3 filter time</i> | <p>(Visible when <i>14.01 Module 1 type = FIO-11</i>) Defines the filter time constant for analog input AI3.</p>  <p style="text-align: center;"> $O = I \times (1 - e^{-t/T})$ </p> <p> I = filter input (step) O = filter output t = time T = filter time constant </p> <p>Note: The signal is also filtered due to the signal interface hardware. See parameter <i>14.61 AI3 filter gain</i>.</p> | 0.100 s |
| | 0.000...30.000 s | Filter time constant. | 1000 = 1 s |
| 14.63 | <i>AI3 min</i> | <p>(Visible when <i>14.01 Module 1 type = FIO-11</i>) Defines the minimum value for analog input AI3. See also parameter <i>14.21 AI tune</i>.</p> | 0.000 mA or V |
| | -22.000...22.000 mA or V | Minimum value of AI3. | 1000 = 1 mA or V |
| 14.64 | <i>AI3 max</i> | <p>(Visible when <i>14.01 Module 1 type = FIO-11</i>) Defines the maximum value for analog input AI3. See also parameter <i>14.21 AI tune</i>.</p> | 10.000 mA or V |
| | -22.000...22.000 mA or V | Maximum value of AI3. | 1000 = 1 mA or V |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | |
|--------|---|---|----------------|---|---|---|---|--------|-----------|--|--|
| 14.65 | <i>AI3 scaled at AI3 min</i> | (Visible when <i>14.01 Module 1 type = FIO-11</i>) Defines the real value that corresponds to the minimum analog input AI3 value defined by parameter <i>14.63 AI3 min</i> .  | 0.000 | | | | | | | | |
| | -32768.000 ...32767.000 | Real value corresponding to minimum AI3 value. | 1 = 1 | | | | | | | | |
| 14.66 | <i>AI3 scaled at AI3 max</i> | (Visible when <i>14.01 Module 1 type = FIO-11</i>) Defines the real value that corresponds to the maximum analog input AI3 value defined by parameter <i>14.64 AI3 max</i> . See the drawing at parameter <i>14.65 AI3 scaled at AI3 min</i> . | 100.000 | | | | | | | | |
| | -32768.000 ...32767.000 | Real value corresponding to maximum AI3 value. | 1 = 1 | | | | | | | | |
| 14.71 | <i>AO force selection</i> | (Visible when <i>14.01 Module 1 type = FIO-11</i> or <i>FAIO-01</i>) The value of the analog output can be overridden for eg. testing purposes. A forced value parameter (<i>14.78 AO1 force data</i>) is provided for the analog output, and its value is applied whenever the corresponding bit in this parameter is 1. | 00b | | | | | | | | |
| | <table border="1" data-bbox="217 1094 925 1201"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 = Force AO1 to value of parameter <i>14.78 AO1 force data</i>.</td> </tr> <tr> <td>1</td> <td>1 = Force AO2 to value of parameter <i>14.88 AO2 force data</i> (FAIO-01 only).</td> </tr> <tr> <td>3...15</td> <td>Reserved.</td> </tr> </tbody> </table> | Bit | Value | 0 | 1 = Force AO1 to value of parameter <i>14.78 AO1 force data</i> . | 1 | 1 = Force AO2 to value of parameter <i>14.88 AO2 force data</i> (FAIO-01 only). | 3...15 | Reserved. | | |
| Bit | Value | | | | | | | | | | |
| 0 | 1 = Force AO1 to value of parameter <i>14.78 AO1 force data</i> . | | | | | | | | | | |
| 1 | 1 = Force AO2 to value of parameter <i>14.88 AO2 force data</i> (FAIO-01 only). | | | | | | | | | | |
| 3...15 | Reserved. | | | | | | | | | | |
| | 00b...11b | Forced values selector for analog outputs. | 1 = 1 | | | | | | | | |
| 14.76 | <i>AO1 actual value</i> | (Visible when <i>14.01 Module 1 type = FIO-11</i> or <i>FAIO-01</i>) Displays the value of AO1 in mA. This parameter is read-only. | - | | | | | | | | |
| | 0.000...22.000 mA | Value of AO1. | 1000 = 1 mA | | | | | | | | |
| 14.77 | <i>AO1 source</i> | (Visible when <i>14.01 Module 1 type = FIO-11</i> or <i>FAIO-01</i>) Selects a signal to be connected to analog output AO1. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor. | <i>Zero</i> | | | | | | | | |
| | Zero | None. | 0 | | | | | | | | |


| No. | Name/Value | Description | Def/ FbEq16 |
|--------------|------------------------------|--|----------------|
| | Motor speed used | 01.01 Motor speed used (page 105). | 1 |
| | Output frequency | 01.06 Output frequency (page 105). | 3 |
| | Motor current | 01.07 Motor current (page 105). | 4 |
| | Motor torque | 01.10 Motor torque (page 105). | 6 |
| | DC voltage | 01.11 DC voltage (page 105). | 7 |
| | Power inu out | 01.14 Output power (page 106). | 8 |
| | Speed ref ramp in | 23.01 Speed ref ramp input (page 203). | 10 |
| | Speed ref ramp out | 23.02 Speed ref ramp output (page 204). | 11 |
| | Speed ref used | 24.01 Used speed reference (page 210). | 12 |
| | Torq ref used | 26.02 Torque reference used | 13 |
| | Freq ref used | 28.02 Frequency ref ramp output (page 226). | 14 |
| | Force PT100 excitation | The output is used to feed an excitation current to 1...3 Pt100 sensors. See section Motor thermal protection (page 83). | 20 |
| | Force KTY84 excitation | The output is used to feed an excitation current to a KTY84 sensor. See section Motor thermal protection (page 83). | 21 |
| | Force PTC excitation | The output is used to feed an excitation current to 1...3 PTC sensors. See section Motor thermal protection (page 83). | 22 |
| | Force Pt1000 excitation | The output is used to feed an excitation current to 1...3 Pt1000 sensors. See section Motor thermal protection (page 83). | 23 |
| | AO1 data storage | 13.91 AO1 data storage (page 149). | 37 |
| | AO2 data storage | 13.92 AO2 data storage (page 149). | 38 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 14.78 | <i>AO1 force data</i> | (Visible when 14.01 Module 1 type = <i>FIO-11</i> or <i>FAIO-01</i>) Forced value that can be used instead of the selected output signal. See parameter 14.71 AO force selection . | 0.000 mA |
| | 0.000...22.000 mA | Forced value of analog output AO1. | 1000 = 1 mA |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------|---|----------------|
| 14.79 | AO1 filter time | <p>(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01) Defines the filtering time constant for analog output AO1.</p>  <p>$O = I \times (1 - e^{-t/T})$</p> <p>I = filter input (step) O = filter output t = time T = filter time constant</p> | 0.100 s |
| | 0.000...30.000 s | Filter time constant. | 1000 = 1 s |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------|--|----------------|
| 14.80 | AO1 source min | <p>(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01)</p> <p>Defines the real value of the signal (selected by parameter 14.77 AO1 source) that corresponds to the minimum AO1 output value (defined by parameter 14.82 AO1 out at AO1 src min).</p>  <p>The figure contains two graphs. The top graph plots I_{AO1} (mA) on the y-axis against 'Signal (real) selected by par. 14.77' on the x-axis. The y-axis has values 4.82 and 4.83. The x-axis has values 14.80 and 14.81. The curve is constant at 4.82 mA for signals up to 14.80, then rises linearly to 4.83 mA at signal 14.81, and remains constant thereafter. The bottom graph plots I_{AO1} (mA) on the y-axis against 'Signal (real) selected by par. 14.77' on the x-axis. The y-axis has values 4.82 and 4.83. The x-axis has values 14.81 and 14.80. The curve is constant at 4.83 mA for signals up to 14.81, then falls linearly to 4.82 mA at signal 14.80, and remains constant thereafter.</p> | 0.0 |
| | -32768.0...32767.0 | Real signal value corresponding to minimum AO1 output value. | 1 = 1 |
| 14.81 | AO1 source max | <p>(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01)</p> <p>Defines the real value of the signal (selected by parameter 14.77 AO1 source) that corresponds to the maximum AO1 output value (defined by parameter 14.83 AO1 out at AO1 src max). See parameter 14.80 AO1 source min.</p> | 100.0 |
| | -32768.0...32767.0 | Real signal value corresponding to maximum AO1 output value. | 1 = 1 |
| 14.82 | AO1 out at AO1 src min | <p>(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01)</p> <p>Defines the minimum output value for analog output AO1. See also drawing at parameter 14.80 AO1 source min.</p> | 0.000 mA |
| | 0.000...22.000 mA | Minimum AO1 output value. | 1000 = 1 mA |
| 14.83 | AO1 out at AO1 src max | <p>(Visible when 14.01 Module 1 type = FIO-11 or FAIO-01)</p> <p>Defines the maximum output value for analog output AO1. See also drawing at parameter 14.80 AO1 source min.</p> | 10.000 mA |
| | 0.000...22.000 mA | Maximum AO1 output value. | 1000 = 1 mA |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------|---|----------------|
| 14.86 | AO2 actual value | (Visible when 14.01 Module 1 type = FAIO-01) Displays the value of AO2 in mA. This parameter is read-only. | - |
| | 0.000...22.000 mA | Value of AO2. | 1000 = 1 mA |
| 14.87 | AO2 source | (Visible when 14.01 Module 1 type = FAIO-01) Selects a signal to be connected to analog output AO2. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor. For the selections, see parameter 14.77 AO1 source. | Zero |
| 14.88 | AO2 force data | (Visible when 14.01 Module 1 type = FAIO-01) Forced value that can be used instead of the selected output signal. See parameter 14.71 AO force selection. | 0.000 mA |
| | 0.000...22.000 mA | Forced value of analog output AO2. | 1000 = 1 mA |
| 14.89 | AO2 filter time | (Visible when 14.01 Module 1 type = FAIO-01) Defines the filtering time constant for analog output AO2.  <p> $O = I \times (1 - e^{-t/T})$ </p> <p> I = filter input (step) O = filter output t = time T = filter time constant </p> | 0.100 s |
| | 0.000...30.000 s | Filter time constant. | 1000 = 1 s |

170 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------|---|----------------|
| 14.90 | AO2 source min | <p>(Visible when 14.01 Module 1 type = FAIO-01)</p> <p>Defines the real value of the signal (selected by parameter 14.87 AO2 source) that corresponds to the minimum AO2 output value (defined by parameter 14.92 AO2 out at AO2 src min).</p>  <p>The figure contains two graphs. The top graph plots I_{AO1} (mA) on the y-axis against 'Signal (real) selected by par. 14.87' on the x-axis. The y-axis has values 14.92 and 14.93. The x-axis has values 14.90 and 14.91. The graph shows a horizontal line at 14.92 mA for signals up to 14.90, then a linear increase to 14.93 mA at signal 14.91, and then a horizontal line at 14.93 mA for higher signals. The bottom graph plots I_{AO1} (mA) on the y-axis against 'Signal (real) selected by par. 14.87' on the x-axis. The y-axis has values 14.92 and 14.93. The x-axis has values 14.91 and 14.90. The graph shows a horizontal line at 14.93 mA for signals up to 14.91, then a linear decrease to 14.92 mA at signal 14.90, and then a horizontal line at 14.92 mA for lower signals.</p> | 0.0 |
| | -32768.0...32767.0 | Real signal value corresponding to minimum AO2 output value. | 1 = 1 |
| 14.91 | AO2 source max | <p>(Visible when 14.01 Module 1 type = k)</p> <p>Defines the real value of the signal (selected by parameter 14.87 AO2 source) that corresponds to the maximum AO2 output value (defined by parameter 14.93 AO2 out at AO2 src max). See parameter 14.90 AO2 source min.</p> | 100.0 |
| | -32768.0...32767.0 | Real signal value corresponding to maximum AO2 output value. | 1 = 1 |
| 14.92 | AO2 out at AO2 src min | <p>(Visible when 14.01 Module 1 type = FAIO-01)</p> <p>Defines the minimum output value for analog output AO2. See also drawing at parameter 14.90 AO2 source min.</p> | 0.000 mA |
| | 0.000...22.000 mA | Minimum AO2 output value. | 1000 = 1 mA |
| 14.93 | AO2 out at AO2 src max | <p>(Visible when 14.01 Module 1 type = FAIO-01)</p> <p>Defines the maximum output value for analog output AO2. See also drawing at parameter 14.90 AO2 source min.</p> | 10.000 mA |
| | 0.000...22.000 mA | Maximum AO2 output value. | 1000 = 1 mA |

| No. | Name/Value | Description | Def/ FbEq16 |
|---|--------------------------|---|----------------|
| 15 I/O extension module 2 | | | |
| Configuration of I/O extension module 2. See also section <i>Programmable I/O extensions</i> (page 56). Note: The contents of the parameter group vary according to the selected I/O extension module type. | | | |
| 15.01 | Module 2 type | See parameter 14.01 Module 1 type. | None |
| 15.02 | Module 2 location | See parameter 14.02 Module 1 location. | Slot 1 |
| 15.03 | Module 2 status | See parameter 14.03 Module 1 status. | No option |
| 15.05 | DIO status | (Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.05 DIO status. | - |
| 15.06 | DIO delayed status | (Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.06 DIO delayed status. | - |
| 15.08 | DIO filter time | (Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.08 DIO filter time. | 10.0 ms |
| 15.09 | DIO1 function | (Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.09 DIO1 function. | Input |
| 15.11 | DIO1 output source | (Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.11 DIO1 output source. | Not energized |
| 15.12 | DIO1 ON delay | (Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.12 DIO1 ON delay. | 0.0 s |
| 15.13 | DIO1 OFF delay | (Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.13 DIO1 OFF delay. | 0.0 s |
| 15.14 | DIO2 function | (Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.14 DIO2 function. | Input |
| 15.15 | DIO2 filter gain | (Visible when 15.01 Module 2 type = FIO-11) See parameter 14.15 DIO2 filter gain. | 7.5 us |
| 15.16 | DIO2 output source | (Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.16 DIO2 output source. | Not energized |
| 15.17 | DIO2 ON delay | (Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.17 DIO2 ON delay. | 0.0 s |
| 15.18 | DIO2 OFF delay | (Visible when 15.01 Module 2 type = FIO-01 or FIO-11) See parameter 14.18 DIO2 OFF delay. | 0.0 s |
| 15.19 | DIO3 configuration | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.19 DIO3 function. | Input |
| 15.19 | AI supervision function | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.19 AI supervision function. | No action |
| 15.20 | AI supervision selection | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.20 AI supervision selection. | 0000 0000b |
| 15.21 | DIO3 output source | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.21 DIO3 output source. | Not energized |
| 15.21 | AI tune | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.21 AI tune. | No action |
| 15.22 | DIO3 ON delay | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.22 DIO3 ON delay. | 0.0 s |
| 15.22 | AI force selection | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.22 AI force selection. | 0000b |

172 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------------------|--|----------------------|
| 15.23 | DIO3 OFF delay | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.23 DIO3 OFF delay . | 0.0 s |
| 15.24 | DIO4 configuration | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.24 DIO4 function . | <i>Input</i> |
| 15.26 | DIO4 output source | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.26 DIO4 output source . | <i>Not energized</i> |
| 15.26 | AI1 actual value | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.26 AI1 actual value . | - |
| 15.27 | DIO4 ON delay | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.27 DIO4 ON delay . | 0.0 s |
| 15.27 | AI1 scaled value | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.27 AI1 scaled value . | - |
| 15.28 | DIO4 OFF delay | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.28 DIO4 OFF delay . | 0.0 s |
| 15.28 | AI1 force data | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.28 AI1 force data . | 0.000 mA |
| 15.29 | AI1 HW switch pos | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.29 AI1 HW switch pos . | - |
| 15.30 | AI1 unit selection | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.30 AI1 unit selection . | <i>mA</i> |
| 15.31 | RO status | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.31 RO status . | - |
| 15.31 | AI1 filter gain | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.31 AI1 filter gain . | <i>1 ms</i> |
| 15.32 | AI1 filter time | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.32 AI1 filter time . | 0.100 s |
| 15.33 | AI1 min | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.33 AI1 min . | 0.000 mA or V |
| 15.34 | RO1 source | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.34 RO1 source . | <i>Not energized</i> |
| 15.34 | AI1 max | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.34 AI1 max . | 10.000 mA or V |
| 15.35 | RO1 ON delay | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.35 RO1 ON delay . | 0.0 s |
| 15.35 | AI1 scaled at AI1 min | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.35 AI1 scaled at AI1 min . | 0.000 |
| 15.36 | RO1 OFF delay | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.36 RO1 OFF delay . | 0.0 s |
| 15.36 | AI1 scaled at AI1 max | (Visible when 15.01 Module 2 type = FIO-11 or FAIO-01) See parameter 14.36 AI1 scaled at AI1 max . | 100.000 |
| 15.37 | RO2 source | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.37 RO2 source . | <i>Not energized</i> |
| 15.38 | RO2 ON delay | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.38 RO2 ON delay . | 0.0 s |
| 15.39 | RO2 OFF delay | (Visible when 15.01 Module 2 type = FIO-01) See parameter 14.39 RO2 OFF delay . | 0.0 s |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------|--|----------------|
| 15.41 | <i>AI2 actual value</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.41 AI2 actual value</i> . | - |
| 15.42 | <i>AI2 scaled value</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.42 AI2 scaled value</i> . | - |
| 15.43 | <i>AI2 force data</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.43 AI2 force data</i> . | 0.000 mA |
| 15.44 | <i>AI2 HW switch position</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.44 AI2 HW switch pos.</i> | - |
| 15.45 | <i>AI2 unit selection</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.45 AI2 unit selection</i> . | mA |
| 15.46 | <i>AI2 filter gain</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.46 AI2 filter gain</i> . | 1 ms |
| 15.47 | <i>AI2 filter time</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.47 AI2 filter time</i> . | 0.100 s |
| 15.48 | <i>AI2 min</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.48 AI2 min</i> . | 0.000 mA or V |
| 15.49 | <i>AI2 max</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.49 AI2 max</i> . | 10.000 mA or V |
| 15.50 | <i>AI2 scaled at AI2 min</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.50 AI2 scaled at AI2 min</i> . | 0.000 |
| 15.51 | <i>AI2 scaled at AI2 max</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.51 AI2 scaled at AI2 max</i> . | 100.000 |
| 15.56 | <i>AI3 actual value</i> | (Visible when <i>15.01 Module 2 type = FIO-11</i>) See parameter <i>14.56 AI3 actual value</i> . | - |
| 15.57 | <i>AI3 scaled value</i> | (Visible when <i>15.01 Module 2 type = FIO-11</i>) See parameter <i>14.57 AI3 scaled value</i> . | - |
| 15.58 | <i>AI3 force data</i> | (Visible when <i>15.01 Module 2 type = FIO-11</i>) See parameter <i>14.58 AI3 force data</i> . | 0.000 mA |
| 15.59 | <i>AI3 HW switch position</i> | (Visible when <i>15.01 Module 2 type = FIO-11</i>) See parameter <i>14.59 AI3 HW switch pos.</i> | - |
| 15.60 | <i>AI3 unit selection</i> | (Visible when <i>15.01 Module 2 type = FIO-11</i>) See parameter <i>14.60 AI3 unit selection</i> . | mA |
| 15.61 | <i>AI3 filter gain</i> | (Visible when <i>15.01 Module 2 type = FIO-11</i>) See parameter <i>14.61 AI3 filter gain</i> . | 1 ms |
| 15.62 | <i>AI3 filter time</i> | (Visible when <i>15.01 Module 2 type = FIO-11</i>) See parameter <i>14.62 AI3 filter time</i> . | 0.100 s |
| 15.63 | <i>AI3 min</i> | (Visible when <i>15.01 Module 2 type = FIO-11</i>) See parameter <i>14.63 AI3 min</i> . | 0.000 mA or V |
| 15.64 | <i>AI3 max</i> | (Visible when <i>15.01 Module 2 type = FIO-11</i>) See parameter <i>14.64 AI3 max</i> . | 10.000 mA or V |
| 15.65 | <i>AI3 scaled at AI3 min</i> | (Visible when <i>15.01 Module 2 type = FIO-11</i>) See parameter <i>14.65 AI3 scaled at AI3 min</i> . | 0.000 |
| 15.66 | <i>AI3 scaled at AI3 max</i> | (Visible when <i>15.01 Module 2 type = FIO-11</i>) See parameter <i>14.66 AI3 scaled at AI3 max</i> . | 100.000 |
| 15.71 | <i>AO force selection</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.71 AO force selection</i> . | 00b |

| No. | Name/Value | Description | Def/ FbEq16 |
|----------------------------------|-------------------------------|--|----------------|
| 15.76 | <i>AO1 actual value</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.76 AO1 actual value</i> . | - |
| 15.77 | <i>AO1 source</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.77 AO1 source</i> . | Zero |
| 15.78 | <i>AO1 force data</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.78 AO1 force data</i> . | 0.000 mA |
| 15.79 | <i>AO1 filter time</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.79 AO1 filter time</i> . | 0.100 s |
| 15.80 | <i>AO1 source min</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.80 AO1 source min</i> . | 0.0 |
| 15.81 | <i>AO1 source max</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.81 AO1 source max</i> . | 100.0 |
| 15.82 | <i>AO1 out at AO1 src min</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.82 AO1 out at AO1 src min</i> . | 0.000 mA |
| 15.83 | <i>AO1 out at AO1 src max</i> | (Visible when <i>15.01 Module 2 type = FIO-11 or FAIO-01</i>) See parameter <i>14.83 AO1 out at AO1 src max</i> . | 10.000 mA |
| 15.86 | <i>AO2 actual value</i> | (Visible when <i>15.01 Module 2 type = FAIO-01</i>) See parameter <i>14.86 AO2 actual value</i> . | - |
| 15.87 | <i>AO2 source</i> | (Visible when <i>15.01 Module 2 type = FAIO-01</i>) See parameter <i>14.87 AO2 source</i> . | Zero |
| 15.88 | <i>AO2 force data</i> | (Visible when <i>15.01 Module 2 type = FAIO-01</i>) See parameter <i>14.88 AO2 force data</i> . | 0.000 mA |
| 15.89 | <i>AO2 filter time</i> | (Visible when <i>15.01 Module 2 type = FAIO-01</i>) See parameter <i>14.89 AO2 filter time</i> . | 0.100 s |
| 15.90 | <i>AO2 source min</i> | (Visible when <i>15.01 Module 2 type = FAIO-01</i>) See parameter <i>14.90 AO2 source min</i> . | 0.0 |
| 15.91 | <i>AO2 source max</i> | (Visible when <i>15.01 Module 2 type = FAIO-01</i>) See parameter <i>14.91 AO2 source max</i> . | 100.0 |
| 15.92 | <i>AO2 out at AO1 src min</i> | (Visible when <i>15.01 Module 2 type = FAIO-01</i>) See parameter <i>14.92 AO2 out at AO2 src min</i> . | 0.000 mA |
| 15.93 | <i>AO2 out at AO1 src max</i> | (Visible when <i>15.01 Module 2 type = FAIO-01</i>) See parameter <i>14.93 AO2 out at AO2 src max</i> . | 10.000 mA |
| 16 I/O extension module 3 | | Configuration of I/O extension module 3. See also section Programmable I/O extensions (page 56). Note: The contents of the parameter group vary according to the selected I/O extension module type. | |
| 16.01 | <i>Module 3 type</i> | See parameter <i>14.01 Module 1 type</i> . | None |
| 16.02 | <i>Module 3 location</i> | See parameter <i>14.02 Module 1 location</i> . | Slot 1 |
| 16.03 | <i>Module 3 status</i> | See parameter <i>14.03 Module 1 status</i> . | No option |
| 16.05 | <i>DIO status</i> | (Visible when <i>16.01 Module 3 type = FIO-01 or FIO-11</i>) See parameter <i>14.05 DIO status</i> . | - |
| 16.06 | <i>DIO delayed status</i> | (Visible when <i>16.01 Module 3 type = FIO-01 or FIO-11</i>) See parameter <i>14.06 DIO delayed status</i> . | - |
| 16.08 | <i>DIO filter time</i> | (Visible when <i>16.01 Module 3 type = FIO-01 or FIO-11</i>) See parameter <i>14.08 DIO filter time</i> . | 10.0 ms |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------------|---|----------------------|
| 16.09 | <i>DIO1 function</i> | (Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.09 DIO1 function. | <i>Input</i> |
| 16.11 | <i>DIO1 output source</i> | (Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.11 DIO1 output source. | <i>Not energized</i> |
| 16.12 | <i>DIO1 ON delay</i> | (Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.12 DIO1 ON delay. | 0.0 s |
| 16.13 | <i>DIO1 OFF delay</i> | (Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.13 DIO1 OFF delay. | 0.0 s |
| 16.14 | <i>DIO2 function</i> | (Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.14 DIO2 function. | <i>Input</i> |
| 16.16 | <i>DIO2 output source</i> | (Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.16 DIO2 output source. | <i>Not energized</i> |
| 16.17 | <i>DIO2 ON delay</i> | (Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.17 DIO2 ON delay. | 0.0 s |
| 16.18 | <i>DIO2 OFF delay</i> | (Visible when 16.01 Module 3 type = FIO-01 or FIO-11) See parameter 14.18 DIO2 OFF delay. | 0.0 s |
| 16.19 | <i>DIO3 function</i> | (Visible when 16.01 Module 3 type = FIO-01) See parameter 14.19 DIO3 function. | <i>Input</i> |
| 16.19 | <i>AI supervision function</i> | (Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.19 AI supervision function. | <i>No action</i> |
| 16.20 | <i>AI supervision selection</i> | (Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.20 AI supervision selection. | 0000 0000b |
| 16.21 | <i>DIO3 output source</i> | (Visible when 16.01 Module 3 type = FIO-01) See parameter 14.21 DIO3 output source. | <i>Not energized</i> |
| 16.21 | <i>AI tune</i> | (Visible when 16.01 Module 3 type = FIO-01 or FAIO-01) See parameter 14.21 DIO3 output source. | <i>No action</i> |
| 16.22 | <i>DIO3 ON delay</i> | (Visible when 16.01 Module 3 type = FIO-01) See parameter 14.22 DIO3 ON delay. | 0.0 s |
| 16.22 | <i>AI force selection</i> | (Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.22 AI force selection. | 0000b |
| 16.23 | <i>DIO3 OFF delay</i> | (Visible when 16.01 Module 3 type = FIO-01) See parameter 14.23 DIO3 OFF delay. | 0.0 s |
| 16.24 | <i>DIO4 configuration</i> | (Visible when 16.01 Module 3 type = FIO-01) See parameter 14.24 DIO4 function. | <i>Input</i> |
| 16.26 | <i>DIO4 output source</i> | (Visible when 16.01 Module 3 type = FIO-01) See parameter 14.26 DIO4 output source. | <i>Not energized</i> |
| 16.26 | <i>AI1 actual value</i> | (Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.26 AI1 actual value. | - |
| 16.27 | <i>DIO4 ON delay</i> | (Visible when 16.01 Module 3 type = FIO-01) See parameter 14.27 DIO4 ON delay. | 0.0 s |
| 16.27 | <i>AI1 scaled value</i> | (Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.27 AI1 scaled value. | - |
| 16.28 | <i>DIO4 OFF delay</i> | (Visible when 16.01 Module 3 type = FIO-01) See parameter 14.28 DIO4 OFF delay. | 0.0 s |
| 16.28 | <i>AI1 force data</i> | (Visible when 16.01 Module 3 type = FIO-11 or FAIO-01) See parameter 14.28 AI1 force data. | 0.000 mA |


176 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------|---|----------------------|
| 16.29 | <i>AI1 HW switch position</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.29 AI1 HW switch pos.</i> | - |
| 16.30 | <i>AI1 unit selection</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.30 AI1 unit selection.</i> | <i>mA</i> |
| 16.31 | <i>RO status</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i>) See parameter <i>14.31 RO status.</i> | - |
| 16.31 | <i>AI1 filter gain</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.31 AI1 filter gain.</i> | <i>1 ms</i> |
| 16.32 | <i>AI1 filter time</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.32 AI1 filter time.</i> | 0.100 s |
| 16.33 | <i>AI1 min</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.33 AI1 min.</i> | 0.000 mA or V |
| 16.34 | <i>RO1 source</i> | (Visible when <i>16.01 Module 3 type = FIO-01</i>) See parameter <i>14.34 RO1 source.</i> | <i>Not energized</i> |
| 16.34 | <i>AI1 max</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.34 AI1 max.</i> | 10.000 mA or V |
| 16.35 | <i>RO1 ON delay</i> | (Visible when <i>16.01 Module 3 type = FIO-01</i>) See parameter <i>14.35 RO1 ON delay.</i> | 0.0 s |
| 16.35 | <i>AI1 scaled at AI1 min</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.35 AI1 scaled at AI1 min.</i> | 0.000 |
| 16.36 | <i>RO1 OFF delay</i> | (Visible when <i>16.01 Module 3 type = FIO-01</i>) See parameter <i>14.36 RO1 OFF delay.</i> | 0.0 s |
| 16.36 | <i>AI1 scaled at AI1 max</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.36 AI1 scaled at AI1 max.</i> | 100.000 |
| 16.37 | <i>RO2 source</i> | (Visible when <i>16.01 Module 3 type = FIO-01</i>) See parameter <i>14.37 RO2 source.</i> | <i>Not energized</i> |
| 16.38 | <i>RO2 ON delay</i> | (Visible when <i>16.01 Module 3 type = FIO-01</i>) See parameter <i>14.38 RO2 ON delay.</i> | 0.0 s |
| 16.39 | <i>RO2 OFF delay</i> | (Visible when <i>16.01 Module 3 type = FIO-01</i>) See parameter <i>14.39 RO2 OFF delay.</i> | 0.0 s |
| 16.41 | <i>AI2 actual value</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.41 AI2 actual value.</i> | - |
| 16.42 | <i>AI2 scaled value</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.42 AI2 scaled value.</i> | - |
| 16.43 | <i>AI2 force data</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.43 AI2 force data.</i> | 0.000 mA |
| 16.44 | <i>AI2 HW switch pos</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.44 AI2 HW switch pos.</i> | - |
| 16.45 | <i>AI2 unit selection</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.45 AI2 unit selection.</i> | <i>mA</i> |
| 16.46 | <i>AI2 filter gain</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.46 AI2 filter gain.</i> | <i>1 ms</i> |
| 16.47 | <i>AI2 filter time</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.47 AI2 filter time.</i> | 0.100 s |
| 16.48 | <i>AI2 min</i> | (Visible when <i>16.01 Module 3 type = FIO-11 or FAIO-01</i>) See parameter <i>14.48 AI2 min.</i> | 0.000 mA or V |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------|--|----------------|
| 16.49 | <i>AI2 max</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i> or <i>FAIO-01</i>) See parameter <i>14.49 AI2 max</i> . | 10.000 mA or V |
| 16.50 | <i>AI2 scaled at AI2 min</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i> or <i>FAIO-01</i>) See parameter <i>14.50 AI2 scaled at AI2 min</i> . | 0.000 |
| 16.51 | <i>AI2 scaled at AI2 max</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i> or <i>FAIO-01</i>) See parameter <i>14.51 AI2 scaled at AI2 max</i> . | 100.000 |
| 16.56 | <i>AI3 actual value</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i>) See parameter <i>14.56 AI3 actual value</i> . | - |
| 16.57 | <i>AI3 scaled value</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i>) See parameter <i>14.57 AI3 scaled value</i> . | - |
| 16.58 | <i>AI3 force data</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i>) See parameter <i>14.58 AI3 force data</i> . | 0.000 mA |
| 16.59 | <i>AI3 HW switch position</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i>) See parameter <i>14.59 AI3 HW switch pos</i> . | - |
| 16.60 | <i>AI3 unit selection</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i>) See parameter <i>14.60 AI3 unit selection</i> . | <i>mA</i> |
| 16.61 | <i>AI3 filter gain</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i>) See parameter <i>14.61 AI3 filter gain</i> . | <i>1 ms</i> |
| 16.62 | <i>AI3 filter time</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i>) See parameter <i>14.62 AI3 filter time</i> . | 0.100 s |
| 16.63 | <i>AI3 min</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i>) See parameter <i>14.63 AI3 min</i> . | 0.000 mA or V |
| 16.64 | <i>AI3 max</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i>) See parameter <i>14.64 AI3 max</i> . | 10.000 mA or V |
| 16.65 | <i>AI3 scaled at AI3 min</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i>) See parameter <i>14.65 AI3 scaled at AI3 min</i> . | 0.000 |
| 16.66 | <i>AI3 scaled at AI3 max</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i>) See parameter <i>14.66 AI3 scaled at AI3 max</i> . | 100.000 |
| 16.71 | <i>AO force selection</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i> or <i>FAIO-01</i>) See parameter <i>14.71 AO force selection</i> . | 00b |
| 16.76 | <i>AO1 actual value</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i> or <i>FAIO-01</i>) See parameter <i>14.76 AO1 actual value</i> . | - |
| 16.77 | <i>AO1 source</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i> or <i>FAIO-01</i>) See parameter <i>14.77 AO1 source</i> . | <i>Zero</i> |
| 16.78 | <i>AO1 force data</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i> or <i>FAIO-01</i>) See parameter <i>14.78 AO1 force data</i> . | 0.000 mA |
| 16.79 | <i>AO1 filter time</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i> or <i>FAIO-01</i>) See parameter <i>14.79 AO1 filter time</i> . | 0.100 s |
| 16.80 | <i>AO1 source min</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i> or <i>FAIO-01</i>) See parameter <i>14.80 AO1 source min</i> . | 0.0 |
| 16.81 | <i>AO1 source max</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i> or <i>FAIO-01</i>) See parameter <i>14.81 AO1 source max</i> . | 100.0 |
| 16.82 | <i>AO1 out at AO1 src min</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i> or <i>FAIO-01</i>) See parameter <i>14.82 AO1 out at AO1 src min</i> . | 0.000 mA |
| 16.83 | <i>AO1 out at AO1 src max</i> | (Visible when <i>16.01 Module 3 type = FIO-11</i> or <i>FAIO-01</i>) See parameter <i>14.83 AO1 out at AO1 src max</i> . | 10.000 mA |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------|---|----------------|
| 16.86 | <i>AO2 actual value</i> | (Visible when <i>16.01 Module 3 type = FAIO-01</i>) See parameter <i>14.86 AO2 actual value</i> . | - |
| 16.87 | <i>AO2 source</i> | (Visible when <i>16.01 Module 3 type = FAIO-01</i>) See parameter <i>14.87 AO2 source</i> . | Zero |
| 16.88 | <i>AO2 force data</i> | (Visible when <i>16.01 Module 3 type = FAIO-01</i>) See parameter <i>14.88 AO2 force data</i> . | 0.000 mA |
| 16.89 | <i>AO2 filter time</i> | (Visible when <i>16.01 Module 3 type = FAIO-01</i>) See parameter <i>14.89 AO2 filter time</i> . | 0.100 s |
| 16.90 | <i>AO2 source min</i> | (Visible when <i>16.01 Module 3 type = FAIO-01</i>) See parameter <i>14.90 AO2 source min</i> . | 0.0 |
| 16.91 | <i>AO2 source max</i> | (Visible when <i>16.01 Module 3 type = FAIO-01</i>) See parameter <i>14.91 AO2 source max</i> . | 100.0 |
| 16.92 | <i>AO2 out at AO2 src min</i> | (Visible when <i>16.01 Module 3 type = FAIO-01</i>) See parameter <i>14.92 AO2 out at AO2 src min</i> . | 0.000 mA |
| 16.93 | <i>AO2 out at AO2 src max</i> | (Visible when <i>16.01 Module 3 type = FAIO-01</i>) See parameter <i>14.93 AO2 out at AO2 src max</i> . | 10.000 mA |

| | | | |
|--------------------------|------------------------------|---|-------------|
| 19 Operation mode | | Selection of local and external control location sources and operating modes. See also section <i>Operating modes of the drive</i> (page 53). | |
| 19.01 | <i>Actual operation mode</i> | Displays the operating mode currently used. See parameters <i>19.11...19.14</i> . This parameter is read-only. | - |
| | Zero | None. | 1 |
| | Speed | Speed control (in DTC motor control mode). | 2 |
| | Torque | Torque control (in DTC motor control mode). | 3 |
| | Min | The torque selector is comparing the output of the speed controller (<i>25.01 Torque reference speed control</i>) and torque reference (<i>26.74 Torque ref ramp out</i>) and the smaller of the two is used. | 4 |
| | Max | The torque selector is comparing the output of the speed controller (<i>25.01 Torque reference speed control</i>) and torque reference (<i>26.74 Torque ref ramp out</i>) and the greater of the two is used. | 5 |
| | Add | The speed controller output is added to the torque reference. | 6 |
| | Scalar (Hz) | Frequency control in scalar motor control mode. | 10 |
| | Scalar (rpm) | Speed control in scalar motor control mode. | 11 |
| | Forced magn. | Motor is in magnetizing mode. | 20 |
| 19.11 | <i>Ext1/Ext2 selection</i> | Selects the source for external control location EXT1/EXT2 selection. 0 = EXT1 1 = EXT2 | <i>EXT1</i> |
| | EXT1 | EXT1 (permanently selected). | 0 |
| | EXT2 | EXT2 (permanently selected). | 1 |
| | FBA A MCW bit 11 | Control word bit 11 received through fieldbus interface A. | 2 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 3 |

| No. | Name/Value | Description | Def/ FbEq16 |
|--------------|--------------------------------------|---|----------------|
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 4 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 5 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 6 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 7 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 8 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 11 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 12 |
| | EFB MCW bit 11 | Control word bit 11 received through the embedded fieldbus interface. | 32 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| <i>19.12</i> | <i>Ext1 control mode 1</i> | Selects the operating mode for external control location EXT1. | <i>Speed</i> |
| | Zero | None. | 1 |
| | Speed | Speed control. The torque reference used is <i>25.01 Torque reference speed control</i> (output of the speed reference chain). | 2 |
| <i>19.14</i> | <i>Ext2 control mode 1</i> | Selects the operating mode for external control location EXT2. For the selections, see parameter <i>19.12 Ext1 control mode 1</i> . | <i>Speed</i> |
| <i>19.16</i> | <i>Local control mode</i> | Selects the operating mode for local control. | <i>Speed</i> |
| | Speed | Speed control. The torque reference used is <i>25.01 Torque reference speed control</i> (output of the speed reference chain). | 0 |
| | Torque | Torque control. The torque reference used is <i>26.74 Torque ref ramp out</i> (output of the torque reference chain). | 1 |
| <i>19.17</i> | <i>Local control disable</i> | Enables/disables local control (start and stop buttons on the control panel, and the local controls on the PC tool).  WARNING! Before disabling local control, ensure that the control panel is not needed for stopping the drive. | <i>No</i> |
| | No | Local control enabled. | 0 |
| | Yes | Local control disabled. | 1 |
| <i>19.20</i> | <i>Scalar control reference unit</i> | Selects the reference type for scalar motor control mode. See also section <i>Operating modes of the drive</i> (page 53), and parameter <i>99.04 Motor ctrl mode</i> . | <i>Rpm</i> |
| | Hz | Hz. The reference is taken from parameter <i>28.02 Frequency ref ramp output</i> (output of the frequency control chain). | 0 |
| | Rpm | Rpm. The reference is taken from parameter <i>23.02 Speed ref ramp output</i> (speed reference after ramping and shaping). | 1 |


| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | |
|---|---|--|---|---|---|-------|-------------------------------------|------|---|------|---------------|-------------------------------------|---|---------------|---|---|---------------|---|-------------------------------------|--|---|---|------|---|
| 20 Start/stop/direction Start/stop/direction and run/start/jog enable signal source selection; positive/negative reference enable signal source selection. For information on control locations, see section Local control vs. external control (page 51). | | | | | | | | | | | | | | | | | | | | | | | | |
| 20.01 | <i>Ext1 commands</i> | Selects the source of start, stop and direction commands for external control location 1 (EXT1). See also parameters 20.02...20.05 . | <i>In1 Start</i> | | | | | | | | | | | | | | | | | | | | | |
| | Not selected | No start or stop command sources selected. | 0 | | | | | | | | | | | | | | | | | | | | | |
| | In1 Start | The source of the start and stop commands is selected by parameter 20.03 Ext1 in1 source . The state transitions of the source bits are interpreted as follows: <table border="1" data-bbox="378 517 779 624" style="margin: 10px auto;"> <thead> <tr> <th>State of source 1 (20.03)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1 (20.02 = Edge)</td> <td>Start</td> </tr> <tr> <td>1 (20.02 = Level)</td> <td></td> </tr> <tr> <td>0</td> <td>Stop</td> </tr> </tbody> </table> | State of source 1 (20.03) | Command | 0 -> 1 (20.02 = Edge) | Start | 1 (20.02 = Level) | | 0 | Stop | 1 | | | | | | | | | | | | | |
| State of source 1 (20.03) | Command | | | | | | | | | | | | | | | | | | | | | | | |
| 0 -> 1 (20.02 = Edge) | Start | | | | | | | | | | | | | | | | | | | | | | | |
| 1 (20.02 = Level) | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Stop | | | | | | | | | | | | | | | | | | | | | | | |
| | In1 Start; In2 Dir | The source selected by 20.03 Ext1 in1 source is the start signal; the source selected by 20.04 Ext1 in2 source determines the direction. The state transitions of the source bits are interpreted as follows: <table border="1" data-bbox="359 738 844 868" style="margin: 10px auto;"> <thead> <tr> <th>State of source 1 (20.03)</th> <th>State of source 2 (20.04)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Any</td> <td>Stop</td> </tr> <tr> <td>0 -> 1 (20.02 = Edge)</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>1 (20.02 = Level)</td> <td>1</td> <td>Start reverse</td> </tr> </tbody> </table> | State of source 1 (20.03) | State of source 2 (20.04) | Command | 0 | Any | Stop | 0 -> 1 (20.02 = Edge) | 0 | Start forward | 1 (20.02 = Level) | 1 | Start reverse | 2 | | | | | | | | | |
| State of source 1 (20.03) | State of source 2 (20.04) | Command | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Any | Stop | | | | | | | | | | | | | | | | | | | | | | |
| 0 -> 1 (20.02 = Edge) | 0 | Start forward | | | | | | | | | | | | | | | | | | | | | | |
| 1 (20.02 = Level) | 1 | Start reverse | | | | | | | | | | | | | | | | | | | | | | |
| | In1 Start fwd; In2 Start rev | The source selected by 20.03 Ext1 in1 source is the forward start signal; the source selected by 20.04 Ext1 in2 source is the reverse start signal. The state transitions of the source bits are interpreted as follows: <table border="1" data-bbox="356 986 848 1235" style="margin: 10px auto;"> <thead> <tr> <th>State of source 1 (20.03)</th> <th>State of source 2 (20.04)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Stop</td> </tr> <tr> <td>0 -> 1 (20.02 = Edge)</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>1 (20.02 = Level)</td> <td>0</td> <td></td> </tr> <tr> <td>0</td> <td>0 -> 1 (20.02 = Edge)</td> <td>Start reverse</td> </tr> <tr> <td>1</td> <td>1 (20.02 = Level)</td> <td></td> </tr> <tr> <td>1</td> <td>1</td> <td>Stop</td> </tr> </tbody> </table> | State of source 1 (20.03) | State of source 2 (20.04) | Command | 0 | 0 | Stop | 0 -> 1 (20.02 = Edge) | 0 | Start forward | 1 (20.02 = Level) | 0 | | 0 | 0 -> 1 (20.02 = Edge) | Start reverse | 1 | 1 (20.02 = Level) | | 1 | 1 | Stop | 3 |
| State of source 1 (20.03) | State of source 2 (20.04) | Command | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | Stop | | | | | | | | | | | | | | | | | | | | | | |
| 0 -> 1 (20.02 = Edge) | 0 | Start forward | | | | | | | | | | | | | | | | | | | | | | |
| 1 (20.02 = Level) | 0 | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 -> 1 (20.02 = Edge) | Start reverse | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 (20.02 = Level) | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | Stop | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | |
|--|--|--|--|--|--|---------|--------|-------|-----|---------------|--------|--------|---|---------------|-----|-----|-----|------|---|
| | In1P Start; In2 Stop | <p>The sources of the start and stop commands are selected by parameters 20.03 Ext1 in1 source and 20.04 Ext1 in2 source. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="423 296 885 400"> <thead> <tr> <th>State of source 1 (20.03)</th> <th>State of source 2 (20.04)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>1</td> <td>Start</td> </tr> <tr> <td>Any</td> <td>0</td> <td>Stop</td> </tr> </tbody> </table> <p>Notes:</p> <ul style="list-style-type: none"> The start signal is always edge-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type. | State of source 1 (20.03) | State of source 2 (20.04) | Command | 0 -> 1 | 1 | Start | Any | 0 | Stop | 4 | | | | | | | |
| State of source 1 (20.03) | State of source 2 (20.04) | Command | | | | | | | | | | | | | | | | | |
| 0 -> 1 | 1 | Start | | | | | | | | | | | | | | | | | |
| Any | 0 | Stop | | | | | | | | | | | | | | | | | |
| | In1P Start; In2 Stop; In3 Dir | <p>The sources of the start and stop commands are selected by parameters 20.03 Ext1 in1 source and 20.04 Ext1 in2 source. The source selected by 20.05 Ext1 in3 source determines the direction. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="437 628 871 778"> <thead> <tr> <th>State of source 1 (20.03)</th> <th>State of source 2 (20.04)</th> <th>State of source 3 (20.05)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>1</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>0 -> 1</td> <td>1</td> <td>1</td> <td>Start reverse</td> </tr> <tr> <td>Any</td> <td>0</td> <td>Any</td> <td>Stop</td> </tr> </tbody> </table> <p>Notes:</p> <ul style="list-style-type: none"> The start signal is always edge-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type. | State of source 1 (20.03) | State of source 2 (20.04) | State of source 3 (20.05) | Command | 0 -> 1 | 1 | 0 | Start forward | 0 -> 1 | 1 | 1 | Start reverse | Any | 0 | Any | Stop | 5 |
| State of source 1 (20.03) | State of source 2 (20.04) | State of source 3 (20.05) | Command | | | | | | | | | | | | | | | | |
| 0 -> 1 | 1 | 0 | Start forward | | | | | | | | | | | | | | | | |
| 0 -> 1 | 1 | 1 | Start reverse | | | | | | | | | | | | | | | | |
| Any | 0 | Any | Stop | | | | | | | | | | | | | | | | |
| | In1P Start fwd; In2P Start rev; In3 Stop | <p>The sources of the start and stop commands are selected by parameters 20.03 Ext1 in1 source, 20.04 Ext1 in2 source and 20.05 Ext1 in3 source. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="423 986 866 1136"> <thead> <tr> <th>State of source 1 (20.03)</th> <th>State of source 2 (20.04)</th> <th>State of source 3 (20.05)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>Any</td> <td>1</td> <td>Start forward</td> </tr> <tr> <td>Any</td> <td>0 -> 1</td> <td>1</td> <td>Start reverse</td> </tr> <tr> <td>Any</td> <td>Any</td> <td>0</td> <td>Stop</td> </tr> </tbody> </table> <p>Note: The start signal is always edge-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type.</p> | State of source 1 (20.03) | State of source 2 (20.04) | State of source 3 (20.05) | Command | 0 -> 1 | Any | 1 | Start forward | Any | 0 -> 1 | 1 | Start reverse | Any | Any | 0 | Stop | 6 |
| State of source 1 (20.03) | State of source 2 (20.04) | State of source 3 (20.05) | Command | | | | | | | | | | | | | | | | |
| 0 -> 1 | Any | 1 | Start forward | | | | | | | | | | | | | | | | |
| Any | 0 -> 1 | 1 | Start reverse | | | | | | | | | | | | | | | | |
| Any | Any | 0 | Stop | | | | | | | | | | | | | | | | |
| | Fieldbus A | <p>The start and stop commands are taken from fieldbus adapter A.</p> <p>Note: The start signal is always level-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type.</p> | 12 | | | | | | | | | | | | | | | | |
| | Embedded fieldbus | <p>The start and stop commands are taken from the embedded fieldbus interface.</p> <p>Note: The start signal is always level-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type.</p> | 14 | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | |
|---|---|--|---|---------|---|-------|-------------------------------------|--|---|------|---|
| | Application Program | The start and stop commands are taken from the application program control word (parameter 06.02 Application control word). Note: The start signal is always level-triggered with this setting regardless of parameter 20.02 Ext1 start trigger type . | 21 | | | | | | | | |
| | ATF | Reserved. | 22 | | | | | | | | |
| 20.02 | Ext1 start trigger type | Defines whether the start signal for external control location EXT1 is edge-triggered or level-triggered. Note: This parameter is only effective when parameter 20.01 Ext1 commands is set to <i>In1 Start</i> , <i>In1 Start; In2 Dir</i> or <i>In1 Start fwd; In2 Start rev</i> . | <i>Level</i> | | | | | | | | |
| | Edge | The start signal is edge-triggered. | 0 | | | | | | | | |
| | Level | The start signal is level-triggered. | 1 | | | | | | | | |
| 20.03 | Ext1 in1 source | Selects source 1 for parameter 20.01 Ext1 commands . | <i>DI1</i> | | | | | | | | |
| | Not selected | 0 (always off). | 0 | | | | | | | | |
| | Selected | 1 (always on). | 1 | | | | | | | | |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 | | | | | | | | |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 | | | | | | | | |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 | | | | | | | | |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 5 | | | | | | | | |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 6 | | | | | | | | |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 7 | | | | | | | | |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status , bit 0). | 10 | | | | | | | | |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status , bit 1). | 11 | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - | | | | | | | | |
| 20.04 | Ext1 in2 source | Selects source 2 for parameter 20.01 Ext1 commands . For the available selections, see parameter 20.03 Ext1 in1 source . | <i>Not selected</i> | | | | | | | | |
| 20.05 | Ext1 in3 source | Selects source 3 for parameter 20.01 Ext1 commands . For the available selections, see parameter 20.03 Ext1 in1 source . | <i>Not selected</i> | | | | | | | | |
| 20.06 | Ext2 commands | Selects the source of start, stop and direction commands for external control location 2 (EXT2). See also parameters 20.07...20.10 . | <i>Not selected</i> | | | | | | | | |
| | Not selected | No start or stop command sources selected. | 0 | | | | | | | | |
| | In1 Start | The source of the start and stop commands is selected by parameter 20.08 Ext2 in1 source . The state transitions of the source bits are interpreted as follows: <table border="1" data-bbox="423 1305 776 1409" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>State of source 1 (20.08)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1 (20.07 = Edge)</td> <td>Start</td> </tr> <tr> <td>1 (20.07 = Level)</td> <td></td> </tr> <tr> <td>0</td> <td>Stop</td> </tr> </tbody> </table> | State of source 1 (20.08) | Command | 0 -> 1 (20.07 = Edge) | Start | 1 (20.07 = Level) | | 0 | Stop | 1 |
| State of source 1 (20.08) | Command | | | | | | | | | | |
| 0 -> 1 (20.07 = Edge) | Start | | | | | | | | | | |
| 1 (20.07 = Level) | | | | | | | | | | | |
| 0 | Stop | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | |
|--|--|--|------------------------------|------------------------------|------------------------------|---------|--------|-------|--|---------------|---------------|-------------------|--|---------------|-----|---|------|------|---|
| | In1 Start; In2 Dir | <p>The source selected by 20.08 Ext2 in1 source is the start signal; the source selected by 20.09 Ext2 in2 source determines the direction. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="415 296 893 424"> <thead> <tr> <th>State of source 1 (20.08)</th> <th>State of source 2 (20.09)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Any</td> <td>Stop</td> </tr> <tr> <td>0 -> 1 (20.07 = Edge)</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>1 (20.07 = Level)</td> <td>1</td> <td>Start reverse</td> </tr> </tbody> </table> | State of source 1 (20.08) | State of source 2 (20.09) | Command | 0 | Any | Stop | 0 -> 1 (20.07 = Edge) | 0 | Start forward | 1 (20.07 = Level) | 1 | Start reverse | 2 | | | | |
| State of source 1 (20.08) | State of source 2 (20.09) | Command | | | | | | | | | | | | | | | | | |
| 0 | Any | Stop | | | | | | | | | | | | | | | | | |
| 0 -> 1 (20.07 = Edge) | 0 | Start forward | | | | | | | | | | | | | | | | | |
| 1 (20.07 = Level) | 1 | Start reverse | | | | | | | | | | | | | | | | | |
| | In1 Start fwd; In2 Start rev | <p>The source selected by 20.08 Ext2 in1 source is the forward start signal; the source selected by 20.09 Ext2 in2 source is the reverse start signal. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="415 539 893 786"> <thead> <tr> <th>State of source 1 (20.08)</th> <th>State of source 2 (20.09)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Stop</td> </tr> <tr> <td>0 -> 1 (20.07 = Edge) 1 (20.07 = Level)</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>0</td> <td>0 -> 1 (20.07 = Edge) 1 (20.07 = Level)</td> <td>Start reverse</td> </tr> <tr> <td>1</td> <td>1</td> <td>Stop</td> </tr> </tbody> </table> | State of source 1 (20.08) | State of source 2 (20.09) | Command | 0 | 0 | Stop | 0 -> 1 (20.07 = Edge) 1 (20.07 = Level) | 0 | Start forward | 0 | 0 -> 1 (20.07 = Edge) 1 (20.07 = Level) | Start reverse | 1 | 1 | Stop | 3 | |
| State of source 1 (20.08) | State of source 2 (20.09) | Command | | | | | | | | | | | | | | | | | |
| 0 | 0 | Stop | | | | | | | | | | | | | | | | | |
| 0 -> 1 (20.07 = Edge) 1 (20.07 = Level) | 0 | Start forward | | | | | | | | | | | | | | | | | |
| 0 | 0 -> 1 (20.07 = Edge) 1 (20.07 = Level) | Start reverse | | | | | | | | | | | | | | | | | |
| 1 | 1 | Stop | | | | | | | | | | | | | | | | | |
| | In1P Start; In2 Stop | <p>The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source and 20.09 Ext2 in2 source. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="415 903 871 1007"> <thead> <tr> <th>State of source 1 (20.08)</th> <th>State of source 2 (20.09)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>1</td> <td>Start</td> </tr> <tr> <td>Any</td> <td>0</td> <td>Stop</td> </tr> </tbody> </table> <p>Notes:</p> <ul style="list-style-type: none"> The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type. | State of source 1 (20.08) | State of source 2 (20.09) | Command | 0 -> 1 | 1 | Start | Any | 0 | Stop | 4 | | | | | | | |
| State of source 1 (20.08) | State of source 2 (20.09) | Command | | | | | | | | | | | | | | | | | |
| 0 -> 1 | 1 | Start | | | | | | | | | | | | | | | | | |
| Any | 0 | Stop | | | | | | | | | | | | | | | | | |
| | In1P Start; In2 Stop; In3 Dir | <p>The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source and 20.09 Ext2 in2 source. The source selected by 20.10 Ext2 in3 source determines the direction. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="415 1235 855 1386"> <thead> <tr> <th>State of source 1 (20.08)</th> <th>State of source 2 (20.09)</th> <th>State of source 3 (20.10)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>1</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>0 -> 1</td> <td>1</td> <td>1</td> <td>Start reverse</td> </tr> <tr> <td>Any</td> <td>0</td> <td>Any</td> <td>Stop</td> </tr> </tbody> </table> <p>Notes:</p> <ul style="list-style-type: none"> The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type. | State of source 1 (20.08) | State of source 2 (20.09) | State of source 3 (20.10) | Command | 0 -> 1 | 1 | 0 | Start forward | 0 -> 1 | 1 | 1 | Start reverse | Any | 0 | Any | Stop | 5 |
| State of source 1 (20.08) | State of source 2 (20.09) | State of source 3 (20.10) | Command | | | | | | | | | | | | | | | | |
| 0 -> 1 | 1 | 0 | Start forward | | | | | | | | | | | | | | | | |
| 0 -> 1 | 1 | 1 | Start reverse | | | | | | | | | | | | | | | | |
| Any | 0 | Any | Stop | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | |
|--|--|---|--|--|--|---------|--------|-----|---|---------------|-----|--------|---|---------------|-----|-----|---|------|---|
| | In1P Start fwd; In2P Start rev; In3 Stop | <p>The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source, 20.09 Ext2 in2 source and 20.10 Ext2 in3 source. The state transitions of the source bits are interpreted as follows:</p> <table border="1"> <thead> <tr> <th>State of source 1 (20.08)</th> <th>State of source 2 (20.09)</th> <th>State of source 3 (20.10)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>Any</td> <td>1</td> <td>Start forward</td> </tr> <tr> <td>Any</td> <td>0 -> 1</td> <td>1</td> <td>Start reverse</td> </tr> <tr> <td>Any</td> <td>Any</td> <td>0</td> <td>Stop</td> </tr> </tbody> </table> <p>Note: The start signal is always edge-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.</p> | State of source 1 (20.08) | State of source 2 (20.09) | State of source 3 (20.10) | Command | 0 -> 1 | Any | 1 | Start forward | Any | 0 -> 1 | 1 | Start reverse | Any | Any | 0 | Stop | 6 |
| State of source 1 (20.08) | State of source 2 (20.09) | State of source 3 (20.10) | Command | | | | | | | | | | | | | | | | |
| 0 -> 1 | Any | 1 | Start forward | | | | | | | | | | | | | | | | |
| Any | 0 -> 1 | 1 | Start reverse | | | | | | | | | | | | | | | | |
| Any | Any | 0 | Stop | | | | | | | | | | | | | | | | |
| | Fieldbus A | <p>The start and stop commands are taken from fieldbus adapter A.</p> <p>Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.</p> | 12 | | | | | | | | | | | | | | | | |
| | Embedded fieldbus | <p>The start and stop commands are taken from the embedded fieldbus interface.</p> <p>Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.</p> | 14 | | | | | | | | | | | | | | | | |
| | Application Program | <p>The start and stop commands are taken from the application program control word (parameter 06.02 Application control word).</p> <p>Note: The start signal is always level-triggered with this setting regardless of parameter 20.07 Ext2 start trigger type.</p> | 21 | | | | | | | | | | | | | | | | |
| | ATF | Reserved. | 22 | | | | | | | | | | | | | | | | |
| 20.07 | Ext2 start trigger type | <p>Defines whether the start signal for external control location EXT2 is edge-triggered or level-triggered.</p> <p>Note: This parameter is only effective when parameter 20.06 Ext2 commands is set to <i>In1 Start</i>, <i>In1 Start; In2 Dir</i> or <i>In1 Start fwd; In2 Start rev</i>.</p> | <i>Edge</i> | | | | | | | | | | | | | | | | |
| | Edge | The start signal is edge-triggered. | 0 | | | | | | | | | | | | | | | | |
| | Level | The start signal is level-triggered. | 1 | | | | | | | | | | | | | | | | |
| 20.08 | Ext2 in1 source | <p>Selects source 1 for parameter 20.06 Ext2 commands. For the available selections, see parameter 20.03 Ext1 in1 source.</p> | <i>Not selected</i> | | | | | | | | | | | | | | | | |
| 20.09 | Ext2 in2 source | <p>Selects source 2 for parameter 20.06 Ext2 commands. For the available selections, see parameter 20.03 Ext1 in1 source.</p> | <i>Not selected</i> | | | | | | | | | | | | | | | | |
| 20.10 | Ext2 in3 source | <p>Selects source 3 for parameter 20.06 Ext2 commands. For the available selections, see parameter 20.03 Ext1 in1 source.</p> | <i>Not selected</i> | | | | | | | | | | | | | | | | |



| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------------|---|--|
| 20.11 | <i>Run enable stop mode</i> | Selects the way the motor is stopped when the run enable signal switches off. The source of the run enable signal is selected by parameter <i>20.12 Run enable 1 source</i> . | <i>Coast</i> (95.20 b10) |
| | Coast | Stop by switching off the output semiconductors of the drive. The motor coasts to a stop.  WARNING! If a mechanical brake is used, ensure it is safe to stop the drive by coasting. | 0 |
| | Ramp | Stop along the active deceleration ramp. See parameter group <i>23 Speed reference ramp</i> on page 203. | 1 |
| | Torque limit | Stop according to torque limits (parameters <i>30.19</i> and <i>30.20</i>). | 2 |
| 20.12 | <i>Run enable 1 source</i> | Selects the source of the external run enable signal. If the run enable signal is switched off, the drive will not start. If already running, the drive will stop according to the setting of parameter <i>20.11 Run enable stop mode</i> . 1 = Run enable signal on. Note: The warning that indicates a missing signal can be suppressed using parameter <i>20.30 Enable signals warning function</i> . See also parameter <i>20.19 Enable start command</i> . | <i>DIIL</i> (95.20 b10); <i>Selected</i> (95.20 b5); <i>D15</i> (95.20 b9); |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | FBA A MCW bit 3 | Control word bit 3 received through fieldbus interface A. | 30 |
| | EFB MCW bit 3 | Control word bit 3 received through the embedded fieldbus interface. | 32 |
| | DIIL | DIIL input (<i>10.02 DI delayed status</i> , bit 15). | 33 |
| | Active control source MCW bit 3 | Control word bit 3 received from the active control source. In case the active source is the control panel, PC tool or drive I/O, the run enable signal is always on. Note: If the drive is running, switching bit 3 off effectively removes both the start and run enable signals. In this case, the stop mode is determined by either <i>20.11 Run enable stop mode</i> or <i>21.03 Stop mode</i> , whichever mode has higher priority. The order of stop modes from highest to lowest priority is <i>Coast – Torque limit – Ramp</i> . | 34 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-----------------------------|---|-----------------|
| 20.19 | <i>Enable start command</i> | <p>Selects the source for the start enable signal. 1 = Start enable.</p> <p>With the signal switched off, any drive start command is inhibited. (Switching the signal off while the drive is running will not stop the drive.)</p> <p>Notes:</p> <ul style="list-style-type: none"> • If a level-triggered start command is on when the start enable signal switches on, the drive will start. (An edge-triggered start signal must be cycled for the drive to start.) See parameters 20.02 Ext1 start trigger type and 20.07 Ext2 start trigger type. • The warning that indicates a missing signal can be suppressed using parameter 20.30 Enable signals warning function. <p>See also parameter 20.12 Run enable 1 source.</p> | <i>Selected</i> |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 5 |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 6 |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status , bit 1). | 11 |
| | DIIL | DIIL input (10.02 DI delayed status , bit 15). | 30 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |



| No. | Name/Value | Description | Def/ FbEq16 |
|--|------------------------------|---|-----------------|
| 20.23 | <i>Positive speed enable</i> | <p>Selects the source of the positive speed enable command. 1 = Positive speed enabled. 0 = Positive speed interpreted as zero speed reference. In the figure below, 23.01 Speed ref ramp input is set to zero after the positive speed enable signal has cleared.</p> <p>Actions in different control modes:</p> <p>Speed control: Speed reference is set to zero and the motor is stopped along the currently active deceleration ramp. The rush controller prevents additional torque terms from running the motor in the positive direction.</p> <p>Torque control: The rush controller monitors the rotation direction of the motor.</p> | <i>Selected</i> |
| <p>The diagram shows four signals over time. 20.23 Positive speed enable starts high and then drops to low. 20.24 Negative speed enable starts low and then rises to high. 23.01 Speed ref ramp input starts at a positive value and then drops to zero. 01.01 Motor speed used starts at a positive value, decreases to zero when the positive speed enable signal drops, and then increases in the negative direction when the negative speed enable signal rises.</p> | | | |
| | | <p>Example: The motor is rotating in the forward direction. To stop the motor, the positive speed enable signal is deactivated by a hardware limit switch (e.g. via digital input). If the positive speed enable signal remains deactivated and the negative speed enable signal is active, only reverse rotation of the motor is allowed.</p> | |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 5 |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 6 |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 20.24 | <i>Negative speed enable</i> | Selects the source of the negative speed reference enable command. See parameter 20.23 Positive speed enable . | <i>Selected</i> |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------|---|---------------------|
| 20.25 | <i>Jogging enable</i> | <p>Selects the source for a jog enable signal. (The sources for jogging activation signals are selected by parameters 20.26 Jogging 1 start source and 20.27 Jogging 2 start source.)</p> <p>1 = Jogging is enabled. 0 = Jogging is disabled.</p> <p>Note: Jogging can be enabled only when no start command from an external control location is active. On the other hand, if jogging is already enabled, the drive cannot be started from an external control location (apart from inching commands through fieldbus). See section Jogging (page 69).</p> | <i>Not selected</i> |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 5 |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 6 |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 20.26 | <i>Jogging 1 start source</i> | <p>If enabled by parameter 20.25 Jogging enable, selects the source for the activation of jogging function 1. (Jogging function 1 can also be activated through fieldbus regardless of parameter 20.25.)</p> <p>1 = Jogging 1 active.</p> <p>Note: If both jogging 1 and 2 are activated, the one that was activated first has priority.</p> | <i>Not selected</i> |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 5 |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 6 |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |


| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | |
|---------------------------|--|--|---------------------|------|---------|---|--------------|---|---|--------------|--------------------------------|--------|----------|--|-----|
| 20.27 | <i>Jogging 2 start source</i> | If enabled by parameter 20.25 Jogging enable , selects the source for the activation of jogging function 2. (Jogging function 2 can also be activated through fieldbus regardless of parameter 20.25 .) 1 = Jogging 2 active. For the selections, see parameter 20.26 Jogging 1 start source . Note: If both jogging 1 and 2 are activated, the one that was activated first has priority. | <i>Not selected</i> | | | | | | | | | | | | |
| 20.30 | <i>Enable signals warning function</i> | Selects enable signal (for example, run enable, start enable) warnings to be suppressed. This parameter can be used to prevent these warnings from flooding the event log. Whenever a bit of this parameter is set to 1, the corresponding warning is suppressed, that is no warning is generated even if the signal is switched off. The bits of this binary number correspond to the following warnings: <table border="1" data-bbox="404 679 902 788"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Warning</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Enable Start</td> <td><i>AFEA Enable start signal missing</i></td> </tr> <tr> <td>1</td> <td>Run enable 1</td> <td><i>AFEB Run enable missing</i></td> </tr> <tr> <td>2...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | Bit | Name | Warning | 0 | Enable Start | <i>AFEA Enable start signal missing</i> | 1 | Run enable 1 | <i>AFEB Run enable missing</i> | 2...15 | Reserved | | 00b |
| Bit | Name | Warning | | | | | | | | | | | | | |
| 0 | Enable Start | <i>AFEA Enable start signal missing</i> | | | | | | | | | | | | | |
| 1 | Run enable 1 | <i>AFEB Run enable missing</i> | | | | | | | | | | | | | |
| 2...15 | Reserved | | | | | | | | | | | | | | |
| | 00b...11b | Suppression of "enable signal missing" warnings. | 1 = 1 | | | | | | | | | | | | |
| 21 Start/stop mode | | | | | | | | | | | | | | | |
| 21.01 | <i>Start mode</i> | Selects the motor start function for the DTC motor control mode, ie. when 99.04 Motor ctrl mode is set to <i>DTC</i> . Notes: <ul style="list-style-type: none"> The start function for the scalar motor control mode is selected by parameter 21.19 Scalar start mode. Starting into a rotating motor is not possible when DC magnetizing is selected (<i>Fast</i> or <i>Constant time</i>). With permanent magnet motors and synchronous reluctance motors, <i>Automatic</i> start mode must be used. This parameter cannot be changed while the drive is running. See also section DC magnetization (page 77). | <i>Automatic</i> | | | | | | | | | | | | |
| | Fast | The drive pre-magnetizes the motor before start. The pre-magnetizing time is determined automatically, being typically 200 ms to 2 s depending on motor size. This mode should be selected if a high break-away torque is required. | 0 | | | | | | | | | | | | |


| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | |
|-------------------|------------------------------------|--|-----------------------|---------------------------|--------|----------------|------------|-----------------|--------------|------------------|----------------|-------------------|--------|
| | Constant time | <p>The drive pre-magnetizes the motor before start. The pre-magnetizing time is defined by parameter 21.02 Magnetization time. This mode should be selected if constant pre-magnetizing time is required. This setting also guarantees the highest possible break-away torque when the pre-magnetizing time is set long enough.</p> <p> WARNING! The drive will start after the set magnetizing time has passed even if motor magnetization is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetizing time is long enough to allow generation of full magnetization and torque.</p> | 1 | | | | | | | | | | |
| | Automatic | Automatic start guarantees optimal motor start in most cases. It includes the flying start function (starting into a rotating motor) and the automatic restart function (a stopped motor can be restarted immediately without waiting the motor flux to die away). The drive motor control program identifies the flux as well as the mechanical state of the motor and starts the motor instantly under all conditions. | 2 | | | | | | | | | | |
| 21.02 | Magnetization time | <p>Defines the pre-magnetization time when</p> <ul style="list-style-type: none"> parameter 21.01 Start mode is set to Constant time (in DTC motor control mode), or parameter 21.19 Scalar start mode is set to Const time (in scalar motor control mode). <p>After the start command, the drive automatically premagnetizes the motor for the set time. To ensure full magnetizing, set this parameter to the same value as, or higher than, the rotor time constant. If not known, use the rule-of-thumb value given in the table below:</p> <table border="1" data-bbox="362 884 835 1059"> <thead> <tr> <th>Motor rated power</th> <th>Constant magnetizing time</th> </tr> </thead> <tbody> <tr> <td>< 1 kW</td> <td>≥ 50 to 100 ms</td> </tr> <tr> <td>1 to 10 kW</td> <td>≥ 100 to 200 ms</td> </tr> <tr> <td>10 to 200 kW</td> <td>≥ 200 to 1000 ms</td> </tr> <tr> <td>200 to 1000 kW</td> <td>≥ 1000 to 2000 ms</td> </tr> </tbody> </table> <p>Note: This parameter cannot be changed while the drive is running.</p> | Motor rated power | Constant magnetizing time | < 1 kW | ≥ 50 to 100 ms | 1 to 10 kW | ≥ 100 to 200 ms | 10 to 200 kW | ≥ 200 to 1000 ms | 200 to 1000 kW | ≥ 1000 to 2000 ms | 500 ms |
| Motor rated power | Constant magnetizing time | | | | | | | | | | | | |
| < 1 kW | ≥ 50 to 100 ms | | | | | | | | | | | | |
| 1 to 10 kW | ≥ 100 to 200 ms | | | | | | | | | | | | |
| 10 to 200 kW | ≥ 200 to 1000 ms | | | | | | | | | | | | |
| 200 to 1000 kW | ≥ 1000 to 2000 ms | | | | | | | | | | | | |
| | 0...10000 ms | Constant DC magnetizing time. | 1 = 1 ms | | | | | | | | | | |
| 21.03 | Stop mode | <p>Selects the way the motor is stopped when a stop command is received.</p> <p>Additional braking is possible by selecting flux braking (see parameter 97.05 Flux braking).</p> | Coast | | | | | | | | | | |
| | Coast | <p>Stop by switching off the output semiconductors of the drive. The motor coasts to a stop.</p> <p> WARNING! If a mechanical brake is used, ensure it is safe to stop the drive by coasting.</p> | 0 | | | | | | | | | | |
| | Ramp | Stop along the active deceleration ramp. See parameter group 23 Speed reference ramp on page 203 . | 1 | | | | | | | | | | |
| | Torque limit | Stop according to torque limits (parameters 30.19 and 30.20). | 2 | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------------|---|--|
| 21.04 | <i>Emergency stop mode</i> | Selects the way the motor is stopped when an emergency stop command is received. The source of the emergency stop signal is selected by parameter <i>21.05 Emergency stop source</i> . | <i>Ramp stop (Off1); Coast stop (Off2) (95.20 b1); Eme ramp stop (Off3) (95.20 b2)</i> |
| | Ramp stop (Off1) | With the drive running: <ul style="list-style-type: none"> • 1 = Normal operation. • 0 = Normal stop along the standard deceleration ramp defined for the particular reference type (see section <i>Reference ramping</i> [page 58]). After the drive has stopped, it can be restarted by removing the emergency stop signal and switching the start signal from 0 to 1. With the drive stopped: <ul style="list-style-type: none"> • 1 = Starting allowed. • 0 = Starting not allowed. | 0 |
| | Coast stop (Off2) | With the drive running: <ul style="list-style-type: none"> • 1 = Normal operation. • 0 = Stop by coasting. The drive can be restarted by restoring the start interlock signal and switching the start signal from 0 to 1. With the drive stopped: <ul style="list-style-type: none"> • 1 = Starting allowed. • 0 = Starting not allowed. | 1 |
| | Eme ramp stop (Off3) | With the drive running: <ul style="list-style-type: none"> • 1 = Normal operation. • 0 = Stop by ramping along emergency stop ramp defined by parameter <i>23.23 Emergency stop time</i>. After the drive has stopped, it can be restarted by removing the emergency stop signal and switching the start signal from 0 to 1. With the drive stopped: <ul style="list-style-type: none"> • 1 = Starting allowed. • 0 = Starting not allowed. | 2 |
| 21.05 | <i>Emergency stop source</i> | Selects the source of the emergency stop signal. The stop mode is selected by parameter <i>21.04 Emergency stop mode</i> . 0 = Emergency stop active 1 = Normal operation Note: This parameter cannot be changed while the drive is running. | <i>Inactive (true); DI4 (95.20 b1, 95.20 b2)</i> |
| | Active (false) | 0. | 0 |
| | Inactive (true) | 1. | 1 |
| | DIIL | DIIL input (<i>10.02 DI delayed status</i> , bit 15). | 2 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 3 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 4 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 5 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 6 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 7 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 8 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------|---|-----------------------|
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 11 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 12 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 21.06 | <i>Zero speed limit</i> | Defines the zero speed limit. The motor is stopped along a speed ramp (when ramped stop is selected) until the defined zero speed limit is reached. After the zero speed delay, the motor coasts to a stop. | 30.00 rpm |
| | 0.00...30000.00 rpm | Zero speed limit. | See par. <i>46.01</i> |
| 21.07 | <i>Zero speed delay</i> | <p>Defines the delay for the zero speed delay function. The function is useful in applications where a smooth and quick restarting is essential. During the delay, the drive knows the rotor position accurately.</p> <p><u>Without zero speed delay:</u> The drive receives a stop command and decelerates along a ramp. When actual motor speed falls below the value of parameter <i>21.06 Zero speed limit</i>, inverter modulation is stopped and the motor coasts to a standstill.</p>  <p><u>With zero speed delay:</u> The drive receives a stop command and decelerates along a ramp. When actual motor speed falls below the value of parameter <i>21.06 Zero speed limit</i>, the zero speed delay function activates. During the delay the function keeps the speed controller live: the inverter modulates, motor is magnetized and the drive is ready for a quick restart.</p>  | 0 ms |
| | 0...30000 ms | Zero speed delay. | 1 = 1 ms |




| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | |
|---|---|--|-----------------------|-----|-------|---|--|---|---|--------|----------|
| 21.08 | <i>DC current control</i> | <p>Activates/deactivates the DC hold and post-magnetization functions. See section <i>DC magnetization</i> (page 77).</p> <p>Notes:</p> <ul style="list-style-type: none"> • These functions are only available in speed control in DTC motor control mode (see page 53). • DC magnetization causes the motor to heat up. In applications where long DC magnetization times are required, externally ventilated motors should be used. If the DC magnetization period is long, DC magnetization cannot prevent the motor shaft from rotating if a constant load is applied to the motor. | 0000b | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 = Enable DC hold. See section <i>DC hold</i> (page 77). Note: The DC hold function has no effect if the start signal is switched off.</td> </tr> <tr> <td>1</td> <td>1 = Enable post-magnetization. See section <i>Post-magnetization</i> (page 77). Note: Post-magnetization is only available when ramping is the selected stop mode (see parameter <i>21.03 Stop mode</i>).</td> </tr> <tr> <td>2...15</td> <td>Reserved</td> </tr> </tbody> </table> | | | | Bit | Value | 0 | 1 = Enable DC hold. See section <i>DC hold</i> (page 77). Note: The DC hold function has no effect if the start signal is switched off. | 1 | 1 = Enable post-magnetization. See section <i>Post-magnetization</i> (page 77). Note: Post-magnetization is only available when ramping is the selected stop mode (see parameter <i>21.03 Stop mode</i>). | 2...15 | Reserved |
| Bit | Value | | | | | | | | | | |
| 0 | 1 = Enable DC hold. See section <i>DC hold</i> (page 77). Note: The DC hold function has no effect if the start signal is switched off. | | | | | | | | | | |
| 1 | 1 = Enable post-magnetization. See section <i>Post-magnetization</i> (page 77). Note: Post-magnetization is only available when ramping is the selected stop mode (see parameter <i>21.03 Stop mode</i>). | | | | | | | | | | |
| 2...15 | Reserved | | | | | | | | | | |
| | 0000b...0011b | DC magnetization selection. | 1 = 1 | | | | | | | | |
| 21.09 | <i>DC hold speed</i> | Defines the DC hold speed. See parameter <i>21.08 DC current control</i> , and section <i>DC hold</i> (page 77). | 5.00 rpm | | | | | | | | |
| | 0.00...1000.00 rpm | DC hold speed. | See par. <i>46.01</i> | | | | | | | | |
| 21.10 | <i>DC current reference</i> | Defines the DC hold current in percent of the motor nominal current. See parameter <i>21.08 DC current control</i> , and section <i>DC magnetization</i> (page 77). | 30.0% | | | | | | | | |
| | 0.0...100.0% | DC hold current. | 1 = 1% | | | | | | | | |
| 21.11 | <i>Post magnetization time</i> | Defines the length of time for which post-magnetization is active after stopping the motor. The magnetization current is defined by parameter <i>21.10 DC current reference</i> . See parameter <i>21.08 DC current control</i> . | 0 s | | | | | | | | |
| | 0...3000 s | Post-magnetization time. | 1 = 1 s | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---|--|----------------|
| 21.12 | <i>Continuous magnetization command</i> | <p>Activates/deactivates (or selects a source that activates/deactivates) continuous magnetization. See section <i>Continuous magnetization</i> (page 78). The magnetization current is calculated on the basis of flux reference (see parameter group <i>97 Motor control</i>).</p> <p>Notes:</p> <ul style="list-style-type: none"> • This function is only available when ramping is the selected stop mode (see parameter <i>21.03 Stop mode</i>), and only in speed control in DTC motor control mode (see page 53). • Continuous magnetization causes the motor to heat up. In applications where long magnetization times are required, externally ventilated motors should be used. • Continuous magnetization may not be able to prevent the motor shaft from rotating during a long period if a constant load is applied to the motor. <p>0 = Normal operation 1 = Magnetization active</p> | <i>Off</i> |
| | Off | 0. | 0 |
| | On | 1. | 1 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 21.13 | <i>Autophasing mode</i> | Selects the way autophasing is performed. See section <i>Autophasing</i> on page 73. | <i>Turning</i> |
| | Turning | This mode gives the most accurate autophasing result. This mode can be used, and is recommended, if the motor is allowed to rotate and the start-up is not time-critical. Note: This mode will cause the motor to rotate. The load torque must be less than 5%. | 0 |
| | Standstill 1 | Faster than the <i>Turning</i> mode, but not as accurate. The motor will not rotate. | 1 |
| | Standstill 2 | An alternative standstill autophasing mode that can be used if the <i>Turning</i> mode cannot be used, and the <i>Standstill 1</i> mode gives erratic results. However, this mode is considerably slower than <i>Standstill 1</i> . | 2 |
| | Turning with Z-pulse | This mode should be used if the zero pulse signal of the pulse encoder is to be observed, and other modes do not give a result. The motor will turn until a zero pulse is detected. | 3 |
| 21.18 | <i>Auto restart time</i> | <p>The motor can be automatically started after a short supply power failure using the automatic restart function. See section <i>Automatic restart</i> (page 80).</p> <p>When this parameter is set to 0.0 seconds, automatic restarting is disabled. Otherwise, the parameter defines the maximum duration of the power failure after which restarting is attempted. Note that this time also includes the DC pre-charging delay.</p> <p> WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a supply break.</p> | 5.0 s |
| | 0.0 s | Automatic restarting disabled. | 0 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------------------------------------|------------------------------|--|-----------------------|
| | 0.1...5.0 s | Maximum power failure duration. | 1 = 1 s |
| 21.19 | <i>Scalar start mode</i> | <p>Selects the motor start function for the scalar motor control mode, i.e. when <i>99.04 Motor ctrl mode</i> is set to <i>Scalar</i>.</p> <p>Notes:</p> <ul style="list-style-type: none"> The start function for the DTC motor control mode is selected by parameter <i>21.01 Start mode</i>. With permanent magnet motors, <i>Automatic</i> start mode must be used. This parameter cannot be changed while the drive is running. <p>See also section <i>DC magnetization</i> (page 77).</p> | <i>Normal</i> |
| | Normal | Immediate start from zero speed. | 0 |
| | Const time | <p>The drive pre-magnetizes the motor before start. The pre-magnetizing time is defined by parameter <i>21.02 Magnetization time</i>. This mode should be selected if constant pre-magnetizing time is required. This setting also guarantees the highest possible break-away torque when the pre-magnetizing time is set long enough.</p> <p>Note: This mode cannot be used to start into a rotating motor.</p> <p> WARNING! The drive starts after the set magnetizing time has passed even if motor magnetization is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetizing time is long enough to allow generation of full magnetization and torque.</p> | 1 |
| | Automatic | This setting should be used in applications where flying starts (i.e. starting into a rotating motor) are required. | 2 |
| 22 Speed reference selection | | Speed reference selection settings; motor potentiometer settings. See the control chain diagrams on pages 476...477. | |
| 22.01 | <i>Speed ref unlimited</i> | Displays the output of the speed reference selection block. See the control chain diagram on page 477. This parameter is read-only. | - |
| | -30000.00 ...30000.00 rpm | Value of the selected speed reference. | See par. <i>46.01</i> |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------|--|-------------------|
| 22.11 | <i>Speed ref1 source</i> | <p>Selects speed reference source 1.</p> <p>Two signal sources can be defined by this parameter and 22.12 Speed ref2 source. A digital source selected by 22.14 Speed ref1/2 selection can be used to switch between the two sources, or a mathematical function (22.13 Speed ref1 function) applied to the two signals to create the reference.</p> | <i>AI1 scaled</i> |
| | Zero | None. | 0 |
| | AI1 scaled | 12.12 AI1 scaled value (see page 141). | 1 |
| | AI2 scaled | 12.22 AI2 scaled value (see page 143). | 2 |
| | FB A ref1 | 03.05 FB A reference 1 (see page 108). | 4 |
| | FB A ref2 | 03.06 FB A reference 2 (see page 108). | 5 |
| | EFB ref1 | 03.09 EFB reference 1 (see page 108). | 8 |
| | EFB ref2 | 03.10 EFB reference 2 (see page 108). | 9 |
| | Motor potentiometer | 22.80 Motor potentiometer ref act (output of the motor potentiometer). | 15 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 22.12 | <i>Speed ref2 source</i> | <p>Selects speed reference source 2.</p> <p>For the selections, and a diagram of reference source selection, see parameter 22.11 Speed ref1 source.</p> | <i>Zero</i> |
| 22.13 | <i>Speed ref1 function</i> | <p>Selects a mathematical function between the reference sources selected by parameters 22.11 Speed ref1 source and 22.12 Speed ref2 source. See diagram at 22.11 Speed ref1 source.</p> | <i>Ref1</i> |
| | Ref1 | Signal selected by 22.11 Speed ref1 source is used as speed reference 1 as such (no function applied). | 0 |
| | Add (ref1 + ref2) | The sum of the reference sources is used as speed reference 1. | 1 |
| | Sub (ref1 - ref2) | The subtraction ([22.11 Speed ref1 source] - [22.12 Speed ref2 source]) of the reference sources is used as speed reference 1. | 2 |
| | Mul (ref1 × ref2) | The multiplication of the reference sources is used as speed reference 1. | 3 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------|---|-----------------------------------|
| | Min (ref1, ref2) | The smaller of the reference sources is used as speed reference 1. | 4 |
| | Max (ref1, ref2) | The greater of the reference sources is used as speed reference 1. | 5 |
| 22.14 | <i>Speed ref1/2 selection</i> | Configures the selection between speed references 1 and 2. See diagram at 22.11 Speed ref1 source . 0 = Speed reference 1 1 = Speed reference 2 | <i>Follow Ext1/Ext2 selection</i> |
| | Speed reference 1 | 0. | 0 |
| | Speed reference 2 | 1. | 1 |
| | Follow Ext1/Ext2 selection | Speed reference 1 is used when external control location EXT1 is active. Speed reference 2 is used when external control location EXT2 is active. See also parameter 19.11 Ext1/Ext2 selection . | 2 |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 3 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 4 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 5 |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 6 |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 7 |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 8 |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status , bit 0). | 11 |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status , bit 1). | 12 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 22.15 | <i>Speed additive 1 source</i> | Defines a reference to be added to the speed reference after reference selection (see page 476). For the selections, see parameter 22.11 Speed ref1 source . Note: For safety reasons, the additive is not applied when any of the stop functions are active. | <i>Zero</i> |
| 22.16 | <i>Speed share</i> | Defines a scaling factor for the selected speed reference (speed reference 1 or 2, multiplied by the defined value). Speed reference 1 or 2 is selected by parameter 22.14 Speed ref1/2 selection . | 1.000 |
| | -8.000...8.000 | Speed reference scaling factor. | 1000 = 1 |
| 22.17 | <i>Speed additive 2 source</i> | Defines a reference to be added to the speed reference after the speed share function (see page 476). For the selections, see parameter 22.11 Speed ref1 source . Note: For safety reasons, the additive is not applied when any of the stop functions are active. | <i>Zero</i> |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|---|---|-----------------------|--|--|--|-----------------------|---------------------|--|--|------|------------------|---|---|------------------|----------|---|---|------------------|---|---|---|------------------|---|---|---|------------------|---|---|---|------------------|---|---|---|------------------|---|---|---|------------------|
| 22.21 | <i>Constant speed function</i> | Determines how constant speeds are selected, and whether the rotation direction signal is considered or not when applying a constant speed. | 0000b | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td rowspan="2">0</td> <td rowspan="2">Constant speed mode</td> <td>1 = Packed: 7 constant speeds are selectable using the three sources defined by parameters 22.22, 22.23 and 22.24.</td> </tr> <tr> <td>0 = Separate: Constant speeds 1, 2 and 3 are separately activated by the sources defined by parameters 22.22, 22.23 and 22.24 respectively. In case of conflict, the constant speed with the smaller number takes priority.</td> </tr> <tr> <td rowspan="2">1</td> <td rowspan="2">Direction enable</td> <td>1 = Start dir: To determine running direction for a constant speed, the sign of the constant speed setting (parameters 22.26...22.32) is multiplied by the direction signal (forward: +1, reverse: -1). This effectively allows the drive to have 14 (7 forward, 7 reverse) constant speeds if all values in 22.26...22.32 are positive.  WARNING: If the direction signal is reverse and the active constant speed is negative, the drive will run in the forward direction.</td> </tr> <tr> <td>0 = Accord Par: The running direction for the constant speed is determined by the sign of the constant speed setting (parameters 22.26...22.32).</td> </tr> <tr> <td>2...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | | | | Bit | Name | Information | 0 | Constant speed mode | 1 = Packed: 7 constant speeds are selectable using the three sources defined by parameters 22.22 , 22.23 and 22.24 . | 0 = Separate: Constant speeds 1, 2 and 3 are separately activated by the sources defined by parameters 22.22 , 22.23 and 22.24 respectively. In case of conflict, the constant speed with the smaller number takes priority. | 1 | Direction enable | 1 = Start dir: To determine running direction for a constant speed, the sign of the constant speed setting (parameters 22.26...22.32) is multiplied by the direction signal (forward: +1, reverse: -1). This effectively allows the drive to have 14 (7 forward, 7 reverse) constant speeds if all values in 22.26...22.32 are positive.  WARNING: If the direction signal is reverse and the active constant speed is negative, the drive will run in the forward direction. | 0 = Accord Par: The running direction for the constant speed is determined by the sign of the constant speed setting (parameters 22.26...22.32). | 2...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | |
| Bit | Name | Information | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Constant speed mode | 1 = Packed: 7 constant speeds are selectable using the three sources defined by parameters 22.22 , 22.23 and 22.24 . | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 = Separate: Constant speeds 1, 2 and 3 are separately activated by the sources defined by parameters 22.22 , 22.23 and 22.24 respectively. In case of conflict, the constant speed with the smaller number takes priority. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Direction enable | 1 = Start dir: To determine running direction for a constant speed, the sign of the constant speed setting (parameters 22.26...22.32) is multiplied by the direction signal (forward: +1, reverse: -1). This effectively allows the drive to have 14 (7 forward, 7 reverse) constant speeds if all values in 22.26...22.32 are positive.  WARNING: If the direction signal is reverse and the active constant speed is negative, the drive will run in the forward direction. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | 0 = Accord Par: The running direction for the constant speed is determined by the sign of the constant speed setting (parameters 22.26...22.32). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0000b...0011b | | Constant speed configuration word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 22.22 | <i>Constant speed sel1</i> | When bit 0 of parameter 22.21 Constant speed function is 0 (Separate), selects a source that activates constant speed 1. When bit 0 of parameter 22.21 Constant speed function is 1 (Packed), this parameter and parameters 22.23 Constant speed sel2 and 22.24 Constant speed sel3 select three sources whose states activate constant speeds as follows: | <i>DI5</i> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Source defined by par. 22.22</th> <th>Source defined by par. 22.23</th> <th>Source defined by par. 22.24</th> <th>Constant speed active</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>None</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>Constant speed 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>Constant speed 2</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>Constant speed 3</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>Constant speed 4</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>Constant speed 5</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>Constant speed 6</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>Constant speed 7</td> </tr> </tbody> </table> | | | | Source defined by par. 22.22 | Source defined by par. 22.23 | Source defined by par. 22.24 | Constant speed active | 0 | 0 | 0 | None | 1 | 0 | 0 | Constant speed 1 | 0 | 1 | 0 | Constant speed 2 | 1 | 1 | 0 | Constant speed 3 | 0 | 0 | 1 | Constant speed 4 | 1 | 0 | 1 | Constant speed 5 | 0 | 1 | 1 | Constant speed 6 | 1 | 1 | 1 | Constant speed 7 |
| Source defined by par. 22.22 | Source defined by par. 22.23 | Source defined by par. 22.24 | Constant speed active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 0 | None | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | 0 | Constant speed 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 0 | Constant speed 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | 0 | Constant speed 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 1 | Constant speed 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | 1 | Constant speed 5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 1 | Constant speed 6 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | 1 | Constant speed 7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Not selected | 0 (always off). | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Selected | 1 (always on). | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|--------------|-------------------------------|--|--------------------------|
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| <i>22.23</i> | <i>Constant speed sel2</i> | When bit 0 of parameter <i>22.21 Constant speed function</i> is 0 (Separate), selects a source that activates constant speed 2. When bit 0 of parameter <i>22.21 Constant speed function</i> is 1 (Packed), this parameter and parameters <i>22.22 Constant speed sel1</i> and <i>22.24 Constant speed sel3</i> select three sources that are used to activate constant speeds. See table at parameter <i>22.22 Constant speed sel1</i> . For the selections, see parameter <i>22.22 Constant speed sel1</i> . | <i>Not selected</i> |
| <i>22.24</i> | <i>Constant speed sel3</i> | When bit 0 of parameter <i>22.21 Constant speed function</i> is 0 (Separate), selects a source that activates constant speed 3. When bit 0 of parameter <i>22.21 Constant speed function</i> is 1 (Packed), this parameter and parameters <i>22.22 Constant speed sel1</i> and <i>22.23 Constant speed sel2</i> select three sources that are used to activate constant speeds. See table at parameter <i>22.22 Constant speed sel1</i> . For the selections, see parameter <i>22.22 Constant speed sel1</i> . | <i>Not selected</i> |
| <i>22.26</i> | <i>Constant speed 1</i> | Defines constant speed 1 (the speed the motor will turn when constant speed 1 is selected). | 300.00 rpm |
| | -30000.00 ... 30000.00 rpm | Constant speed 1. | See par. <i>46.01</i> |
| <i>22.27</i> | <i>Constant speed 2</i> | Defines constant speed 2. | 0.00 rpm |
| | -30000.00 ... 30000.00 rpm | Constant speed 2. | See par. <i>46.01</i> |
| <i>22.28</i> | <i>Constant speed 3</i> | Defines constant speed 3. | 0.00 rpm |
| | -30000.00 ... 30000.00 rpm | Constant speed 3. | See par. <i>46.01</i> |
| <i>22.29</i> | <i>Constant speed 4</i> | Defines constant speed 4. | 0.00 rpm |
| | -30000.00 ... 30000.00 rpm | Constant speed 4. | See par. <i>46.01</i> |
| <i>22.30</i> | <i>Constant speed 5</i> | Defines constant speed 5. | 0.00 rpm |
| | -30000.00 ... 30000.00 rpm | Constant speed 5. | See par. <i>46.01</i> |
| <i>22.31</i> | <i>Constant speed 6</i> | Defines constant speed 6. | 0.00 rpm |
| | -30000.00 ... 30000.00 rpm | Constant speed 6. | See par. <i>46.01</i> |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | |
|---|---|---|-----------------------------------|-----|------|-------------|---|--------|--------------------------------------|--|---|-----------|---|--|--------|----------|--|
| 22.32 | Constant speed 7 | Defines constant speed 7. | 0.00 rpm | | | | | | | | | | | | | | |
| | -30000.00 ... 30000.00 rpm | Constant speed 7. | See par. 46.01 | | | | | | | | | | | | | | |
| 22.41 | Speed ref safe | Defines a safe speed reference value that is used with supervision functions such as <ul style="list-style-type: none"> • 12.03 AI supervision function • 49.05 Communication loss action • 50.02 FBA A comm loss func • 50.32 FBA B comm loss func • 58.14 Communication loss action. | 0.00 rpm | | | | | | | | | | | | | | |
| | -30000.00 ...30000.00 rpm | Safe speed reference. | See par. 46.01 | | | | | | | | | | | | | | |
| 22.42 | Jogging 1 ref | Defines the speed reference for jogging function 1. | 0.00 rpm | | | | | | | | | | | | | | |
| | -30000.00 ... 30000.00 rpm | Speed reference for jogging function 1. | See par. 46.01 | | | | | | | | | | | | | | |
| 22.43 | Jogging 2 ref | Defines the speed reference for jogging function 2. | 0.00 rpm | | | | | | | | | | | | | | |
| | -30000.00 ... 30000.00 rpm | Speed reference for jogging function 2. | See par. 46.01 | | | | | | | | | | | | | | |
| 22.51 | Critical speed function | Enables/disables the critical speeds function. Also determines whether the specified ranges are effective in both rotating directions or not. See also section Critical speeds (frequencies) (page 59). | 0000b | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td rowspan="2">0</td> <td rowspan="2">Enable</td> <td>1 = Enable: Critical speeds enabled.</td> </tr> <tr> <td>0 = Disable: Critical speeds disabled.</td> </tr> <tr> <td rowspan="2">1</td> <td rowspan="2">Sign mode</td> <td>1 = Signed: The signs of parameters 22.52...22.57 are taken into account.</td> </tr> <tr> <td>0 = Absolute: Parameters 22.52...22.57 are handled as absolute values. Each range is effective in both directions of rotation.</td> </tr> <tr> <td>2...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | | | | Bit | Name | Information | 0 | Enable | 1 = Enable: Critical speeds enabled. | 0 = Disable: Critical speeds disabled. | 1 | Sign mode | 1 = Signed: The signs of parameters 22.52...22.57 are taken into account. | 0 = Absolute: Parameters 22.52...22.57 are handled as absolute values. Each range is effective in both directions of rotation. | 2...15 | Reserved | |
| Bit | Name | Information | | | | | | | | | | | | | | | |
| 0 | Enable | 1 = Enable: Critical speeds enabled. | | | | | | | | | | | | | | | |
| | | 0 = Disable: Critical speeds disabled. | | | | | | | | | | | | | | | |
| 1 | Sign mode | 1 = Signed: The signs of parameters 22.52...22.57 are taken into account. | | | | | | | | | | | | | | | |
| | | 0 = Absolute: Parameters 22.52...22.57 are handled as absolute values. Each range is effective in both directions of rotation. | | | | | | | | | | | | | | | |
| 2...15 | Reserved | | | | | | | | | | | | | | | | |
| | 0000b...0011b | Critical speeds configuration word. | 1 = 1 | | | | | | | | | | | | | | |
| 22.52 | Critical speed 1 low | Defines the low limit for critical speed range 1. Note: This value must be less than or equal to the value of 22.53 Critical speed 1 high . | 0.00 rpm | | | | | | | | | | | | | | |
| | -30000.00 ...30000.00 rpm | Low limit for critical speed 1. | See par. 46.01 | | | | | | | | | | | | | | |
| 22.53 | Critical speed 1 high | Defines the high limit for critical speed range 1. Note: This value must be greater than or equal to the value of 22.52 Critical speed 1 low . | 0.00 rpm | | | | | | | | | | | | | | |
| | -30000.00 ...30000.00 rpm | High limit for critical speed 1. | See par. 46.01 | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|---|-----------------------------------|
| 22.54 | <i>Critical speed 2 low</i> | Defines the low limit for critical speed range 2. Note: This value must be less than or equal to the value of 22.55 Critical speed 2 high . | 0.00 rpm |
| | -30000.00 ...30000.00 rpm | Low limit for critical speed 2. | See par. 46.01 |
| 22.55 | <i>Critical speed 2 high</i> | Defines the high limit for critical speed range 2. Note: This value must be greater than or equal to the value of 22.54 Critical speed 2 low . | 0.00 rpm |
| | -30000.00 ...30000.00 rpm | High limit for critical speed 2. | See par. 46.01 |
| 22.56 | <i>Critical speed 3 low</i> | Defines the low limit for critical speed range 3. Note: This value must be less than or equal to the value of 22.57 Critical speed 3 high . | 0.00 rpm |
| | -30000.00 ...30000.00 rpm | Low limit for critical speed 3. | See par. 46.01 |
| 22.57 | <i>Critical speed 3 high</i> | Defines the high limit for critical speed range 3. Note: This value must be greater than or equal to the value of 22.56 Critical speed 3 low . | 0.00 rpm |
| | -30000.00 ...30000.00 rpm | High limit for critical speed 3. | See par. 46.01 |
| 22.71 | <i>Motor potentiometer function</i> | Activates and selects the mode of the motor potentiometer. See section Motor potentiometer (page 78). | <i>Disabled</i> |
| | Disabled | Motor potentiometer is disabled and its value set to 0. | 0 |
| | Enabled (init at stop/power-up) | When enabled, the motor potentiometer first adopts the value defined by parameter 22.72 Motor potentiometer initial value . When the drive is running, the value can be adjusted from the up and down sources defined by parameters 22.73 Motor potentiometer up source and 22.74 Motor potentiometer down source . A stop or a power cycle will reset the motor potentiometer to the initial value (22.72). | 1 |
| | Enabled (resume always) | As Enabled (init at stop/power-up) , but the motor potentiometer value is retained over a stop or a power cycle. | 2 |
| 22.72 | <i>Motor potentiometer initial value</i> | Defines an initial value (starting point) for the motor potentiometer. See the selections of parameter 22.71 Motor potentiometer function . | 0.00 |
| | -32768.00... 32767.00 | Initial value for motor potentiometer. | 1 = 1 |
| 22.73 | <i>Motor potentiometer up source</i> | Selects the source of motor potentiometer up signal. 0 = No change 1 = Increase motor potentiometer value. (If both the up and down sources are on, the potentiometer value will not change.) | <i>Not selected</i> |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 |

202 Parameters



| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|---|---------------------|
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 22.74 | <i>Motor potentiometer down source</i> | Selects the source of motor potentiometer down signal. 0 = No change 1 = Decrease motor potentiometer value. (If both the up and down sources are on, the potentiometer value will not change.) For the selections, see parameter 22.73 <i>Motor potentiometer up source</i> . | <i>Not selected</i> |
| 22.75 | <i>Motor potentiometer ramp time</i> | Defines the change rate of the motor potentiometer. This parameter specifies the time required for the motor potentiometer to change from minimum (22.76) to maximum (22.77). The same change rate applies in both directions. | 60.0 s |
| | 0.0 ... 3600.0 s | Motor potentiometer change time. | 10 = 1 s |
| 22.76 | <i>Motor potentiometer min value</i> | Defines the minimum value of the motor potentiometer. | -1500.00 |
| | -32768.00... 32767.00 | Motor potentiometer minimum. | 1 = 1 |
| 22.77 | <i>Motor potentiometer max value</i> | Defines the maximum value of the motor potentiometer. | 1500.00 |
| | -32768.00... 32767.00 | Motor potentiometer maximum. | 1 = 1 |
| 22.80 | <i>Motor potentiometer ref act</i> | Displays the output of the motor potentiometer function. (The motor potentiometer is configured using parameters 22.71...22.74.) This parameter is read-only. | - |
| | -32768.00... 32767.00 | Value of motor potentiometer. | 1 = 1 |
| 22.81 | <i>Speed reference act 1</i> | Displays the value of speed reference source 1 (selected by parameter 22.11 <i>Speed ref1 source</i>). See the control chain diagram on page 476. This parameter is read-only. | - |
| | -30000.00 ...30000.00 rpm | Value of reference source 1. | See par. 46.01 |
| 22.82 | <i>Speed reference act 2</i> | Displays the value of speed reference source 2 (selected by parameter 22.12 <i>Speed ref2 source</i>). See the control chain diagram on page 476. This parameter is read-only. | - |
| | -30000.00 ...30000.00 rpm | Value of reference source 2. | See par. 46.01 |

| No. | Name/Value | Description | Def/ FbEq16 |
|--------------------------------|------------------------------|---|--------------------------------|
| 22.83 | <i>Speed reference act 3</i> | Displays the value of speed reference after the mathematical function applied by parameter 22.13 Speed ref1 function and reference 1/2 selection (22.14 Speed ref1/2 selection). See the control chain diagram on page 476 . This parameter is read-only. | - |
| | -30000.00 ...30000.00 rpm | Speed reference after source selection. | See par. 46.01 |
| 22.84 | <i>Speed reference act 4</i> | Displays the value of speed reference after application of 1st speed additive (22.15 Speed additive 1 source). See the control chain diagram on page 476 . This parameter is read-only. | - |
| | -30000.00 ...30000.00 rpm | Speed reference after additive 1. | See par. 46.01 |
| 22.85 | <i>Speed reference act 5</i> | Displays the value of speed reference after the application of the speed share scaling factor (22.16 Speed share). See the control chain diagram on page 476 . This parameter is read-only. | - |
| | -30000.00 ...30000.00 rpm | Speed reference after speed share scaling. | See par. 46.01 |
| 22.86 | <i>Speed reference act 6</i> | Displays the value of speed reference after application of 2nd speed additive (22.17 Speed additive 2 source). See the control chain diagram on page 476 . This parameter is read-only. | - |
| | -30000.00 ...30000.00 rpm | Speed reference after additive 2. | See par. 46.01 |
| 22.87 | <i>Speed reference act 7</i> | Displays the value of speed reference before application of critical speeds. See the control chain diagram on page 477 . The value is received from 22.86 Speed reference act 6 unless overridden by <ul style="list-style-type: none"> • any constant speed • a jogging reference • network control reference • control panel reference • safe speed reference. This parameter is read-only. | - |
| | -30000.00 ...30000.00 rpm | Speed reference before application of critical speeds. | See par. 46.01 |
| 23 Speed reference ramp | | Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive). See the control chain diagram on page 477 . | |
| 23.01 | <i>Speed ref ramp input</i> | Displays the used speed reference (in rpm) before it enters the ramping and shaping functions. See the control chain diagram on page 477 . This parameter is read-only. | - |
| | -30000.00 ...30000.00 rpm | Speed reference before ramping and shaping. | See par. 46.01 |

204 Parameters


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------------|---|---------------------------------------|
| 23.02 | <i>Speed ref ramp output</i> | Displays the ramped and shaped speed reference in rpm. See the control chain diagram on page 477. This parameter is read-only. | - |
| | -30000.00 ...30000.00 rpm | Speed reference after ramping and shaping. | See par. 46.01 |
| 23.11 | <i>Ramp set selection</i> | Selects the source that switches between the two sets of acceleration/deceleration ramp times defined by parameters 23.12...23.15. 0 = Acceleration time 1 and deceleration time 1 are active 1 = Acceleration time 2 and deceleration time 2 are active | <i>D14; Acc/Dec time 2 (95.20 b1)</i> |
| | Acc/Dec time 1 | 0. | 0 |
| | Acc/Dec time 2 | 1. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 23.12 | <i>Acceleration time 1</i> | Defines acceleration time 1 as the time required for the speed to change from zero to the speed defined by parameter 46.01 <i>Speed scaling</i> (not to parameter 30.12 <i>Maximum speed</i>). If the speed reference increases faster than the set acceleration rate, the motor speed will follow the acceleration rate. If the speed reference increases slower than the set acceleration rate, the motor speed will follow the reference. If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits. | 20.000 s |
| | 0.000...1800.000 s | Acceleration time 1. | 10 = 1 s |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------------|--|----------------|
| 23.13 | Deceleration time 1 | <p>Defines deceleration time 1 as the time required for the speed to change from the speed defined by parameter 46.01 Speed scaling (not from parameter 30.12 Maximum speed) to zero.</p> <p>If the speed reference decreases slower than the set deceleration rate, the motor speed will follow the reference.</p> <p>If the reference changes faster than the set deceleration rate, the motor speed will follow the deceleration rate.</p> <p>If the deceleration rate is set too short, the drive will automatically prolong the deceleration in order not to exceed drive torque limits (or not to exceed a safe DC link voltage). If there is any doubt about the deceleration time being too short, ensure that DC overvoltage control is on (parameter 30.30 Overvoltage control).</p> <p>Note: If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor.</p> | 20.000 s |
| | 0.000...1800.000 s | Deceleration time 1. | 10 = 1 s |
| 23.14 | Acceleration time 2 | Defines acceleration time 2. See parameter 23.12 Acceleration time 1 . | 60.000 s |
| | 0.000...1800.000 s | Acceleration time 2. | 10 = 1 s |
| 23.15 | Deceleration time 2 | Defines deceleration time 2. See parameter 23.13 Deceleration time 1 . | 60.000 s |
| | 0.000...1800.000 s | Deceleration time 2. | 10 = 1 s |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------|---|----------------|
| 23.16 | <i>Shape time acc 1</i> | <p>Defines the shape of the acceleration ramp at the beginning of the acceleration.</p> <p>0.000 s: Linear ramp. Suitable for steady acceleration or deceleration and for slow ramps.</p> <p>0.001...1000.000 s: S-curve ramp. S-curve ramps are ideal for lifting applications. The S-curve consists of symmetrical curves at both ends of the ramp and a linear part in between.</p> <p>Acceleration:</p>  <p>Deceleration:</p>  | 0.000 s |
| | 0.000...1800.000 s | Ramp shape at start of acceleration. | 10 = 1 s |
| 23.17 | <i>Shape time acc 2</i> | Defines the shape of the acceleration ramp at the end of the acceleration. See parameter 23.16 Shape time acc 1 . | 0.000 s |
| | 0.000...1800.000 s | Ramp shape at end of acceleration. | 10 = 1 s |
| 23.18 | <i>Shape time dec 1</i> | Defines the shape of the deceleration ramp at the beginning of the deceleration. See parameter 23.16 Shape time acc 1 . | 0.000 s |
| | 0.000...1800.000 s | Ramp shape at start of deceleration. | 10 = 1 s |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------------|---|-----------------|
| 23.19 | <i>Shape time dec 2</i> | Defines the shape of the deceleration ramp at the end of the deceleration. See parameter 23.16 Shape time acc 1 . | 0.000 s |
| | 0.000...1800.000 s | Ramp shape at end of deceleration. | 10 = 1 s |
| 23.20 | <i>Acc time jogging</i> | Defines the acceleration time for the jogging function i.e. the time required for the speed to change from zero to the speed value defined by parameter 46.01 Speed scaling . | 60.000 s |
| | 0.000 ...1800.000 s | Acceleration time for jogging. | 10 = 1 s |
| 23.21 | <i>Dec time jogging</i> | Defines the deceleration time for the jogging function i.e. the time required for the speed to change from the speed value defined by parameter 46.01 Speed scaling to zero. | 60.000 s |
| | 0.000 ...1800.000 s | Deceleration time for jogging. | 10 = 1 s |
| 23.23 | <i>Emergency stop time</i> | In speed control mode, this parameter defines the deceleration rate for emergency stop Off3 as the time it would take for the speed to decrease from the value of parameter 46.01 Speed scaling to zero. This also applies to torque control (if present) because the drive switches to speed control on receiving an emergency stop Off3 command. In frequency control mode, this parameter specifies the time it would take for the frequency to decrease from the value of 46.02 Frequency scaling to zero. The emergency stop mode and activation source are selected by parameters 21.04 Emergency stop mode and 21.05 Emergency stop source respectively. Emergency stop can also be activated through fieldbus. Note: Emergency stop Off1 uses the standard deceleration ramp as defined by parameters 23.11...23.19 (speed control) or 28.71...28.75 (frequency control). | 3.000 s |
| | 0.000...1800.000 s | Emergency stop Off3 deceleration time. | 10 = 1 s |
| 23.24 | <i>Speed ramp in zero source</i> | Selects a source that forces the speed reference to zero just before it enters the ramp function. 0 = Force speed reference to zero before the ramp function 1 = Speed reference continues towards the ramp function as normal | <i>Inactive</i> |
| | Active | 0. | 0 |
| | Inactive | 1. | 1 |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 5 |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 6 |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------------|---|--------------------------------|
| 23.26 | <i>Ramp out balancing enable</i> | <p>Selects the source for enabling/disabling speed reference ramp balancing.</p> <p>This function is used to generate a smooth transfer from a torque- or tension-controlled motor back to being speed-controlled. The balancing output would be tracking the present "line" speed of the application and when transfer is required, the speed reference can then be quickly "seeded" to the correct line speed. Balancing is also possible in the speed controller, see parameter 25.09 Speed ctrl balancing enable.</p> <p>See also parameter 23.27 Ramp out balancing ref.</p> <p>0 = Disabled 1 = Enabled</p> | <i>Not selected</i> |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 5 |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 6 |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 23.27 | <i>Ramp out balancing ref</i> | <p>Defines the reference for speed ramp balancing. The output of the ramp generator is forced to this value when balancing is enabled by parameter 23.26 Ramp out balancing enable.</p> | 0.00 rpm |
| | -30000.00 ...30000.00 rpm | Speed ramp balancing reference. | See par. 46.01 |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---|---|---------------------|
| 23.28 | <i>Variable slope enable</i> | <p>Activates the variable slope function, which controls the slope of the speed ramp during a speed reference change. This allows for a constantly variable ramp rate to be generated, instead of just the standard two ramps normally available.</p> <p>If the update interval of the signal from an external control system and the variable slope rate (23.29 <i>Variable slope rate</i>) are equal, the resulting speed reference (23.02 <i>Speed ref ramp output</i>) is a straight line.</p>  <p>t = update interval of signal from external control system A = speed reference change during t</p> <p>This function is only active in remote control.</p> | <i>Off</i> |
| | Off | Variable slope disabled. | 0 |
| | On | Variable slope enabled (not available in local control). | 1 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 23.29 | <i>Variable slope rate</i> | <p>Defines the rate of the speed reference change when variable slope is enabled by parameter 23.28 <i>Variable slope enable</i>.</p> <p>For the best result, enter the reference update interval into this parameter.</p> | 50 ms |
| | 2...30000 ms | Variable slope rate. | 1 = 1 ms |
| 23.39 | <i>Follower speed correction out</i> | <p>Displays the speed correction term for the load share function with a speed-controlled follower drive.</p> <p>See section <i>Motor control</i> (page 57).</p> <p>This parameter is read-only.</p> | - |
| | -30000.00 ...30000.00 rpm | Speed correction term. | See par. 46.01 |
| 23.40 | <i>Follower speed correction enable</i> | <p>With a speed-controlled follower, selects the source for enabling/disabling the load share function.</p> <p>See section <i>Motor control</i> (page 57).</p> <p>0 = Disabled 1 = Enabled</p> | <i>Not selected</i> |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |


| No. | Name/Value | Description | Def/ FbEq16 |
|--|---------------------------------------|--|----------------|
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 23.41 | <i>Follower speed correction gain</i> | Adjusts the gain of the speed correction term in a speed-controlled follower. In effect, defines how accurately the follower follows the master torque. A greater value results in a more accurate performance. See section <i>Motor control</i> (page 57). | 1.00% |
| | 0.00...100.00% | Speed correction term adjustment. | 1 = 1% |
| 24 Speed reference conditioning | | | |
| 24 Speed reference conditioning | | Speed error calculation; speed error window control configuration; speed error step. See the control chain diagrams on pages 481 and 483. | |
| 24.01 | <i>Used speed reference</i> | Displays the ramped and corrected speed reference (before speed error calculation). See the control chain diagram on page 481. This parameter is read-only. | - |
| | -30000.00 ...30000.00 rpm | Speed reference used for speed error calculation. | See par. 46.01 |
| 24.02 | <i>Used speed feedback</i> | Displays the speed feedback used for speed error calculation. See the control chain diagram on page 481. This parameter is read-only. | - |
| | -30000.00 ...30000.00 rpm | Speed feedback used for speed error calculation. | See par. 46.01 |
| 24.03 | <i>Speed error filtered</i> | Displays the filtered speed error. See the control chain diagram on page 481. This parameter is read-only. | - |
| | -30000.0 ...30000.0 rpm | Filtered speed error. | See par. 46.01 |
| 24.04 | <i>Speed error inverted</i> | Displays the inverted (unfiltered) speed error. See the control chain diagram on page 481. This parameter is read-only. | - |
| | -30000.0 ...30000.0 rpm | Inverted speed error. | See par. 46.01 |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------|--|--------------------------------|
| 24.11 | <i>Speed correction</i> | <p>Defines a speed reference correction, ie. a value added to the existing reference between ramping and limitation. This is useful to trim the speed if necessary, for example to adjust draw between sections of a paper machine.</p> <p>Note: For safety reasons, the correction is not applied when an emergency stop is active.</p> <p> WARNING! If the speed reference correction exceeds 21.06 Zero speed limit, a ramp stop may be impossible. Make sure the correction is reduced or removed when a ramp stop is required.</p> <p>See the control chain diagram on page 481.</p> | 0.00 rpm |
| | -10000.00 ...10000.00 rpm | Speed reference correction. | See par. 46.01 |
| 24.12 | <i>Speed error filter time</i> | <p>Defines the time constant of the speed error low-pass filter. If the used speed reference changes rapidly, the possible interferences in the speed measurement can be filtered with the speed error filter. Reducing the ripple with this filter may cause speed controller tuning problems. A long filter time constant and fast acceleration time contradict one another. A very long filter time results in unstable control.</p> | 0 ms |
| | 0...10000 ms | Speed error filtering time constant. 0 = filtering disabled. | 1 = 1 ms |



| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|--|----------------|
| 24.41 | <i>Speed error window control enable</i> | <p>Enables/disables (or selects a source that enables/disables) speed error window control, sometimes also referred to as deadband control or strip break protection. It forms a speed supervision function for a torque-controlled drive, preventing the motor from running away if the material that is being held under tension breaks.</p> <p>Note: Speed error window control is only effective when the operating mode is active (see parameters 19.12 and 19.14), or when the drive is a speed-controlled follower (see page 57).</p> <p>If the motor load is lost, then the motor speed rises. The speed error (speed reference - actual speed) increases until it exits the speed error window. When this is detected, the exceeding part of the error value is connected to the speed controller. The speed controller produces a reference term relative to the input and gain (25.02 Speed proportional gain).</p> <p>The activation of speed error window control is indicated by bit 3 of 06.19 Speed control status word.</p> <p>The window boundaries are defined by 24.43 Speed error window high and 24.44 Speed error window low as follows:</p>  <p>Note: Parameter 24.44 (rather than 24.43) defines the overspeed limit in both directions of rotation. This is because the function monitors speed error (which is negative in case of overspeed, positive in case of underspeed).</p> <p>0 = Speed error window control disabled 1 = Speed error window control enabled</p> | <i>Disable</i> |
| | Disable | 0. | 0 |
| | Enable | 1. | 1 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------------------------|---------------------------------------|--|-----------------------------|
| 24.42 | <i>Speed window control mode</i> | When speed error window control (see parameter 24.41 <i>Speed error window control enable</i>) is enabled, this parameter determines whether the speed controller only observes the proportional term instead of all three (P, I and D) terms. | <i>Normal speed control</i> |
| | Normal speed control | All these terms (parameters 25.02, 25.03 and 25.04) are observed by the speed controller. | 0 |
| | P-control | Only the proportional term (25.02) is observed by the speed controller. The integral and derivative terms are internally forced to zero. | 1 |
| 24.43 | <i>Speed error window high</i> | Defines the upper boundary of the speed error window. See parameter 24.41 <i>Speed error window control enable</i> . | 0.00 rpm |
| | 0.00...3000.00 rpm | Upper boundary of speed error window. | See par. 46.01 |
| 24.44 | <i>Speed error window low</i> | Defines the lower boundary of the speed error window. See parameter 24.41 <i>Speed error window control enable</i> . | 0.00 rpm |
| | 0.00...3000.00 rpm | Lower boundary of speed error window. | See par. 46.01 |
| 24.46 | <i>Speed error step</i> | Defines an additional speed error step given to the input of the speed controller (and added to the speed error value). This can be used in large drive systems for dynamic speed normalizing.  WARNING! Make sure the error step value is removed when a stop command is given. | 0.00 rpm |
| | -3000.00 ...3000.00 rpm | Speed error step. | See par. 46.01 |
| 25 Speed control | | Speed controller settings. See the control chain diagrams on pages 481 and 483. | |
| 25.01 | <i>Torque reference speed control</i> | Displays the speed controller output that is transferred to the torque controller. See the control chain diagram on page 483. This parameter is read-only. | - |
| | -1600.0...1600.0% | Limited speed controller output torque. | See par. 46.03 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------|--|----------------|
| 25.02 | <i>Speed proportional gain</i> | <p>Defines the proportional gain (K_p) of the speed controller. Too high a gain may cause speed oscillation. The figure below shows the speed controller output after an error step when the error remains constant.</p>  <p>Gain = $K_p = 1$ T_I = Integration time = 0 T_D = Derivation time = 0</p> <p>Controller output = $K_p \times e$</p> <p>E</p> <p>Controller output</p> <p>e = Error value</p> <p>Time</p> <p>If gain is set to 1, a 10% change in error value (reference - actual value) causes the speed controller output to change by 10%, ie. the output value is input \times gain. Note: This parameter is automatically set by the speed controller autotune function. See section <i>Speed controller autotune</i> (page 59).</p> | 10.00 |
| | 0.00...250.00 | Proportional gain for speed controller. | 100 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------|--|----------------|
| 25.03 | <i>Speed integration time</i> | <p>Defines the integration time of the speed controller. The integration time defines the rate at which the controller output changes when the error value is constant and the proportional gain of the speed controller is 1. The shorter the integration time, the faster the continuous error value is corrected. This time constant must be set to the same order of magnitude as the time constant (time to respond) of the actual mechanical system being controlled, otherwise instability will result.</p> <p>Setting the integration time to zero disables the I-part of the controller. This is useful to do when tuning the proportional gain; adjust the proportional gain first, then return the integration time.</p> <p>Anti-windup (the integrator just integrates up to 100%) stops the integrator if the controller output is limited.</p> <p>The figure below shows the speed controller output after an error step when the error remains constant.</p>  <p>Note: This parameter is automatically set by the speed controller autotune function. See section Speed controller autotune (page 59)</p> | 2.50 s |
| | 0.00 ... 1000.00 s | Integration time for speed controller. | 10 = 1 s |

| No. | Name/Value | Description | Def/ FbEq16 |
|------------------|---|-------------|----------------|
| 25.04 | <p><i>Speed derivation time</i></p> <p>Defines the derivation time of the speed controller. Derivative action boosts the controller output if the error value changes. The longer the derivation time, the more the speed controller output is boosted during the change. If the derivation time is set to zero, the controller works as a PI controller, otherwise as a PID controller. The derivation makes the control more responsive for disturbances. For simple applications (especially those without a pulse encoder), derivative time is not normally required and should be left at zero.</p> <p>The speed error derivative must be filtered with a low pass filter to eliminate disturbances.</p> <p>The figure below shows the speed controller output after an error step when the error remains constant.</p>  <p>Gain = $K_p = 1$ T_I = Integration time > 0 T_D = Derivation time > 0 T_s = Sample time period = 250 μs Δe = Error value change between two samples</p> | 0.000 s | |
| 0.000...10.000 s | Derivation time for speed controller. | 1000 = 1 s | |
| 25.05 | <p><i>Derivation filter time</i></p> <p>Defines the derivation filter time constant. See parameter 25.04 Speed derivation time.</p> | 8 ms | |
| 0...10000 ms | Derivation filter time constant. | 1 = 1 ms | |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|--|----------------|
| 25.06 | Acc comp derivation time | <p>Defines the derivation time for acceleration/(deceleration) compensation. In order to compensate for a high inertia load during acceleration, a derivative of the reference is added to the output of the speed controller. The principle of a derivative action is described under parameter 25.04 Speed derivation time.</p> <p>Note: As a general rule, set this parameter to the value between 50 and 100% of the sum of the mechanical time constants of the motor and the driven machine.</p> <p>The figure below shows the speed responses when a high inertia load is accelerated along a ramp.</p> <p>No acceleration compensation:</p>  <p>Acceleration compensation:</p>  | 0.00 s |
| | 0.00...1000.00 s | Acceleration compensation derivation time. | 10 = 1 s |
| 25.07 | Acc comp filter time | Defines the acceleration (or deceleration) compensation filter time constant. See parameters 25.04 Speed derivation time and 25.06 Acc comp derivation time . | 8.0 ms |
| | 0.0...1000.0 ms | Acceleration/deceleration compensation filter time. | 1 = 1 ms |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------------------|---|---------------------|
| 25.08 | <i>Drifting rate</i> | <p>Defines the droop rate in percent of the nominal motor speed. Drooping decreases the drive speed slightly as the drive load increases. The actual speed decrease at a certain operating point depends on the droop rate setting and the drive load (= torque reference / speed controller output). At 100% speed controller output, drooping is at its nominal level, that is equal to the value of this parameter. The drooping effect decreases linearly to zero along with the decreasing load.</p> <p>The correct droop rate for a process must be found out case by case in practice.</p> <p>Speed decrease = Speed controller output × Drooping × Nominal speed Example: Speed controller output is 50%, droop rate is 1%, nominal speed of the drive is 1500 rpm. Speed decrease = 0.50 × 0.01 × 1500 rpm = 7.5 rpm.</p> <p>Motor speed in % of nominal</p>  | 0.00% |
| | 0.00...100.00% | Droop rate. | 100 = 1% |
| 25.09 | <i>Speed ctrl balancing enable</i> | <p>Selects the source for enabling/disabling speed controller output balancing.</p> <p>This function is used to generate a smooth transfer from a torque- or tension-controlled motor back to being speed-controlled. When balancing is enabled, the output of the speed controller is forced to the value of <i>25.10 Speed ctrl balancing ref.</i></p> <p>Balancing is also possible in the ramp generator, see parameter <i>23.26 Ramp out balancing enable.</i></p> <p>0 = Disabled 1 = Enabled</p> | <i>Not selected</i> |
| | Not selected | 0. | 1 |
| | Selected | 1. | 2 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |

| No. | Name/Value | Description | Def/ FbEq16 |
|--------------|----------------------------------|--|----------------|
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 25.10 | <i>Speed ctrl balancing ref</i> | Defines the reference used in speed controller output balancing. The output of the speed controller is forced to this value when balancing is enabled by parameter 25.09 <i>Speed ctrl balancing enable</i> . | 0.0% |
| | -300.0...300.0% | Speed control output balancing reference. | See par. 46.03 |
| 25.11 | <i>Speed control min torque</i> | Defines the minimum speed controller output torque. | -300.0% |
| | -1600.0...0.0% | Minimum speed controller output torque. | See par. 46.03 |
| 25.12 | <i>Speed control max torque</i> | Defines the maximum speed controller output torque. | 300.0% |
| | 0.0...1600.0% | Maximum speed controller output torque. | See par. 46.03 |
| 25.13 | <i>Min torq sp ctrl em stop</i> | Defines the minimum speed controller output torque during a ramped emergency stop (Off1 or Off3). | -400.0% |
| | -1600.0 ... 0.0% | Minimum speed controller output torque for ramped emergency stop. | See par. 46.03 |
| 25.14 | <i>Max torq sp ctrl em stop</i> | Defines the maximum speed controller output torque during a ramped emergency stop (Off1 or Off3). | 400.0% |
| | 0.0...1600.0% | Maximum speed controller output torque for ramped emergency stop. | See par. 46.03 |
| 25.15 | <i>Proportional gain em stop</i> | Defines the proportional gain for the speed controller when an emergency stop is active. See parameter 25.02 <i>Speed proportional gain</i> . | 10.00 |
| | 1.00...250.00 | Proportional gain upon an emergency stop. | 100 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-----------------------------------|---|----------------|
| 25.18 | <i>Speed adapt min limit</i> | <p>Minimum actual speed for speed controller adaptation.</p> <p>Speed controller gain and integration time can be adapted according to actual speed (<i>90.01 Motor speed for control</i>). This is done by multiplying the gain (<i>25.02 Speed proportional gain</i>) and integration time (<i>25.03 Speed integration time</i>) by coefficients at certain speeds. The coefficients are defined individually for both gain and integration time.</p> <p>When actual speed is below or equal to <i>25.18 Speed adapt min limit</i>, the gain and integration time are multiplied by <i>25.21 Kp adapt coef at min speed</i> and <i>25.22 Ti adapt coef at min speed</i> respectively.</p> <p>When actual speed is equal to or above <i>25.19 Speed adapt max limit</i>, no adaptation takes place (the coefficient is 1).</p> <p>When actual speed is between <i>25.18 Speed adapt min limit</i> and <i>25.19 Speed adapt max limit</i>, the coefficients for the gain and integration time are calculated linearly on the basis of the breakpoints.</p> <p>See also the block diagram on page 483.</p> <div data-bbox="162 670 952 1021" style="text-align: center;"> </div> | 0 rpm |
| | 0...30000 rpm | Minimum actual speed for speed controller adaptation. | 1 = 1 rpm |
| 25.19 | <i>Speed adapt max limit</i> | Maximum actual speed for speed controller adaptation. See parameter <i>25.18 Speed adapt min limit</i> . | 0 rpm |
| | 0...30000 rpm | Maximum actual speed for speed controller adaptation. | 1 = 1 rpm |
| 25.21 | <i>Kp adapt coef at min speed</i> | Proportional gain coefficient at minimum actual speed. See parameter <i>25.18 Speed adapt min limit</i> . | 1.000 |
| | 0.000...10.000 | Proportional gain coefficient at minimum actual speed. | 1000 = 1 |
| 25.22 | <i>Ti adapt coef at min speed</i> | Integration time coefficient at minimum actual speed. See parameter <i>25.18 Speed adapt min limit</i> . | 1.000 |
| | 0.000...10.000 | Integration time coefficient at minimum actual speed. | 1000 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|---|------------------------------------|---|----------------|
| 25.25 | <i>Torque adapt max limit</i> | <p>Maximum torque reference for speed controller adaptation. Speed controller gain can be adapted according to the final unlimited torque reference (26.01 <i>Torque reference to TC</i>). This can be used to smooth out disturbances caused by a small load and backlashes.</p> <p>The functionality involves multiplying the gain (25.02 <i>Speed proportional gain</i>) by a coefficient within a certain torque range.</p> <p>When the torque reference is 0%, the gain is multiplied by the value of parameter 25.27 <i>Kp adapt coef at min torque</i>.</p> <p>When the torque reference is equal to or above 25.25 <i>Torque adapt max limit</i>, no adaptation takes place (the coefficient is 1).</p> <p>Between 0% and 25.25 <i>Torque adapt max limit</i>, the coefficient for the gain is calculated linearly on the basis of the breakpoints.</p> <p>Filtering can be applied on the torque reference using parameter 25.26 <i>Torque adapt filt time</i>.</p> <p>See also the block diagram on page 483.</p> | 0.0% |
| <p>Coefficient for K_p (proportional gain)</p> | | | |
| | 0.0...1600.0% | Maximum torque reference for speed controller adaptation. | See par. 46.03 |
| 25.26 | <i>Torque adapt filt time</i> | <p>Defines a filter time constant for the adaptation, in effect adjusting the rate of change of the gain.</p> <p>See parameter 25.25 <i>Torque adapt max limit</i>.</p> | 0.000 s |
| | 0.000...100.000 s | Filter time for adaptation. | 100 = 1 s |
| 25.27 | <i>Kp adapt coef at min torque</i> | <p>Proportional gain coefficient at 0% torque reference.</p> <p>See parameter 25.25 <i>Torque adapt max limit</i>.</p> | 1.000 |
| | 0.000...10.000 | Proportional gain coefficient at 0% torque reference. | 1000 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------------|--|----------------|
| 25.30 | <i>Flux adaptation enable</i> | <p>Enables/disables speed controller adaptation based on motor flux reference (01.24 Flux actual %).</p> <p>The proportional gain of the speed controller is multiplied by a coefficient of 0...1 between 0...100% flux reference respectively.</p> <p>See also the block diagram on page 483.</p> <p>Coefficient for K_p (proportional gain)</p>  <p>Flux reference (01.24) (%)</p> | Enable |
| | Disable | Speed controller adaptation based on flux reference disabled. | 0 |
| | Enable | Speed controller adaptation based on flux reference enabled. | 1 |
| 25.33 | <i>Speed controller autotune</i> | <p>Activates (or selects a source that activates) the speed controller autotune function. See section <i>Speed controller autotune</i> (page 59).</p> <p>The autotune will automatically set parameters 25.02 <i>Speed proportional gain</i>, 25.03 <i>Speed integration time</i> and 25.37 <i>Mechanical time constant</i>.</p> <p>The prerequisites for performing the autotune routine are:</p> <ul style="list-style-type: none"> the motor identification run (ID run) has been successfully completed the speed and torque limits (parameter group 30 <i>Limits</i>) have been set speed feedback filtering (parameter group 90 <i>Feedback selection</i>), speed error filtering (24 <i>Speed reference conditioning</i>) and zero speed (21 <i>Start/stop mode</i>) have been set, and the drive has been started and is running in speed control mode. <p>WARNING! The motor and machinery will run against the torque and speed limits during the autotune routine. MAKE SURE IT IS SAFE TO ACTIVATE THE AUTOTUNE FUNCTION!</p> <p>The autotune routine can be aborted by stopping the drive.</p> <p>0 -> 1 = Activate speed controller autotune</p> <p>Note: The value does not revert to 0 automatically.</p> | Off |
| | Off | 0. | 0 |
| | On | 1. | 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------------------|---|----------------|
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 25.34 | <i>Speed controller autotune mode</i> | Defines a control preset for the speed controller autotune function. The setting affects the way the torque reference will respond to a speed reference step. | <i>Normal</i> |
| | Smooth | Slow but robust response. | 0 |
| | Normal | Medium setting. | 1 |
| | Tight | Fast response. May produce too high a gain value for some applications. | 2 |
| 25.37 | <i>Mechanical time constant</i> | Mechanical time constant of the drive and the machinery as determined by the speed controller autotune function. The value can be adjusted manually. | - |
| | 0.00 ... 1000.00 s | Mechanical time constant. | 10 = 1 s |
| 25.38 | <i>Autotune torque step</i> | Defines an added torque value used by the autotune function. This value is scaled to motor nominal torque. Note that the torque used by the autotune function can also be limited by the torque limits (in parameter group 30 <i>Limits</i>) and nominal motor torque. | 10.00% |
| | 0.00 ... 100.00% | Autotune torque step. | 100 = 1% |
| 25.39 | <i>Autotune speed step</i> | Defines a speed value added to the initial speed for the autotune routine. The initial speed (speed used when autotune is activated) plus the value of this parameter is the calculated maximum speed used by the autotune routine. The maximum speed can also be limited by the speed limits (in parameter group 30 <i>Limits</i>) and nominal motor speed. The value is scaled to motor nominal speed. Note: The motor will exceed the calculated maximum speed slightly at the end of each acceleration stage. | 10.00% |
| | 0.00 ... 100.00% | Autotune speed step. | 100 = 1% |
| 25.40 | <i>Autotune repeat times</i> | Determines how many acceleration/deceleration cycles are performed during the autotune routine. Increasing the value will improve the accuracy of the autotune function, and allow the use of smaller torque or speed step values. | 10 |
| | 1...10 | Number of cycles during autotune routine. | 1 = 1 |
| 25.53 | <i>Torque prop reference</i> | Displays the output of the proportional (P) part of the speed controller. See the control chain diagram on page 483. This parameter is read-only. | - |
| | -30000.0...30000.0% | P-part output of speed controller. | See par. 46.03 |
| 25.54 | <i>Torque integral reference</i> | Displays the output of the integral (I) part of the speed controller. See the control chain diagram on page 483. This parameter is read-only. | - |
| | -30000.0...30000.0% | I-part output of speed controller. | See par. 46.03 |


| No. | Name/Value | Description | Def/ FbEq16 |
|----------------------------------|------------------------------------|---|---------------------|
| 25.55 | <i>Torque deriv reference</i> | Displays the output of the derivative (D) part of the speed controller. See the control chain diagram on page 483. This parameter is read-only. | - |
| | -30000.0...30000.0% | D-part output of speed controller. | See par. 46.03 |
| 25.56 | <i>Torque acc compensation</i> | Displays the output of the acceleration compensation function. See the control chain diagram on page 483. This parameter is read-only. | - |
| | -30000.0...30000.0% | Output of acceleration compensation function. | See par. 46.03 |
| 25.57 | <i>Torque reference unbalanced</i> | Displays the acceleration-compensated output of the speed controller. See the control chain diagram on page 483. This parameter is read-only. | - |
| | -30000.0...30000.0% | Acceleration-compensated output of speed controller. | See par. 46.03 |
| 26 Torque reference chain | | Settings for the torque reference chain. | |
| 26.01 | <i>Torque reference to TC</i> | Displays the final torque reference given to the torque controller in percent. This reference is then acted upon by various final limiters, like power, torque, load etc. This parameter is read-only. | - |
| | -1600.0 ... 1600.0% | Torque reference for torque control. | - |
| 26.02 | <i>Torque reference used</i> | Displays the final torque reference (in percent of motor nominal torque) given to the DTC core, and comes after frequency, voltage and torque limitation. This parameter is read-only. | - |
| | -1600.0 ... 1600.0% | Torque reference for torque control. | - |
| 26.51 | <i>Oscillation damping</i> | Parameters 26.51...26.58 configure the oscillation damping function. See section <i>Oscillation damping</i> (page 62). This parameter enables (or selects a source that enables) the oscillation damping algorithm. 1 = Oscillation damping algorithm enabled | <i>Not selected</i> |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------------------|---|---------------------|
| 26.52 | <i>Oscillation damping out enable</i> | Determines (or selects a source that determines) whether the output of the oscillation damping function is added to the torque reference or not. Note: Before enabling the oscillation damping output, adjust parameters 26.53...26.57. Then monitor the input signal (selected by 26.53) and the output (26.58) to make sure that the correction is safe to apply. 1 = Add oscillation damping output to torque reference | <i>Not selected</i> |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (10.02 DI delayed status, bit 0). | 2 |
| | DI2 | Digital input DI2 (10.02 DI delayed status, bit 1). | 3 |
| | DI3 | Digital input DI3 (10.02 DI delayed status, bit 2). | 4 |
| | DI4 | Digital input DI4 (10.02 DI delayed status, bit 3). | 5 |
| | DI5 | Digital input DI5 (10.02 DI delayed status, bit 4). | 6 |
| | DI6 | Digital input DI6 (10.02 DI delayed status, bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status, bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status, bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 26.53 | <i>Oscillation compensation input</i> | Selects the input signal for the oscillation damping function. Note: Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output. | <i>Speed error</i> |
| | Speed error | -(24.04 Speed error inverted), ie. 24.01 Used speed reference - 24.02 Used speed feedback. Note: This setting is not supported in scalar motor control mode. | 0 |
| | DC voltage | 01.11 DC voltage. (The value is internally filtered.) | 1 |
| 26.55 | <i>Oscillation damping frequency</i> | Defines the center frequency of the oscillation damping filter. Set the value according to the number of oscillation peaks in the monitored signal (selected by 26.53) per second. Note: Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output. | 31.0 Hz |
| | 0.1 ... 60.0 Hz | Center frequency for oscillation damping. | 10 = 1 Hz |
| 26.56 | <i>Oscillation damping phase</i> | Defines a phase shift for the output of the filter. Note: Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output. | 180 deg |
| | 0...360 deg | Phase shift for oscillation damping function output. | 10 = 1 deg |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------------------------------------|--------------------------------------|--|-------------------|
| 26.57 | <i>Oscillation damping gain</i> | Defines a gain for the output of the oscillation damping function, ie. how much the output of the filter is amplified before it is added to the torque reference. Oscillation gain is scaled according to the speed controller gain so that changing the gain will not disturb oscillation damping. Note: Before changing this parameter run-time, disable the oscillation damping output using parameter 26.52. Monitor the behavior of 26.58 before re-enabling the output. | 1.0% |
| | 0.0 ... 100.0% | Gain setting for oscillation damping output. | 10 = 1% |
| 26.58 | <i>Oscillation damping output</i> | Displays the output of the oscillation damping function. This value is added to the torque reference (as allowed by parameter 26.52 <i>Oscillation damping out enable</i>). This parameter is read-only. | - |
| | -1600.000 ... 1600.000% | Output of the oscillation damping function. | 10 = 1% |
| 26.81 | <i>Rush control gain</i> | Rush controller gain term. See section <i>Rush control</i> (page 62). | 10.0 |
| | 0.0 ...10000.0 | Rush controller gain (0.0 = disabled). | 1 = 1 |
| 26.82 | <i>Rush control integration time</i> | Rush controller integration time term. | 2.0 s |
| | 0.0 ...10.0 s | Rush controller integration time (0.0 = disabled). | 1 = 1 s |
| 28 Frequency reference chain | | Settings for the frequency reference chain. See the control chain diagrams on pages 484 and 484. | |
| 28.01 | <i>Frequency ref ramp input</i> | Displays the used frequency reference before ramping. See the control chain diagram on page 484. This parameter is read-only. | - |
| | -500.00...500.00 Hz | Frequency reference before ramping. | See par. 46.02 |
| 28.02 | <i>Frequency ref ramp output</i> | Displays the final frequency reference (after selection, limitation and ramping). See the control chain diagram on page 484. This parameter is read-only. | - |
| | -500.00...500.00 Hz | Final frequency reference. | See par. 46.02 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------|--|----------------|
| 28.11 | <i>Frequency ref1 source</i> | <p>Selects frequency reference source 1.</p> <p>Two signal sources can be defined by this parameter and 28.12 Frequency ref2 source. A digital source selected by 28.14 Frequency ref1/2 selection can be used to switch between the two sources, or a mathematical function (28.13 Frequency ref1 function) applied to the two signals to create the reference.</p> | <i>Zero</i> |
| | | | |
| | Zero | None. | 0 |
| | AI1 scaled | 12.12 AI1 scaled value (see page 141). | 1 |
| | AI2 scaled | 12.22 AI2 scaled value (see page 143). | 2 |
| | FB A ref1 | 03.05 FB A reference 1 (see page 108). | 4 |
| | FB A ref2 | 03.06 FB A reference 2 (see page 108). | 5 |
| | EFB ref1 | 03.09 EFB reference 1 (see page 108). | 8 |
| | EFB ref2 | 03.10 EFB reference 2 (see page 108). | 9 |
| | Motor potentiometer | 22.80 Motor potentiometer ref act (output of the motor potentiometer). | 15 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 28.12 | <i>Frequency ref2 source</i> | <p>Selects frequency reference source 2.</p> <p>For the selections, and a diagram of reference source selection, see parameter 28.11 Frequency ref1 source.</p> | <i>Zero</i> |
| 28.13 | <i>Frequency ref1 function</i> | <p>Selects a mathematical function between the reference sources selected by parameters 28.11 Frequency ref1 source and 28.12 Frequency ref2 source. See diagram at 28.11 Frequency ref1 source.</p> | <i>Ref1</i> |
| | Ref1 | Signal selected by 28.11 Frequency ref1 source is used as frequency reference 1 as such (no function applied). | 0 |
| | Add (ref1 + ref2) | The sum of the reference sources is used as frequency reference 1. | 1 |
| | Sub (ref1 - ref2) | The subtraction (28.11 Frequency ref1 source - 28.12 Frequency ref2 source) of the reference sources is used as frequency reference 1. | 2 |
| | Mul (ref1 × ref2) | The multiplication of the reference sources is used as frequency reference 1. | 3 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------------------|---|-----------------------------------|
| | Min (ref1, ref2) | The smaller of the reference sources is used as frequency reference 1. | 4 |
| | Max (ref1, ref2) | The greater of the reference sources is used as frequency reference 1. | 5 |
| 28.14 | <i>Frequency ref1/2 selection</i> | Configures the selection between frequency references 1 and 2. See diagram at 28.11 Frequency ref1 source . 0 = Frequency reference 1 1 = Frequency reference 2 | <i>Follow Ext1/Ext2 selection</i> |
| | Frequency reference 1 | 0. | 0 |
| | Frequency reference 2 | 1. | 1 |
| | Follow Ext1/Ext2 selection | Frequency reference 1 is used when external control location EXT1 is active. Frequency reference 2 is used when external control location EXT2 is active. See also parameter 19.11 Ext1/Ext2 selection . | 2 |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 3 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 4 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 5 |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 6 |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 7 |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 8 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 28.21 | <i>Constant frequency function</i> | Determines how constant frequencies are selected, and whether the rotation direction signal is considered or not when applying a constant frequency. | 0000b |

| Bit | Name | Information |
|-----|--------------------|---|
| 0 | Constant freq mode | 1 = Packed: 7 constant frequencies are selectable using the three sources defined by parameters 28.22 , 28.23 and 28.24 . 0 = Separate: Constant frequencies 1, 2 and 3 are separately activated by the sources defined by parameters 28.22 , 28.23 and 28.24 respectively. In case of conflict, the constant frequency with the smaller number takes priority. |
| 1 | Direction enable | 1 = Start dir: To determine running direction for a constant frequency, the sign of the constant frequency setting (parameters 28.26...28.32) is multiplied by the direction signal (forward: +1, reverse: -1). This effectively allows the drive to have 14 (7 forward, 7 reverse) constant frequencies if all values in 28.26...28.32 are positive.  WARNING: If the direction signal is reverse and the active constant frequency is negative, the drive will run in the forward direction. 0 = According to Par: The running direction for the constant frequency is determined by the sign of the constant speed setting (parameters 28.26...28.32). |

| | | |
|---------------|--|-------|
| 0000b...0011b | Constant frequency configuration word. | 1 = 1 |
|---------------|--|-------|

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|------------------------------|--------------------------------|---|------------------------------|------------------------------|------------------------------|---------------------------|---|---|---|------|---|---|---|----------------------|---|---|---|----------------------|---|---|---|----------------------|---|---|---|----------------------|---|---|---|----------------------|---|---|---|----------------------|---|---|---|----------------------|---------------------|
| 28.22 | <i>Constant frequency sel1</i> | <p>When bit 0 of parameter <i>28.21 Constant frequency function</i> is 0 (Separate), selects a source that activates constant frequency 1.</p> <p>When bit 0 of parameter <i>28.21 Constant frequency function</i> is 1 (Packed), this parameter and parameters <i>28.23 Constant frequency sel2</i> and <i>28.24 Constant frequency sel3</i> select three sources whose states activate constant frequencies as follows:</p> <table border="1" data-bbox="280 411 963 678"> <thead> <tr> <th>Source defined by par. 28.22</th> <th>Source defined by par. 28.23</th> <th>Source defined by par. 28.24</th> <th>Constant frequency active</th> </tr> </thead> <tbody> <tr><td>0</td><td>0</td><td>0</td><td>None</td></tr> <tr><td>1</td><td>0</td><td>0</td><td>Constant frequency 1</td></tr> <tr><td>0</td><td>1</td><td>0</td><td>Constant frequency 2</td></tr> <tr><td>1</td><td>1</td><td>0</td><td>Constant frequency 3</td></tr> <tr><td>0</td><td>0</td><td>1</td><td>Constant frequency 4</td></tr> <tr><td>1</td><td>0</td><td>1</td><td>Constant frequency 5</td></tr> <tr><td>0</td><td>1</td><td>1</td><td>Constant frequency 6</td></tr> <tr><td>1</td><td>1</td><td>1</td><td>Constant frequency 7</td></tr> </tbody> </table> | Source defined by par. 28.22 | Source defined by par. 28.23 | Source defined by par. 28.24 | Constant frequency active | 0 | 0 | 0 | None | 1 | 0 | 0 | Constant frequency 1 | 0 | 1 | 0 | Constant frequency 2 | 1 | 1 | 0 | Constant frequency 3 | 0 | 0 | 1 | Constant frequency 4 | 1 | 0 | 1 | Constant frequency 5 | 0 | 1 | 1 | Constant frequency 6 | 1 | 1 | 1 | Constant frequency 7 | <i>Not selected</i> |
| Source defined by par. 28.22 | Source defined by par. 28.23 | Source defined by par. 28.24 | Constant frequency active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 0 | None | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | 0 | Constant frequency 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 0 | Constant frequency 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | 0 | Constant frequency 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | 1 | Constant frequency 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | 1 | Constant frequency 5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | 1 | Constant frequency 6 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | 1 | Constant frequency 7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Not selected | 0. | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Selected | 1. | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 28.23 | <i>Constant frequency sel2</i> | <p>When bit 0 of parameter <i>28.21 Constant frequency function</i> is 0 (Separate), selects a source that activates constant frequency 2.</p> <p>When bit 0 of parameter <i>28.21 Constant frequency function</i> is 1 (Packed), this parameter and parameters <i>28.22 Constant frequency sel1</i> and <i>28.24 Constant frequency sel3</i> select three sources that are used to activate constant frequencies. See table at parameter <i>28.22 Constant frequency sel1</i>.</p> <p>For the selections, see parameter <i>28.22 Constant frequency sel1</i>.</p> | <i>Not selected</i> | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------|---|--------------------------------|
| 28.24 | <i>Constant frequency sel3</i> | When bit 0 of parameter <i>28.21 Constant frequency function</i> is 0 (Separate), selects a source that activates constant frequency 3. When bit 0 of parameter <i>28.21 Constant frequency function</i> is 1 (Packed), this parameter and parameters <i>28.22 Constant frequency sel1</i> and <i>28.23 Constant frequency sel2</i> select three sources that are used to activate constant frequencies. See table at parameter <i>28.22 Constant frequency sel1</i> . For the selections, see parameter <i>28.22 Constant frequency sel1</i> . | <i>Not selected</i> |
| 28.26 | <i>Constant frequency 1</i> | Defines constant frequency 1 (the frequency the motor will turn when constant frequency 1 is selected). | 0.00 Hz |
| | -500.00 ... 500.00 Hz | Constant frequency 1. | See par. 46.02 |
| 28.27 | <i>Constant frequency 2</i> | Defines constant frequency 2. | 0.00 Hz |
| | -500.00 ... 500.00 Hz | Constant frequency 2. | See par. 46.02 |
| 28.28 | <i>Constant frequency 3</i> | Defines constant frequency 3. | 0.00 Hz |
| | -500.00 ... 500.00 Hz | Constant frequency 3. | See par. 46.02 |
| 28.29 | <i>Constant frequency 4</i> | Defines constant frequency 4. | 0.00 Hz |
| | -500.00 ... 500.00 Hz | Constant frequency 4. | See par. 46.02 |
| 28.30 | <i>Constant frequency 5</i> | Defines constant frequency 5. | 0.00 Hz |
| | -500.00 ... 500.00 Hz | Constant frequency 5. | See par. 46.02 |
| 28.31 | <i>Constant frequency 6</i> | Defines constant frequency 6. | 0.00 Hz |
| | -500.00 ... 500.00 Hz | Constant frequency 6. | See par. 46.02 |
| 28.32 | <i>Constant frequency 7</i> | Defines constant frequency 7. | 0.00 Hz |
| | -500.00 ... 500.00 Hz | Constant frequency 7. | See par. 46.02 |
| 28.41 | <i>Frequency ref safe</i> | Defines a safe frequency reference value that is used with supervision functions such as <ul style="list-style-type: none"> • 12.03 AI supervision function • 49.05 Communication loss action • 50.02 FBA A comm loss func • 50.32 FBA B comm loss func • 58.14 Communication loss action. | 0.00 Hz |
| | -500.00...500.00 Hz | Safe frequency reference. | See par. 46.02 |





| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | |
|-------|------------------------------------|--|----------------|------|-------------|---|--------|---|---|---|-----------|---|--|--|
| 28.51 | <i>Critical frequency function</i> | Enables/disables the critical frequencies function. Also determines whether the specified ranges are effective in both rotating directions or not. See also section <i>Critical speeds (frequencies)</i> (page 59). | 00b | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td rowspan="2">0</td> <td rowspan="2">Enable</td> <td>1 = Enable: Critical frequencies enabled.</td> </tr> <tr> <td>0 = Disable: Critical frequencies disabled.</td> </tr> <tr> <td rowspan="2">1</td> <td rowspan="2">Sign mode</td> <td>1 = According to par: The signs of parameters 28.52...28.57 are taken into account.</td> </tr> <tr> <td>0 = Absolute: Parameters 28.52...28.57 are handled as absolute values. Each range is effective in both directions of rotation.</td> </tr> </tbody> </table> | Bit | Name | Information | 0 | Enable | 1 = Enable: Critical frequencies enabled. | 0 = Disable: Critical frequencies disabled. | 1 | Sign mode | 1 = According to par: The signs of parameters 28.52...28.57 are taken into account. | 0 = Absolute: Parameters 28.52...28.57 are handled as absolute values. Each range is effective in both directions of rotation. | |
| Bit | Name | Information | | | | | | | | | | | | |
| 0 | Enable | 1 = Enable: Critical frequencies enabled. | | | | | | | | | | | | |
| | | 0 = Disable: Critical frequencies disabled. | | | | | | | | | | | | |
| 1 | Sign mode | 1 = According to par: The signs of parameters 28.52...28.57 are taken into account. | | | | | | | | | | | | |
| | | 0 = Absolute: Parameters 28.52...28.57 are handled as absolute values. Each range is effective in both directions of rotation. | | | | | | | | | | | | |
| | 0000b...0011b | Critical frequencies configuration word. | 1 = 1 | | | | | | | | | | | |
| 28.52 | <i>Critical frequency 1 low</i> | Defines the low limit for critical frequency 1. Note: This value must be less than or equal to the value of 28.53 <i>Critical frequency 1 high</i> . | 0.00 Hz | | | | | | | | | | | |
| | -500.00...500.00 Hz | Low limit for critical frequency 1. | See par. 46.02 | | | | | | | | | | | |
| 28.53 | <i>Critical frequency 1 high</i> | Defines the high limit for critical frequency 1. Note: This value must be greater than or equal to the value of 28.52 <i>Critical frequency 1 low</i> . | 0.00 Hz | | | | | | | | | | | |
| | -500.00...500.00 Hz | High limit for critical frequency 1. | See par. 46.02 | | | | | | | | | | | |
| 28.54 | <i>Critical frequency 2 low</i> | Defines the low limit for critical frequency 2. Note: This value must be less than or equal to the value of 28.55 <i>Critical frequency 2 high</i> . | 0.00 Hz | | | | | | | | | | | |
| | -500.00...500.00 Hz | Low limit for critical frequency 2. | See par. 46.02 | | | | | | | | | | | |
| 28.55 | <i>Critical frequency 2 high</i> | Defines the high limit for critical frequency 2. Note: This value must be greater than or equal to the value of 28.54 <i>Critical frequency 2 low</i> . | 0.00 Hz | | | | | | | | | | | |
| | -500.00...500.00 Hz | High limit for critical frequency 2. | See par. 46.02 | | | | | | | | | | | |
| 28.56 | <i>Critical frequency 3 low</i> | Defines the low limit for critical frequency 3. Note: This value must be less than or equal to the value of 28.57 <i>Critical frequency 3 high</i> . | 0.00 Hz | | | | | | | | | | | |
| | -500.00...500.00 Hz | Low limit for critical frequency 3. | See par. 46.02 | | | | | | | | | | | |
| 28.57 | <i>Critical frequency 3 high</i> | Defines the high limit for critical frequency 3. Note: This value must be greater than or equal to the value of 28.56 <i>Critical frequency 3 low</i> . | 0.00 Hz | | | | | | | | | | | |
| | -500.00...500.00 Hz | High limit for critical frequency 3. | See par. 46.02 | | | | | | | | | | | |





| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|---|--------------------------------|
| 28.71 | Freq ramp set selection | Selects a source that switches between the two sets of acceleration/deceleration times defined by parameters 28.72...28.75 . 0 = Acceleration time 1 and deceleration time 1 are in force 1 = Acceleration time 2 and deceleration time 2 are in force | Acc/Dec time 1 |
| | Acc/Dec time 1 | 0. | 0 |
| | Acc/Dec time 2 | 1. | 1 |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 5 |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 6 |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status , bit 1). | 11 |
| | Other [bit] | Source selection (see Terms and abbreviations on page 101). | - |
| 28.72 | Freq acceleration time 1 | Defines acceleration time 1 as the time required for the frequency to change from zero to the frequency defined by parameter 46.02 Frequency scaling (not to parameter 30.14 Maximum frequency). If the reference increases faster than the set acceleration rate, the motor will follow the acceleration rate. If the reference increases slower than the set acceleration rate, the motor frequency will follow the reference. If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits. | 20.000 s |
| | 0.000...1800.000 s | Acceleration time 1. | 10 = 1 s |
| 28.73 | Freq deceleration time 1 | Defines deceleration time 1 as the time required for the frequency to change from the frequency defined by parameter 46.02 Frequency scaling (not from parameter 30.14 Maximum frequency) to zero. If there is any doubt about the deceleration time being too short, ensure that DC overvoltage control (30.30 Overvoltage control) is on. Note: If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor. | 20.000 s |
| | 0.000...1800.000 s | Deceleration time 1. | 10 = 1 s |
| 28.74 | Freq acceleration time 2 | Defines acceleration time 2. See parameter 28.72 Freq acceleration time 1 . | 60.000 s |
| | 0.000...1800.000 s | Acceleration time 2. | 10 = 1 s |
| 28.75 | Freq deceleration time 2 | Defines deceleration time 2. See parameter 28.73 Freq deceleration time 1 . | 60.000 s |
| | 0.000...1800.000 s | Deceleration time 2. | 10 = 1 s |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|--|-----------------------|
| 28.76 | <i>Freq ramp in zero source</i> | Selects a source that forces the frequency reference to zero. 0 = Force frequency reference to zero 1 = Normal operation | <i>Inactive</i> |
| | Active | 0. | 0 |
| | Inactive | 1. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 28.77 | <i>Freq ramp hold</i> | Selects a source that forces the output of the frequency ramp generator to actual frequency value. 0 = Force ramp output to actual frequency 1 = Normal operation | <i>Inactive</i> |
| | Active | 0. | 0 |
| | Inactive | 1. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 28.78 | <i>Freq ramp output balancing</i> | Defines a reference for frequency ramp balancing. The output of the ramp generator is forced to this value when balancing is enabled by parameter <i>28.79 Freq ramp output balancing enable</i> . | 0.00 Hz |
| | -500.00...500.00 Hz | Frequency ramp balancing reference. | See par. <i>46.02</i> |
| 28.79 | <i>Freq ramp output balancing enable</i> | Selects the source for enabling/disabling speed ramp balancing. See parameter <i>28.78 Freq ramp output balancing</i> . 0 = Disabled 1 = Enabled | <i>Not selected</i> |
| | Not selected | 0. | |
| | Selected | 1. | |

| No. | Name/Value | Description | Def/ FbEq16 |
|--------------|--------------------------------|---|-----------------------|
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| <i>28.90</i> | <i>Frequency ref act 1</i> | Displays the value of frequency reference source 1 (selected by parameter <i>28.11 Frequency ref1 source</i>). See the control chain diagram on page 484. This parameter is read-only. | - |
| | -500.00...500.00 Hz | Value of frequency reference source 1. | See par. <i>46.02</i> |
| <i>28.91</i> | <i>Frequency ref act 2</i> | Displays the value of frequency reference source 2 (selected by parameter <i>28.12 Frequency ref2 source</i>). See the control chain diagram on page 484. This parameter is read-only. | - |
| | -500.00...500.00 Hz | Value of frequency reference source 2. | See par. <i>46.02</i> |
| <i>28.92</i> | <i>Frequency ref act 3</i> | Displays the frequency reference after the function applied by parameter <i>28.13 Frequency ref1 function</i> (if any), and after selection (<i>28.14 Frequency ref1/2 selection</i>). See the control chain diagram on page 484. This parameter is read-only. | - |
| | -500.00...500.00 Hz | Frequency reference after selection. | See par. <i>46.02</i> |
| <i>28.96</i> | <i>Frequency ref act 7</i> | Displays the frequency reference after application of constant frequencies, control panel reference, etc. See the control chain diagram on page 484. This parameter is read-only. | - |
| | -500.00...500.00 Hz | Frequency reference 7. | See par. <i>46.02</i> |
| <i>28.97</i> | <i>Frequency ref unlimited</i> | Displays the frequency reference after application of critical frequencies, but before ramping and limiting. See the control chain diagram on page 484. This parameter is read-only. | - |
| | -500.00...500.00 Hz | Frequency reference before ramping and limiting. | See par. <i>46.02</i> |

| No. | Name/Value | Description | Def/ FbEq16 |
|------------------|---------------------|--|----------------|
| 30 Limits | | Drive operation limits. | |
| 30.01 | <i>Limit word 1</i> | Displays limit word 1. This parameter is read-only. | - |
| Bit | Name | Description | |
| 0 | Torq lim | 1 = Drive torque is being limited by the motor control (undervoltage control, current control, load angle control or pull-out control), or by the torque limits defined by parameters. | |
| 1 | Spd ctl tlim min | 1 = Speed controller output is being limited by 25.11 Speed control min torque | |
| 2 | Spd ctl tlim max | 1 = Speed controller output is being limited by 25.12 Speed control max torque | |
| 3 | Torq ref max | 1 = Torque reference ramp input is being limited by 26.09 Maximum torque ref , source of 30.25 Minimum torque sel , 30.26 Power motoring limit or 30.27 Power generating limit . | |
| 4 | Torq ref min | 1 = Torque reference ramp input is being limited by 26.08 Minimum torque ref , source of 30.18 Minimum torque sel , 30.26 Power motoring limit or 30.27 Power generating limit . | |
| 5 | Tlim max speed | 1 = Torque reference is being limited by the rush control because of maximum speed limit (30.12 Maximum speed) | |
| 6 | Tlim min speed | 1 = Torque reference is being limited by the rush control because of minimum speed limit (30.11 Minimum speed) | |
| 7 | Max speed ref lim | 1 = Speed reference is being limited by 30.12 Maximum speed | |
| 8 | Min speed ref lim | 1 = Speed reference is being limited by 30.11 Minimum speed | |
| 9 | Max freq ref lim | 1 = Frequency reference is being limited by 30.14 Maximum frequency | |
| 10 | Min freq ref lim | 1 = Frequency reference is being limited by 30.13 Minimum frequency | |
| 11 | Reserved | | |
| 12 | Sw freq ref lim | 1 = Requested output frequency cannot be reached because of switching frequency limitation (because of output filtering or ATEX-related protections) | |
| 13...15 | Reserved | | |
| 0000h...FFFFh | | Limit word 1. | 1 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|----------------------------|---|--|-----|------|-------------|---|--------------|---|---|-------------|--|---|----------------|---|---|----------------|---|---|------------------|---|---|------------|---|---|---------------|---|---|----------|--|---|---------|--|---|-------------|--|----|--------------|---|----|--------------|--|----|----------------------|--|----|---------------|---|---------|----------|--|
| 30.02 | <i>Torque limit status</i> | Displays the torque controller limitation status word. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Undervoltage</td> <td>*1 = Intermediate DC circuit undervoltage</td> </tr> <tr> <td>1</td> <td>Overvoltage</td> <td>*1 = Intermediate DC circuit overvoltage</td> </tr> <tr> <td>2</td> <td>Minimum torque</td> <td>*1 = Torque is being limited by 30.19 Minimum torque 1, 30.26 Power motoring limit or 30.27 Power generating limit</td> </tr> <tr> <td>3</td> <td>Maximum torque</td> <td>*1 = Torque is being limited by 30.20 Maximum torque 1, 30.26 Power motoring limit or 30.27 Power generating limit</td> </tr> <tr> <td>4</td> <td>Internal current</td> <td>1 = An inverter current limit (identified by bits 8...11) is active</td> </tr> <tr> <td>5</td> <td>Load angle</td> <td>(With permanent magnet motors and synchronous reluctance motors only) 1 = Load angle limit is active, ie. the motor cannot produce any more torque</td> </tr> <tr> <td>6</td> <td>Motor pullout</td> <td>(With asynchronous motors only) 1 = Motor pull-out limit is active, ie. the motor cannot produce any more torque</td> </tr> <tr> <td>7</td> <td>Reserved</td> <td></td> </tr> <tr> <td>8</td> <td>Thermal</td> <td>1 = Input current is being limited by the main circuit thermal limit</td> </tr> <tr> <td>9</td> <td>Max current</td> <td>*1 = Maximum output current (I_{MAX}) is being limited</td> </tr> <tr> <td>10</td> <td>User current</td> <td>*1 = Output current is being limited by 30.17 Maximum current</td> </tr> <tr> <td>11</td> <td>Thermal IGBT</td> <td>*1 = Output current is being limited by a calculated thermal current value</td> </tr> <tr> <td>12</td> <td>IGBT overtemperature</td> <td>*1 = Output current is being limited because of estimated IGBT temperature</td> </tr> <tr> <td>13</td> <td>IGBT overload</td> <td>*1 = Output current is being limited because of IGBT junction to case temperature</td> </tr> <tr> <td>14...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> <p>*Only one out of bits 0...3, and one out of bits 9...13 can be on simultaneously. The bit typically indicates the limit that is exceeded first.</p> | | | | Bit | Name | Description | 0 | Undervoltage | *1 = Intermediate DC circuit undervoltage | 1 | Overvoltage | *1 = Intermediate DC circuit overvoltage | 2 | Minimum torque | *1 = Torque is being limited by 30.19 Minimum torque 1 , 30.26 Power motoring limit or 30.27 Power generating limit | 3 | Maximum torque | *1 = Torque is being limited by 30.20 Maximum torque 1 , 30.26 Power motoring limit or 30.27 Power generating limit | 4 | Internal current | 1 = An inverter current limit (identified by bits 8...11) is active | 5 | Load angle | (With permanent magnet motors and synchronous reluctance motors only) 1 = Load angle limit is active, ie. the motor cannot produce any more torque | 6 | Motor pullout | (With asynchronous motors only) 1 = Motor pull-out limit is active, ie. the motor cannot produce any more torque | 7 | Reserved | | 8 | Thermal | 1 = Input current is being limited by the main circuit thermal limit | 9 | Max current | *1 = Maximum output current (I_{MAX}) is being limited | 10 | User current | *1 = Output current is being limited by 30.17 Maximum current | 11 | Thermal IGBT | *1 = Output current is being limited by a calculated thermal current value | 12 | IGBT overtemperature | *1 = Output current is being limited because of estimated IGBT temperature | 13 | IGBT overload | *1 = Output current is being limited because of IGBT junction to case temperature | 14...15 | Reserved | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Undervoltage | *1 = Intermediate DC circuit undervoltage | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Overvoltage | *1 = Intermediate DC circuit overvoltage | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Minimum torque | *1 = Torque is being limited by 30.19 Minimum torque 1 , 30.26 Power motoring limit or 30.27 Power generating limit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Maximum torque | *1 = Torque is being limited by 30.20 Maximum torque 1 , 30.26 Power motoring limit or 30.27 Power generating limit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Internal current | 1 = An inverter current limit (identified by bits 8...11) is active | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Load angle | (With permanent magnet motors and synchronous reluctance motors only) 1 = Load angle limit is active, ie. the motor cannot produce any more torque | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Motor pullout | (With asynchronous motors only) 1 = Motor pull-out limit is active, ie. the motor cannot produce any more torque | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Thermal | 1 = Input current is being limited by the main circuit thermal limit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Max current | *1 = Maximum output current (I_{MAX}) is being limited | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | User current | *1 = Output current is being limited by 30.17 Maximum current | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | Thermal IGBT | *1 = Output current is being limited by a calculated thermal current value | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | IGBT overtemperature | *1 = Output current is being limited because of estimated IGBT temperature | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | IGBT overload | *1 = Output current is being limited because of IGBT junction to case temperature | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0000h...FFFFh | | Torque limitation status word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 30.11 | <i>Minimum speed</i> | Defines the minimum allowed speed.  WARNING! This value must not be higher than 30.12 Maximum speed .  In frequency control mode, this limit is not effective. Make sure the frequency limits (30.13 and 30.14) are set appropriately if frequency control is used. | -1500.00 rpm; -1800.00 rpm (95.20 b0) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| -30000.00 ...30000.00 rpm | | Minimum allowed speed. | See par. 46.01 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 30.12 | <i>Maximum speed</i> | Defines the maximum allowed speed.  WARNING! This value must not be lower than 30.11 Minimum speed .  WARNING! In frequency control mode, this limit is not effective. Make sure the frequency limits (30.13 and 30.14) are set appropriately if frequency control is used. | 1500.00 rpm; 1800.00 rpm (95.20 b0) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| -30000.00 ...30000.00 rpm | | Maximum speed. | See par. 46.01 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------------|---|--|
| 30.13 | <i>Minimum frequency</i> | <p>Defines the minimum allowed frequency.</p> <p> WARNING! This value must not be higher than 30.14 Maximum frequency.</p> <p> WARNING! This limit is effective in frequency control mode only.</p> | -50.00 Hz; -60.00 Hz (95.20 b0) |
| | -500.00...500.00 Hz | Minimum frequency. | See par. 46.02 |
| 30.14 | <i>Maximum frequency</i> | <p>Defines the maximum allowed frequency.</p> <p> WARNING! This value must not be lower than 30.13 Minimum frequency.</p> <p> WARNING! This limit is effective in frequency control mode only.</p> | 50.00 Hz; 60.00 Hz (95.20 b0) |
| | -500.00...500.00 Hz | Maximum frequency. | See par. 46.02 |
| 30.15 | <i>Maximum start current enable</i> | <p>A temporary motor current limit specifically for starting can be defined by this parameter and 30.16 Maximum start current.</p> <p>When this parameter is set to <i>Enable</i>, the drive observes the start current limit defined by 30.16 Maximum start current. The limit is in force for 2 seconds after initial magnetization (of an asynchronous induction motor) or autophasing (of a permanent magnet motor), but not more often than once in every 7 seconds. Otherwise, the limit defined by 30.17 Maximum current is in force.</p> <p>Note: The availability of a start current higher than the general limit depends on drive hardware.</p> | <i>Disable</i> |
| | Disable | Start current limit disabled. | 0 |
| | Enable | Start current limit enabled. | 1 |
| 30.16 | <i>Maximum start current</i> | Defines the maximum start current when enabled by parameter 30.15 Maximum start current enable . | - |
| | 0.00...30000.00 A | Maximum motor start current. | 1 = 1 A |
| 30.17 | <i>Maximum current</i> | Defines the maximum allowed motor current. | 0.00 A |
| | 0.00...30000.00 A | Maximum motor current. | 1 = 1 A |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------|---|-------------------------|
| 30.18 | <i>Minimum torque sel</i> | <p>Selects a source that switches between two different predefined minimum torque limits.</p> <p>0 = Minimum torque limit defined by 30.19 is active 1 = Minimum torque limit selected by 30.21 is active</p> <p>The user can define two sets of torque limits, and switch between the sets using a binary source such as a digital input. The minimum limit selection (30.18) is independent of the maximum limit selection (30.25).</p> <p>The first set of limits is defined by parameters 30.19 and 30.20. The second set has selector parameters for both the minimum (30.21) and maximum (30.22) limits that allows the use of a selectable analog source (such as an analog input).</p>  <p>Note: In addition to the user-defined limits, torque may be limited for other reasons (such as power limitation). Refer to the block diagram on page 484.</p> | <i>Minimum torque 1</i> |
| | Minimum torque 1 | 0 (minimum torque limit defined by 30.19 is active). | 0 |
| | Minimum torque 2 source | 1 (minimum torque limit selected by 30.21 is active). | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------|---|-------------------------|
| 30.19 | <i>Minimum torque 1</i> | Defines a minimum torque limit for the drive (in percent of nominal motor torque). See diagram at parameter 30.18 Minimum torque sel. The limit is effective when <ul style="list-style-type: none"> the source selected by 30.18 Minimum torque sel is 0, or 30.18 is set to <i>Minimum torque 1</i>. | -300.0% |
| | -1600.0...0.0% | Minimum torque limit 1. | See par. 46.03 |
| 30.20 | <i>Maximum torque 1</i> | Defines a maximum torque limit for the drive (in percent of nominal motor torque). See diagram at parameter 30.18 Minimum torque sel. The limit is effective when <ul style="list-style-type: none"> the source selected by 30.25 Maximum torque sel is 0, or 30.25 is set to <i>Maximum torque 1</i>. | 300.0% |
| | 0.0...1600.0% | Maximum torque 1. | See par. 46.03 |
| 30.21 | <i>Minimum torque 2 source</i> | Defines the source of the minimum torque limit for the drive (in percent of nominal motor torque) when <ul style="list-style-type: none"> the source selected by parameter 30.18 Minimum torque sel is 1, or 30.18 is set to <i>Minimum torque 2 source</i>. See diagram at 30.18 Minimum torque sel. Note: Any positive values received from the selected source are inverted. | <i>Minimum torque 2</i> |
| | Zero | None. | 0 |
| | AI1 scaled | 12.12 AI1 scaled value (see page 141). | 1 |
| | AI2 scaled | 12.22 AI2 scaled value (see page 143). | 2 |
| | Minimum torque 2 | 30.23 Minimum torque 2 . | 6 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 30.22 | <i>Maximum torque 2 source</i> | Defines the source of the maximum torque limit for the drive (in percent of nominal motor torque) when <ul style="list-style-type: none"> the source selected by parameter 30.25 is 1, or 30.25 is set to <i>Maximum torque 2 source</i>. See diagram at 30.18 Minimum torque sel. Note: Any negative values received from the selected source are inverted. | <i>Maximum torque 2</i> |
| | Zero | None. | 0 |
| | AI1 scaled | 12.12 AI1 scaled value (see page 141). | 1 |
| | AI2 scaled | 12.22 AI2 scaled value (see page 143). | 2 |
| | Maximum torque 2 | 30.24 Maximum torque 2 . | 6 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |

240 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------|--|-------------------------|
| 30.23 | <i>Minimum torque 2</i> | Defines the minimum torque limit for the drive (in percent of nominal motor torque) when <ul style="list-style-type: none"> the source selected by parameter <i>30.18 Minimum torque sel</i> is 1, and <i>30.21</i> is set to <i>Minimum torque 2</i>. See diagram at <i>30.18 Minimum torque sel</i> . | -300.0% |
| | -1600.0...0.0% | Minimum torque limit 2. | See par. 46.03 |
| 30.24 | <i>Maximum torque 2</i> | Defines the maximum torque limit for the drive (in percent of nominal motor torque) when <ul style="list-style-type: none"> the source selected by parameter <i>30.25 Maximum torque sel</i> is 1, and <i>30.22</i> is set to <i>Maximum torque 2</i>. See diagram at <i>30.18 Minimum torque sel</i> . | 300.0% |
| | 0.0...1600.0% | Maximum torque limit 2. | See par. 46.03 |
| 30.25 | <i>Maximum torque sel</i> | Selects a source that switches between two different maximum torque limits. 0 = Maximum torque limit 1 defined by <i>30.20</i> is active 1 = Maximum torque limit selected by <i>30.22</i> is active See also parameter <i>30.18 Minimum torque sel</i> . | <i>Maximum torque 1</i> |
| | Maximum torque 1 | 0. | 0 |
| | Maximum torque 2 source | 1. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 30.26 | <i>Power motoring limit</i> | Defines the maximum allowed power fed by the inverter to the motor in percent of nominal motor power. | 300.00% |
| | 0.00...600.00% | Maximum motoring power. | 1 = 1% |
| 30.27 | <i>Power generating limit</i> | Defines the maximum allowed power fed by the motor to the inverter in percent of nominal motor power. | -300.00% |
| | -600.00...0.00% | Maximum generating power. | 1 = 1% |
| 30.30 | <i>Overvoltage control</i> | Enables the overvoltage control of the intermediate DC link. Fast braking of a high inertia load causes the voltage to rise to the overvoltage control limit. To prevent the DC voltage from exceeding the limit, the overvoltage controller automatically decreases the braking torque. Note: If the drive is equipped with a brake chopper and resistor, or a regenerative supply unit, the controller must be disabled. | <i>Enable</i> |
| | Disable | Overvoltage control disabled. | 0 |

| No. | Name/Value | Description | Def/ FbEq16 |
|--------------------------------------|-----------------------------|---|---|
| | Enable | Overvoltage control enabled. | 1 |
| 30.31 | <i>Undervoltage control</i> | Enables the undervoltage control of the intermediate DC link. If the DC voltage drops due to input power cut off, the undervoltage controller will automatically decrease the motor torque in order to keep the voltage above the lower limit. By decreasing the motor torque, the inertia of the load will cause regeneration back to the drive, keeping the DC link charged and preventing an undervoltage trip until the motor coasts to a stop. This will act as a power-loss ride-through functionality in systems with high inertia, such as a centrifuge or a fan. | <i>Enable</i> |
| | Disable | Undervoltage control disabled. | 0 |
| | Enable | Undervoltage control enabled. | 1 |
| 31 Fault functions | | | |
| 31.01 External event 1 source | | Configuration of external events; selection of behavior of the drive upon fault situations. | |
| | Active (false) | Defines the source of external event 1. See also parameter <i>31.02 External event 1 type</i> . 0 = Trigger event 1 = Normal operation | <i>Inactive (true);</i> <i>DI6 (95.20 b8)</i> |
| | Inactive (true) | | |
| | DIIL | DIIL input (<i>10.02 DI delayed status</i> , bit 15). | 2 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 3 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 4 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 5 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 6 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 7 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 8 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 11 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 12 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 31.02 External event 1 type | | Selects the type of external event 1. | <i>Fault</i> <i>(95.20 b8)</i> |
| | Fault | The external event generates a fault. | 0 |
| | Warning | The external event generates a warning. | 1 |
| | Warning/Fault | If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning. | 3 |
| 31.03 External event 2 source | | Defines the source of external event 2. See also parameter <i>31.04 External event 2 type</i> . For the selections, see parameter <i>31.01 External event 1 source</i> . | <i>Inactive (true),</i> <i>DIIL</i> <i>(95.20 b8)</i> |
| 31.04 External event 2 type | | Selects the type of external event 2. | |
| | Fault | The external event generates a fault. | 0 |
| | Warning | The external event generates a warning. | 1 |

242 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------|---|------------------------|
| | Warning/Fault | If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning. | 3 |
| 31.05 | <i>External event 3 source</i> | Defines the source of external event 3. See also parameter <i>31.06 External event 3 type</i> . For the selections, see parameter <i>31.01 External event 1 source</i> . | <i>Inactive (true)</i> |
| 31.06 | <i>External event 3 type</i> | Selects the type of external event 3. | |
| | Fault | The external event generates a fault. | 0 |
| | Warning | The external event generates a warning. | 1 |
| | Warning/Fault | If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning. | 3 |
| 31.07 | <i>External event 4 source</i> | Defines the source of external event 4. See also parameter <i>31.08 External event 4 type</i> . For the selections, see parameter <i>31.01 External event 1 source</i> . | <i>Inactive (true)</i> |
| 31.08 | <i>External event 4 type</i> | Selects the type of external event 4. | |
| | Fault | The external event generates a fault. | 0 |
| | Warning | The external event generates a warning. | 1 |
| | Warning/Fault | If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning. | 3 |
| 31.09 | <i>External event 5 source</i> | Defines the source of external event 5. See also parameter <i>31.10 External event 5 type</i> . For the selections, see parameter <i>31.01 External event 1 source</i> . | <i>Inactive (true)</i> |
| 31.10 | <i>External event 5 type</i> | Selects the type of external event 5. | |
| | Fault | The external event generates a fault. | 0 |
| | Warning | The external event generates a warning. | 1 |
| | Warning/Fault | If the drive is modulating, the external event generates a fault. Otherwise, the event generates a warning. | 3 |
| 31.11 | <i>Fault reset selection</i> | Selects the source of an external fault reset signal. The signal resets the drive after a fault trip if the cause of the fault no longer exists. 0 -> 1 = Reset Note: A fault reset from the fieldbus interface is always observed regardless of this parameter. | <i>Not selected</i> |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | FBA A MCW bit 7 | Control word bit 7 received through fieldbus interface A. | 30 |



| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-----------------------|---|---|----------------|-------|---|-------------|---|-------------|---|--------------|---|----------------------|---|-------------|-------|----------|---|--|---|--|----|---|----|---|----|---|----|---|----|---|----|---|--|
| | EFB MCW bit 7 | Control word bit 7 received through the embedded fieldbus interface. | 32 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 31.12 | Autoreset selection | <p>Selects faults that are automatically reset. The parameter is a 16-bit word with each bit corresponding to a fault type. Whenever a bit is set to 1, the corresponding fault is automatically reset.</p> <p>The number and interval of reset attempts are defined by parameters 31.14...31.16.</p> <p>Note: The autoreset function is only available in external control; see section Local control vs. external control (page 51).</p> <p>The bits of this binary number correspond to the following faults:</p> | 0000h | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Fault</th> </tr> </thead> <tbody> <tr><td>0</td><td>Overcurrent</td></tr> <tr><td>1</td><td>Overvoltage</td></tr> <tr><td>2</td><td>Undervoltage</td></tr> <tr><td>3</td><td>AI supervision fault</td></tr> <tr><td>4</td><td>Supply unit</td></tr> <tr><td>5...7</td><td>Reserved</td></tr> <tr><td>8</td><td>Application fault 1 (defined in the application program)</td></tr> <tr><td>9</td><td>Application fault 2 (defined in the application program)</td></tr> <tr><td>10</td><td>Selectable fault (see parameter 31.13 User selectable fault)</td></tr> <tr><td>11</td><td>External fault 1 (from source selected by parameter 31.01 External event 1 source)</td></tr> <tr><td>12</td><td>External fault 2 (from source selected by parameter 31.03 External event 2 source)</td></tr> <tr><td>13</td><td>External fault 3 (from source selected by parameter 31.05 External event 3 source)</td></tr> <tr><td>14</td><td>External fault 4 (from source selected by parameter 31.07 External event 4 source)</td></tr> <tr><td>15</td><td>External fault 5 (from source selected by parameter 31.09 External event 5 source)</td></tr> </tbody> </table> | Bit | Fault | 0 | Overcurrent | 1 | Overvoltage | 2 | Undervoltage | 3 | AI supervision fault | 4 | Supply unit | 5...7 | Reserved | 8 | Application fault 1 (defined in the application program) | 9 | Application fault 2 (defined in the application program) | 10 | Selectable fault (see parameter 31.13 User selectable fault) | 11 | External fault 1 (from source selected by parameter 31.01 External event 1 source) | 12 | External fault 2 (from source selected by parameter 31.03 External event 2 source) | 13 | External fault 3 (from source selected by parameter 31.05 External event 3 source) | 14 | External fault 4 (from source selected by parameter 31.07 External event 4 source) | 15 | External fault 5 (from source selected by parameter 31.09 External event 5 source) | |
| Bit | Fault | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Overcurrent | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Overvoltage | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Undervoltage | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | AI supervision fault | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Supply unit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5...7 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Application fault 1 (defined in the application program) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Application fault 2 (defined in the application program) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Selectable fault (see parameter 31.13 User selectable fault) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | External fault 1 (from source selected by parameter 31.01 External event 1 source) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | External fault 2 (from source selected by parameter 31.03 External event 2 source) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | External fault 3 (from source selected by parameter 31.05 External event 3 source) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | External fault 4 (from source selected by parameter 31.07 External event 4 source) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | External fault 5 (from source selected by parameter 31.09 External event 5 source) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Automatic reset configuration word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 31.13 | User selectable fault | Defines the fault that can be automatically reset using parameter 31.12 Autoreset selection , bit 10. The faults are listed in chapter Fault tracing (page 405). | 0000h | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Fault code. | 10 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 31.14 | Number of trials | <p>Defines the maximum number of automatic resets that the drive is allowed to attempt within the time specified by 31.15 Total trials time.</p> <p>If the fault persists, subsequent reset attempts will be made at intervals defined by 31.16 Delay time.</p> <p>The faults to be automatically reset are defined by 31.12 Autoreset selection.</p> | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0...5 | Number of automatic resets. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

244 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------|--|----------------|
| 31.15 | <i>Total trials time</i> | Defines a time window for automatic fault resets. The maximum number of attempts made during any period of this length is defined by 31.14 Number of trials . Note: If the fault condition remains and cannot be reset, each reset attempt will generate an event and start a new time window. In practice, if the specified number of resets (31.14) at specified intervals (31.16) take longer than the value of 31.15 , the drive will continue to attempt resetting the fault until the cause is eventually removed. | 30.0 s |
| | 1.0...600.0 s | Time for automatic resets. | 10 = 1 s |
| 31.16 | <i>Delay time</i> | Defines the time that the drive will wait after a fault (or a previous reset attempt) before attempting an automatic reset. See parameter 31.12 Autoreset selection . | 0.0 s |
| | 0.0...120.0 s | Autoreset delay. | 10 = 1 s |
| 31.19 | <i>Motor phase loss</i> | Selects how the drive reacts when a motor phase loss is detected. | <i>Fault</i> |
| | No action | No action taken. | 0 |
| | Fault | The drive trips on fault 3381 Output phase loss . | 1 |
| 31.20 | <i>Earth fault</i> | Selects how the drive reacts when an earth fault or current unbalance is detected in the motor or the motor cable. | <i>Fault</i> |
| | No action | No action taken. | 0 |
| | Warning | The drive generates an A2B3 Earth leakage warning. | 1 |
| | Fault | The drive trips on fault 2330 Earth leakage . | 2 |
| 31.21 | <i>Supply phase loss</i> | Selects how the drive reacts when a supply phase loss is detected. | <i>Fault</i> |
| | No action | No action taken. | 0 |
| | Fault | The drive trips on fault 3130 Input phase loss . | 1 |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | |
|--------|--------------------------------|--|--|--|---------------------------------|-----|-----|-----|---------|-----------------------------------|---|---|---|-------------------------------------|---|---|---|--|--------------------|---|---|--|---|
| 31.22 | <i>STO indication run/stop</i> | <p>Selects which indications are given when one or both Safe torque off (STO) signals are switched off or lost. The indications also depend on whether the drive is running or stopped when this occurs.</p> <p>The tables at each selection below show the indications generated with that particular setting.</p> <p>Notes:</p> <ul style="list-style-type: none"> This parameter does not affect the operation of the STO function itself. The STO function will operate regardless of the setting of this parameter: a running drive will stop upon removal of one or both STO signals, and will not start until both STO signals are restored and all faults reset. The loss of only one STO signal always generates a fault as it is interpreted as a malfunction. <p>For more information on the STO, see the <i>Hardware manual</i> of the drive.</p> | <i>Fault/Fault</i> | | | | | | | | | | | | | | | | | | | | |
| | Fault/Fault | <table border="1" data-bbox="418 619 890 826"> <thead> <tr> <th colspan="2">Inputs</th> <th rowspan="2">Indication (running or stopped)</th> </tr> <tr> <th>IN1</th> <th>IN2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Fault <i>5091 Safe torque off</i></td> </tr> <tr> <td>0</td> <td>1</td> <td>Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1 loss</i></td> </tr> <tr> <td>1</td> <td>0</td> <td>Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2 loss</i></td> </tr> <tr> <td>1</td> <td>1</td> <td>(Normal operation)</td> </tr> </tbody> </table> | Inputs | | Indication (running or stopped) | IN1 | IN2 | 0 | 0 | Fault <i>5091 Safe torque off</i> | 0 | 1 | Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1 loss</i> | 1 | 0 | Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2 loss</i> | 1 | 1 | (Normal operation) | 0 | | | |
| Inputs | | Indication (running or stopped) | | | | | | | | | | | | | | | | | | | | | |
| IN1 | IN2 | | | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | Fault <i>5091 Safe torque off</i> | | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1 loss</i> | | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2 loss</i> | | | | | | | | | | | | | | | | | | | | | |
| 1 | 1 | (Normal operation) | | | | | | | | | | | | | | | | | | | | | |
| | Fault/Warning | <table border="1" data-bbox="418 874 890 1161"> <thead> <tr> <th colspan="2">Inputs</th> <th colspan="2">Indication</th> </tr> <tr> <th>IN1</th> <th>IN2</th> <th>Running</th> <th>Stopped</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Fault <i>5091 Safe torque off</i></td> <td>Warning <i>A5A0 Safe torque off</i></td> </tr> <tr> <td>0</td> <td>1</td> <td>Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1 loss</i></td> <td>Warning <i>A5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1 loss</i></td> </tr> <tr> <td>1</td> <td>0</td> <td>Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2 loss</i></td> <td>Warning <i>A5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2 loss</i></td> </tr> </tbody> </table> | Inputs | | Indication | | IN1 | IN2 | Running | Stopped | 0 | 0 | Fault <i>5091 Safe torque off</i> | Warning <i>A5A0 Safe torque off</i> | 0 | 1 | Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1 loss</i> | Warning <i>A5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1 loss</i> | 1 | 0 | Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2 loss</i> | Warning <i>A5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2 loss</i> | 1 |
| Inputs | | Indication | | | | | | | | | | | | | | | | | | | | | |
| IN1 | IN2 | Running | Stopped | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | Fault <i>5091 Safe torque off</i> | Warning <i>A5A0 Safe torque off</i> | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1 loss</i> | Warning <i>A5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1 loss</i> | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2 loss</i> | Warning <i>A5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2 loss</i> | | | | | | | | | | | | | | | | | | | | |
| | Fault/Event | <table border="1" data-bbox="418 1206 890 1485"> <thead> <tr> <th colspan="2">Inputs</th> <th colspan="2">Indication</th> </tr> <tr> <th>IN1</th> <th>IN2</th> <th>Running</th> <th>Stopped</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Fault <i>5091 Safe torque off</i></td> <td>Event <i>B5A0 Safe torque off</i></td> </tr> <tr> <td>0</td> <td>1</td> <td>Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1 loss</i></td> <td>Event <i>B5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1 loss</i></td> </tr> <tr> <td>1</td> <td>0</td> <td>Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2 loss</i></td> <td>Event <i>B5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2 loss</i></td> </tr> </tbody> </table> | Inputs | | Indication | | IN1 | IN2 | Running | Stopped | 0 | 0 | Fault <i>5091 Safe torque off</i> | Event <i>B5A0 Safe torque off</i> | 0 | 1 | Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1 loss</i> | Event <i>B5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1 loss</i> | 1 | 0 | Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2 loss</i> | Event <i>B5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2 loss</i> | 2 |
| Inputs | | Indication | | | | | | | | | | | | | | | | | | | | | |
| IN1 | IN2 | Running | Stopped | | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | Fault <i>5091 Safe torque off</i> | Event <i>B5A0 Safe torque off</i> | | | | | | | | | | | | | | | | | | | | |
| 0 | 1 | Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1 loss</i> | Event <i>B5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1 loss</i> | | | | | | | | | | | | | | | | | | | | |
| 1 | 0 | Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2 loss</i> | Event <i>B5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2 loss</i> | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | |
|--------|------------------------------|---|----------------|--|---------------------------------|-----|-----|---|---|-------------------------------------|---|---|--|---|---|--|---|---|--------------------|---|
| | Warning/Warning | <table border="1"> <thead> <tr> <th colspan="2">Inputs</th> <th rowspan="2">Indication (running or stopped)</th> </tr> <tr> <th>IN1</th> <th>IN2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Warning <i>A5A0 Safe torque off</i></td> </tr> <tr> <td>0</td> <td>1</td> <td>Warning <i>A5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1 loss</i></td> </tr> <tr> <td>1</td> <td>0</td> <td>Warning <i>A5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2 loss</i></td> </tr> <tr> <td>1</td> <td>1</td> <td>(Normal operation)</td> </tr> </tbody> </table> | Inputs | | Indication (running or stopped) | IN1 | IN2 | 0 | 0 | Warning <i>A5A0 Safe torque off</i> | 0 | 1 | Warning <i>A5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1 loss</i> | 1 | 0 | Warning <i>A5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2 loss</i> | 1 | 1 | (Normal operation) | 3 |
| Inputs | | Indication (running or stopped) | | | | | | | | | | | | | | | | | | |
| IN1 | IN2 | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | Warning <i>A5A0 Safe torque off</i> | | | | | | | | | | | | | | | | | | |
| 0 | 1 | Warning <i>A5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1 loss</i> | | | | | | | | | | | | | | | | | | |
| 1 | 0 | Warning <i>A5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2 loss</i> | | | | | | | | | | | | | | | | | | |
| 1 | 1 | (Normal operation) | | | | | | | | | | | | | | | | | | |
| | Event/Event | <table border="1"> <thead> <tr> <th colspan="2">Inputs</th> <th rowspan="2">Indication (running or stopped)</th> </tr> <tr> <th>IN1</th> <th>IN2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Event <i>B5A0 Safe torque off</i></td> </tr> <tr> <td>0</td> <td>1</td> <td>Event <i>B5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1 loss</i></td> </tr> <tr> <td>1</td> <td>0</td> <td>Event <i>B5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2 loss</i></td> </tr> <tr> <td>1</td> <td>1</td> <td>(Normal operation)</td> </tr> </tbody> </table> | Inputs | | Indication (running or stopped) | IN1 | IN2 | 0 | 0 | Event <i>B5A0 Safe torque off</i> | 0 | 1 | Event <i>B5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1 loss</i> | 1 | 0 | Event <i>B5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2 loss</i> | 1 | 1 | (Normal operation) | 4 |
| Inputs | | Indication (running or stopped) | | | | | | | | | | | | | | | | | | |
| IN1 | IN2 | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | Event <i>B5A0 Safe torque off</i> | | | | | | | | | | | | | | | | | | |
| 0 | 1 | Event <i>B5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1 loss</i> | | | | | | | | | | | | | | | | | | |
| 1 | 0 | Event <i>B5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2 loss</i> | | | | | | | | | | | | | | | | | | |
| 1 | 1 | (Normal operation) | | | | | | | | | | | | | | | | | | |
| | No indication/No indication | <table border="1"> <thead> <tr> <th colspan="2">Inputs</th> <th rowspan="2">Indication (running or stopped)</th> </tr> <tr> <th>IN1</th> <th>IN2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>None</td> </tr> <tr> <td>0</td> <td>1</td> <td>Fault <i>FA81 Safe torque off 1 loss</i></td> </tr> <tr> <td>1</td> <td>0</td> <td>Fault <i>FA82 Safe torque off 2 loss</i></td> </tr> <tr> <td>1</td> <td>1</td> <td>(Normal operation)</td> </tr> </tbody> </table> | Inputs | | Indication (running or stopped) | IN1 | IN2 | 0 | 0 | None | 0 | 1 | Fault <i>FA81 Safe torque off 1 loss</i> | 1 | 0 | Fault <i>FA82 Safe torque off 2 loss</i> | 1 | 1 | (Normal operation) | 5 |
| Inputs | | Indication (running or stopped) | | | | | | | | | | | | | | | | | | |
| IN1 | IN2 | | | | | | | | | | | | | | | | | | | |
| 0 | 0 | None | | | | | | | | | | | | | | | | | | |
| 0 | 1 | Fault <i>FA81 Safe torque off 1 loss</i> | | | | | | | | | | | | | | | | | | |
| 1 | 0 | Fault <i>FA82 Safe torque off 2 loss</i> | | | | | | | | | | | | | | | | | | |
| 1 | 1 | (Normal operation) | | | | | | | | | | | | | | | | | | |
| 31.23 | <i>Wiring or earth fault</i> | <p>Selects how the drive reacts to incorrect input power and motor cable connection (i.e. input power cable is connected to drive motor connection).</p> <p>Note: The protection must be disabled with drive/inverter hardware supplied from a common DC bus.</p> | <i>Fault</i> | | | | | | | | | | | | | | | | | |
| | No action | No action taken (protection disabled). | 0 | | | | | | | | | | | | | | | | | |
| | Fault | The drive trips on fault <i>3181 Cross connection</i> . | 1 | | | | | | | | | | | | | | | | | |
| 31.24 | <i>Stall function</i> | <p>Selects how the drive reacts to a motor stall condition. A stall condition is defined as follows:</p> <ul style="list-style-type: none"> • The drive exceeds the stall current limit (<i>31.25 Stall current limit</i>), and • the output frequency is below the level set by parameter <i>31.27 Stall frequency limit</i> or the motor speed is below the level set by parameter <i>31.26 Stall speed limit</i>, and • the conditions above have been true longer than the time set by parameter <i>31.28 Stall time</i>. | <i>Fault</i> | | | | | | | | | | | | | | | | | |
| | No action | None (stall supervision disabled). | 0 | | | | | | | | | | | | | | | | | |
| | Warning | The drive generates an <i>A780 Motor stall</i> warning. | 1 | | | | | | | | | | | | | | | | | |
| | Fault | The drive trips on fault <i>7121 Motor stall</i> . | 2 | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------------|--|---|
| 31.25 | <i>Stall current limit</i> | Stall current limit in percent of the nominal current of the motor. See parameter 31.24 Stall function . | 200.0% |
| | 0.0...1600.0% | Stall current limit. | - |
| 31.26 | <i>Stall speed limit</i> | Stall speed limit in rpm. See parameter 31.24 Stall function . | 150.00 rpm; 180.00 rpm (95.20 b0) |
| | 0.00...10000.00 rpm | Stall speed limit. | See par. 46.01 |
| 31.27 | <i>Stall frequency limit</i> | Stall frequency limit. See parameter 31.24 Stall function . Note: Setting the limit below 10 Hz is not recommended. | 15.00 Hz; 18.00 Hz (95.20 b0) |
| | 0.00...500.00 Hz | Stall frequency limit. | See par. 46.02 |
| 31.28 | <i>Stall time</i> | Stall time. See parameter 31.24 Stall function . | 20 s |
| | 0...3600 s | Stall time. | - |
| 31.30 | <i>Overspeed trip margin</i> | <p>Defines, together with 30.11 Minimum speed and 30.12 Maximum speed, the maximum allowed speed of the motor (overspeed protection). If actual speed (90.01 Motor speed for control) exceeds the speed limit defined by parameter 30.11 or 30.12 by more than the value of this parameter, the drive trips on the 7310 Overspeed fault.</p> <p> WARNING! This function only supervises the speed in DTC motor control mode. The function is not effective in scalar motor control mode.</p> <p>Example: If the maximum speed is 1420 rpm and speed trip margin is 300 rpm, the drive trips at 1720 rpm.</p> <p>Speed (90.01)</p>  | 500.00 rpm |
| | 0.00...10000.0 rpm | Overspeed trip margin. | See par. 46.01 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---|---|----------------|
| 31.32 | <i>Emergency ramp supervision</i> | <p>Parameters <i>31.32 Emergency ramp supervision</i> and <i>31.33 Emergency ramp supervision delay</i>, together with <i>01.29 Speed change rate</i>, provide a supervision function for emergency stop modes Off1 and Off3.</p> <p>The supervision is based on either</p> <ul style="list-style-type: none"> • observing the time within which the motor stops, or • comparing the actual and expected deceleration rates. <p>If this parameter is set to 0%, the maximum stop time is directly set in parameter <i>31.33</i>. Otherwise, <i>31.32</i> defines the maximum allowed deviation from the expected deceleration rate, which is calculated from parameters <i>23.11...23.19</i> (Off1) or <i>23.23 Emergency stop time</i> (Off3). If the actual deceleration rate (<i>01.29</i>) deviates too much from the expected rate, the drive trips on <i>73B0 Emergency ramp failed</i>, sets bit 8 of <i>06.17 Drive status word 2</i>, and coasts to a stop.</p> <p>If <i>31.32</i> is set to 0% and <i>31.33</i> is set to 0 s, the emergency stop ramp supervision is disabled.</p> <p>See also parameter <i>21.04 Emergency stop mode</i>.</p> | 0% |
| | 0...300% | Maximum deviation from expected deceleration rate. | 1 = 1% |
| 31.33 | <i>Emergency ramp supervision delay</i> | <p>If parameter <i>31.32 Emergency ramp supervision</i> is set to 0%, this parameter defines the maximum time an emergency stop (mode Off1 or Off3) is allowed to take. If the motor has not stopped when the time elapses, the drive trips on <i>73B0 Emergency ramp failed</i>, sets bit 8 of <i>06.17 Drive status word 2</i>, and coasts to a stop.</p> <p>If <i>31.32</i> is set to a value other than 0%, this parameter defines a delay between the receipt of the emergency stop command and the activation of the supervision. It is recommended to specify a short delay to allow the speed change rate to stabilize.</p> | 0 s |
| | 0...32767 s | Maximum ramp-down time, or supervision activation delay. | 1 = 1 s |
| 31.35 | <i>Main fan fault function</i> | Selects how the drive reacts when a main cooling fan fault is detected. | <i>Fault</i> |
| | Fault | The drive trips on fault <i>5080 Fan</i> . | 0 |
| | Warning | The drive generates an <i>A581 Fan</i> warning. | 1 |
| | No action | No action taken. | 2 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------------|--|----------------|
| 31.36 | <i>Aux fan fault bypass</i> | <p>(Only visible with a ZCU control unit)</p> <p>Temporarily suppresses auxiliary fan faults. Certain drive types (especially those protected to IP55) have an auxiliary fan built into the front cover as standard. If the fan is sticking or disconnected, the control program first generates a warning (<i>A582 Auxiliary fan missing</i>), then a fault (<i>5081 Auxiliary fan broken</i>).</p> <p>If it is necessary to operate the drive without the front cover (for example, during commissioning), this parameter can be activated to temporarily suppress the fault.</p> <p>Note:</p> <ul style="list-style-type: none"> • The parameter must be activated within 2 minutes of control unit reboot (either by cycling the power or by parameter <i>96.08</i>). • The parameter only suppresses the fault, not the warning. • The parameter will be in effect until the auxiliary fan is reconnected and detected, or until the next control unit reboot. | <i>Off</i> |
| | Off | Normal operation. | 0 |
| | Temporarily bypassed | The auxiliary fan fault indication is temporarily suppressed. The setting will revert automatically to <i>Off</i> . | 1 |
| 31.37 | <i>Ramp stop supervision</i> | <p>Parameters <i>31.37 Ramp stop supervision</i> and <i>31.38 Ramp stop supervision delay</i>, together with <i>01.29 Speed change rate</i>, provide a supervision function for normal (ie. non-emergency) ramp stopping.</p> <p>The supervision is based on either</p> <ul style="list-style-type: none"> • observing the time within which the motor stops, or • comparing the actual and expected deceleration rates. <p>If this parameter is set to 0%, the maximum stop time is directly set in parameter <i>31.38</i>. Otherwise, <i>31.37</i> defines the maximum allowed deviation from the expected deceleration rate, which is calculated from parameters <i>23.11...23.19</i>. If the actual deceleration rate (<i>01.29</i>) deviates too much from the expected rate, the drive trips on <i>73B1 Stop failed</i>, sets bit 14 of <i>06.17 Drive status word 2</i>, and coasts to a stop.</p> <p>If <i>31.32</i> is set to 0% and <i>31.33</i> is set to 0 s, the ramp stop supervision is disabled.</p> | 0% |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | |
|--------|------------------------------------|--|----------------|-------|---|-------------|---|----------|---|-----------|---|-----------|--------|----------|--|
| | 0...300% | Maximum deviation from expected deceleration rate. | 1 = 1% | | | | | | | | | | | | |
| 31.38 | <i>Ramp stop supervision delay</i> | If parameter <i>31.37 Ramp stop supervision</i> is set to 0%, this parameter defines the maximum time a ramp stop is allowed to take. If the motor has not stopped when the time elapses, the drive trips on <i>73B1 Stop failed</i> , sets bit 14 of <i>06.17 Drive status word 2</i> , and coasts to a stop. If <i>31.37</i> is set to a value other than 0%, this parameter defines a delay between the receipt of the stop command and the activation of the supervision. It is recommended to specify a short delay to allow the speed change rate to stabilize. | 0 s | | | | | | | | | | | | |
| | 0...32767 s | Maximum ramp-down time, or supervision activation delay. | 1 = 1 s | | | | | | | | | | | | |
| 31.40 | <i>Disable warnings</i> | Selects warnings to be suppressed. The parameter is a 16-bit word with each bit corresponding to a warning. Whenever a bit is set to 1, the corresponding warning is suppressed. The bits of this binary number correspond to the following warnings: | 0000b | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Fault</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Overvoltage</td> </tr> <tr> <td>1</td> <td>Reserved</td> </tr> <tr> <td>2</td> <td>Encoder 1</td> </tr> <tr> <td>3</td> <td>Encoder 2</td> </tr> <tr> <td>4...15</td> <td>Reserved</td> </tr> </tbody> </table> | Bit | Fault | 0 | Overvoltage | 1 | Reserved | 2 | Encoder 1 | 3 | Encoder 2 | 4...15 | Reserved | |
| Bit | Fault | | | | | | | | | | | | | | |
| 0 | Overvoltage | | | | | | | | | | | | | | |
| 1 | Reserved | | | | | | | | | | | | | | |
| 2 | Encoder 1 | | | | | | | | | | | | | | |
| 3 | Encoder 2 | | | | | | | | | | | | | | |
| 4...15 | Reserved | | | | | | | | | | | | | | |
| | 000b...1101b | Warning suppression word. | 1 = 1 | | | | | | | | | | | | |
| 31.42 | <i>Overcurrent fault limit</i> | Sets a custom motor current fault limit. The drive automatically sets an internal motor current limit according to the drive hardware. The internal limit is appropriate in most cases, but this parameter can be used to set a lower current limit, for example, to protect a permanent magnet motor from demagnetization. With this parameter at 0.0 A, only the internal limit is in force. | | | | | | | | | | | | | |
| | 0.00...30000.0 A | Custom motor current fault limit | - | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | |
|--|-------------------------------|--|------------------|-----|------|-------------|---|----------------------|---|---|----------------------|---|---|----------------------|---|--------|----------|--|
| 32 Supervision | | Configuration of signal supervision functions 1...3. Three values can be chosen to be monitored; a warning or fault is generated whenever predefined limits are exceeded. See also section <i>Signal supervision</i> (page 89). | | | | | | | | | | | | | | | | |
| 32.01 | <i>Supervision status</i> | Signal supervision status word. Indicates whether the values monitored by the signal supervision functions are within or outside their respective limits. Note: This word is independent of the drive actions defined by parameters 32.06, 32.16 and 32.26. | 0000b | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Supervision 1 active</td> <td>1 = Signal selected by 32.07 is outside its limits.</td> </tr> <tr> <td>1</td> <td>Supervision 2 active</td> <td>1 = Signal selected by 32.17 is outside its limits.</td> </tr> <tr> <td>2</td> <td>Supervision 3 active</td> <td>1 = Signal selected by 32.27 is outside its limits.</td> </tr> <tr> <td>3...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | | | | Bit | Name | Description | 0 | Supervision 1 active | 1 = Signal selected by 32.07 is outside its limits. | 1 | Supervision 2 active | 1 = Signal selected by 32.17 is outside its limits. | 2 | Supervision 3 active | 1 = Signal selected by 32.27 is outside its limits. | 3...15 | Reserved | |
| Bit | Name | Description | | | | | | | | | | | | | | | | |
| 0 | Supervision 1 active | 1 = Signal selected by 32.07 is outside its limits. | | | | | | | | | | | | | | | | |
| 1 | Supervision 2 active | 1 = Signal selected by 32.17 is outside its limits. | | | | | | | | | | | | | | | | |
| 2 | Supervision 3 active | 1 = Signal selected by 32.27 is outside its limits. | | | | | | | | | | | | | | | | |
| 3...15 | Reserved | | | | | | | | | | | | | | | | | |
| 0000...0111b | | Signal supervision status word. | 1 = 1 | | | | | | | | | | | | | | | |
| 32.05 | <i>Supervision 1 function</i> | Selects the mode of signal supervision function 1. Determines how the monitored signal (see parameter 32.07) is compared to its lower and upper limits (32.09 and 32.10 respectively). The action to be taken when the condition is fulfilled is selected by 32.06. | <i>Disabled</i> | | | | | | | | | | | | | | | |
| Disabled | | Signal supervision 1 not in use. | 0 | | | | | | | | | | | | | | | |
| Low | | Action is taken whenever the signal falls below its lower limit. | 1 | | | | | | | | | | | | | | | |
| High | | Action is taken whenever the signal rises above its upper limit. | 2 | | | | | | | | | | | | | | | |
| Abs low | | Action is taken whenever the absolute value of the signal falls below its (absolute) lower limit. | 3 | | | | | | | | | | | | | | | |
| Abs high | | Action is taken whenever the absolute value of the signal rises above its (absolute) upper limit. | 4 | | | | | | | | | | | | | | | |
| Both | | Action is taken whenever the signal falls below its low limit or rises above its high limit. | 5 | | | | | | | | | | | | | | | |
| Abs both | | Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit. | 6 | | | | | | | | | | | | | | | |
| 32.06 | <i>Supervision 1 action</i> | Selects the action the drive takes when the value monitored by signal supervision 1 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 <i>Supervision status</i> . | <i>No action</i> | | | | | | | | | | | | | | | |
| No action | | No action taken. | 0 | | | | | | | | | | | | | | | |
| Warning | | A warning (<i>A8B0 Signal supervision</i>) is generated. | 1 | | | | | | | | | | | | | | | |
| Fault | | The drive trips on <i>80B0 Signal supervision</i> . | 2 | | | | | | | | | | | | | | | |
| 32.07 | <i>Supervision 1 signal</i> | Selects the signal to be monitored by signal supervision function 1. | <i>Zero</i> | | | | | | | | | | | | | | | |
| Zero | | None. | 0 | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------|---|--|-----------------|
| | Speed | 01.01 Motor speed used (page 105). | 1 |
| | Frequency | 01.06 Output frequency (page 105). | 3 |
| | Current | 01.07 Motor current (page 105). | 4 |
| | Torque | 01.10 Motor torque (page 105). | 6 |
| | DC voltage | 01.11 DC voltage (page 105). | 7 |
| | Output power | 01.14 Output power (page 106). | 8 |
| | AI1 | 12.11 AI1 actual value (page 141). | 9 |
| | AI2 | 12.21 AI2 actual value (page 143). | 10 |
| | Speed ref ramp in | 23.01 Speed ref ramp input (page 203). | 18 |
| | Speed ref ramp out | 23.02 Speed ref ramp output (page 204). | 19 |
| | Speed ref used | 24.01 Used speed reference (page 210). | 20 |
| | Torque ref used | 26.02 Torque reference used | 21 |
| | Freq ref used | 28.02 Frequency ref ramp output (page 226). | 22 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 32.08 | Supervision 1 filter time | Defines a filter time constant for the signal monitored by signal supervision 1. | 0.000 s |
| | 0.000...30.000 s | Signal filter time. | 1000 = 1 s |
| 32.09 | Supervision 1 low | Defines the lower limit for signal supervision 1. | 0.00 |
| | -21474830.00 ...21474830.00 | Low limit. | - |
| 32.10 | Supervision 1 high | Defines the upper limit for signal supervision 1. | 0.00 |
| | -21474830.00 ...21474830.00 | Upper limit. | - |
| 32.15 | Supervision 2 function | Selects the mode of signal supervision function 2. Determines how the monitored signal (see parameter 32.17) is compared to its lower and upper limits (32.19 and 32.20 respectively). The action to be taken when the condition is fulfilled is selected by 32.16 . | <i>Disabled</i> |
| | Disabled | Signal supervision 2 not in use. | 0 |
| | Low | Action is taken whenever the signal falls below its lower limit. | 1 |
| | High | Action is taken whenever the signal rises above its upper limit. | 2 |
| | Abs low | Action is taken whenever the absolute value of the signal falls below its (absolute) lower limit. | 3 |
| | Abs high | Action is taken whenever the absolute value of the signal rises above its (absolute) upper limit. | 4 |
| | Both | Action is taken whenever the signal falls below its low limit or rises above its high limit. | 5 |
| | Abs both | Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit. | 6 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------|---|--|---------------------------|
| 32.16 | Supervision 2 action | Selects the action the drive takes when the value monitored by signal supervision 2 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 Supervision status . | No action |
| | No action | No action taken. | 0 |
| | Warning | A warning (A8B1 Signal supervision 2) is generated. | 1 |
| | Fault | The drive trips on 80B1 Signal supervision 2 . | 2 |
| 32.17 | Supervision 2 signal | Selects the signal to be monitored by signal supervision function 2. For the available selections, see parameter 32.07 Supervision 1 signal . | Zero |
| 32.18 | Supervision 2 filter time | Defines a filter time constant for the signal monitored by signal supervision 2. | 0.000 s |
| | 0.000...30.000 s | Signal filter time. | 1000 = 1 s |
| 32.19 | Supervision 2 low | Defines the lower limit for signal supervision 2. | 0.00 |
| | -21474830.00 ...21474830.00 | Low limit. | - |
| 32.20 | Supervision 2 high | Defines the upper limit for signal supervision 2. | 0.00 |
| | -21474830.00 ...21474830.00 | Upper limit. | - |
| 32.25 | Supervision 3 function | Selects the mode of signal supervision function 3. Determines how the monitored signal (see parameter 32.27) is compared to its lower and upper limits (32.29 and 32.30 respectively). The action to be taken when the condition is fulfilled is selected by 32.26 . | Disabled |
| | Disabled | Signal supervision 3 not in use. | 0 |
| | Low | Action is taken whenever the signal falls below its lower limit. | 1 |
| | High | Action is taken whenever the signal rises above its upper limit. | 2 |
| | Abs low | Action is taken whenever the absolute value of the signal falls below its (absolute) lower limit. | 3 |
| | Abs high | Action is taken whenever the absolute value of the signal rises above its (absolute) upper limit. | 4 |
| | Both | Action is taken whenever the signal falls below its low limit or rises above its high limit. | 5 |
| | Abs both | Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit. | 6 |
| 32.26 | Supervision 3 action | Selects the action the drive takes when the value monitored by signal supervision 3 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 Supervision status . | No action |
| | No action | No action taken. | 0 |
| | Warning | A warning (A8B2 Signal supervision 3) is generated. | 1 |
| | Fault | The drive trips on 80B2 Signal supervision 3 . | 2 |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | |
|---------------------------------------|----------------------------------|---|----------------|------|-------------|---|----------|---|---|----------|---|---|--------|---|---|--------|---|---|---------|---|---|---------|---|--------|----------|--|--|
| 32.27 | <i>Supervision 3 signal</i> | Selects the signal to be monitored by signal supervision function 3. For the available selections, see parameter 32.07 Supervision 1 signal . | <i>Zero</i> | | | | | | | | | | | | | | | | | | | | | | | | |
| 32.28 | <i>Supervision 3 filter time</i> | Defines a filter time constant for the signal monitored by signal supervision 3. | 0.000 s | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0.000...30.000 s | Signal filter time. | 1000 = 1 s | | | | | | | | | | | | | | | | | | | | | | | | |
| 32.29 | <i>Supervision 3 low</i> | Defines the lower limit for signal supervision 3. | 0.00 | | | | | | | | | | | | | | | | | | | | | | | | |
| | -21474830.00 ...21474830.00 | Low limit. | - | | | | | | | | | | | | | | | | | | | | | | | | |
| 32.30 | <i>Supervision 3 high</i> | Defines the upper limit for signal supervision 3. | 0.00 | | | | | | | | | | | | | | | | | | | | | | | | |
| | -21474830.00 ...21474830.00 | Upper limit. | - | | | | | | | | | | | | | | | | | | | | | | | | |
| 33 Generic timer & counter | | Configuration of maintenance timers/counters. See also section Maintenance timers and counters (page 89). | | | | | | | | | | | | | | | | | | | | | | | | | |
| 33.01 | <i>Counter status</i> | Displays the maintenance timer/counter status word, indicating which maintenance timers/counters have exceeded their limits. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>On-time1</td> <td>1 = On-time timer 1 has reached its preset limit.</td> </tr> <tr> <td>1</td> <td>On-time2</td> <td>1 = On-time timer 2 has reached its preset limit.</td> </tr> <tr> <td>2</td> <td>Edge 1</td> <td>1 = Signal edge counter 1 has reached its preset limit.</td> </tr> <tr> <td>3</td> <td>Edge 2</td> <td>1 = Signal edge counter 2 has reached its preset limit.</td> </tr> <tr> <td>4</td> <td>Value 1</td> <td>1 = Value counter 1 has reached its preset limit.</td> </tr> <tr> <td>5</td> <td>Value 2</td> <td>1 = Value counter 2 has reached its preset limit.</td> </tr> <tr> <td>6...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | Bit | Name | Description | 0 | On-time1 | 1 = On-time timer 1 has reached its preset limit. | 1 | On-time2 | 1 = On-time timer 2 has reached its preset limit. | 2 | Edge 1 | 1 = Signal edge counter 1 has reached its preset limit. | 3 | Edge 2 | 1 = Signal edge counter 2 has reached its preset limit. | 4 | Value 1 | 1 = Value counter 1 has reached its preset limit. | 5 | Value 2 | 1 = Value counter 2 has reached its preset limit. | 6...15 | Reserved | | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | On-time1 | 1 = On-time timer 1 has reached its preset limit. | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | On-time2 | 1 = On-time timer 2 has reached its preset limit. | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Edge 1 | 1 = Signal edge counter 1 has reached its preset limit. | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Edge 2 | 1 = Signal edge counter 2 has reached its preset limit. | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Value 1 | 1 = Value counter 1 has reached its preset limit. | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Value 2 | 1 = Value counter 2 has reached its preset limit. | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000 0000b...0011 1111b | Maintenance time/counter status word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | |
| 33.10 | <i>On-time 1 actual</i> | Displays the actual present value of on-time timer 1. The timer runs whenever the signal selected by parameter 33.13 On-time 1 source is on. When the timer exceeds the limit set by 33.11 On-time 1 warn limit , bit 0 of 33.01 Counter status is set to 1. The warning specified by 33.14 On-time 1 warn message is also given if enabled by 33.12 On-time 1 function . The timer can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds. | - | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0...4294967295 s | Actual present value of on-time timer 1. | - | | | | | | | | | | | | | | | | | | | | | | | | |
| 33.11 | <i>On-time 1 warn limit</i> | Sets the warning limit for on-time timer 1. | 0 s | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0...4294967295 s | Warning limit for on-time timer 1. | - | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | |
|--|--|---|---------------------------|-----|----------|---|--|---|---|--------|----------|
| 33.12 | <i>On-time 1 function</i> | Configures on-time timer 1. | 0000b | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 0 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 0 of 33.01) switches to 1, and remains so until 33.10 is reset. The warning (if enabled) also stays active until 33.10 is reset.</td> </tr> <tr> <td>1</td> <td>Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.14) is given when the limit is reached</td> </tr> <tr> <td>2...15</td> <td>Reserved</td> </tr> </tbody> </table> | | | | Bit | Function | 0 | Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 0 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 0 of 33.01) switches to 1, and remains so until 33.10 is reset. The warning (if enabled) also stays active until 33.10 is reset. | 1 | Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.14) is given when the limit is reached | 2...15 | Reserved |
| Bit | Function | | | | | | | | | | |
| 0 | Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 0 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 0 of 33.01) switches to 1, and remains so until 33.10 is reset. The warning (if enabled) also stays active until 33.10 is reset. | | | | | | | | | | |
| 1 | Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.14) is given when the limit is reached | | | | | | | | | | |
| 2...15 | Reserved | | | | | | | | | | |
| | 0000b...0011b | On-time timer 1 configuration word. | 1 = 1 | | | | | | | | |
| 33.13 | <i>On-time 1 source</i> | Selects the signal to be monitored by on-time timer 1. | <i>False</i> | | | | | | | | |
| | False | Constant 0 (timer disabled). | 0 | | | | | | | | |
| | True | Constant 1. | 1 | | | | | | | | |
| | RO1 | Bit 0 of 10.21 RO status (page 131). | 2 | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - | | | | | | | | |
| 33.14 | <i>On-time 1 warn message</i> | Selects the optional warning message for on-time timer 1. | <i>On-time 1 exceeded</i> | | | | | | | | |
| | On-time 1 exceeded | A886 On-time 1 . The message text can be edited on the control panel by choosing Menu – Settings – Edit texts. | 0 | | | | | | | | |
| | Clean device | A88C Device clean . | 6 | | | | | | | | |
| | Maintain additional cooling fan | A890 Additional cooling . | 7 | | | | | | | | |
| | Maintain cabinet fan | A88E Cabinet fan . | 8 | | | | | | | | |
| | Maintain DC capacitors | A88D DC capacitor . | 9 | | | | | | | | |
| | Maintain motor bearing | A880 Motor bearing . | 10 | | | | | | | | |
| 33.20 | <i>On-time 2 actual</i> | Displays the actual present value of on-time timer 2. The timer runs whenever the signal selected by parameter 33.23 On-time 2 source is on. When the timer exceeds the limit set by 33.21 On-time 2 warn limit , bit 1 of 33.01 Counter status is set to 1. The warning specified by 33.24 On-time 2 warn message is also given if enabled by 33.22 On-time 2 function . The timer can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds. | - | | | | | | | | |
| | 0...4294967295 s | Actual present value of on-time timer 2. | - | | | | | | | | |
| 33.21 | <i>On-time 2 warn limit</i> | Sets the warning limit for on-time timer 2. | 0 s | | | | | | | | |
| | 0...4294967295 s | Warning limit for on-time timer 2. | - | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | |
|--------|--|--|---------------------------|----------|---|--|---|---|--------|----------|--|
| 33.22 | <i>On-time 2 function</i> | Configures on-time timer 2. | 0000b | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 1 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 1 of 33.01) switches to 1, and remains so until 33.20 is reset. The warning (if enabled) also stays active until 33.20 is reset.</td> </tr> <tr> <td>1</td> <td>Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.24) is given when the limit is reached</td> </tr> <tr> <td>2...15</td> <td>Reserved</td> </tr> </tbody> </table> | Bit | Function | 0 | Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 1 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 1 of 33.01) switches to 1, and remains so until 33.20 is reset. The warning (if enabled) also stays active until 33.20 is reset. | 1 | Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.24) is given when the limit is reached | 2...15 | Reserved | |
| Bit | Function | | | | | | | | | | |
| 0 | Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 1 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 1 of 33.01) switches to 1, and remains so until 33.20 is reset. The warning (if enabled) also stays active until 33.20 is reset. | | | | | | | | | | |
| 1 | Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.24) is given when the limit is reached | | | | | | | | | | |
| 2...15 | Reserved | | | | | | | | | | |
| | 0000b...0011b | On-time timer 2 configuration word. | 1 = 1 | | | | | | | | |
| 33.23 | <i>On-time 2 source</i> | Selects the signal to be monitored by on-time timer 2. | <i>False</i> | | | | | | | | |
| | False | Constant 0 (timer disabled). | 0 | | | | | | | | |
| | True | Constant 1. | 1 | | | | | | | | |
| | RO1 | Bit 0 of 10.21 RO status (page 131). | 2 | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - | | | | | | | | |
| 33.24 | <i>On-time 2 warn message</i> | Selects the optional warning message for on-time timer 2. | <i>On-time 2 exceeded</i> | | | | | | | | |
| | On-time 2 exceeded | A887 On-time 2 . The message text can be edited on the control panel by choosing Menu – Settings – Edit texts. | 1 | | | | | | | | |
| | Clean device | A88C Device clean . | 6 | | | | | | | | |
| | Maintain additional cool fan | A890 Additional cooling . | 7 | | | | | | | | |
| | Maintain cabinet fan | A88E Cabinet fan . | 8 | | | | | | | | |
| | Maintain DC capacitors | A88D DC capacitor . | 9 | | | | | | | | |
| | Maintain motor bearing | A880 Motor bearing . | 10 | | | | | | | | |
| 33.30 | <i>Edge counter 1 actual</i> | Actual present value of signal edge counter 1. The counter is incremented every time the signal selected by parameter 33.33 Edge counter 1 source switches on or off (or either, depending on the setting of 33.32 Edge counter 1 function). A divisor may be applied to the count (see 33.34 Edge counter 1 divider). When the counter exceeds the limit set by 33.31 Edge counter 1 warn limit , bit 2 of 33.01 Counter status is set to 1. The warning specified by 33.35 Edge counter 1 warn message is also given if enabled by 33.32 Edge counter 1 function . The counter can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds. | - | | | | | | | | |
| | 0...4294967295 | Actual present value of signal edge counter 1. | - | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | |
|--------|--|---|--------------------------------|-----|----------|---|---|---|---|---|---|---|--|--------|----------|
| 33.31 | <i>Edge counter 1 warn limit</i> | Sets the warning limit for signal edge counter 1. | 0 | | | | | | | | | | | | |
| | 0...4294967295 | Warning limit for signal edge counter 1. | - | | | | | | | | | | | | |
| 33.32 | <i>Edge counter 1 function</i> | Configures signal edge counter 1. | 0000b | | | | | | | | | | | | |
| | <table border="1"> <thead> <tr> <th>Bit</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 2 of 33.01) switches to 1 and remains so until the counter is again incremented. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 2 of 33.01) switches to 1, and remains so until 33.30 is reset. The warning (if enabled) also stays active until 33.30 is reset.</td> </tr> <tr> <td>1</td> <td>Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.35) is given when the limit is reached</td> </tr> <tr> <td>2</td> <td>Count rising edges 0 = Disable: Rising edges are not counted 1 = Enable: Rising edges are counted</td> </tr> <tr> <td>3</td> <td>Count falling edges 0 = Disable: Falling edges are not counted 1 = Enable: Falling edges are counted</td> </tr> <tr> <td>4...15</td> <td>Reserved</td> </tr> </tbody> </table> | | | Bit | Function | 0 | Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 2 of 33.01) switches to 1 and remains so until the counter is again incremented. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 2 of 33.01) switches to 1, and remains so until 33.30 is reset. The warning (if enabled) also stays active until 33.30 is reset. | 1 | Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.35) is given when the limit is reached | 2 | Count rising edges 0 = Disable: Rising edges are not counted 1 = Enable: Rising edges are counted | 3 | Count falling edges 0 = Disable: Falling edges are not counted 1 = Enable: Falling edges are counted | 4...15 | Reserved |
| Bit | Function | | | | | | | | | | | | | | |
| 0 | Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 2 of 33.01) switches to 1 and remains so until the counter is again incremented. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 2 of 33.01) switches to 1, and remains so until 33.30 is reset. The warning (if enabled) also stays active until 33.30 is reset. | | | | | | | | | | | | | | |
| 1 | Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.35) is given when the limit is reached | | | | | | | | | | | | | | |
| 2 | Count rising edges 0 = Disable: Rising edges are not counted 1 = Enable: Rising edges are counted | | | | | | | | | | | | | | |
| 3 | Count falling edges 0 = Disable: Falling edges are not counted 1 = Enable: Falling edges are counted | | | | | | | | | | | | | | |
| 4...15 | Reserved | | | | | | | | | | | | | | |
| | 0000b...1111b | Edge counter 1 configuration word. | 1 = 1 | | | | | | | | | | | | |
| 33.33 | <i>Edge counter 1 source</i> | Selects the signal to be monitored by signal edge counter 1. | <i>False</i> | | | | | | | | | | | | |
| | False | Constant 0. | 0 | | | | | | | | | | | | |
| | True | Constant 1. | 1 | | | | | | | | | | | | |
| | RO1 | Bit 0 of 10.21 RO status (page 131). | 2 | | | | | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - | | | | | | | | | | | | |
| 33.34 | <i>Edge counter 1 divider</i> | Defines a divisor for signal edge counter 1. Determines how many signal edges increment the counter by 1. | 1 | | | | | | | | | | | | |
| | 1...4294967295 | Divisor for signal edge counter 1. | - | | | | | | | | | | | | |
| 33.35 | <i>Edge counter 1 warn message</i> | Selects the optional warning message for signal edge counter 1. | <i>Edge counter 1 exceeded</i> | | | | | | | | | | | | |
| | Edge counter 1 exceeded | A888 Edge counter 1 . The message text can be edited on the control panel by choosing Menu – Settings – Edit texts. | 2 | | | | | | | | | | | | |
| | Counted main contactor | A884 Main contactor . | 11 | | | | | | | | | | | | |
| | Counted output relay | A881 Output relay . | 12 | | | | | | | | | | | | |
| | Counted motor starts | A882 Motor starts . | 13 | | | | | | | | | | | | |
| | Counted power ups | A883 Power ups . | 14 | | | | | | | | | | | | |
| | Counted DC charges | A885 DC charge . | 15 | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | |
|--|---|--|----------------|-----|----------|---|---|---|---|---|---|---|--|--------|----------|
| 33.40 | <i>Edge counter 2 actual</i> | Displays the actual present value of signal edge counter 2. The counter is incremented every time the signal selected by parameter 33.43 Edge counter 2 source switches on or off (or either, depending on the setting of 33.42 Edge counter 2 function). A divisor may be applied to the count (see 33.44 Edge counter 2 divider). When the counter exceeds the limit set by 33.41 Edge counter 2 warn limit , bit 3 of 33.01 Counter status is set to 1. The warning specified by 33.45 Edge counter 2 warn message is also given if enabled by 33.42 Edge counter 2 function . The counter can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds. | - | | | | | | | | | | | | |
| | 0...4294967295 | Actual present value of signal edge counter 2. | - | | | | | | | | | | | | |
| 33.41 | <i>Edge counter 2 warn limit</i> | Sets the warning limit for signal edge counter 2. | 0 | | | | | | | | | | | | |
| | 0...4294967295 | Warning limit for signal edge counter 2. | - | | | | | | | | | | | | |
| 33.42 | <i>Edge counter 2 function</i> | Configures signal edge counter 2. | 0000b | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 3 of 33.01) remains 1 until the counter is again incremented. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: After the limit is reached, the counter status (bit 3 of 33.01) remains 1 until 33.40 is reset. The warning (if enabled) also stays active until 33.40 is reset.</td> </tr> <tr> <td>1</td> <td>Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.45) is given when the limit is reached</td> </tr> <tr> <td>2</td> <td>Count rising edges 0 = Disable: Rising edges are not counted 1 = Enable: Rising edges are counted</td> </tr> <tr> <td>3</td> <td>Count falling edges 0 = Disable: Falling edges are not counted 1 = Enable: Falling edges are counted</td> </tr> <tr> <td>4...15</td> <td>Reserved</td> </tr> </tbody> </table> | | | | Bit | Function | 0 | Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 3 of 33.01) remains 1 until the counter is again incremented. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: After the limit is reached, the counter status (bit 3 of 33.01) remains 1 until 33.40 is reset. The warning (if enabled) also stays active until 33.40 is reset. | 1 | Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.45) is given when the limit is reached | 2 | Count rising edges 0 = Disable: Rising edges are not counted 1 = Enable: Rising edges are counted | 3 | Count falling edges 0 = Disable: Falling edges are not counted 1 = Enable: Falling edges are counted | 4...15 | Reserved |
| Bit | Function | | | | | | | | | | | | | | |
| 0 | Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 3 of 33.01) remains 1 until the counter is again incremented. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: After the limit is reached, the counter status (bit 3 of 33.01) remains 1 until 33.40 is reset. The warning (if enabled) also stays active until 33.40 is reset. | | | | | | | | | | | | | | |
| 1 | Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.45) is given when the limit is reached | | | | | | | | | | | | | | |
| 2 | Count rising edges 0 = Disable: Rising edges are not counted 1 = Enable: Rising edges are counted | | | | | | | | | | | | | | |
| 3 | Count falling edges 0 = Disable: Falling edges are not counted 1 = Enable: Falling edges are counted | | | | | | | | | | | | | | |
| 4...15 | Reserved | | | | | | | | | | | | | | |
| | 0000b...1111b | Edge counter 2 configuration word. | 1 = 1 | | | | | | | | | | | | |
| 33.43 | <i>Edge counter 2 source</i> | Selects the signal to be monitored by signal edge counter 2. | <i>False</i> | | | | | | | | | | | | |
| | False | 0. | 0 | | | | | | | | | | | | |
| | True | 1. | 1 | | | | | | | | | | | | |
| | RO1 | Bit 0 of 10.21 RO status (page 131). | 2 | | | | | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - | | | | | | | | | | | | |
| 33.44 | <i>Edge counter 2 divider</i> | Defines a divisor for signal edge counter 2. Determines how many signal edges increment the counter by 1. | 1 | | | | | | | | | | | | |
| | 1...4294967295 | Divisor for signal edge counter 2. | - | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------------------|---|--------------------------------|
| 33.45 | <i>Edge counter 2 warn message</i> | Selects the optional warning message for signal edge counter 2. | <i>Edge counter 2 exceeded</i> |
| | Edge counter 2 exceeded | <i>A889 Edge counter 2.</i> The message text can be edited on the control panel by choosing Menu – Settings – Edit texts. | 3 |
| | Counted main contactor | <i>A884 Main contactor.</i> | 11 |
| | Counted output relay | <i>A881 Output relay.</i> | 12 |
| | Counted motor starts | <i>A882 Motor starts.</i> | 13 |
| | Counted power ups | <i>A883 Power ups.</i> | 14 |
| | Counted DC charges | <i>A885 DC charge.</i> | 15 |
| 33.50 | <i>Value counter 1 actual</i> | Displays the actual present value of value counter 1. The value of the source selected by parameter <i>33.53 Value counter 1 source</i> is read at one-second intervals and added to the counter. A divisor can be applied to the count (see <i>33.54 Value counter 1 divider</i>). When the counter exceeds the limit set by <i>33.51 Value counter 1 warn limit</i> , bit 4 of <i>33.01 Counter status</i> is set to 1. The warning specified by <i>33.55 Value counter 1 warn message</i> is also given if enabled by <i>33.52 Value counter 1 function</i> . The counter can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds. | - |
| | -2147483008 ...2147483008 | Actual present value of value counter 1. | - |
| 33.51 | <i>Value counter 1 warn limit</i> | Sets the limit for value counter 1. With a positive limit, bit 4 of <i>33.01 Counter status</i> is set to 1 (and a warning optionally generated) when the counter is equal or greater than the limit. With a negative limit, bit 4 of <i>33.01 Counter status</i> is set to 1 (and a warning optionally generated) when the counter is equal or smaller than the limit. 0 = Counter disabled. | 0 |
| | -2147483008 ...2147483008 | Limit for value counter 1. | - |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | |
|--|--|---|---------------------------------|-----|----------|---|--|---|---|--------|----------|
| 33.52 | <i>Value counter 1 function</i> | Configures value counter 1. | 0000b | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 4 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 4 of 33.01) switches to 1, and remains so until 33.50 is reset. The warning (if enabled) also stays active until 33.50 is reset.</td> </tr> <tr> <td>1</td> <td>Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.55) is given when the limit is reached</td> </tr> <tr> <td>2...15</td> <td>Reserved</td> </tr> </tbody> </table> | | | | Bit | Function | 0 | Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 4 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 4 of 33.01) switches to 1, and remains so until 33.50 is reset. The warning (if enabled) also stays active until 33.50 is reset. | 1 | Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.55) is given when the limit is reached | 2...15 | Reserved |
| Bit | Function | | | | | | | | | | |
| 0 | Counter mode 0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 4 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds. 1 = Saturate: When the limit is reached, the counter status (bit 4 of 33.01) switches to 1, and remains so until 33.50 is reset. The warning (if enabled) also stays active until 33.50 is reset. | | | | | | | | | | |
| 1 | Warning enable 0 = Disable: No warning is given when the limit is reached 1 = Enable: A warning (see 33.55) is given when the limit is reached | | | | | | | | | | |
| 2...15 | Reserved | | | | | | | | | | |
| | 0000b...0011b | Value counter 1 configuration word. | 1 = 1 | | | | | | | | |
| 33.53 | <i>Value counter 1 source</i> | Selects the signal to be monitored by value counter 1. | <i>Not selected</i> | | | | | | | | |
| | Not selected | None (counter disabled). | 0 | | | | | | | | |
| | Motor speed | 01.01 Motor speed used (see page 105). | 1 | | | | | | | | |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - | | | | | | | | |
| 33.54 | <i>Value counter 1 divider</i> | Defines a divisor for value counter 1. The value of the monitored signal is divided by this value before integration. | 1.000 | | | | | | | | |
| | 0.001...2147483.000 | Divisor for value counter 1. | - | | | | | | | | |
| 33.55 | <i>Value counter 1 warn message</i> | Selects the optional warning message for value counter 1. | <i>Value counter 1 exceeded</i> | | | | | | | | |
| | Value counter 1 exceeded | A88A Value counter 1 . The message text can be edited on the control panel by choosing Menu – Settings – Edit texts. | 4 | | | | | | | | |
| | Maintain motor bearing | A880 Motor bearing . | 10 | | | | | | | | |
| 33.60 | <i>Value counter 2 actual</i> | Displays the actual present value of value counter 2. The value of the source selected by parameter 33.63 Value counter 2 source is read at one-second intervals and added to the counter. A divisor can be applied to the count (see 33.64 Value counter 2 divider). When the counter exceeds the limit set by 33.61 Value counter 2 warn limit , bit 5 of 33.01 Counter status is set to 1. The warning specified by 33.65 Value counter 2 warn message is also given if enabled by 33.62 Value counter 2 function . The counter can be reset from the Drive composer PC tool, or from the control panel by keeping Reset depressed for over 3 seconds. | - | | | | | | | | |
| | -2147483008 ...2147483008 | Actual present value of value counter 2. | - | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | |
|--|---|---|---------------------------------|-----|----------|---|---|---|---|--------|----------|
| 33.61 | <i>Value counter 2 warn limit</i> | <p>Sets the limit for value counter 2.</p> <p>With a positive limit, bit 5 of 33.01 Counter status is set to 1 (and a warning optionally generated) when the counter is equal or greater than the limit.</p> <p>With a negative limit, bit 5 of 33.01 Counter status is set to 1 (and a warning optionally generated) when the counter is equal or smaller than the limit.</p> <p>0 = Counter disabled.</p> | 0 | | | | | | | | |
| | -2147483008 ...2147483008 | Limit for value counter 2. | - | | | | | | | | |
| 33.62 | <i>Value counter 2 function</i> | Configures value counter 2. | 0000b | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>0</td> <td> <p>Counter mode</p> <p>0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 5 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds.</p> <p>1 = Saturate: When the limit is reached, the counter status (bit 5 of 33.01) switches to 1, and remains so until 33.60 is reset. The warning (if enabled) also stays active until 33.60 is reset.</p> </td> </tr> <tr> <td>1</td> <td> <p>Warning enable</p> <p>0 = Disable: No warning is given when the limit is reached</p> <p>1 = Enable: A warning (see 33.65) is given when the limit is reached</p> </td> </tr> <tr> <td>2...15</td> <td>Reserved</td> </tr> </tbody> </table> | | | | Bit | Function | 0 | <p>Counter mode</p> <p>0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 5 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds.</p> <p>1 = Saturate: When the limit is reached, the counter status (bit 5 of 33.01) switches to 1, and remains so until 33.60 is reset. The warning (if enabled) also stays active until 33.60 is reset.</p> | 1 | <p>Warning enable</p> <p>0 = Disable: No warning is given when the limit is reached</p> <p>1 = Enable: A warning (see 33.65) is given when the limit is reached</p> | 2...15 | Reserved |
| Bit | Function | | | | | | | | | | |
| 0 | <p>Counter mode</p> <p>0 = Loop: When the limit is reached, the counter is reset. The counter status (bit 5 of 33.01) switches to 1 for one second. The warning (if enabled) stays active for at least 10 seconds.</p> <p>1 = Saturate: When the limit is reached, the counter status (bit 5 of 33.01) switches to 1, and remains so until 33.60 is reset. The warning (if enabled) also stays active until 33.60 is reset.</p> | | | | | | | | | | |
| 1 | <p>Warning enable</p> <p>0 = Disable: No warning is given when the limit is reached</p> <p>1 = Enable: A warning (see 33.65) is given when the limit is reached</p> | | | | | | | | | | |
| 2...15 | Reserved | | | | | | | | | | |
| | 0000b...0011b | Value counter 2 configuration word. | 1 = 1 | | | | | | | | |
| 33.63 | <i>Value counter 2 source</i> | Selects the signal to be monitored by value counter 2. | <i>Not selected</i> | | | | | | | | |
| | Not selected | None (counter disabled). | 0 | | | | | | | | |
| | Motor speed | 01.01 Motor speed used (see page 105). | 1 | | | | | | | | |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - | | | | | | | | |
| 33.64 | <i>Value counter 2 divider</i> | Defines a divisor for value counter 2. The value of the monitored signal is divided by this value before integration. | 1.000 | | | | | | | | |
| | 0.001...2147483.000 | Divisor for value counter 2. | - | | | | | | | | |
| 33.65 | <i>Value counter 2 warn message</i> | Selects the optional warning message for value counter 2. | <i>Value counter 2 exceeded</i> | | | | | | | | |
| | Value counter 2 exceeded | A88B Value counter 2 . The message text can be edited on the control panel by choosing Menu – Settings – Edit texts. | 5 | | | | | | | | |
| | Maintain motor bearing | A880 Motor bearing . | 10 | | | | | | | | |



| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|---|----------------|-----|------|-------------|---|------------------------|--|---|------------------------|--|---|--------------------------|--|---|------------------------|--|---|------------------------|--|---|--------------------------|--|---|------------------------|--|---|------------------------|--|---|--------------------------|--|--------|----------|--|
| 35 Motor thermal protection | | Motor thermal protection settings such as temperature measurement configuration, load curve definition and motor fan control configuration. See also section Motor thermal protection (page 83). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 35.01 | <i>Motor estimated temperature</i> | Displays the motor temperature as estimated by the internal motor thermal protection model (see parameters 35.50...35.55). The unit is selected by parameter 96.16 Unit selection This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | -60...1000 °C or °F | Estimated motor temperature. | 1 = 1° | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 35.02 | <i>Measured temperature 1</i> | Displays the temperature received through the source defined by parameter 35.11 Temperature 1 source . The unit is selected by parameter 96.16 Unit selection . Note: With a PTC sensor, the unit is ohms. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | -60...1000 °C, -76...9032 °F, 0 ohm or [35.12] ohm | Measured temperature 1. | 1 = 1 unit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 35.03 | <i>Measured temperature 2</i> | Displays the temperature received through the source defined by parameter 35.21 Temperature 2 source . The unit is selected by parameter 96.16 Unit selection . Note: With a PTC sensor, the unit is ohms. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | -60...1000 °C, -76...9032 °F, 0 ohm or [35.22] ohm | Measured temperature 2. | 1 = 1 unit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 35.04 | <i>FEX-01/FPTC-01 status word</i> | Displays the status of optional FEX-01/FPTC-01 modules. The word can be used as the source of eg. external events. The modules are activated by parameter 35.30 FEX-01/FPTC-01 configuration word . This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Module found in slot 1</td> <td>1 = Yes: An FEX-01/FPTC-01 module has been detected in slot 1.</td> </tr> <tr> <td>1</td> <td>Fault active in slot 1</td> <td>1 = Yes: The module in slot 1 has an active fault.</td> </tr> <tr> <td>2</td> <td>Warning active in slot 1</td> <td>1 = Yes: The module in slot 1 has an active warning.</td> </tr> <tr> <td>3</td> <td>Module found in slot 2</td> <td>1 = Yes: An FEX-01/FPTC-01 module has been detected in slot 2.</td> </tr> <tr> <td>4</td> <td>Fault active in slot 2</td> <td>1 = Yes: The module in slot 2 has an active fault.</td> </tr> <tr> <td>5</td> <td>Warning active in slot 2</td> <td>1 = Yes: The module in slot 2 has an active warning.</td> </tr> <tr> <td>6</td> <td>Module found in slot 3</td> <td>1 = Yes: An FEX-01/FPTC-01 module has been detected in slot 3.</td> </tr> <tr> <td>7</td> <td>Fault active in slot 3</td> <td>1 = Yes: The module in slot 3 has an active fault.</td> </tr> <tr> <td>8</td> <td>Warning active in slot 3</td> <td>1 = Yes: The module in slot 3 has an active warning.</td> </tr> <tr> <td>9...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | | | | Bit | Name | Description | 0 | Module found in slot 1 | 1 = Yes: An FEX-01/FPTC-01 module has been detected in slot 1. | 1 | Fault active in slot 1 | 1 = Yes: The module in slot 1 has an active fault. | 2 | Warning active in slot 1 | 1 = Yes: The module in slot 1 has an active warning. | 3 | Module found in slot 2 | 1 = Yes: An FEX-01/FPTC-01 module has been detected in slot 2. | 4 | Fault active in slot 2 | 1 = Yes: The module in slot 2 has an active fault. | 5 | Warning active in slot 2 | 1 = Yes: The module in slot 2 has an active warning. | 6 | Module found in slot 3 | 1 = Yes: An FEX-01/FPTC-01 module has been detected in slot 3. | 7 | Fault active in slot 3 | 1 = Yes: The module in slot 3 has an active fault. | 8 | Warning active in slot 3 | 1 = Yes: The module in slot 3 has an active warning. | 9...15 | Reserved | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Module found in slot 1 | 1 = Yes: An FEX-01/FPTC-01 module has been detected in slot 1. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Fault active in slot 1 | 1 = Yes: The module in slot 1 has an active fault. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Warning active in slot 1 | 1 = Yes: The module in slot 1 has an active warning. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Module found in slot 2 | 1 = Yes: An FEX-01/FPTC-01 module has been detected in slot 2. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Fault active in slot 2 | 1 = Yes: The module in slot 2 has an active fault. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Warning active in slot 2 | 1 = Yes: The module in slot 2 has an active warning. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Module found in slot 3 | 1 = Yes: An FEX-01/FPTC-01 module has been detected in slot 3. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | Fault active in slot 3 | 1 = Yes: The module in slot 3 has an active fault. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Warning active in slot 3 | 1 = Yes: The module in slot 3 has an active warning. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0000h...FFFFh | | FEX-01/FPTC-01 status word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-----------------------------|--|-----------------|
| 35.11 | <i>Temperature 1 source</i> | Selects the source from which measured temperature 1 is read. Usually this source is from a sensor connected to the motor controlled by the drive, but it could be used to measure and monitor a temperature from other parts of the process as long as a suitable sensor is used as per the selection list. | <i>Disabled</i> |
| | Disabled | None. Temperature monitoring function 1 is disabled. | 0 |
| | Estimated temperature | Estimated motor temperature (see parameter <i>35.01 Motor estimated temperature</i>). The temperature is estimated from an internal drive calculation. It is important to set up the ambient temperature of the motor in <i>35.50 Motor ambient temperature</i> . | 1 |
| | KTY84 analog I/O | KTY84 sensor connected to the analog input selected by parameter <i>35.14 Temperature 1 AI source</i> and an analog output. The analog input can be from the standard I/O or from an extension module. The following settings are required: <ul style="list-style-type: none"> Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the unit selection parameter of the input to volt. Set the source selection parameter of the analog output to "<i>Force KTY84 excitation</i>". Select the analog input in parameter <i>35.14</i>. In case the input is located on an I/O extension module, use the selection <i>Other</i> to point at the actual input value parameter (for example, <i>14.26 AI1 actual value</i>). The analog output feeds a constant current through the sensor. As the resistance of the sensor changes along with its temperature, the voltage over the sensor changes. The voltage is read by the analog input and converted into degrees. | 2 |
| | KTY84 encoder module 1 | KTY84 sensor connected to encoder interface 1. See also parameters <i>91.21 Module 1 temp sensor type</i> and <i>91.22 Module 1 temp filter time</i> . | 3 |
| | KTY84 encoder module 2 | KTY84 sensor connected to encoder interface 2. See also parameters <i>91.24 Module 2 temp sensor type</i> and <i>91.25 Module 2 temp filter time</i> . | 4 |
| | 1 × Pt100 analog I/O | Pt100 sensor connected to a standard analog input selected by parameter <i>35.14 Temperature 1 AI source</i> and an analog output. The input and output can be on the drive control unit or on an extension module. The required settings are the same as with selection <i>KTY84 analog I/O</i> , except that the source selection parameter of the analog output must be set to <i>Force Pt100 excitation</i> . | 5 |
| | 2 × Pt100 analog I/O | As selection <i>1 × Pt100 analog I/O</i> , but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly. | 6 |
| | 3 × Pt100 analog I/O | As selection <i>1 × Pt100 analog I/O</i> , but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly. | 7 |



| No. | Name/Value | Description | Def/ FbEq16 |
|-----|---|---|---------------------|
| | PTC DI6 | PTC sensor connected to digital input DI6 (see the connection diagram on page 84). Note: Either 0 ohm (normal temperature) or the value of parameter 35.02 Measured temperature 1 (excessive temperature) is shown. | 8 |
| | PTC analog I/O | PTC sensor connected to a standard analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The input and output can be on the drive control unit or on an extension module. The required settings are the same as with selection KTY84 analog I/O , except that the source selection parameter of the analog output must be set to Force PTC excitation . Note: Either 0 ohm (normal temperature) or 4000 ohm (excessive temperature) will be shown by 35.02 Measured temperature 1 . | 20 |
| | PTC encoder module 1 | PTC sensor connected to encoder interface 1. See also parameters 91.21 Module 1 temp sensor type and 91.22 Module 1 temp filter time . | 9 |
| | PTC encoder module 2 | PTC sensor connected to encoder interface 2. See also parameters 91.24 Module 2 temp sensor type and 91.25 Module 2 temp filter time . | 10 |
| | Direct temperature | The temperature is taken from the source selected by parameter 35.14 Temperature 1 AI source . The value of the source is assumed to be in the unit of temperature specified by 96.16 Unit selection . | 11 |
| | 1 × Pt1000 analog I/O | Pt1000 sensor connected to a standard analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The input and output can be on the drive control unit or on an extension module. The required settings are the same as with selection KTY84 analog I/O , except that the source selection parameter of the analog output must be set to Force Pt1000 excitation . | 13 |
| | 2 × Pt1000 analog I/O | As selection 1 × Pt1000 analog I/O , but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly. | 14 |
| | 3 × Pt1000 analog I/O | As selection 1 × Pt1000 analog I/O , but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly. | 15 |
| | 35.12 Temperature 1 fault limit | Defines the fault limit for temperature monitoring function 1. When measured temperature 1 exceeds the limit, the drive trips on fault 4981 External temperature . The unit is selected by parameter 96.16 Unit selection . Note: With a PTC sensor, the unit is ohms. | 130 °C or 266 °F |
| | -60...5000 °C or ohm, or -76...1832 °F | Fault limit for temperature monitoring function 1. | 1 = 1 unit |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---|--|---------------------|
| 35.13 | <i>Temperature 1 warning limit</i> | Defines the warning limit for temperature monitoring function 1. When measured temperature 1 exceeds this limit, a warning (<i>A491 External temperature</i>) is generated. The unit is selected by parameter <i>96.16 Unit selection</i> . Note: With a PTC sensor, the unit is ohms. | 110 °C or 230 °F |
| | -60...5000 °C or ohm, or -76...9032 °F | Warning limit for temperature monitoring function 1. | 1 = 1 unit |
| 35.14 | <i>Temperature 1 AI source</i> | Specifies the analog input when the setting of <i>35.11 Temperature 1 source</i> requires measurement through an analog input. Note: If the input is located on an I/O extension module, use the selection <i>Other</i> to point to the AI actual value in group 14, 15 or 16, eg. <i>14.26 AI1 actual value</i> . | <i>Not selected</i> |
| | Not selected | None. | 0 |
| | AI1 actual value | Analog input AI1 on the control unit. | 1 |
| | AI2 actual value | Analog input AI2 on the control unit. | 2 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page <i>101</i>). | - |
| 35.21 | <i>Temperature 2 source</i> | Selects the source from which measured temperature 2 is read. Usually this source is from a sensor connected to the motor controlled by the drive, but it could be used to measure and monitor a temperature from other parts of the process as long as a suitable sensor is used as per the selection list. | <i>Disabled</i> |
| | Disabled | None. Temperature monitoring function 2 is disabled. | 0 |
| | Estimated temperature | Estimated motor temperature (see parameter <i>35.01 Motor estimated temperature</i>). The temperature is estimated from an internal drive calculation. It is important to set up the ambient temperature of the motor in <i>35.50 Motor ambient temperature</i> . | 1 |
| | KTY84 analog I/O | KTY84 sensor connected to the analog input selected by parameter <i>35.24 Temperature 2 AI source</i> and an analog output. The input and output can be on the drive control unit or on an extension module. The following settings are required: <ul style="list-style-type: none"> • Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. • Set the unit selection parameter of the input to volt. • Set the source selection parameter of the analog output to "<i>Force KTY84 excitation</i>". • Select the analog input in parameter <i>35.24</i>. In case the input is located on an I/O extension module, use the selection <i>Other</i> to point at the actual input value parameter (for example, <i>14.26 AI1 actual value</i>). The analog output feeds a constant current through the sensor. As the resistance of the sensor changes along with its temperature, the voltage over the sensor changes. The voltage is read by the analog input and converted into degrees. | 2 |



| No. | Name/Value | Description | Def/ FbEq16 |
|-----|------------------------|---|----------------|
| | KTY84 encoder module 1 | KTY84 sensor connected to encoder interface 1. See also parameters 91.21 Module 1 temp sensor type and 91.22 Module 1 temp filter time . | 3 |
| | KTY84 encoder module 2 | KTY84 sensor connected to encoder interface 2. See also parameters 91.24 Module 2 temp sensor type and 91.25 Module 2 temp filter time . | 4 |
| | 1 × Pt100 analog I/O | Pt100 sensor connected to a standard analog input selected by parameter 35.24 Temperature 2 AI source and an analog output. The input and output can be on the drive control unit or on an extension module. The required settings are the same as with selection KTY84 analog I/O , except that the source selection parameter of the analog output must be set to Force Pt100 excitation . | 5 |
| | 2 × Pt100 analog I/O | As selection 1 × Pt100 analog I/O , but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly. | 6 |
| | 3 × Pt100 analog I/O | As selection 1 × Pt100 analog I/O , but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly. | 7 |
| | PTC DI6 | PTC sensor connected to digital input DI6 (see the connection diagram on page 84). Note: Either 0 ohm (normal temperature) or the value of parameter 35.03 Measured temperature 2 (excessive temperature) is shown. | 8 |
| | PTC analog I/O | PTC sensor connected to a standard analog input selected by parameter 35.24 Temperature 2 AI source and an analog output. The input and output can be on the drive control unit or on an extension module. The required settings are the same as with selection KTY84 analog I/O , except that the source selection parameter of the analog output must be set to Force PTC excitation . Note: Either 0 ohm (normal temperature) or 4000 ohm (excessive temperature) will be shown by 35.03 Measured temperature 2 . | 20 |
| | PTC encoder module 1 | PTC sensor connected to encoder interface 1. See also parameters 91.21 Module 1 temp sensor type and 91.22 Module 1 temp filter time . | 9 |
| | PTC encoder module 2 | PTC sensor connected to encoder interface 2. See also parameters 91.24 Module 2 temp sensor type and 91.25 Module 2 temp filter time . | 10 |
| | Direct temperature | The temperature is taken from the source selected by parameter 35.24 Temperature 2 AI source . The value of the source is assumed to be in the unit of temperature specified by 96.16 Unit selection . | 11 |
| | 1 × Pt1000 analog I/O | Pt1000 sensor connected to a standard analog input selected by parameter 35.24 Temperature 2 AI source and an analog output. The input and output can be on the drive control unit or on an extension module. The required settings are the same as with selection KTY84 analog I/O , except that the source selection parameter of the analog output must be set to Force Pt1000 excitation . | 13 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------------|--|----------------|
| 35.50 | <i>Motor ambient temperature</i> | <p>Defines the ambient temperature of the motor for the motor thermal protection model. The unit is selected by parameter 96.16 Unit selection.</p> <p>The motor thermal protection model estimates the motor temperature on the basis of parameters 35.50...35.55. The motor temperature increases if it operates in the region above the load curve, and decreases if it operates in the region below the load curve.</p> <p> WARNING! The model cannot protect the motor if the motor does not cool properly because of dust, dirt, etc.</p> | 20 °C or 68 °F |
| | -60...100 °C or -75...212 °F | Ambient temperature. | 1 = 1° |
| 35.51 | <i>Motor load curve</i> | <p>Defines the motor load curve together with parameters 35.52 Zero speed load and 35.53 Break point. The load curve is used by the motor thermal protection model to estimate the motor temperature.</p> <p>When the parameter is set to 100%, the maximum load is taken as the value of parameter 99.06 Motor nominal current (higher loads heat up the motor). The load curve level should be adjusted if the ambient temperature differs from the nominal value set in 35.50 Motor ambient temperature.</p>  <p>I/I_N (%)</p> <p>I = Motor current I_N = Nominal motor</p> <p>150</p> <p>100</p> <p>50</p> <p>35.52</p> <p>35.53</p> <p>35.51</p> <p>Drive output frequency</p> | 100% |
| | 50...150% | Maximum load for the motor load curve. | 1 = 1% |
| 35.52 | <i>Zero speed load</i> | <p>Defines the motor load curve together with parameters 35.51 Motor load curve and 35.53 Break point. Defines the maximum motor load at zero speed of the load curve. A higher value can be used if the motor has an external motor fan to boost the cooling. See the motor manufacturer's recommendations.</p> <p>See parameter 35.51 Motor load curve.</p> | 100% |
| | 50...150% | Zero speed load for the motor load curve. | 1 = 1% |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------------------|---|--------------------------------|
| 35.53 | <i>Break point</i> | Defines the motor load curve together with parameters 35.51 Motor load curve and 35.52 Zero speed load . Defines the break point frequency of the load curve i.e. the point at which the motor load curve begins to decrease from the value of parameter 35.51 Motor load curve towards the value of parameter 35.52 Zero speed load . See parameter 35.51 Motor load curve . | 45.00 Hz |
| | 1.00...500.00 Hz | Break point for the motor load curve. | See par. 46.02 |
| 35.54 | <i>Motor nominal temperature rise</i> | Defines the temperature rise of the motor above ambient when the motor is loaded with nominal current. See the motor manufacturer's recommendations. The unit is selected by parameter 96.16 Unit selection . | 80 °C or 176 °F |
| | 0...300 °C or 32...572 °F | Temperature rise. | 1 = 1° |
| 35.55 | <i>Motor thermal time constant</i> | Defines the thermal time constant for use with the motor thermal protection model, defined as the time to reach 63% of the nominal motor temperature. See the motor manufacturer's recommendations. | 256 s |
| | 100...10000 s | Motor thermal time constant. | 1 = 1 s |



270 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------|---|----------------|
| 35.60 | <i>Cable temperature</i> | Shows the calculated temperature of the motor cable. See section <i>Thermal protection of motor cable</i> (page 86). 102% = overtemperature warning (<i>A480 Motor cable overload</i>) 106% = overtemperature fault (<i>4000 Motor cable overload</i>) This parameter is read-only. | 0.0% |
| | 0.0...200.0% | Calculated temperature of motor cable. | 1 = 1% |
| 35.61 | <i>Cable nominal current</i> | Specifies the continuous current of the motor cable for the thermal protection function in the control program.  WARNING! The value entered in this parameter must be limited according to all factors affecting the loadability of the cable, such as ambient temperature, cabling arrangement, and shrouding. Refer to the technical data from the cable manufacturer. | 10000.00 A |
| | 0.00...10000.00 A | Continuous current-carrying capacity of motor cable. | 1 = 1 A |
| 35.62 | <i>Cable thermal rise time</i> | Specifies the thermal time of the motor cable for the thermal protection function in the control program. This value is defined as the time to reach 63% of the nominal cable temperature when the cable is loaded with nominal current (parameter <i>35.61 Cable nominal current</i>). 0 s = Thermal protection of motor cable disabled Refer to the technical data from the cable manufacturer. | 1 s |
| | | <p>Cable current</p>  <p>Temperature rise</p> <p>Cable thermal time</p> | |
| | 0 s | Thermal protection of motor cable disabled. | 1 = 1 s |
| | 0...50000 s | Motor cable thermal time constant. | 1 = 1 s |

| No. | Name/Value | Description | Def/ FbEq16 |
|------------------------|---|--|---|
| 35.100 | DOL starter control source | Parameters 35.100 ... 35.106 configure a monitored start/stop control logic for external equipment such as a contactor-controlled motor cooling fan. This parameter selects the signal that starts and stops the fan. 0 = Stop 1 = Start The output controlling the fan contactor is to be connected to parameter 35.105 , bit 1. On and off delays can be set for the fan by 35.101 and 35.102 respectively. A feedback signal from the fan can be connected to an input selected by 35.103 ; the loss of the feedback will optionally trigger a warning or fault (see 35.104 and 35.106). | Off , 06.16 b6 (95.20 b6) |
| | Off | 0 (function disabled). | 0 |
| | On | 1. | 1 |
| | Running | Bit 6 of 06.16 Drive status word 1 (see page 117). | 2 |
| | Other [bit] | Source selection (see Terms and abbreviations on page 101). | - |
| 35.101 | DOL starter on delay | Defines a start delay for the motor fan. The delay timer starts when the control source selected by parameter 35.100 switches on. After the delay, bit 1 of 35.105 switches on. | 0 s |
| | 0...42949673 s | Motor fan start delay. | 1 = 1 s |
| 35.102 | DOL starter off delay | Defines a stop delay for the motor fan. The delay timer starts when the control source selected by parameter 35.100 switches off. After the delay, bit 1 of 35.105 switches off. | 20 min |
| | 0...715828 min | Motor fan stop delay. | 1 = 1 min |
| 35.103 | DOL starter feedback source | Selects the input for motor fan feedback signal. 0 = Stopped 1 = Running After the fan is started (bit 1 of 35.105 switches on), feedback is expected within the time set by 35.104 . | Not selected ; DI5 (95.20 b6) |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 5 |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 6 |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status , bit 1). | 11 |
| | Other [bit] | Source selection (see Terms and abbreviations on page 101). | - |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | |
|--|-----------------------------------|--|--|-----|------|-------------|---|---------------|--|---|-----------------------|---|---|--------------|--|---|----------------|---|--------|----------|--|
| 35.104 | <i>DOL starter feedback delay</i> | Defines a feedback delay for the motor fan. The delay timer starts when bit 1 of 35.105 switches on. If no feedback is received from the fan until the delay elapses, the action selected by 35.106 is taken. Note: This delay is only applied at start. If the feedback signal is lost during run, the action selected by 35.106 is taken immediately. | 0 s; 5s (95.20 b6) | | | | | | | | | | | | | | | | | | |
| | 0...42949673 s | Motor fan start delay. | 1 = 1 s | | | | | | | | | | | | | | | | | | |
| 35.105 | <i>DOL starter status word</i> | Status of the motor fan control logic. Bit 1 is the control output for the fan, to be selected as the source of, for example, a digital or relay output. The other bits indicate the statuses of the selected control and feedback sources, and the fault status. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Start command</td> <td>Status of fan control source selected by 35.100. 0 = Stop requested 1 = Start requested</td> </tr> <tr> <td>1</td> <td>Delayed start command</td> <td>Fan control bit (delays observed). Select this bit as the source of the output controlling the fan. 0 = Stopped 1 = Started</td> </tr> <tr> <td>2</td> <td>DOL feedback</td> <td>Status of fan feedback (source selected by 35.103). 0 = Stopped 1 = Running</td> </tr> <tr> <td>3</td> <td>DOL fault (-1)</td> <td>Fault status. 0 = Fault (fan feedback missing). The action taken is selected by 35.106. 1 = No fault</td> </tr> <tr> <td>4...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | | | | Bit | Name | Description | 0 | Start command | Status of fan control source selected by 35.100 . 0 = Stop requested 1 = Start requested | 1 | Delayed start command | Fan control bit (delays observed). Select this bit as the source of the output controlling the fan. 0 = Stopped 1 = Started | 2 | DOL feedback | Status of fan feedback (source selected by 35.103). 0 = Stopped 1 = Running | 3 | DOL fault (-1) | Fault status. 0 = Fault (fan feedback missing). The action taken is selected by 35.106 . 1 = No fault | 4...15 | Reserved | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | |
| 0 | Start command | Status of fan control source selected by 35.100 . 0 = Stop requested 1 = Start requested | | | | | | | | | | | | | | | | | | | |
| 1 | Delayed start command | Fan control bit (delays observed). Select this bit as the source of the output controlling the fan. 0 = Stopped 1 = Started | | | | | | | | | | | | | | | | | | | |
| 2 | DOL feedback | Status of fan feedback (source selected by 35.103). 0 = Stopped 1 = Running | | | | | | | | | | | | | | | | | | | |
| 3 | DOL fault (-1) | Fault status. 0 = Fault (fan feedback missing). The action taken is selected by 35.106 . 1 = No fault | | | | | | | | | | | | | | | | | | | |
| 4...15 | Reserved | | | | | | | | | | | | | | | | | | | | |
| | 0000b...1111b | Status of motor fan control logic. | 1 = 1 | | | | | | | | | | | | | | | | | | |
| 35.106 | <i>DOL starter event type</i> | Selects the action taken when missing fan feedback is detected by the motor fan control logic. | <i>Fault</i> | | | | | | | | | | | | | | | | | | |
| | No action | No action taken. | 0 | | | | | | | | | | | | | | | | | | |
| | Warning | The drive generates a warning (A781 Motor fan). | 1 | | | | | | | | | | | | | | | | | | |
| | Fault | Drive trips on 71B1 Motor fan . | 2 | | | | | | | | | | | | | | | | | | |

| | | | |
|-------------------------|--------------------------|---|----------------------|
| 36 Load analyzer | | Peak value and amplitude logger settings. See also section Load analyzer (page 90). | |
| 36.01 | <i>PVL signal source</i> | Selects the signal to be monitored by the peak value logger. The signal is filtered using the filtering time specified by parameter 36.02 PVL filter time . The peak value is stored, along with other pre-selected signals at the time, into parameters 36.10...36.15 . The peak value logger can be reset using parameter 36.09 Reset loggers . The date and time of the last reset are stored into parameters 36.16 and 36.17 respectively. | <i>Power inu out</i> |
| | Zero | None (peak value logger disabled). | 0 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------|------------------------------------|---|------------------------------|
| | Motor speed used | 01.01 Motor speed used (page 105). | 1 |
| | Output frequency | 01.06 Output frequency (page 105). | 3 |
| | Motor current | 01.07 Motor current (page 105). | 4 |
| | Motor torque | 01.10 Motor torque (page 105). | 6 |
| | DC voltage | 01.11 DC voltage (page 105). | 7 |
| | Power inu out | 01.14 Output power (page 106). | 8 |
| | Speed ref ramp in | 23.01 Speed ref ramp input (page 203). | 10 |
| | Speed ref ramped | 23.02 Speed ref ramp output (page 204). | 11 |
| | Speed ref used | 24.01 Used speed reference (page 210). | 12 |
| | Torq ref used | 26.02 Torque reference used | 13 |
| | Freq ref used | 28.02 Frequency ref ramp output (page 226). | 14 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 36.02 | PVL filter time | Defines a filtering time for the peak value logger. See parameter 36.01 PVL signal source . | 2.00 s |
| | 0.00...120.00 s | Peak value logger filtering time. | 100 = 1 s |
| 36.06 | AL2 signal source | Selects the signal to be monitored by amplitude logger 2. The signal is sampled at 200 ms intervals. The results are displayed by parameters 36.40...36.49 . Each parameter represents an amplitude range, and shows what portion of the samples fall within that range. The signal value corresponding to 100% is defined by parameter 36.07 AL2 signal scaling . Amplitude logger 2 can be reset using parameter 36.09 Reset loggers . The date and time of the last reset are stored into parameters 36.50 and 36.51 respectively. For the selections, see parameter 36.01 PVL signal source . | Motor torque |
| 36.07 | AL2 signal scaling | Defines the signal value that corresponds to 100% amplitude. | 100.00 |
| | 0.00...32767.00 | Signal value corresponding to 100%. | 1 = 1 |
| 36.09 | Reset loggers | Resets the peak value logger and/or amplitude logger 2. (Amplitude logger 1 cannot be reset.) | Done |
| | Done | Reset completed or not requested (normal operation). | 0 |
| | All | Reset both the peak value logger and amplitude logger 2. | 1 |
| | PVL | Reset the peak value logger. | 2 |
| | AL2 | Reset amplitude logger 2. | 3 |
| 36.10 | PVL peak value | Displays the peak value recorded by the peak value logger. | 0.00 |
| | -32768.00...32767.00 | Peak value. | 1 = 1 |
| 36.11 | PVL peak date | Displays the date on which the peak value was recorded. | - |
| | - | Peak occurrence date. | - |
| 36.12 | PVL peak time | Displays the time at which the peak value was recorded. | - |
| | - | Peak occurrence time. | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------|---|-----------------------------------|
| 36.13 | <i>PVL current at peak</i> | Displays the motor current at the moment the peak value was recorded. | 0.00 A |
| | -32768.00 ...32767.00 A | Motor current at peak. | 1 = 1 A |
| 36.14 | <i>PVL DC voltage at peak</i> | Displays the voltage in the intermediate DC circuit of the drive at the moment the peak value was recorded. | 0.00 V |
| | 0.00...2000.00 V | DC voltage at peak. | 10 = 1 V |
| 36.15 | <i>PVL speed at peak</i> | Displays the motor speed at the moment the peak value was recorded. | 0.00 rpm |
| | -32768.00 ...32767.00 rpm | Motor speed at peak. | See par. 46.01 |
| 36.16 | <i>PVL reset date</i> | Displays the date on which the peak value logger was last reset. | - |
| | - | Last reset date of the peak value logger. | - |
| 36.17 | <i>PVL reset time</i> | Displays the time at which the peak value logger was last reset. | - |
| | - | Last reset time of the peak value logger. | - |
| 36.20 | <i>AL1 0 to 10%</i> | Displays the percentage of samples recorded by amplitude logger 1 that fall between 0 and 10%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 1 samples between 0 and 10%. | 1 = 1% |
| 36.21 | <i>AL1 10 to 20%</i> | Displays the percentage of samples recorded by amplitude logger 1 that fall between 10 and 20%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 1 samples between 10 and 20%. | 1 = 1% |
| 36.22 | <i>AL1 20 to 30%</i> | Displays the percentage of samples recorded by amplitude logger 1 that fall between 20 and 30%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 1 samples between 20 and 30%. | 1 = 1% |
| 36.23 | <i>AL1 30 to 40%</i> | Displays the percentage of samples recorded by amplitude logger 1 that fall between 30 and 40%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 1 samples between 30 and 40%. | 1 = 1% |
| 36.24 | <i>AL1 40 to 50%</i> | Displays the percentage of samples recorded by amplitude logger 1 that fall between 40 and 50%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 1 samples between 40 and 50%. | 1 = 1% |
| 36.25 | <i>AL1 50 to 60%</i> | Displays the percentage of samples recorded by amplitude logger 1 that fall between 50 and 60%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 1 samples between 50 and 60%. | 1 = 1% |
| 36.26 | <i>AL1 60 to 70%</i> | Displays the percentage of samples recorded by amplitude logger 1 that fall between 60 and 70%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 1 samples between 60 and 70%. | 1 = 1% |
| 36.27 | <i>AL1 70 to 80%</i> | Displays the percentage of samples recorded by amplitude logger 1 that fall between 70 and 80%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 1 samples between 70 and 80%. | 1 = 1% |
| 36.28 | <i>AL1 80 to 90%</i> | Displays the percentage of samples recorded by amplitude logger 1 that fall between 80 and 90%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 1 samples between 80 and 90%. | 1 = 1% |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-----------------------|---|----------------|
| 36.29 | <i>AL1 over 90%</i> | Displays the percentage of samples recorded by amplitude logger 1 that exceed 90%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 1 samples over 90%. | 1 = 1% |
| 36.40 | <i>AL2 0 to 10%</i> | Displays the percentage of samples recorded by amplitude logger 2 that fall between 0 and 10%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 2 samples between 0 and 10%. | 1 = 1% |
| 36.41 | <i>AL2 10 to 20%</i> | Displays the percentage of samples recorded by amplitude logger 2 that fall between 10 and 20%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 2 samples between 10 and 20%. | 1 = 1% |
| 36.42 | <i>AL2 20 to 30%</i> | Displays the percentage of samples recorded by amplitude logger 2 that fall between 20 and 30%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 2 samples between 20 and 30%. | 1 = 1% |
| 36.43 | <i>AL2 30 to 40%</i> | Displays the percentage of samples recorded by amplitude logger 2 that fall between 30 and 40%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 2 samples between 30 and 40%. | 1 = 1% |
| 36.44 | <i>AL2 40 to 50%</i> | Displays the percentage of samples recorded by amplitude logger 2 that fall between 40 and 50%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 2 samples between 40 and 50%. | 1 = 1% |
| 36.45 | <i>AL2 50 to 60%</i> | Displays the percentage of samples recorded by amplitude logger 2 that fall between 50 and 60%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 2 samples between 50 and 60%. | 1 = 1% |
| 36.46 | <i>AL2 60 to 70%</i> | Displays the percentage of samples recorded by amplitude logger 2 that fall between 60 and 70%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 2 samples between 60 and 70%. | 1 = 1% |
| 36.47 | <i>AL2 70 to 80%</i> | Displays the percentage of samples recorded by amplitude logger 2 that fall between 70 and 80%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 2 samples between 70 and 80%. | 1 = 1% |
| 36.48 | <i>AL2 80 to 90%</i> | Displays the percentage of samples recorded by amplitude logger 2 that fall between 80 and 90%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 2 samples between 80 and 90%. | 1 = 1% |
| 36.49 | <i>AL2 over 90%</i> | Displays the percentage of samples recorded by amplitude logger 2 that exceed 90%. | 0.00% |
| | 0.00...100.00% | Amplitude logger 2 samples over 90%. | 1 = 1% |
| 36.50 | <i>AL2 reset date</i> | Displays the date on which amplitude logger 2 was last reset. | - |
| | - | Last reset date of amplitude logger 2. | - |
| 36.51 | <i>AL2 reset time</i> | Displays the time at which amplitude logger 2 was last reset. | - |
| | - | Last reset time of amplitude logger 2. | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------------------------------|-------------------------------------|---|-----------------|
| 43 Brake chopper | | Settings for the internal brake chopper. | |
| 43.01 | <i>Braking resistor temperature</i> | Displays the estimated temperature of the brake resistor, or how close the brake resistor is to being too hot. The value is given in percent where 100% is the temperature the resistor would reach if the maximum continuous braking power (<i>43.09 Brake resistor Pmax cont</i>) is applied to the resistor for 100% rated time. The thermal time constant (<i>43.08 Brake resistor thermal tc</i>) defines the rated time to achieve 63% temperature. 100% would be reached when 100% time has elapsed. This parameter is read-only. | - |
| 0.0...120.0% | | Estimated brake resistor temperature. | 1 = 1% |
| 43.06 | <i>Brake chopper enable</i> | Enables brake chopper control. Note: Before enabling brake chopper control, ensure that <ul style="list-style-type: none"> • a brake resistor is connected, and • the supply voltage range (parameter <i>95.01 Supply voltage</i>) has been selected correctly. | <i>Disabled</i> |
| Disabled | | Brake chopper control disabled. | 0 |
| Enabled with thermal model | | Brake chopper control enabled with resistor overload protection. Note: Before using this setting, ensure that overvoltage control is switched off (parameter <i>30.30 Overvoltage control</i>). | 1 |
| Enabled without thermal model | | Brake chopper control enabled without resistor overload protection. This setting can be used, for example, if the resistor is equipped with a thermal circuit breaker that is wired to stop the drive if the resistor overheats. Before using this setting, ensure that overvoltage control is switched off (parameter <i>30.30 Overvoltage control</i>) | 2 |
| Overvoltage peak protection | | Brake chopper control enabled in an overvoltage condition. This setting is intended for situations where <ul style="list-style-type: none"> • the braking chopper is not needed for runtime operation, ie. to dissipate the inertial energy of the motor, • the motor is able to store a considerable amount of magnetic energy in its windings, and • the motor might, deliberately or inadvertently, be stopped by coasting. In such a situation, the motor would potentially discharge enough magnetic energy towards the drive to cause damage. To protect the drive, the brake chopper can be used with a small resistor dimensioned merely to handle the magnetic energy (not the inertial energy) of the motor. With this setting, the brake chopper is activated only whenever the DC voltage exceeds the overvoltage limit. During normal use, the brake chopper is not operating. | 3 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------------|-------------------------------------|---|----------------|
| 43.07 | <i>Brake chopper runtime enable</i> | Selects the source for quick brake chopper on/off control. 0 = Brake chopper IGBT pulses are cut off 1 = Normal brake chopper IGBT modulation. This parameter can be used to program the chopper control to function only when the supply is missing from a drive with a regenerative supply unit. | On |
| | Off | 0. | 0 |
| | On | 1. | 1 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 43.08 | <i>Brake resistor thermal tc</i> | Defines the thermal time constant of the brake resistor for overload protection. | 0 s |
| | 0...10000 s | Brake resistor thermal time constant. | 1 = 1 s |
| 43.09 | <i>Brake resistor Pmax cont</i> | Defines the maximum continuous braking power of the resistor (in kW) which will raise the resistor temperature to the maximum allowed value. The value is used in the overload protection. | 0.00 kW |
| | 0.00...10000.00 kW | Maximum continuous braking power. | 1 = 1 kW |
| 43.10 | <i>Brake resistance</i> | Defines the resistance value of the brake resistor. The value is used for brake chopper protection. | 0.0 ohm |
| | 0.0...1000.0 ohm | Brake resistor resistance value. | 1 = 1 ohm |
| 43.11 | <i>Brake resistor fault limit</i> | Selects the fault limit for the brake resistor temperature protection function. When the limit is exceeded, the drive trips on fault 7183 BR excess temperature . The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter 43.09 Brake resistor Pmax cont . | 105% |
| | 0...150% | Brake resistor temperature fault limit. | 1 = 1% |
| 43.12 | <i>Brake resistor warning limit</i> | Selects the warning limit for the brake resistor temperature protection function. When the limit is exceeded, the drive generates a A793 BR excess temperature warning. The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter 43.09 Brake resistor Pmax cont . | 95% |
| | 0...150% | Brake resistor temperature warning limit. | 1 = 1% |
| 45 Energy efficiency | | Settings for the energy saving calculators. See also section Energy savings calculator (page 90). | |
| 45.01 | <i>Saved GW hours</i> | Displays the energy saved in GWh compared to direct-on-line motor connection. This parameter is incremented when 45.02 Saved MW hours rolls over. This parameter is read-only (see parameter 45.21 Energy calculations reset). | - |
| | 0...65535 GWh | Energy savings in GWh. | 1 = 1 GWh |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------------|--|----------------------|
| 45.02 | <i>Saved MW hours</i> | Displays the energy saved in MWh compared to direct-on-line motor connection. This parameter is incremented when 45.03 Saved kW hours rolls over. When this parameter rolls over, parameter 45.01 Saved GW hours is incremented. This parameter is read-only (see parameter 45.21 Energy calculations reset). | - |
| | 0...999 MWh | Energy savings in MWh. | 1 = 1 MWh |
| 45.03 | <i>Saved kW hours</i> | Displays the energy saved in kWh compared to direct-on-line motor connection. If the internal brake chopper of the drive is enabled, all energy fed by the motor to the drive is assumed to be converted into heat, but the calculation still records savings made by controlling the speed. If the chopper is disabled, then regenerated energy from the motor is also recorded here. When this parameter rolls over, parameter 45.02 Saved MW hours is incremented. This parameter is read-only (see parameter 45.21 Energy calculations reset). | - |
| | 0.0...999.9 kWh | Energy savings in kWh. | 10 = 1 kWh |
| 45.05 | <i>Saved money x1000</i> | Displays the monetary savings in thousands compared to direct-on-line motor connection. This parameter is incremented when 45.06 Saved money rolls over. The currency is defined by parameter 45.17 Tariff currency unit . This parameter is read-only (see parameter 45.21 Energy calculations reset). | - |
| | 0...4294967295 thousands | Monetary savings in thousands of units. | - |
| 45.06 | <i>Saved money</i> | Displays the monetary savings compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in kWh by the currently active energy tariff (45.14 Tariff selection). When this parameter rolls over, parameter 45.05 Saved money x1000 is incremented. The currency is defined by parameter 45.17 Tariff currency unit . This parameter is read-only (see parameter 45.21 Energy calculations reset). | - |
| | 0.00...999.99 units | Monetary savings. | 1 = 1 unit |
| 45.08 | <i>CO2 reduction in kilotons</i> | Displays the reduction in CO ₂ emissions in metric kilotons compared to direct-on-line motor connection. This value is incremented when parameter 45.09 CO2 reduction in tons rolls over. This parameter is read-only (see parameter 45.21 Energy calculations reset). | - |
| | 0...65535 metric kilotons | Reduction in CO ₂ emissions in metric kilotons. | 1 = 1 metric kiloton |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------------|---|------------------------|
| 45.09 | <i>CO2 reduction in tons</i> | Displays the reduction in CO ₂ emissions in metric tons compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in MWh by the value of parameter <i>45.18 CO2 conversion factor</i> (by default, 0.5 metric tons/MWh). When this parameter rolls over, parameter <i>45.08 CO2 reduction in kilotons</i> is incremented. This parameter is read-only (see parameter <i>45.21 Energy calculations reset</i>). | - |
| | 0.0...999.9 metric tons | Reduction in CO ₂ emissions in metric tons. | 1 = 1 metric ton |
| 45.11 | <i>Energy optimizer</i> | Enables/disables the energy optimization function. The function optimizes the motor flux so that total energy consumption and motor noise level are reduced when the drive operates below the nominal load. The total efficiency (motor and drive) can be improved by 1...20% depending on load torque and speed. Note: With a permanent magnet motor or a synchronous reluctance motor, energy optimization is always enabled regardless of this parameter. | <i>Disable</i> |
| | Disable | Energy optimization disabled. | 0 |
| | Enable | Energy optimization enabled. | 1 |
| 45.12 | <i>Energy tariff 1</i> | Defines energy tariff 1 (price of energy per kWh). Depending on the setting of parameter <i>45.14 Tariff selection</i> , either this value or <i>45.13 Energy tariff 2</i> is used for reference when monetary savings are calculated. The currency is defined by parameter <i>45.17 Tariff currency unit</i> . Note: Tariffs are read only at the instant of selection, and are not applied retroactively. | 1.000 units |
| | 0.000...4294966.296 units | Energy tariff 1. | - |
| 45.13 | <i>Energy tariff 2</i> | Defines energy tariff 2 (price of energy per kWh). See parameter <i>45.12 Energy tariff 1</i> . | 2.000 units |
| | 0.000...4294966.296 units | Energy tariff 2. | - |
| 45.14 | <i>Tariff selection</i> | Selects (or defines a source that selects) which pre-defined energy tariff is used. 0 = <i>45.12 Energy tariff 1</i> 1 = <i>45.13 Energy tariff 2</i> | <i>Energy tariff 1</i> |
| | Energy tariff 1 | 0. | 0 |
| | Energy tariff 2 | 1. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |




| No. | Name/Value | Description | Def/ FbEq16 |
|---------------------------------------|----------------------------------|--|---|
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 45.17 | <i>Tariff currency unit</i> | Specifies the currency used for the savings calculations. | <i>EUR</i> |
| | Local currency | Local currency. The name of the currency can be edited by choosing Menu - Settings - Edit texts on the control panel. | 100 |
| | EUR | Euro. | 101 |
| | USD | US dollar. | 102 |
| 45.18 | <i>CO2 conversion factor</i> | Defines a factor for conversion of saved energy into CO ₂ emissions (kg/kWh or tn/MWh). | 0.500 tn/MWh |
| | 0.000 ...65.535 tn/MWh | Factor for conversion of saved energy into CO ₂ emissions. | 1 = 1 tn/MWh |
| 45.19 | <i>Comparison power</i> | Actual power that the motor absorbs when connected direct-on-line and operating the application. The value is used for reference when energy savings are calculated. Note: The accuracy of the energy savings calculation is directly dependent on the accuracy of this value. If nothing is entered here, then the nominal motor power is used by the calculation, but that may inflate the energy savings reported as many motors do not absorb nameplate power. | 0.0 kW |
| | 0.0...100000.0 kW | Motor power. | See par. 46.04 |
| 45.21 | <i>Energy calculations reset</i> | Resets the savings counter parameters 45.01...45.09 | <i>Done</i> |
| | Done | Reset not requested (normal operation), or reset complete. | 0 |
| | Reset | Reset the savings counter parameters. The value reverts automatically to <i>Done</i> . | 1 |
| 46 Monitoring/scaling settings | | Speed supervision settings; actual signal filtering; general scaling settings. | |
| 46.01 | <i>Speed scaling</i> | Defines the maximum speed value used to define the acceleration ramp rate and the initial speed value used to define the deceleration ramp rate (see parameter group 23 <i>Speed reference ramp</i>). The speed acceleration and deceleration ramp times are therefore related to this value (not to parameter 30.12 <i>Maximum speed</i>). Also defines the 16-bit scaling of speed-related parameters. The value of this parameter corresponds to 20000 in fieldbus, master/follower etc. communication. | 1500.00 rpm; 1800.00 rpm (95.20 b0) |
| | 0.10...30000.00 rpm | Acceleration/deceleration terminal/initial speed. | 1 = 1 rpm |
| 46.02 | <i>Frequency scaling</i> | Defines the maximum frequency value used to define the acceleration ramp rate and the initial frequency value used to define deceleration ramp rate (see parameter group 28 <i>Frequency reference chain</i>). The frequency acceleration and deceleration ramp times are therefore related to this value (not to parameter 30.14 <i>Maximum frequency</i>). Also defines the 16-bit scaling of frequency-related parameters. The value of this parameter corresponds to 20000 in fieldbus, master/follower etc. communication. | 50.00 Hz; 60.00 Hz (95.20 b0) |
| | 0.10...1000.00 Hz | Acceleration/deceleration terminal/initial frequency. | 10 = 1 Hz |




| No. | Name/Value | Description | Def/ FbEq16 |
|------------------------|---------------------------------------|---|----------------|
| 47 Data storage | | Data storage parameters that can be written to and read from using other parameters' source and target settings. Note that there are different storage parameters for different data types. Integer-type storage parameters cannot be used as the source of other parameters. See also section Data storage parameters (page 92). | |
| 47.01 | Data storage 1 real32 | Data storage parameter 1. Parameters 47.01 ... 47.08 are real 32-bit numbers that can be used as source values of other parameters. Storage parameters 47.01 ... 47.08 can be used as the target of received 16-bit data. The scaling and range are defined by parameters 47.31 ... 47.38 . | 0.000 |
| | -2147483.000 ...2147483.000 | 32-bit data real (floating point) number. | - |
| 47.02 | Data storage 2 real32 | Data storage parameter 2. See also parameter 47.01 Data storage 1 real32 . | 0.000 |
| | -2147483.00 ...2147483.000 | 32-bit data real (floating point) number. | - |
| 47.03 | Data storage 3 real32 | Data storage parameter 3. See also parameter 47.01 Data storage 1 real32 . | 0.000 |
| | -2147483.000 ...2147483.000 | 32-bit data real (floating point) number. | - |
| 47.04 | Data storage 4 real32 | Data storage parameter 4. See also parameter 47.01 Data storage 1 real32 . | 0.000 |
| | -2147483.000 ...2147483.000 | 32-bit data real (floating point) number. | - |
| 47.05 | Data storage 5 real32 | Data storage parameter 5. See also parameter 47.01 Data storage 1 real32 . | 0.000 |
| | -2147483.000 ...2147483.000 | 32-bit data real (floating point) number. | - |
| 47.06 | Data storage 6 real32 | Data storage parameter 6. See also parameter 47.01 Data storage 1 real32 . | 0.000 |
| | -2147483.000 ...2147483.000 | 32-bit data real (floating point) number. | - |
| 47.07 | Data storage 7 real32 | Data storage parameter 7. See also parameter 47.01 Data storage 1 real32 . | 0.000 |
| | -2147483.000 ...2147483.000 | 32-bit data real (floating point) number. | - |
| 47.08 | Data storage 8 real32 | Data storage parameter 8. See also parameter 47.01 Data storage 1 real32 . | 0.000 |
| | -2147483.000 ...2147483.000 | 32-bit data real (floating point) number. | - |
| 47.11 | Data storage 1 int32 | Data storage parameter 9. | 0 |
| | -2147483648 ...2147483647 | 32-bit integer. | - |

282 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|---|-----------------|
| 47.12 | Data storage 2 int32 | Data storage parameter 10. | 0 |
| | -2147483648 ...2147483647 | 32-bit integer. | - |
| 47.13 | Data storage 3 int32 | Data storage parameter 11. | 0 |
| | -2147483648 ...2147483647 | 32-bit integer. | - |
| 47.14 | Data storage 4 int32 | Data storage parameter 12. | 0 |
| | -2147483648 ...2147483647 | 32-bit integer. | - |
| 47.15 | Data storage 5 int32 | Data storage parameter 13. | 0 |
| | -2147483648 ...2147483647 | 32-bit integer. | - |
| 47.16 | Data storage 6 int32 | Data storage parameter 14. | 0 |
| | -2147483648 ...2147483647 | 32-bit integer. | - |
| 47.17 | Data storage 7 int32 | Data storage parameter 15. | 0 |
| | -2147483648 ...2147483647 | 32-bit integer. | - |
| 47.18 | Data storage 8 int32 | Data storage parameter 16. | 0 |
| | -2147483648 ...2147483647 | 32-bit integer. | - |
| 47.21 | Data storage 1 int16 | Data storage parameter 17. | 0 |
| | -32768...32767 | 16-bit integer. | 1 = 1 |
| 47.22 | Data storage 2 int16 | Data storage parameter 18. | 0 |
| | -32768...32767 | 16-bit integer. | 1 = 1 |
| 47.23 | Data storage 3 int16 | Data storage parameter 19. | 0 |
| | -32768...32767 | 16-bit integer. | 1 = 1 |
| 47.24 | Data storage 4 int16 | Data storage parameter 20. | 0 |
| | -32768...32767 | 16-bit integer. | 1 = 1 |
| 47.25 | Data storage 5 int16 | Data storage parameter 21. | 0 |
| | -32768...32767 | 16-bit integer. | 1 = 1 |
| 47.26 | Data storage 6 int16 | Data storage parameter 22. | 0 |
| | -32768...32767 | 16-bit integer. | 1 = 1 |
| 47.27 | Data storage 7 int16 | Data storage parameter 23. | 0 |
| | -32768...32767 | 16-bit integer. | 1 = 1 |
| 47.28 | Data storage 8 int16 | Data storage parameter 24. | 0 |
| | -32768...32767 | 16-bit integer. | 1 = 1 |
| 47.31 | Data storage 1 real32 type | Defines the scaling of parameter 47.01 Data storage 1 real32 to and from 16-bit integer format. This scaling is used when the data storage parameter is the target of received 16-bit data. The setting also defines the visible range of the storage parameter. | <i>Unscaled</i> |
| | Unscaled | Data storage only. Range: -2147483.264 ... 2147473.264. | 0 |

| No. | Name/Value | Description | Def/ FbEq16 |
|------------------------------------|-----------------------------------|--|----------------|
| | Transparent | Scaling: 1 = 1. Range: -32768 ... 32767. | 1 |
| | General | Scaling: 1 = 100. Range: -327.68 ... 327.67. | 2 |
| | Torque | The scaling is defined by parameter 46.03 Torque scaling. Range: -1600.0 ... 1600.0. | 3 |
| | Speed | The scaling is defined by parameter 46.01 Speed scaling. Range: -30000.00 ... 30000.00. | 4 |
| | Frequency | The scaling is defined by parameter 46.02 Frequency scaling. Range: -500.00 ... 500.00. | 5 |
| 47.32 | <i>Data storage 2 real32 type</i> | Defines the 16-bit scaling of parameter 47.02 Data storage 2 real32. See parameter 47.31 Data storage 1 real32 type. | Unscaled |
| 47.33 | <i>Data storage 3 real32 type</i> | Defines the 16-bit scaling of parameter 47.03 Data storage 3 real32. See parameter 47.31 Data storage 1 real32 type. | Unscaled |
| 47.34 | <i>Data storage 4 real32 type</i> | Defines the 16-bit scaling of parameter 47.04 Data storage 4 real32. See parameter 47.31 Data storage 1 real32 type. | Unscaled |
| 47.35 | <i>Data storage 5 real32 type</i> | Defines the 16-bit scaling of parameter 47.05 Data storage 5 real32. See parameter 47.31 Data storage 1 real32 type. | Unscaled |
| 47.36 | <i>Data storage 6 real32 type</i> | Defines the 16-bit scaling of parameter 47.06 Data storage 6 real32. See parameter 47.31 Data storage 1 real32 type. | Unscaled |
| 47.37 | <i>Data storage 7 real32 type</i> | Defines the 16-bit scaling of parameter 47.07 Data storage 7 real32. See parameter 47.31 Data storage 1 real32 type. | Unscaled |
| 47.38 | <i>Data storage 8 real32 type</i> | Defines the 16-bit scaling of parameter 47.08 Data storage 8 real32. See parameter 47.31 Data storage 1 real32 type. | Unscaled |
| 49 Panel port communication | | Communication settings for the control panel port on the drive. | |
| 49.01 | <i>Node ID number</i> | Defines the node ID of the drive. All devices connected to the network must have a unique node ID. Note: For networked drives, it is advisable to reserve ID 1 for spare/replacement drives. | 1 |
| | 1...32 | Node ID. | 1 = 1 |
| 49.03 | <i>Baud rate</i> | Defines the transfer rate of the link. | 230.4 kbps |
| | 38.4 kbps | 38.4 kbit/s. | 1 |
| | 57.6 kbps | 57.6 kbit/s. | 2 |
| | 86.4 kbps | 86.4 kbit/s. | 3 |
| | 115.2 kbps | 115.2 kbit/s. | 4 |
| | 230.4 kbps | 230.4 kbit/s. | 5 |
| 49.04 | <i>Communication loss time</i> | Sets a timeout for control panel (or PC tool) communication. If a communication break lasts longer than the timeout, the action specified by parameter 49.05 Communication loss action is taken. | 10.0 s |
| | 0.3...3000.0 s | Panel/PC tool communication timeout. | 10 = 1 s |




| No. | Name/Value | Description | Def/ FbEq16 |
|----------------------------------|----------------------------------|---|------------------|
| 49.05 | <i>Communication loss action</i> | Selects how the drive reacts to a control panel (or PC tool) communication break. | <i>Fault</i> |
| | No action | No action taken. | 0 |
| | Fault | Drive trips on <i>7081 Panel port communication</i> . | 1 |
| | Last speed | Drive generates an <i>A7EE Panel loss</i> warning and freezes the speed to the level the drive was operating at. The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 2 |
| | Speed ref safe | Drive generates an <i>A7EE Panel loss</i> warning and sets the speed to the speed defined by parameter <i>22.41 Speed ref safe</i> (or <i>28.41 Frequency ref safe</i> when frequency reference is being used).  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 3 |
| | Fault always | Drive trips on <i>7081 Panel port communication</i> . This occurs even though no control is expected from the panel (or PC tool). | 4 |
| | Warning | Drive generates an <i>A7EE Panel loss</i> warning. This occurs even though no control is expected from the panel (or PC tool).  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 5 |
| 49.06 | <i>Refresh settings</i> | Applies the settings of parameters <i>49.01...49.05</i> . Note: Refreshing may cause a communication break, so reconnecting the drive may be required. | <i>Done</i> |
| | Done | Refresh done or not requested. | 0 |
| | Refresh | Refresh parameters <i>49.01...49.05</i> . The value reverts automatically to <i>Done</i> . | 1 |
| 50 Fieldbus adapter (FBA) | | Fieldbus communication configuration. See also chapter <i>Fieldbus control through a fieldbus adapter</i> (page 461). | |
| 50.01 | <i>FBA A enable</i> | Enables/disables communication between the drive and fieldbus adapter A, and specifies the slot the adapter is installed into. | <i>Disable</i> |
| | Disable | Communication between drive and fieldbus adapter A disabled. | 0 |
| | Option slot 1 | Communication between drive and fieldbus adapter A enabled. The adapter is in slot 1. | 1 |
| | Option slot 2 | Communication between drive and fieldbus adapter A enabled. The adapter is in slot 2. | 2 |
| | Option slot 3 | Communication between drive and fieldbus adapter A enabled. The adapter is in slot 3. | 3 |
| 50.02 | <i>FBA A comm loss func</i> | Selects how the drive reacts upon a fieldbus communication break. The time delay is defined by parameter <i>50.03 FBA A comm loss t out</i> . | <i>No action</i> |
| | No action | No action taken. | 0 |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | |
|---|------------------------------|--|---------------------------|--|----------------|---------|---------------|--------------|----------------------------|----------------|-------------------|------------------|--------------------------------|
| | Fault | Communication break detection active. Upon a communication break, the drive trips on a <i>7510 FBA A communication</i> fault and coasts to a stop. | 1 | | | | | | | | | | |
| | Last speed | Communication break detection active. Upon a communication break, the drive generates a warning (<i>A7C1 FBA A communication</i>) and freezes the speed to the level the drive was operating at. The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 2 | | | | | | | | | | |
| | Speed ref safe | Communication break detection active. Upon a communication break, the drive generates a warning (<i>A7C1 FBA A communication</i>) and sets the speed to the value defined by parameter <i>22.41 Speed ref safe</i> (when speed reference is being used) or <i>28.41 Frequency ref safe</i> (when frequency reference is being used).  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 3 | | | | | | | | | | |
| | Fault always | Drive trips on <i>7510 FBA A communication</i> . This occurs even though no control is expected from the fieldbus. | 4 | | | | | | | | | | |
| | Warning | Drive generates an <i>A7C1 FBA A communication</i> warning. This occurs even though no control is expected from the fieldbus.  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 5 | | | | | | | | | | |
| <i>50.03</i> | <i>FBA A comm loss t out</i> | Defines the time delay before the action defined by parameter <i>50.02 FBA A comm loss func</i> is taken. Time count starts when the communication link fails to update the message. As a rule of thumb, this parameter should be set to at least 3 times the transmit interval of the master. | 0.3 s | | | | | | | | | | |
| | 0.3...6553.5 s | Time delay. | 1 = 1 s | | | | | | | | | | |
| <i>50.04</i> | <i>FBA A ref1 type</i> | Selects the type and scaling of reference 1 received from fieldbus adapter A. The scaling of the reference is defined by parameters <i>46.01...46.03</i> , depending on which reference type is selected by this parameter. | <i>Speed or frequency</i> | | | | | | | | | | |
| | Speed or frequency | Type and scaling are chosen automatically according to the currently active operation mode as follows: | 0 | | | | | | | | | | |
| <table border="1" data-bbox="217 1182 1034 1310"> <thead> <tr> <th>Operation mode (see par. <i>19.01</i>)</th> <th>Reference type</th> <th>Scaling</th> </tr> </thead> <tbody> <tr> <td>Speed control</td> <td rowspan="2"><i>Speed</i></td> <td rowspan="2"><i>46.01 Speed scaling</i></td> </tr> <tr> <td>Torque control</td> </tr> <tr> <td>Frequency control</td> <td><i>Frequency</i></td> <td><i>46.02 Frequency scaling</i></td> </tr> </tbody> </table> | | | | Operation mode (see par. <i>19.01</i>) | Reference type | Scaling | Speed control | <i>Speed</i> | <i>46.01 Speed scaling</i> | Torque control | Frequency control | <i>Frequency</i> | <i>46.02 Frequency scaling</i> |
| Operation mode (see par. <i>19.01</i>) | Reference type | Scaling | | | | | | | | | | | |
| Speed control | <i>Speed</i> | <i>46.01 Speed scaling</i> | | | | | | | | | | | |
| Torque control | | | | | | | | | | | | | |
| Frequency control | <i>Frequency</i> | <i>46.02 Frequency scaling</i> | | | | | | | | | | | |
| | Transparent | No scaling is applied. | 1 | | | | | | | | | | |
| | General | Generic reference with a scaling of 100 = 1 (ie. integer and two decimals). | 2 | | | | | | | | | | |
| | Torque | The scaling is defined by parameter 46.03 Torque scaling. | 3 | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | |
|--|---|---|------------------------------------|---|---------------------------|---------|---------------|---|-------------------------------------|----------------|---|---|-------------------|---|---|
| | Speed | The scaling is defined by parameter 46.01 Speed scaling . | 4 | | | | | | | | | | | | |
| | Frequency | The scaling is defined by parameter 46.02 Frequency scaling . | 5 | | | | | | | | | | | | |
| 50.05 | FBA A ref2 type | Selects the type and scaling of reference 2 received from fieldbus adapter A. The scaling of the reference is defined by parameters 46.01...46.03 , depending on which reference type is selected by this parameter. For the selections, see parameter 50.04 FBA A ref1 type . | Speed or frequency | | | | | | | | | | | | |
| 50.07 | FBA A actual 1 type | Selects the type/source and scaling of actual value 1 transmitted to the fieldbus network through fieldbus adapter A. | Speed or frequency | | | | | | | | | | | | |
| | Speed or frequency | Type/source and scaling are chosen automatically according to the currently active operation mode as follows: | 0 | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Operation mode (see par. 19.01)</th> <th>Actual 1 type (source)</th> <th>Scaling</th> </tr> </thead> <tbody> <tr> <td>Speed control</td> <td>Speed (01.01 Motor speed used)</td> <td>46.01 Speed scaling</td> </tr> <tr> <td>Torque control</td> <td>Frequency (01.06 Output frequency)</td> <td>46.02 Frequency scaling</td> </tr> <tr> <td>Frequency control</td> <td>Frequency (01.06 Output frequency)</td> <td>46.02 Frequency scaling</td> </tr> </tbody> </table> | | | | Operation mode (see par. 19.01) | Actual 1 type (source) | Scaling | Speed control | Speed (01.01 Motor speed used) | 46.01 Speed scaling | Torque control | Frequency (01.06 Output frequency) | 46.02 Frequency scaling | Frequency control | Frequency (01.06 Output frequency) | 46.02 Frequency scaling |
| Operation mode (see par. 19.01) | Actual 1 type (source) | Scaling | | | | | | | | | | | | | |
| Speed control | Speed (01.01 Motor speed used) | 46.01 Speed scaling | | | | | | | | | | | | | |
| Torque control | Frequency (01.06 Output frequency) | 46.02 Frequency scaling | | | | | | | | | | | | | |
| Frequency control | Frequency (01.06 Output frequency) | 46.02 Frequency scaling | | | | | | | | | | | | | |
| | Transparent | The value selected by parameter 50.10 FBA A act1 transparent source is sent as actual value 1. No scaling is applied (the 16-bit scaling is 1 = 1 unit). | 1 | | | | | | | | | | | | |
| | General | The value selected by parameter 50.10 FBA A act1 transparent source is sent as actual value 1 with a 16-bit scaling of 100 = 1 unit (ie. integer and two decimals). | 2 | | | | | | | | | | | | |
| | Torque | 01.10 Motor torque is sent as actual value 1. | 3 | | | | | | | | | | | | |
| | Speed | 01.01 Motor speed used is sent as actual value 1. The scaling is defined by parameter 46.01 Speed scaling . | 4 | | | | | | | | | | | | |
| | Frequency | 01.06 Output frequency is sent as actual value 1. The scaling is defined by parameter 46.02 Frequency scaling . | 5 | | | | | | | | | | | | |
| | Position | Motor position is sent as actual value 1. See parameter 90.06 Motor position scaled . | 6 | | | | | | | | | | | | |
| 50.08 | FBA A actual 2 type | Selects the type/source and scaling of actual value 2 transmitted to the fieldbus network through fieldbus adapter A. For the selections, see parameter 50.07 FBA A actual 1 type . | Speed or frequency | | | | | | | | | | | | |
| 50.09 | FBA A SW transparent source | Selects the source of the fieldbus status word when the fieldbus adapter is set to a transparent communication profile eg. by its configuration parameters (group 51 FBA A settings). | Not selected | | | | | | | | | | | | |
| | Not selected | No source selected. | - | | | | | | | | | | | | |
| | Other | Source selection (see Terms and abbreviations on page 101). | - | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|--|---------------------|
| 50.10 | <i>FBA A act1 transparent source</i> | When parameter <i>50.07 FBA A actual 1 type</i> is set to <i>Transparent</i> or <i>General</i> this parameter selects the source of actual value 1 transmitted to the fieldbus network through fieldbus adapter A. | <i>Not selected</i> |
| | Not selected | No source selected. | - |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 50.11 | <i>FBA A act2 transparent source</i> | When parameter <i>50.08 FBA A actual 2 type</i> is set to <i>Transparent</i> or <i>General</i> this parameter selects the source of actual value 2 transmitted to the fieldbus network through fieldbus adapter A. | <i>Not selected</i> |
| | Not selected | No source selected. | - |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 50.12 | <i>FBA A debug mode</i> | Enables the display of raw (unmodified) data received from and sent to fieldbus adapter A in parameters <i>50.13...50.18</i> . This functionality should only be used for debugging. | <i>Disable</i> |
| | Disable | Display of raw data from fieldbus adapter A disabled. | 0 |
| | Fast | Display of raw data from fieldbus adapter A enabled. | 1 |
| 50.13 | <i>FBA A control word</i> | Displays the raw (unmodified) control word sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter <i>50.12 FBA A debug mode</i> . This parameter is read-only. | - |
| | 0000000h ...FFFFFFFh | Control word sent by master to fieldbus adapter A. | - |
| 50.14 | <i>FBA A reference 1</i> | Displays raw (unmodified) reference REF1 sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter <i>50.12 FBA A debug mode</i> . This parameter is read-only. | - |
| | -2147483648 ...2147483647 | Raw REF1 sent by master to fieldbus adapter A. | - |
| 50.15 | <i>FBA A reference 2</i> | Displays raw (unmodified) reference REF2 sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter <i>50.12 FBA A debug mode</i> . This parameter is read-only. | - |
| | -2147483648 ...2147483647 | Raw REF2 sent by master to fieldbus adapter A. | - |
| 50.16 | <i>FBA A status word</i> | Displays the raw (unmodified) status word sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter <i>50.12 FBA A debug mode</i> . This parameter is read-only. | - |
| | 0000000h ...FFFFFFFh | Status word sent by fieldbus adapter A to master. | - |
| 50.17 | <i>FBA A actual value 1</i> | Displays raw (unmodified) actual value ACT1 sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter <i>50.12 FBA A debug mode</i> . This parameter is read-only. | - |
| | -2147483648 ...2147483647 | Raw ACT1 sent by fieldbus adapter A to master. | - |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | |
|-------------------|------------------------------|--|------------------|---------------|---------------|-------------------|-------|------|---------------|------|-------|-------------|--------|------|------------------|--------|------|---------------|
| 50.18 | <i>FBA A actual value 2</i> | Displays raw (unmodified) actual value ACT2 sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter <i>50.12 FBA A debug mode</i> . This parameter is read-only. | - | | | | | | | | | | | | | | | |
| | -2147483648 ...2147483647 | Raw ACT2 sent by fieldbus adapter A to master. | - | | | | | | | | | | | | | | | |
| 50.21 | <i>FBA A timelevel sel</i> | <p>Selects the communication time levels. In general, lower time levels of read/write services reduce CPU load. The table below shows the time levels of the read/write services for cyclic high and cyclic low data with each parameter setting.</p> <table border="1"> <thead> <tr> <th>Selection</th> <th>Cyclic high *</th> <th>Cyclic low **</th> </tr> </thead> <tbody> <tr> <td><i>Monitoring</i></td> <td>10 ms</td> <td>2 ms</td> </tr> <tr> <td><i>Normal</i></td> <td>2 ms</td> <td>10 ms</td> </tr> <tr> <td><i>Fast</i></td> <td>500 µs</td> <td>2 ms</td> </tr> <tr> <td><i>Very fast</i></td> <td>250 µs</td> <td>2 ms</td> </tr> </tbody> </table> <p>* Cyclic high data consists of fieldbus Status word, Act1 and Act2. ** Cyclic low data consists of the parameter data mapped to parameter groups <i>52 FBA A data in</i> and <i>53 FBA A data out</i>, and acyclic data. Control word, Ref1 and Ref2 are handled as interrupts generated on receipt of cyclic high messages.</p> | Selection | Cyclic high * | Cyclic low ** | <i>Monitoring</i> | 10 ms | 2 ms | <i>Normal</i> | 2 ms | 10 ms | <i>Fast</i> | 500 µs | 2 ms | <i>Very fast</i> | 250 µs | 2 ms | <i>Normal</i> |
| Selection | Cyclic high * | Cyclic low ** | | | | | | | | | | | | | | | | |
| <i>Monitoring</i> | 10 ms | 2 ms | | | | | | | | | | | | | | | | |
| <i>Normal</i> | 2 ms | 10 ms | | | | | | | | | | | | | | | | |
| <i>Fast</i> | 500 µs | 2 ms | | | | | | | | | | | | | | | | |
| <i>Very fast</i> | 250 µs | 2 ms | | | | | | | | | | | | | | | | |
| | Normal | Normal speed. | 0 | | | | | | | | | | | | | | | |
| | Fast | Fast speed. | 1 | | | | | | | | | | | | | | | |
| | Very fast | Very fast speed. | 2 | | | | | | | | | | | | | | | |
| | Monitoring | Low speed. Optimized for PC tool communication and monitoring usage. | 3 | | | | | | | | | | | | | | | |
| 50.31 | <i>FBA B enable</i> | Enables/disables communication between the drive and fieldbus adapter B, and specifies the slot the adapter is installed into. | <i>Disable</i> | | | | | | | | | | | | | | | |
| | Disable | Communication between drive and fieldbus adapter B disabled. | 0 | | | | | | | | | | | | | | | |
| | Option slot 1 | Communication between drive and fieldbus adapter B enabled. The adapter is in slot 1. | 1 | | | | | | | | | | | | | | | |
| | Option slot 2 | Communication between drive and fieldbus adapter B enabled. The adapter is in slot 2. | 2 | | | | | | | | | | | | | | | |
| | Option slot 3 | Communication between drive and fieldbus adapter B enabled. The adapter is in slot 3. | 3 | | | | | | | | | | | | | | | |
| 50.32 | <i>FBA B comm loss func</i> | Selects how the drive reacts upon a fieldbus communication break. The time delay is defined by parameter <i>50.33 FBA B comm loss timeout</i> . | <i>No action</i> | | | | | | | | | | | | | | | |
| | No action | No action taken. | 0 | | | | | | | | | | | | | | | |
| | Fault | Communication break detection active. Upon a communication break, the drive trips on a <i>7520 FBA B communication</i> fault and coasts to a stop. | 1 | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|--------------|------------------------------------|---|---------------------------|
| | Last speed | Communication break detection active. Upon a communication break, the drive generates a warning (<i>A7C1 FBA B communication</i>) and freezes the speed to the level the drive was operating at. The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 2 |
| | Speed ref safe | Communication break detection active. Upon a communication break, the drive generates a warning (<i>A7C2 FBA B communication</i>) and sets the speed to the value defined by parameter <i>22.41 Speed ref safe</i> (or <i>28.41 Frequency ref safe</i> when frequency reference is being used).  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 3 |
| | Fault always | Drive trips on <i>7520 FBA B communication</i> . This occurs even though no control is expected from the fieldbus. | 4 |
| | Warning | Drive generates an <i>A7C2 FBA B communication</i> warning. This occurs even though no control is expected from the fieldbus.  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 5 |
| <i>50.33</i> | <i>FBA B comm loss timeout</i> | Defines the time delay before the action defined by parameter <i>50.32 FBA B comm loss func</i> is taken. Time count starts when the communication link fails to update the message. As a rule of thumb, this parameter should be set to at least 3 times the transmit interval of the master. | 0.3 s |
| | 0.3...6553.5 s | Time delay. | 1 = 1 s |
| <i>50.34</i> | <i>FBA B ref1 type</i> | Selects the type and scaling of reference 1 received from fieldbus adapter B. For the selections, see parameter <i>50.04 FBA A ref1 type</i> . | <i>Speed or frequency</i> |
| <i>50.35</i> | <i>FBA B ref2 type</i> | Selects the type and scaling of reference 2 received from fieldbus adapter B. For the selections, see parameter <i>50.04 FBA A ref1 type</i> . | <i>Speed or frequency</i> |
| <i>50.37</i> | <i>FBA B actual 1 type</i> | Selects the type/source and scaling of actual value 1 transmitted to the fieldbus network through fieldbus adapter B. For the selections, see parameter <i>50.07 FBA A actual 1 type</i> . | <i>Speed or frequency</i> |
| <i>50.38</i> | <i>FBA B actual 2 type</i> | Selects the type/source and scaling of actual value 2 transmitted to the fieldbus network through fieldbus adapter B. For the selections, see parameter <i>50.07 FBA A actual 1 type</i> . | <i>Speed or frequency</i> |
| <i>50.39</i> | <i>FBA B SW transparent source</i> | Selects the source of the fieldbus status word when the fieldbus adapter is set to a transparent communication profile eg. by its configuration parameters (group <i>54 FBA B settings</i>). | <i>Not selected</i> |
| | Not selected | No source selected. | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------------|--|---------------------|
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 50.40 | <i>FBA B act1 transparent source</i> | When parameter <i>50.37 FBA B actual 1 type</i> is set to <i>Transparent</i> or <i>General</i> this parameter selects the source of actual value 1 transmitted to the fieldbus network through fieldbus adapter B. | <i>Not selected</i> |
| | Not selected | No source selected. | - |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 50.41 | <i>FBA B act2 transparent source</i> | When parameter <i>50.38 FBA B actual 2 type</i> is set to <i>Transparent</i> or <i>General</i> this parameter selects the source of actual value 2 transmitted to the fieldbus network through fieldbus adapter B. | <i>Not selected</i> |
| | Not selected | No source selected. | - |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 50.42 | <i>FBA B debug mode</i> | Enables the display of raw (unmodified) data received from and sent to fieldbus adapter B in parameters <i>50.43...50.48</i> . This functionality should only be used for debugging. | <i>Disable</i> |
| | Disable | Display of raw data from fieldbus adapter B disabled. | 0 |
| | Fast | Display of raw data from fieldbus adapter B enabled. | 1 |
| 50.43 | <i>FBA B control word</i> | Displays the raw (unmodified) control word sent by the master (PLC) to fieldbus adapter B if debugging is enabled by parameter <i>50.42 FBA B debug mode</i> . This parameter is read-only. | - |
| | 0000000h ...FFFFFFFh | Control word sent by master to fieldbus adapter B. | - |
| 50.44 | <i>FBA B reference 1</i> | Displays raw (unmodified) reference REF1 sent by the master (PLC) to fieldbus adapter B if debugging is enabled by parameter <i>50.42 FBA B debug mode</i> . This parameter is read-only. | - |
| | -2147483648 ...2147483647 | Raw REF1 sent by master to fieldbus adapter B. | - |
| 50.45 | <i>FBA B reference 2</i> | Displays raw (unmodified) reference REF2 sent by the master (PLC) to fieldbus adapter B if debugging is enabled by parameter <i>50.42 FBA B debug mode</i> . This parameter is read-only. | - |
| | -2147483648 ...2147483647 | Raw REF2 sent by master to fieldbus adapter B. | - |
| 50.46 | <i>FBA B status word</i> | Displays the raw (unmodified) status word sent by fieldbus adapter B to the master (PLC) if debugging is enabled by parameter <i>50.42 FBA B debug mode</i> . This parameter is read-only. | - |
| | 0000000h ...FFFFFFFh | Status word sent by fieldbus adapter B to master. | - |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | |
|--------------------------|------------------------------|---|----------------|---------------|---------------|-------------------|-------|------|---------------|------|-------|-------------|--------|------|------------------|--------|------|---------------|
| 50.47 | <i>FBA B actual value 1</i> | Displays raw (unmodified) actual value ACT1 sent by fieldbus adapter B to the master (PLC) if debugging is enabled by parameter <i>50.42 FBA B debug mode</i> . This parameter is read-only. | - | | | | | | | | | | | | | | | |
| | -2147483648 ...2147483647 | Raw ACT1 sent by fieldbus adapter B to master. | - | | | | | | | | | | | | | | | |
| 50.48 | <i>FBA B actual value 2</i> | Displays raw (unmodified) actual value ACT2 sent by fieldbus adapter B to the master (PLC) if debugging is enabled by parameter <i>50.42 FBA B debug mode</i> . This parameter is read-only. | - | | | | | | | | | | | | | | | |
| | -2147483648 ...2147483647 | Raw ACT2 sent by fieldbus adapter B to master. | - | | | | | | | | | | | | | | | |
| 50.51 | <i>FBA B timelevel sel</i> | <p>Selects the communication time levels.</p> <p>In general, lower time levels of read/write services reduce CPU load. The table below shows the time levels of the read/write services for cyclic high and cyclic low data with each parameter setting.</p> <table border="1" data-bbox="441 638 855 772"> <thead> <tr> <th>Selection</th> <th>Cyclic high *</th> <th>Cyclic low **</th> </tr> </thead> <tbody> <tr> <td><i>Monitoring</i></td> <td>10 ms</td> <td>2 ms</td> </tr> <tr> <td><i>Normal</i></td> <td>2 ms</td> <td>10 ms</td> </tr> <tr> <td><i>Fast</i></td> <td>500 µs</td> <td>2 ms</td> </tr> <tr> <td><i>Very fast</i></td> <td>250 µs</td> <td>2 ms</td> </tr> </tbody> </table> <p>* Cyclic high data consists of fieldbus Status word, Act1 and Act2.</p> <p>** Cyclic low data consists of the parameter data mapped to parameter groups <i>55 FBA B data in</i> and <i>56 FBA B data out</i>, and acyclic data.</p> <p>Control word, Ref1 and Ref2 are handled as interrupts generated on receipt of cyclic high messages.</p> | Selection | Cyclic high * | Cyclic low ** | <i>Monitoring</i> | 10 ms | 2 ms | <i>Normal</i> | 2 ms | 10 ms | <i>Fast</i> | 500 µs | 2 ms | <i>Very fast</i> | 250 µs | 2 ms | <i>Normal</i> |
| Selection | Cyclic high * | Cyclic low ** | | | | | | | | | | | | | | | | |
| <i>Monitoring</i> | 10 ms | 2 ms | | | | | | | | | | | | | | | | |
| <i>Normal</i> | 2 ms | 10 ms | | | | | | | | | | | | | | | | |
| <i>Fast</i> | 500 µs | 2 ms | | | | | | | | | | | | | | | | |
| <i>Very fast</i> | 250 µs | 2 ms | | | | | | | | | | | | | | | | |
| | Normal | Normal speed. | 0 | | | | | | | | | | | | | | | |
| | Fast | Fast speed. | 1 | | | | | | | | | | | | | | | |
| | Very fast | Very fast speed. | 2 | | | | | | | | | | | | | | | |
| | Monitoring | Low speed. Optimized for PC tool communication and monitoring usage. | 3 | | | | | | | | | | | | | | | |
| 51 FBA A settings | | Fieldbus adapter A configuration. | | | | | | | | | | | | | | | | |
| 51.01 | <i>FBA A type</i> | Displays the type of the connected fieldbus adapter module. 0 = Module is not found or is not properly connected, or is disabled by parameter <i>50.01 FBA A enable</i> ; 1 = FPBA; 32 = FCAN; 37 = FDNA; 101 = FCNA, 128 = FENA-11/21; 135 = FECA; 136 = FEPL; 485 = FSCA. This parameter is read-only. | - | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------|---|----------------|
| 51.02 | <i>FBA A Par2</i> | Parameters 51.02...51.26 are adapter module-specific. For more information, see the documentation of the fieldbus adapter module. Note that not all of these parameters are necessarily in use. | - |
| | 0...65535 | Fieldbus adapter configuration parameter. | 1 = 1 |
| | ... | ... | ... |
| 51.26 | <i>FBA A Par26</i> | See parameter 51.02 <i>FBA A Par2</i> . | - |
| | 0...65535 | Fieldbus adapter configuration parameter. | 1 = 1 |
| 51.27 | <i>FBA A par refresh</i> | Validates any changed fieldbus adapter module configuration settings. After refreshing, the value reverts automatically to <i>Done</i> . Note: This parameter cannot be changed while the drive is running. | <i>Done</i> |
| | Done | Refreshing done. | 0 |
| | Refresh | Refreshing. | 1 |
| 51.28 | <i>FBA A par table ver</i> | Displays the parameter table revision of the fieldbus adapter module mapping file (stored in the memory of the drive). In format axyz, where ax = major table revision number; yz = minor table revision number. This parameter is read-only. | - |
| | | Parameter table revision of adapter module. | - |
| 51.29 | <i>FBA A drive type code</i> | Displays the drive type code in the fieldbus adapter module mapping file (stored in the memory of the drive). This parameter is read-only. | - |
| | 0...65535 | Drive type code stored in the mapping file. | 1 = 1 |
| 51.30 | <i>FBA A mapping file ver</i> | Displays the fieldbus adapter module mapping file revision stored in the memory of the drive in decimal format. This parameter is read-only. | - |
| | 0...65535 | Mapping file revision. | 1 = 1 |
| 51.31 | <i>D2FBA A comm status</i> | Displays the status of the fieldbus adapter module communication. | - |
| | Not configured | Adapter is not configured. | 0 |
| | Initializing | Adapter is initializing. | 1 |
| | Time out | A timeout has occurred in the communication between the adapter and the drive. | 2 |
| | Configuration error | Adapter configuration error: mapping file not found in the file system of the drive, or mapping file upload has failed more than three times. | 3 |
| | Off-line | Fieldbus communication is off-line. | 4 |
| | On-line | Fieldbus communication is on-line, or fieldbus adapter has been configured not to detect a communication break. For more information, see the documentation of the fieldbus adapter. | 5 |
| | Reset | Adapter is performing a hardware reset. | 6 |

| No. | Name/Value | Description | Def/ FbEq16 |
|--------------------------|--------------------------|---|----------------|
| 51.32 | <i>FBA A comm SW ver</i> | Displays the patch and build versions of the adapter module firmware in format xxyy, where xx = patch version number, yy = build version number. Example: C802 = 200.02 (patch version 200, build version 2). | |
| | | Patch and build versions of adapter module firmware. | - |
| 51.33 | <i>FBA A appl SW ver</i> | Displays the major and minor versions of the adapter module firmware in format xyy, where x = major revision number, yy = minor revision number. Example: 300 = 3.00 (major version 3, minor version 00). | |
| | | Major and minor versions of adapter module firmware. | - |
| 52 FBA A data in | | Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter A. Note: 32-bit values require two consecutive parameters. Whenever a 32-bit value is selected in a data parameter, the next parameter is automatically reserved. | |
| 52.01 | <i>FBA A data in1</i> | Parameters 52.01 ... 52.12 select data to be transferred from the drive to the fieldbus controller through fieldbus adapter A. | <i>None</i> |
| | None | None. | 0 |
| | CW 16bit | Control Word (16 bits) | 1 |
| | Ref1 16bit | Reference REF1 (16 bits) | 2 |
| | Ref2 16bit | Reference REF2 (16 bits) | 3 |
| | SW 16bit | Status Word (16 bits) | 4 |
| | Act1 16bit | Actual value ACT1 (16 bits) | 5 |
| | Act2 16bit | Actual value ACT2 (16 bits) | 6 |
| | CW 32bit | Control Word (32 bits) | 11 |
| | Ref1 32bit | Reference REF1 (32 bits) | 12 |
| | Ref2 32bit | Reference REF2 (32 bits) | 13 |
| | SW 32bit | Status Word (32 bits) | 14 |
| | Act1 32bit | Actual value ACT1 (32 bits) | 15 |
| | Act2 32bit | Actual value ACT2 (32 bits) | 16 |
| | SW2 16bit | Status Word 2 (16 bits) | 24 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| ... | ... | ... | ... |
| 52.12 | <i>FBA A data in12</i> | See parameter 52.01 FBA A data in1 . | <i>None</i> |
| 53 FBA A data out | | Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter A. Note: 32-bit values require two consecutive parameters. Whenever a 32-bit value is selected in a data parameter, the next parameter is automatically reserved. | |
| 53.01 | <i>FBA A data out1</i> | Parameters 53.01 ... 53.12 select data to be transferred from the fieldbus controller to the drive through fieldbus adapter A. | <i>None</i> |
| | None | None. | 0 |




| No. | Name/Value | Description | Def/ FbEq16 |
|--------------------------|------------------------------|--|----------------|
| | CW 16bit | Control Word (16 bits) | 1 |
| | Ref1 16bit | Reference REF1 (16 bits) | 2 |
| | Ref2 16bit | Reference REF2 (16 bits) | 3 |
| | CW 32bit | Control Word (32 bits) | 11 |
| | Ref1 32bit | Reference REF1 (32 bits) | 12 |
| | Ref2 32bit | Reference REF2 (32 bits) | 13 |
| | CW2 16bit | Control Word 2 (16 bits) | 21 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| ... | ... | ... | ... |
| 53.12 | <i>FBA A data out12</i> | See parameter <i>53.01 FBA A data out1</i> . | <i>None</i> |
| 54 FBA B settings | | Fieldbus adapter B configuration. | |
| 54.01 | <i>FBA B type</i> | Displays the type of the connected fieldbus adapter module. 0 = Module is not found or is not properly connected, or is disabled by parameter <i>50.31 FBA B enable</i> ; 1 = FPBA; 32 = FCAN; 37 = FDNA; 101 = FCNA; 128 = FENA-11/21; 135 = FECA; 136 = FEPL; 485 = FSCA. This parameter is read-only. | - |
| 54.02 | <i>FBA B Par2</i> | Parameters <i>54.02...54.26</i> are adapter module-specific. For more information, see the documentation of the fieldbus adapter module. Note that not all of these parameters are necessarily in use. | - |
| | 0...65535 | Fieldbus adapter configuration parameter. | 1 = 1 |
| ... | ... | ... | ... |
| 54.26 | <i>FBA B Par26</i> | See parameter <i>54.02 FBA B Par2</i> . | - |
| | 0...65535 | Fieldbus adapter configuration parameter. | 1 = 1 |
| 54.27 | <i>FBA B par refresh</i> | Validates any changed fieldbus adapter module configuration settings. After refreshing, the value reverts automatically to <i>Done</i> . Note: This parameter cannot be changed while the drive is running. | <i>Done</i> |
| | Done | Refreshing done. | 0 |
| | Refresh | Refreshing. | 1 |
| 54.28 | <i>FBA B par table ver</i> | Displays the parameter table revision of the fieldbus adapter module mapping file (stored in the memory of the drive). In format axyz, where ax = major table revision number; yz = minor table revision number. This parameter is read-only. | - |
| | | Parameter table revision of adapter module. | - |
| 54.29 | <i>FBA B drive type code</i> | Displays the drive type code in the fieldbus adapter module mapping file (stored in the memory of the drive). This parameter is read-only. | - |
| | 0...65535 | Drive type code stored in the mapping file. | 1 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------------------------|-------------------------------|--|----------------|
| 54.30 | <i>FBA B mapping file ver</i> | Displays the fieldbus adapter module mapping file revision stored in the memory of the drive in decimal format. This parameter is read-only. | - |
| | 0...65535 | Mapping file revision. | 1 = 1 |
| 54.31 | <i>D2FBA B comm status</i> | Displays the status of the fieldbus adapter module communication. | - |
| | Not configured | Adapter is not configured. | 0 |
| | Initializing | Adapter is initializing. | 1 |
| | Time out | A timeout has occurred in the communication between the adapter and the drive. | 2 |
| | Configuration error | Adapter configuration error: mapping file not found in the file system of the drive, or mapping file upload has failed more than three times. | 3 |
| | Off-line | Fieldbus communication is off-line. | 4 |
| | On-line | Fieldbus communication is on-line, or fieldbus adapter has been configured not to detect a communication break. For more information, see the documentation of the fieldbus adapter. | 5 |
| | Reset | Adapter is performing a hardware reset. | 6 |
| 54.32 | <i>FBA B comm SW ver</i> | Displays the patch and build versions of the adapter module firmware in format xxyy, where xx = patch version number, yy = build version number. Example: C802 = 200.02 (patch version 200, build version 2). | |
| | | Patch and build versions of adapter module firmware. | - |
| 54.33 | <i>FBA B appl SW ver</i> | Displays the major and minor versions of the adapter module firmware in format xyy, where x = major revision number, yy = minor revision number. Example: 300 = 3.00 (major version 3, minor version 00). | |
| | | Major and minor versions of adapter module firmware. | - |
| 55 FBA B data in | | Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter B. | |
| 55.01 | <i>FBA B data in1</i> | Parameters 55.01...55.12 select data to be transferred from the drive to the fieldbus controller through fieldbus adapter B. | <i>None</i> |
| | None | None. | 0 |
| | CW 16bit | Control Word (16 bits) | 1 |
| | Ref1 16bit | Reference REF1 (16 bits) | 2 |
| | Ref2 16bit | Reference REF2 (16 bits) | 3 |
| | SW 16bit | Status Word (16 bits) | 4 |
| | Act1 16bit | Actual value ACT1 (16 bits) | 5 |
| | Act2 16bit | Actual value ACT2 (16 bits) | 6 |
| | CW 32bit | Control Word (32 bits) | 11 |
| | Ref1 32bit | Reference REF1 (32 bits) | 12 |
| | Ref2 32bit | Reference REF2 (32 bits) | 13 |
| | SW 32bit | Status Word (32 bits) | 14 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------------|-------------------------|--|----------------|
| | Act1 32bit | Actual value ACT1 (32 bits) | 15 |
| | Act2 32bit | Actual value ACT2 (32 bits) | 16 |
| | SW2 16bit | Status Word 2 (16 bits) | 24 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| ... | ... | ... | ... |
| 55.12 | <i>FBA B data in12</i> | See parameter 55.01 <i>FBA B data in1</i> . | <i>None</i> |
| 56 FBA B data out | | Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter B. | |
| 56.01 | <i>FBA B data out1</i> | Parameters 56.01...56.12 select data to be transferred from the fieldbus controller to the drive through fieldbus adapter B. | <i>None</i> |
| | None | None. | 0 |
| | CW 16bit | Control Word (16 bits) | 1 |
| | Ref1 16bit | Reference REF1 (16 bits) | 2 |
| | Ref2 16bit | Reference REF2 (16 bits) | 3 |
| | CW 32bit | Control Word (32 bits) | 11 |
| | Ref1 32bit | Reference REF1 (32 bits) | 12 |
| | Ref2 32bit | Reference REF2 (32 bits) | 13 |
| | CW2 16bit | Control Word 2 (16 bits) | 21 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| ... | ... | ... | ... |
| 56.12 | <i>FBA B data out12</i> | See parameter 56.01 <i>FBA B data out1</i> . | <i>None</i> |
| 58 Embedded fieldbus | | Configuration of the embedded fieldbus (EFB) interface. See also chapter <i>Fieldbus control through the embedded fieldbus interface (EFB)</i> (page 437). | |
| 58.01 | <i>Protocol enable</i> | Enables/disables the embedded fieldbus interface and selects the protocol to use. Note: When the embedded fieldbus interface is enabled, the drive-to-drive link functionality is automatically disabled | <i>None</i> |
| | None | None. | 0 |
| | Modbus RTU | Embedded fieldbus interface is enabled and uses the Modbus RTU protocol. | 1 |
| 58.02 | <i>Protocol ID</i> | Displays the protocol ID and revision. This parameter is read-only. | - |
| | | Protocol ID and revision. | 1 = 1 |
| 58.03 | <i>Node address</i> | Defines the node address of the drive on the fieldbus link. Values 1...247 are allowable. Two devices with the same address are not allowed on-line. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 <i>Communication control</i> . | 1 |
| | 0...255 | Node address (values 1...247 are allowable). | 1 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------|---------------------------------------|--|---------------------------|
| 58.04 | Baud rate | Selects the transfer rate of the fieldbus link. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control . | 19.2 kbps |
| | 9.6 kbps | 9.6 kbit/s. | 2 |
| | 19.2 kbps | 19.2 kbit/s. | 3 |
| | 38.4 kbps | 38.4 kbit/s. | 4 |
| | 57.6 kbps | 57.6 kbit/s. | 5 |
| | 76.8 kbps | 76.8 kbit/s. | 6 |
| | 115.2 kbps | 115.2 kbit/s. | 7 |
| 58.05 | Parity | Selects the type of parity bit and the number of stop bits. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control . | 8 EVEN 1 |
| | 8 NONE 1 | Eight data bits, no parity bit, one stop bit. | 0 |
| | 8 NONE 2 | Eight data bits, no parity bit, two stop bits. | 1 |
| | 8 EVEN 1 | Eight data bits, even parity bit, one stop bit. | 2 |
| | 8 ODD 1 | Eight data bits, odd parity bit, one stop bit. | 3 |
| 58.06 | Communication control | Validates any changes in the EFB settings, or activates silent mode. | Enabled |
| | Enabled | Normal operation. | 0 |
| | Refresh settings | Validates any changed EFB configuration settings. Reverts automatically to Enabled . | 1 |
| | Silent mode | Activates silent mode (no messages are transmitted). Silent mode can be terminated by activating the Refresh settings selection of this parameter. | 2 |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------|----------------------------------|---|----------------|------|-------------|---|-------------|-------------------------------|---|-----------------|--|---|-------------|--|---|-------------|----------|---|--------------|--|---|--------------|--|---|-----------------|--|---|-----------------|--|---|------------|--|---|---------------------------|---|----|-----------|--|----|-------------|---|----|------------|----------|----|------------|----------|----|------------|----------|----|----------------|----------|--|
| 58.07 | <i>Communication diagnostics</i> | Displays the status of the EFB communication. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Init failed</td> <td>1 = EFB initialization failed</td> </tr> <tr> <td>1</td> <td>Addr config err</td> <td>1 = Node address not allowed by protocol</td> </tr> <tr> <td>2</td> <td>Silent mode</td> <td>1 = Drive not allowed to transmit 0 = Drive allowed to transmit</td> </tr> <tr> <td>3</td> <td>Autobauding</td> <td>Reserved</td> </tr> <tr> <td>4</td> <td>Wiring error</td> <td>1 = Errors detected (A/B wires possibly swapped)</td> </tr> <tr> <td>5</td> <td>Parity error</td> <td>1 = Error detected: check parameters 58.04 and 58.05</td> </tr> <tr> <td>6</td> <td>Baud rate error</td> <td>1 = Error detected: check parameters 58.05 and 58.04</td> </tr> <tr> <td>7</td> <td>No bus activity</td> <td>1 = 0 bytes received during last 5 seconds</td> </tr> <tr> <td>8</td> <td>No packets</td> <td>1 = 0 packets (addressed to any device) detected during last 5 seconds</td> </tr> <tr> <td>9</td> <td>Noise or addressing error</td> <td>1 = Errors detected (interference, or another device with the same address on line)</td> </tr> <tr> <td>10</td> <td>Comm loss</td> <td>1 = 0 packets addressed to the drive received within timeout (58.16)</td> </tr> <tr> <td>11</td> <td>CW/Ref loss</td> <td>1 = No control word or references received within timeout (58.16)</td> </tr> <tr> <td>12</td> <td>Not active</td> <td>Reserved</td> </tr> <tr> <td>13</td> <td>Protocol 1</td> <td>Reserved</td> </tr> <tr> <td>14</td> <td>Protocol 2</td> <td>Reserved</td> </tr> <tr> <td>15</td> <td>Internal error</td> <td>Reserved</td> </tr> </tbody> </table> | Bit | Name | Description | 0 | Init failed | 1 = EFB initialization failed | 1 | Addr config err | 1 = Node address not allowed by protocol | 2 | Silent mode | 1 = Drive not allowed to transmit 0 = Drive allowed to transmit | 3 | Autobauding | Reserved | 4 | Wiring error | 1 = Errors detected (A/B wires possibly swapped) | 5 | Parity error | 1 = Error detected: check parameters 58.04 and 58.05 | 6 | Baud rate error | 1 = Error detected: check parameters 58.05 and 58.04 | 7 | No bus activity | 1 = 0 bytes received during last 5 seconds | 8 | No packets | 1 = 0 packets (addressed to any device) detected during last 5 seconds | 9 | Noise or addressing error | 1 = Errors detected (interference, or another device with the same address on line) | 10 | Comm loss | 1 = 0 packets addressed to the drive received within timeout (58.16) | 11 | CW/Ref loss | 1 = No control word or references received within timeout (58.16) | 12 | Not active | Reserved | 13 | Protocol 1 | Reserved | 14 | Protocol 2 | Reserved | 15 | Internal error | Reserved | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Init failed | 1 = EFB initialization failed | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Addr config err | 1 = Node address not allowed by protocol | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Silent mode | 1 = Drive not allowed to transmit 0 = Drive allowed to transmit | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Autobauding | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Wiring error | 1 = Errors detected (A/B wires possibly swapped) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Parity error | 1 = Error detected: check parameters 58.04 and 58.05 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Baud rate error | 1 = Error detected: check parameters 58.05 and 58.04 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | No bus activity | 1 = 0 bytes received during last 5 seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | No packets | 1 = 0 packets (addressed to any device) detected during last 5 seconds | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Noise or addressing error | 1 = Errors detected (interference, or another device with the same address on line) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Comm loss | 1 = 0 packets addressed to the drive received within timeout (58.16) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | CW/Ref loss | 1 = No control word or references received within timeout (58.16) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | Not active | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | Protocol 1 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | Protocol 2 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | Internal error | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | EFB communication status. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 58.08 | <i>Received packets</i> | Displays a count of valid packets addressed to the drive. During normal operation, this number increases constantly. Can be reset from the control panel by keeping Reset depressed for over 3 seconds. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0...4294967295 | Number of received packets addressed to the drive. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 58.09 | <i>Transmitted packets</i> | Displays a count of valid packets transmitted by the drive. During normal operation, this number increases constantly. Can be reset from the control panel by keeping Reset depressed for over 3 seconds. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0...4294967295 | Number of transmitted packets. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 58.10 | <i>All packets</i> | Displays a count of valid packets addressed to any device on the bus. During normal operation, this number increases constantly. Can be reset from the control panel by keeping Reset depressed for over 3 seconds. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0...4294967295 | Number of all received packets. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------------|--|-------------------------|
| 58.11 | <i>UART errors</i> | Displays a count of character errors received by the drive. An increasing count indicates a configuration problem on the bus. Can be reset from the control panel by keeping Reset depressed for over 3 seconds. | - |
| | 0...4294967295 | Number of UART errors. | 1 = 1 |
| 58.12 | <i>CRC errors</i> | Displays a count of packets with a CRC error received by the drive. An increasing count indicates interference on the bus. Can be reset from the control panel by keeping Reset depressed for over 3 seconds. | - |
| | 0...4294967295 | Number of CRC errors. | 1 = 1 |
| 58.14 | <i>Communication loss action</i> | Selects how the drive reacts to an EFB communication break. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control . See also parameters 58.15 Communication loss mode and 58.16 Communication loss time . | <i>Fault</i> |
| | No | No action taken (monitoring disabled). | 0 |
| | Fault | Drive trips on 6681 EFB comm loss . This only occurs if control is expected from the EFB (EFB selected as source of start/stop in the currently active location). | 1 |
| | Last speed | Drive generates an A7CE EFB comm loss warning and freezes the speed to the level the drive was operating at. This only occurs if control is expected from the EFB. The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 2 |
| | Speed ref safe | Drive generates an A7CE EFB comm loss warning and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). This only occurs if control is expected from the EFB.  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 3 |
| | Fault always | Drive trips on 6681 EFB comm loss . This occurs even though no control is expected from the EFB. | 4 |
| | Warning | Drive generates an A7CE EFB comm loss warning. This occurs even though no control is expected from the EFB.  WARNING! Make sure that it is safe to continue operation in case of a communication break. | 5 |
| 58.15 | <i>Communication loss mode</i> | Defines which message types reset the timeout counter for detecting an EFB communication loss. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control . See also parameters 58.14 Communication loss action and 58.16 Communication loss time . | <i>Cw / Ref1 / Ref2</i> |
| | Any message | Any message addressed to the drive resets the timeout. | 1 |



| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | |
|------------------------------------|--------------------------------|---|------------------------------------|----------------|---------|---------------|--------------|----------------------------|----------------|-------------------|------------------|--------------------------------|--|
| | Cw / Ref1 / Ref2 | A write of the control word or a reference from the fieldbus resets the timeout. | 2 | | | | | | | | | | |
| 58.16 | <i>Communication loss time</i> | Sets a timeout for EFB communication. If a communication break lasts longer than the timeout, the action specified by parameter <i>58.14 Communication loss action</i> is taken. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter <i>58.06 Communication control</i> . See also parameter <i>58.15 Communication loss mode</i> . | 3.0 s | | | | | | | | | | |
| | 0.0 ... 6000.0 s | EFB communication timeout. | 1 = 1 | | | | | | | | | | |
| 58.17 | <i>Transmit delay</i> | Defines a minimum response delay in addition to any fixed delay imposed by the protocol. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter <i>58.06 Communication control</i> . | 0 ms | | | | | | | | | | |
| | 0...65535 ms | Minimum response delay. | 1 = 1 | | | | | | | | | | |
| 58.18 | <i>EFB control word</i> | Displays the raw (unmodified) control word sent by the Modbus controller to the drive. For debugging purposes. This parameter is read-only. | - | | | | | | | | | | |
| | 0000h...FFFFh | Control word sent by Modbus controller to the drive. | 1 = 1 | | | | | | | | | | |
| 58.19 | <i>EFB status word</i> | Displays the raw (unmodified) status word sent by the drive to the Modbus controller. For debugging purposes. This parameter is read-only. | - | | | | | | | | | | |
| | 0000h...FFFFh | Status word sent by the drive to the Modbus controller. | 1 = 1 | | | | | | | | | | |
| 58.25 | <i>Control profile</i> | Defines the control profile used by the protocol. | <i>ABB Drives</i> | | | | | | | | | | |
| | ABB Drives | ABB Drives profile (with a 16-bit control word) with registers in the classic format for backward compatibility. | 0 | | | | | | | | | | |
| | Transparent | Transparent profile (16-bit or 32-bit control word) with registers in the classic format. | 2 | | | | | | | | | | |
| 58.26 | <i>EFB ref1 type</i> | Selects the type and scaling of reference 1 received through the embedded fieldbus interface. The scaled reference is displayed by <i>03.09 EFB reference 1</i> . | <i>Speed or frequency</i> | | | | | | | | | | |
| | Speed or frequency | Type and scaling is chosen automatically according to the currently active operation mode as follows: | 0 | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Operation mode (see par. 19.01)</th> <th>Reference type</th> <th>Scaling</th> </tr> </thead> <tbody> <tr> <td>Speed control</td> <td rowspan="2"><i>Speed</i></td> <td rowspan="2"><i>46.01 Speed scaling</i></td> </tr> <tr> <td>Torque control</td> </tr> <tr> <td>Frequency control</td> <td><i>Frequency</i></td> <td><i>46.02 Frequency scaling</i></td> </tr> </tbody> </table> | Operation mode (see par. 19.01) | Reference type | Scaling | Speed control | <i>Speed</i> | <i>46.01 Speed scaling</i> | Torque control | Frequency control | <i>Frequency</i> | <i>46.02 Frequency scaling</i> | |
| Operation mode (see par. 19.01) | Reference type | Scaling | | | | | | | | | | | |
| Speed control | <i>Speed</i> | <i>46.01 Speed scaling</i> | | | | | | | | | | | |
| Torque control | | | | | | | | | | | | | |
| Frequency control | <i>Frequency</i> | <i>46.02 Frequency scaling</i> | | | | | | | | | | | |
| | Transparent | No scaling is applied. | 1 | | | | | | | | | | |
| | General | Generic reference with a specific scaling of 100 = 1 ((ie. integer and two decimals). | 2 | | | | | | | | | | |
| | Torque | The scaling is defined by parameter <i>46.03 Torque scaling</i> . | 3 | | | | | | | | | | |
| | Speed | The scaling is defined by parameter <i>46.01 Speed scaling</i> . | 4 | | | | | | | | | | |
| | Frequency | The scaling is defined by parameter <i>46.02 Frequency scaling</i> . | 5 | | | | | | | | | | |


| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | |
|---|--|---|---|---------------------------|---------|---------------|--|-------------------------------------|----------------|--|--|-------------------|--|---|--|
| 58.27 | <i>EFB ref2 type</i> | Selects the type and scaling of reference 2 received through the embedded fieldbus interface. The scaled reference is displayed by 03.10 EFB reference 2 . For the selections, see parameter 58.26 EFB ref1 type . | <i>Torque</i> | | | | | | | | | | | | |
| 58.28 | <i>EFB act1 type</i> | Selects the type of actual value 1. | <i>Speed or frequency</i> | | | | | | | | | | | | |
| | Speed or frequency | Type/source and scaling are chosen automatically according to the currently active operation mode as follows: | 0 | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Operation mode (see par. 19.01)</th> <th>Actual 1 type (source)</th> <th>Scaling</th> </tr> </thead> <tbody> <tr> <td>Speed control</td> <td><i>Speed</i> (01.01 Motor speed used)</td> <td>46.01 Speed scaling</td> </tr> <tr> <td>Torque control</td> <td></td> <td></td> </tr> <tr> <td>Frequency control</td> <td><i>Frequency</i> (01.06 Output frequency)</td> <td>46.02 Frequency scaling</td> </tr> </tbody> </table> | Operation mode (see par. 19.01) | Actual 1 type (source) | Scaling | Speed control | <i>Speed</i> (01.01 Motor speed used) | 46.01 Speed scaling | Torque control | | | Frequency control | <i>Frequency</i> (01.06 Output frequency) | 46.02 Frequency scaling | |
| Operation mode (see par. 19.01) | Actual 1 type (source) | Scaling | | | | | | | | | | | | | |
| Speed control | <i>Speed</i> (01.01 Motor speed used) | 46.01 Speed scaling | | | | | | | | | | | | | |
| Torque control | | | | | | | | | | | | | | | |
| Frequency control | <i>Frequency</i> (01.06 Output frequency) | 46.02 Frequency scaling | | | | | | | | | | | | | |
| | Transparent | The value selected by parameter 58.31 EFB act1 transparent source is sent as actual value 1. No scaling is applied (the 16-bit scaling is 1 = 1 unit). | 1 | | | | | | | | | | | | |
| | General | The value selected by parameter 58.31 EFB act1 transparent source is sent as actual value 1 with a 16-bit scaling of 100 = 1 unit (ie. integer and two decimals). | 2 | | | | | | | | | | | | |
| | Torque | 01.10 Motor torque is sent as actual value 1. The scaling is defined by parameter 46.03 . | 3 | | | | | | | | | | | | |
| | Speed | 01.01 Motor speed used is sent as actual value 1. The scaling is defined by parameter 46.01 Speed scaling . | 4 | | | | | | | | | | | | |
| | Frequency | 01.06 Output frequency is sent as actual value 1. The scaling is defined by parameter 46.02 Frequency scaling . | 5 | | | | | | | | | | | | |
| | Position | Motor position is sent as actual value 1. See parameter 90.06 Motor position scaled . | 6 | | | | | | | | | | | | |
| 58.29 | <i>EFB act2 type</i> | Selects the type of actual value 2. For the selections, see parameter 58.28 EFB act1 type . | <i>Torque</i> | | | | | | | | | | | | |
| 58.30 | <i>EFB status word transparent source</i> | Selects the source of the status word when 58.25 Control profile is set to <i>Transparent</i> . | <i>Not selected</i> | | | | | | | | | | | | |
| | Not selected | None. | 0 | | | | | | | | | | | | |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - | | | | | | | | | | | | |
| 58.31 | <i>EFB act1 transparent source</i> | Selects the source of actual value 1 when 58.28 EFB act1 type is set to <i>Transparent</i> or <i>General</i> . | <i>Not selected</i> | | | | | | | | | | | | |
| | Not selected | None. | 0 | | | | | | | | | | | | |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - | | | | | | | | | | | | |
| 58.32 | <i>EFB act2 transparent source</i> | Selects the source of actual value 1 when 58.29 EFB act2 type is set to <i>Transparent</i> or <i>General</i> . | <i>Not selected</i> | | | | | | | | | | | | |
| | Not selected | None. | 0 | | | | | | | | | | | | |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|--------|-----------------|--|----------------|
| 58.33 | Addressing mode | Defines the mapping between parameters and holding registers in the 400101...465535 Modbus register range. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control . | Mode 0 |
| | Mode 0 | 16-bit values (groups 1...99, indexes 1...99): Register address = 400000 + 100 × parameter group + parameter index. For example, parameter 22.80 would be mapped to register 400000 + 2200 + 80 = 402280. 32-bit values (groups 1...99, indexes 1...99): Register address = 420000 + 200 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 420000 + 4400 + 160 = 424560. | 0 |
| | Mode 1 | 16-bit values (groups 1...255, indexes 1...255): Register address = 400000 + 256 × parameter group + parameter index. For example, parameter 22.80 would be mapped to register 400000 + 5632 + 80 = 405712. | 1 |
| | Mode 2 | 32-bit values (groups 1...127, indexes 1...255): Register address = 400000 + 512 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 400000 + 11264 + 160 = 411424. | 2 |
| 58.34 | Word order | Selects in which order 16-bit registers of 32-bit parameters are transferred. For each register, the first byte contains the high order byte and the second byte contains the low order byte. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control . | LO-HI |
| | HI-LO | The first register contains the high order word, the second contains the low order word. | 0 |
| | LO-HI | The first register contains the low order word, the second contains the high order word. | 1 |
| 58.101 | Data I/O 1 | Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400001. The master defines the type of the data (input or output). The value is transmitted in a Modbus frame consisting of two 16-bit words. If the value is 16-bit, it is transmitted in the LSW (least significant word). If the value is 32-bit, the subsequent parameter is also reserved for it and must be set to <i>None</i> . | CW 16bit |
| | None | None. | 0 |
| | CW 16bit | Control Word (16 bits). | 1 |
| | Ref1 16bit | Reference REF1 (16 bits). | 2 |
| | Ref2 16bit | Reference REF2 (16 bits). | 3 |
| | SW 16bit | Status Word (16 bits). | 4 |
| | Act1 16bit | Actual value ACT1 (16 bits). | 5 |
| | Act2 16bit | Actual value ACT2 (16 bits). | 6 |
| | CW 32bit | Control Word (32 bits). | 11 |
| | Ref1 32bit | Reference REF1 (32 bits). | 12 |
| | Ref2 32bit | Reference REF2 (32 bits). | 13 |

| No. | Name/Value | Description | Def/ FbEq16 |
|------------------------|-----------------------------|---|----------------------------|
| | SW 32bit | Status Word (32 bits). | 14 |
| | Act1 32bit | Actual value ACT1 (32 bits). | 15 |
| | Act2 32bit | Actual value ACT2 (32 bits). | 16 |
| | CW2 16bit | Control Word 2 (16 bits). When a 32-bit control word is used, this setting means the most-significant 16 bits. | 21 |
| | SW2 16bit | Status Word 2 (16 bits). When a 32-bit control word is used, this setting means the most-significant 16 bits. | 24 |
| | RO/DIO control word | Parameter 10.99 RO/DIO control word . | 31 |
| | AO1 data storage | Parameter 13.91 AO1 data storage . | 32 |
| | AO2 data storage | Parameter 13.92 AO2 data storage . | 33 |
| | Feedback data storage | Parameter 40.91 Feedback data storage. | 40 |
| | Setpoint data storage | Parameter 40.92 Setpoint data storage. | 41 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 58.102 | Data I/O 2 | Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400002. For the selections, see parameter 58.101 Data I/O 1 . | Ref1 16bit |
| 58.103 | Data I/O 3 | Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400003. For the selections, see parameter 58.101 Data I/O 1 . | Ref2 16bit |
| 58.104 | Data I/O 4 | Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400004. For the selections, see parameter 58.101 Data I/O 1 . | SW 16bit |
| 58.105 | Data I/O 5 | Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400005. For the selections, see parameter 58.101 Data I/O 1 . | Act1 16bit |
| 58.106 | Data I/O 6 | Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400006. For the selections, see parameter 58.101 Data I/O 1 . | Act2 16bit |
| 58.107 | Data I/O 7 | Parameter selector for Modbus register address 400007. For the selections, see parameter 58.101 Data I/O 1 . | None |
| ... | ... | ... | ... |
| 58.124 | Data I/O 24 | Parameter selector for Modbus register address 400024. For the selections, see parameter 58.101 Data I/O 1 . | None |
| 74 Pump setup | | Basic functions of applications. | |
| 74.01 | Pump enable | Enables the pump functions related to parameters in group 74 to 79. | Enable |
| | Disable | Disables pump function. | 0 |
| | Enable | Enables pump function. | 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|--------------|---|--|--------------------|
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 5 |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 6 |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status , bit 0). | 8 |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status , bit 1). | 9 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 74.02 | <i>Run-time hours reset source</i> | Defines the command source used to reset the run-time hour counter (09.07 Run-time hours) of the pump. | <i>No</i> |
| | No | Run-time hours reset disabled. | 0 |
| | Yes | Run-time hours reset enabled. | 1 |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 |
| | DI3 | Digital input DI3 (10.02 DI delayed status , bit 2). | 4 |
| | DI4 | Digital input DI4 (10.02 DI delayed status , bit 3). | 5 |
| | DI5 | Digital input DI5 (10.02 DI delayed status , bit 4). | 6 |
| | DI6 | Digital input DI6 (10.02 DI delayed status , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (11.02 DIO delayed status , bit 0). | 8 |
| | DIO2 | Digital input/output DIO2 (11.02 DIO delayed status , bit 1). | 9 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on 101). | - |
| 74.03 | <i>Gear reduction ratio</i> | Defines the transmission reduction ratio for PCP application. Note: This feature is not available for ESP. | 1.000 |
| | 1.000...1000.000 | Value range. | 1000 = 1 |
| 74.04 | <i>Speed ref type</i> | Selects the reference type between motor speed or pump speed. Note: Not applicable for ESP. | <i>Pump speed</i> |
| | Pump speed | Speed reference of the pump. | 0 |
| | Motor speed | Speed reference of the motor. | 1 |
| 74.05 | <i>Speed ref source</i> | Selects the source for the speed reference. | <i>All1 scaled</i> |
| | Zero | Source not selected. | 0 |
| | All1 scaled | 12.12 All1 scaled value (see page 141). | 1 |
| | All2 scaled | 12.22 All2 scaled value (see page 141). | 2 |
| | FBA1 ref | Fieldbus adapter A reference1. | 3 |
| | FBA2 ref | Fieldbus adapter A reference2. | 4 |
| | EFB1 ref | Embedded fieldbus reference 1. | |
| | EFB2 ref | Embedded fieldbus reference 2. | |
| | Motor potentiometer ref | 22.80 Motor potentiometer ref act (output of the motor potentiometer) | 5 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------|---|---|---------------------------|
| | Constant ref | Constant speed reference. See par. 74.06 . | 6 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on 101). | - |
| 74.06 | Speed ref | Sets the speed reference for parameter 74.05 Speed ref source , if set as Constant ref . | 0.00 Prpm, rpm or Hz |
| | 0.00...30000.00 Prpm | Speed reference. | 10 = 1 Prpm, rpm or Hz |
| 74.07 | Minimum rod speed | Defines the minimum allowed rod/pump speed.  WARNING! This value must not be higher than 74.06 Speed ref Note: Operational units for PCP is Prpm and for ESP is Hz. | 0.00 Prpm, rpm or Hz |
| | -10000.00 ...10000.00 Prpm | Minimum rod speed. | 10 = 1 Prpm, rpm or Hz |
| 74.08 | Maximum rod speed | Defines the maximum allowed rod/pump speed.  WARNING! This value must not be lower than 74.07 Minimum rod speed . Note: Operational unit for PCP and ESP is rpm and Hz respectively. | 0.00 Prpm, rpm or Hz |
| | -10000.00 ...10000.00 Prpm | Maximum rod speed. | 10 = 1 Prpm, rpm or Hz |
| 74.10 | Rod acc time | Defines the acceleration time for the rod/pump: from zero to 74.08 Maximum rod speed . | 20.000 s |
| | 0.000...10000.000 s | Rod acceleration time. | 10 = 1 s |
| 74.11 | Rod dec time | Defines the deceleration time for the rod/pump: from 74.08 Maximum rod speed to zero speed. | 20.000 s |
| | 0.000...10000.000 s | Rod acceleration time. | 10 = 1 s |
| 74.12 | Starting speed enable | Enables the pump starting speed function. See section Pump starting speed on page 33 . | Disable |
| | Disable | Disables pump ramp up. | 0 |
| | Enable | Enables pump ramp up. | 1 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 74.13 | Starting speed | Defines the starting speed. See section Pump starting speed on page 33 . | 0.00 Prpm, rpm or Hz |
| | -10000.00... 10000.00 Prpm | Pump starting speed. | 10 = 1 Prpm, rpm or Hz |
| 74.14 | Starting speed acc time | Defines the acceleration time for the Pump starting speed function. See section Pump starting speed on page 33 . | 0.000 s |
| | 0.0000 ...10000.000 s | Pump starting speed acceleration time. | 10 = 1 s |
| 74.15 | Starting speed time delay | Defines the delay time for the Pump starting speed function. After this delay, start up procedure ends and the function releases control over speed reference. | 0.000 s |
| | 0.0000 ...10000.000 s | Starting speed delay time. | 10 = 1 s |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------------|---|------------------------|
| 74.18 | <i>Minimum rod torq ref</i> | <p>Defines minimum allowed torque reference for PCP.</p> <p> WARNING! Default = 0 is recommended for safety purpose to avoid unexpected backward rotation and rod damages.</p> <p>Note: Not applicable for ESP.</p> | 0.00 N•m or lbft |
| | -10000.00...0.00 N•m | Minimum rod torque reference. | 10 = 1 N•m or lbft |
| 74.19 | <i>Maximum rod torq ref</i> | <p>Defines maximum allowed torque reference for PCP.</p> <p>Note: Not applicable for ESP.</p> | 0.00 N•m or lbft |
| | 0.00...10000.00 N•m | Maximum rod torque reference. | 10 = 1 N•m or lbft |
| 74.21 | <i>Brake confirmation enable</i> | Enables the Brake confirmation function or selects the source for the enable signal. See section <i>Pump backspin control</i> on page 47. | Disable |
| | Disable | Disables brake confirmation function. | 0 |
| | Enable | Enables brake confirmation function. | 1 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 74.22 | <i>Brake confirmation source</i> | <p>Selects the source of the actual signal used in the Brake confirmation function. The analog signal feedback from the brake device is compared to <i>74.23 Brake confirmation limit</i>.</p> <p>If the actual value is below the limit longer than <i>74.25 Brake confirmation time</i>, the function controls the mechanical brake on. See also section <i>Pump backspin control</i> on page 47.</p> | Disable |
| | Zero | Source not selected. | 0 |
| | AI1 scaled | <i>12.12 AI1 scaled value</i> (see page 141). | 1 |
| | AI2 scaled | <i>12.22 AI2 scaled value</i> (see page 143). | 2 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 74.23 | <i>Brake confirmation limit</i> | Defines the limit in percentage of range selected by analog input source in parameter <i>74.22 Brake confirmation source</i> . | 0.00% |
| | 0.00...100.00% | Brake confirmation limit. | 100 = 1% |
| 74.24 | <i>Brake confirmation speed</i> | Defines the reference value used in the Brake confirmation function. See parameter <i>74.22 Brake confirmation source</i> . | 0.00 Prpm, rpm or Hz |
| | -500.00...0.00 Prpm | Reference speed. | 10 = 1 Prpm, rpm or Hz |
| 74.25 | <i>Brake confirmation time</i> | Defines the time limit for the Brake confirmation function. See parameter <i>74.22 Brake confirmation source</i> . | 0.000 s |
| | 0.000...30.000 s | Brake confirmation time. | 10 = 1 s |
| 74.26 | <i>Pressure unit selection</i> | Selects the unit to display for pressure related values on the keypad. | kPa |
| | kPa | kPa | 0 |
| | psi | psi | 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|------------------------------|------------------------------------|---|------------------------|
| 74.27 | <i>Depth unit selection</i> | Selects the unit to display for depth related values on the keypad. | m |
| | m | Meters | 0 |
| | ft | Feet | 1 |
| | Joints | Joints | 2 |
| 75 Pump level control | | Pump level control function. | |
| 75.01 | <i>Level control enable</i> | Enables Pump level control function. See section <i>Pump level control</i> on page 34. | Disable |
| | Disable | Disables Pump level control function. | 0 |
| | Enable | Enables Pump level control function. | 1 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 75.02 | <i>Fluid level ref</i> | Defines the fluid level set point for the Pump level control function. | 0.00 m, ft or Joints |
| | 0.00...100000.00 m | Reference | 10 = 1 m, ft or Joints |
| 75.03 | <i>Fluid level source function</i> | Selects a mathematical function between the feedback sources selected by parameters 75.04 <i>Fluid level source 1</i> and 75.05 <i>Fluid level source 2</i> . | Source1 |
| | Source1 | See parameter 75.04 | 0 |
| | Source2 | See parameter 75.05 | 1 |
| | Source1 + Source2 | Sum of sources 1 and 2 | 2 |
| | Source1 - Source2 | Source 2 subtracted from source 1 | 3 |
| | Source1 x Source2 | Source 1 multiplied by source 2 | 4 |
| | Source1/Source2 | Source 1 divided by source 2 | 5 |
| 75.04 | <i>Fluid level source 1</i> | Defines source 1 for parameter 75.03 <i>Fluid level source function</i> . | Zero |
| | Zero | Source not selected | 0 |
| | AI1 scaled | 12.12 AI1 scaled value (see page 141) | 1 |
| | AI2 scaled | 12.22 AI2 scaled value (see page 143) | 2 |
| | FBA1 ref | Fieldbus adapter A reference1 | 3 |
| | FBA2 ref | Fieldbus adapter A reference2 | 4 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101) | - |
| 75.05 | <i>Fluid level source 2</i> | Defines source 2 for parameter 75.03 <i>Fluid level source function</i> . | Zero |
| | Zero | Source not selected | 0 |
| | AI1 scaled | 12.12 AI1 scaled value (see page 141) | 1 |
| | AI2 scaled | 12.22 AI2 scaled value (see page 143) | 2 |
| | FBA1 ref | Fieldbus adapter A reference1 | 3 |
| | FBA2 ref | Fieldbus adapter A reference2 | 4 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101) | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-----------------------------|---|------------------------|
| 75.06 | <i>Level meas range</i> | Defines the measuring range for the Pump level control function. | 0.00 m, ft or Joints |
| | 0.00...100000.00 m | Measuring range | 10 = 1 m, ft or Joints |
| 75.07 | <i>Fluid level p-gain</i> | Defines the gain for the Pump level control function. Note: This value should be kept low to avoid unwanted oscillation from the drive speed reference causing the pump to cycle up and down in rpm. | 0.00 |
| | 0.00...5.00 | Proportional gain | 100 = 1 |
| 75.08 | <i>Fluid level i-time</i> | Defines the integration time for the Pump level control function. Note: This value should be kept at a fairly large value to avoid unwanted oscillation from the drive speed reference causing the pump to cycle up and down in rpm. | 0.000 s |
| | 0.000...3600.000 s | Integration time | 10 = 1 s |
| 75.09 | <i>Level control invert</i> | Selects the reaction characteristics of the Pump level control function. | Disable |
| | Disable | When the feedback signal selected by 75.03 Fluid level source 1 is less than 75.02 Fluid level ref , the PI regulator output increases, causing the speed reference to increase. | 0 |
| | Enable | When the feedback signal selected by 75.03 Fluid level source 1 is greater than 75.02 Fluid level ref , the PI regulator output increases, causing the speed reference to increase. | 1 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 75.10 | <i>Sleep control enable</i> | Enables the Sleep and wake up function. See section Sleep and wake up function on page 35. | Disable |
| | Disable | Disables sleep and wake up control function. | 0 |
| | Enable | Enables sleep and wake up control function. | 1 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101) | - |
| 75.11 | <i>Sleep warning enable</i> | Enables the warning for the Sleep and wake up function. See section Sleep and wake up function on page 35. | Disable |
| | Disable | Disables sleep and wake up warning. | 0 |
| | Enable | Enables sleep and wake up warning. | 1 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101) | - |
| 75.12 | <i>Sleep limit type</i> | Selects the sleep function type: sleep at low limit or sleep at high limit. | Low limit |
| | Low limit | If 75.10 Sleep control enable is enabled and 75.14 Sleep signal source 1 is less than or equal to 75.16 Sleep level and the condition is true longer than the time 75.08 Fluid level i-time , the pump will shut down. The Sleep function is active until 75.14 Sleep signal source 1 increases to a level greater than or equal to 75.18 Wakeup level . See section Sleep and wake up function on page 35. | 0 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------|--|---|-----------------------|
| | High limit | If 75.14 Sleep signal source 1 is greater than or equal to 75.16 Sleep level and the condition is true longer than time 75.08 Fluid level i-time , the pump will shut down. The Sleep function is active until 75.14 Sleep signal source 1 increases to a level less than or equal to 75.18 Wakeup level . See section Sleep and wake up function on page 35. | 1 |
| 75.13 | Sleep signal source function | Selects a mathematical function between the feedback sources selected by parameters 75.14 Sleep signal source 1 and 75.15 Sleep signal source 2 . | Source 1 |
| | Source1 | See parameter 75.14 . | 0 |
| | Source2 | See parameter 75.15 . | 1 |
| | Source1 + Source2 | Sum of sources 1 and 2. | 2 |
| | Source1 - Source2 | Source 2 subtracted from source 1. | 3 |
| | Source1 x Source2 | Source 1 multiplied by source 2. | 4 |
| | Source1 / Source2 | Source 1 divided by source 2. | 5 |
| 75.14 | Sleep signal source 1 | Defines the source 1 signal monitored for activation of sleep function. | Zero |
| | Zero | Zero | 0 |
| | AI1 scaled | 12.12 AI1 scaled value (see page 141) | 1 |
| | AI2 scaled | 12.22 AI2 scaled value (see page 143) | 2 |
| | FBA1 ref | Fieldbus adapter A reference1 | 3 |
| | FBA2 ref | Fieldbus adapter A reference2 | 4 |
| | Rod speed | Actual rod speed | 5 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101) | - |
| 75.15 | Sleep signal source 2 | Defines the source 2 signal monitored for activation of sleep function. | Zero |
| | Zero | Zero | 0 |
| | AI1 scaled | 12.12 AI1 scaled value (see page 141). | 1 |
| | AI2 scaled | 12.22 AI2 scaled value (see page 143). | 2 |
| | FBA1 ref | Fieldbus adapter A reference1 | 3 |
| | FBA2 ref | Fieldbus adapter A reference2 | 4 |
| | Rod speed | Actual rod speed | 5 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 75.16 | Sleep level | Defines the set point for activation of sleep function. The set point percentage of range selected by analog input source in parameter 75.14 Sleep signal source 1 or 75.15 Sleep signal source 2 . See section Sleep and wake up function on page 35. Note: The Wakeup level has higher priority than the Sleep level. | 0.00 SourceUnit |
| | 0.00...100000000.00 SourceUnit | Sleep level. | 100 = 1 SourceUnit |

| No. | Name/Value | Description | Def/ FbEq16 |
|------------------------------------|---------------------------------------|---|-----------------------|
| 75.17 | <i>Sleep delay time</i> | Defines the time period required to verify Sleep condition. | 0.000 s |
| | 0.000...10000.000 s | Sleep delay time. | 10 = 1 s |
| 75.18 | <i>Wakeup level</i> | Defines the set point for the deactivation of sleep function. The set point percentage of range selected by analog input source in parameter 75.14 Sleep signal source 1 or 75.15 Sleep signal source 2 . Note: The Wakeup level has higher priority than the Sleep level. | 0.00 SourceUnit |
| | 0.00...100000000.00 SourceUnit | Wakeup level. | 100 = 1 SourceUnit |
| 75.19 | <i>Wakeup delay time</i> | Defines the time period required for verifying Wakeup condition. | 0.000 s |
| | 0.000...10000.000 s | Wakeup delay time. | 10 = 1 s |
| 75.20 | <i>Maximum sleep time</i> | Maximum period of time allowed for pump to stay in sleep mode. Note: To disable this function set parameter value to 0.000. | 0.000 s |
| | 0.000...100000.000 s | Value range | 10 = 1 s |
| 76 Pump pressure protection | | Pump pressure protection function. | |
| 76.01 | <i>Pressure protection function</i> | Enables Pump pressure protection function. See section Pump pressure protection on page 40. | Disable |
| | Disable | Disables Pump pressure protection function. | 0 |
| | Enable | Enables Pump pressure protection function. | 1 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 76.02 | <i>Pressure protection latching</i> | Defines the latching type for pump pressure protection. | Non latching |
| | Non latching | A high pressure or high discharge pressure activates the warning message that is displayed as long as the high pressure condition is active. If the high pressure condition is missing, the pump regains a normal run condition. If the shutdown process finishes and the pump shuts off and the high pressure condition is missing, the pump starts automatically if a valid start command is present. | 0 |
| | Latching | The main difference from "Non latching" function is the pump trips on a fault and does not start automatically even if a valid start command is present. A fault reset is required to start the pump. | 1 |
| | Latch zero speed | Until the speed is above zero, the pump is in the "Non latching" type and after the speed reaches zero the pump is in the "Latching" type function. | 2 |
| 76.03 | <i>Digital feedback source enable</i> | Enables the source of digital feedback for high pressure protection. | FALSE |
| | FALSE | Disables digital feedback. | 0 |
| | TRUE | Enables digital feedback. | 1 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|----------------------------------|---|--|-------------------|
| 76.04 | Digital feedback source | Selects the source of digital feedback for high pressure protection. | FALSE |
| | FALSE | High pressure condition detected. | 0 |
| | TRUE | No high pressure condition. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 8 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 0). | 9 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 76.05 | Analog feedback source enable | Enables the source of analog feedback for high pressure protection. | FALSE |
| | FALSE | Disables analog feedback. | 0 |
| | TRUE | Enables digital feedback. | 1 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 76.06 | Analog feedback source | Selects the source of analog feedback for high pressure protection. | Zero |
| | Zero | Zero | 0 |
| | AI1 scaled | <i>12.12 AI1 scaled value</i> (see page 141). | 1 |
| | AI2 scaled | <i>12.22 AI2 scaled value</i> (see page 143). | 2 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 76.07 | Analog feedback limit | Defines the analog feedback limit. If the feedback is above this limit, a fault or warning is indicated. | 0.00 kPa or psi |
| | 0.00...10000.00 Kpa | Analog feedback limit. | 10 = 1 kPa or psi |
| 76.08 | Analog feedback limit delay time | Defines the time period required to verify the analog feedback limit. | 0.000 s |
| | 0.000...3600.000 s | Analog feedback limit delay time. | 10 = 1 s |
| 77 Pump torque protection | | Pump torque protection function. | |
| 77.01 | Rod torq limit display | Selects the rod protection measurement as torque or current. See <i>Pump torque protection</i> , page 41. | Torque |
| | Torque | Rod torque value for rod torque protection. See parameters <i>77.04 Rod torq1 limit</i> and <i>77.09 Rod torq2 limit</i> . | 0 |
| | Current | Motor current value for rod current protection. See parameters <i>77.04 Rod torq1 limit</i> and <i>77.09 Rod torq2 limit</i> . | 1 |

312 Parameters


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-----------------------------|---|------------------------|
| 77.02 | <i>Rod torq1 function</i> | Enables the Rod torque 1 function for pump torque protection. | Disable |
| | Disable | Disables the Rod torque 1 function. | 0 |
| | Enable | Enables the Rod torque 1 function. | 1 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 77.03 | <i>Rod torq1 limit type</i> | Selects the Rod torque 1 limit type of the fault condition in <i>77.04 Rod torq1 limit</i> . Note: A warning is displayed during the shutdown process. | Low limit |
| | Low limit | The control program triggers the Torque pressure protection function when <i>09.01 Rod torque</i> is less than or equal to <i>77.04 Rod torq1 limit</i> and <i>09.05 Rod speed</i> is less than or equal to <i>77.05 Rod torq1 speed</i> for a period of time greater than <i>77.06 Rod torq1 delay time</i> . A hysteresis (of <i>Rod torque</i> * 5%) is present in the comparator meaning, once the condition is set, it latches until the <i>09.01 Rod torque</i> increases to a value of [<i>Rod torq1 limit</i> + (<i>Rod torque</i> * 05)]. | 0 |
| | High limit | The control program triggers the Torque pressure protection function when <i>09.01 Rod torque</i> is greater than or equal to <i>77.04 Rod torq1 limit</i> and <i>09.05 Rod speed</i> is greater than or equal to <i>77.05 Rod torq1 speed</i> for a period of time greater than <i>77.06 Rod torq1 delay time</i> . A hysteresis (of <i>Rod torque</i> * 5%) is present in the comparator meaning, once the condition is set, it latches until the <i>09.01 Rod torque</i> decreases to a value of [<i>Rod torq1 limit</i> - (<i>Rod torque</i> * 05)]. | 1 |
| 77.04 | <i>Rod torq1 limit</i> | Defines the torque limit for Rod torque 1 function in engineering units. | 0.00 N•m, lbft or A |
| | 0.00...10000.00 N•m | Rod torque 1 limit. | 10 = 1 N•m, lbft or A |
| 77.05 | <i>Rod torq1 speed</i> | Defines the speed limit for rod torque 1 functionality in engineering units. | 0.00 Prpm, rpm or Hz |
| | -3600.00 ...3600.00 Prpm | Rod torque 1 speed. | 10 = 1 Prpm, rpm or Hz |
| 77.06 | <i>Rod torq1 delay time</i> | Defines the time period for confirming the high torque 1 condition. | 0.000 s |
| | 0.000...10000.000 s | Rod torque 1 delay time. | 10 = 1 s |
| 77.07 | <i>Rod torq2 function</i> | Defines the Rod torque 2 function for pump torque protection. | Disable |
| | Disable | 0 | 0 |
| | Enable | 1 | 1 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------------|---|------------------------|
| 77.08 | <i>Rod torq2 limit type</i> | Selects the Rod torque 2 limit type for the fault condition in <i>77.09 Rod torq2 limit</i> . Note: A warning is displayed during the shutdown process. | Low limit |
| | Low limit | The control program triggers the Torque pressure protection function when <i>09.01 Rod torque</i> is less than or equal to <i>77.09 Rod torq2 limit</i> for the time period greater than <i>77.10 Rod torq2 delay time</i> . A hysteresis (of <i>Rod torque</i> * 5%) is present in the comparator meaning, once the condition is set, it latches until the <i>Rod torque</i> increases to a value of [<i>Rod torq2 limit</i> + (<i>Rod torque</i> * 05)]. | 0 |
| | High limit | The control program triggers the Torque pressure protection function when <i>09.01 Rod torque</i> is greater than or equal to <i>77.09 Rod torq2 limit</i> for a period of time greater than <i>77.10 Rod torq2 delay time</i> . A hysteresis (of <i>Rod torque</i> * 5%) is present in the comparator meaning, once the condition is set, it latches until the <i>Rod torque</i> decreases to a value of [<i>Rod torq2 limit</i> - (<i>Rod torque</i> * 05)]. | 1 |
| 77.09 | <i>Rod torq2 limit</i> | Defines the torque limit for Rod torque 2 limit in engineering units. | 0.00 N•m, lbft or A |
| | 0.00...10000.00 N•m | Rod torque 2 limit. | 10 = 1 N•m, lbft or A |
| 77.10 | <i>Rod torq2 delay time</i> | Defines the time period for confirming high torque 2 condition. | 0.000 s |
| | 0.000...10000.000 s | Rod torque 2 delay time. | 10 = 1 s |
| 77.11 | <i>Rod torq2 additive speed ref</i> | Defines the additional speed reference that adds to the speed reference once the Rod torque 2 limit function is triggered. | 0.00 Prpm, rpm or Hz |
| | -3600.00 ...3600.00 Prpm | Rod torque 2 additive speed reference. | 10 = 1 Prpm, rpm or Hz |
| 77.12 | <i>Rod torq2 speed delay time</i> | Defines the time period to keep the parameter <i>77.11 Rod torq2 additive speed ref</i> active even when the required condition is not available. | 0.000 s |
| | 0.000...10000.000 s | Rod torque 2 speed delay time. | 10 = 1 s |
| 77.13 | <i>Rod torq2 limit counter</i> | Counts the number of times the additional speed reference is added to speed reference. Note: One counted cycle is considered as appliance of <i>77.11 Rod torq2 additive speed ref</i> and returning the previous value. | 0 |
| | 0...100 | Rod torque 2 limit counter. | 1 = 1 |
| 77.14 | <i>Rod torq2 time window</i> | Defines the time period at which <i>77.13 Rod torq2 limit counter</i> exceeds its limit and triggers a fault condition. | 0.000 s |
| | 0.000...7200.000 s | Rod torque 2 time window. | 10 = 1 s |

314 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-------------------------------------|--------------------------------|--|-------------------------|
| 78 Pump underload protection | | | |
| Pump underload protection function. | | | |
| 78.01 | Underload limit display | Selects the pump underload protection measurement as torque or current. See <i>Pump underload protection</i> , page 44. | Torque |
| | Torque | Rod torque value for rod torque protection. See parameters <i>78.03 Torque1</i> , <i>78.05 Torque2</i> and <i>78.07 Torque3</i> , which are percentage of rod torque limits in parameter <i>74.19 Maximum rod torq ref</i> . | 0 |
| | Current | Motor current value for pump underload protection. See parameters, <i>78.03 Torque1</i> , <i>78.05 Torque2</i> and <i>78.07 Torque3</i> , which are percentage of motor current limits in parameter <i>99.06 Motor nominal current</i> . | 1 |
| 78.02 | Underload function | Selects the Pump underload protection function. See section <i>Settings</i> on page 44. | No |
| | No | No reaction on protection condition. | 0 |
| | Warning | Display warning message. | 1 |
| | Fault | The control program triggers a fault condition and displays the warning message. Note: The fault is triggered only after the pump stops. | 2 |
| 78.03 | Torque1 | Defines the torque 1 value used for the Y position of the first X-Y plot to create the user defined underload curve for the system. | 1600.00 T(%) or A(%) |
| | 0.00...10000.00 T(%) | Torque 1 | 10 = 1 T(%) or A(%) |
| 78.04 | Speed1 | Defines the Rod speed 1 value used for the X position of the first X-Y plot to create the user defined underload curve for the system. | 0.00 Prpm, rpm or Hz |
| | -3600.00 ...3600.00 Prpm | Speed 1 | 10 = 1 Prpm, rpm or Hz |
| 78.05 | Torque2 | Defines the Rod torque 2 value used for the Y position of the second X-Y plot to create the user defined underload curve for the system. | 1600.00 T(%) or A(%) |
| | 0.00...10000.00 T(%) | Torque 2 | 10 = 1 T(%) or A(%) |
| 78.06 | Speed2 | Defines the Rod speed 2 value used for the X position of the second X-Y plot to create the user defined underload curve for the system. | 1000.00 Prpm, rpm or Hz |
| | -3600.00 ...3600.00 Prpm | Speed 2 | 10 = 1 Prpm, rpm or Hz |
| 78.07 | Torque3 | Defines the Rod torque 3 value used for the Y position of the third X-Y plot to create the user defined underload curve for the system. | 1600.00 T(%) or A(%) |
| | 0.00...10000.00 T(%) | Torque 3 | 10 = 1 T(%) or A(%) |

| No. | Name/Value | Description | Def/ FbEq16 |
|---------------------------------------|--|--|-------------------------------|
| 78.08 | <i>Speed3</i> | Defines the Rod speed 3 value used for the X position of the third X-Y plot to create the user defined underload curve for the system. | 1500.00 Prpm, rpm or Hz |
| | -3600.00 ...3600.00 Prpm | Speed 3 | 10 = 1 Prpm, rpm or Hz |
| 78.09 | <i>Underload delay time</i> | Defines the time required to confirm the underload condition. | 0.000 s |
| | 0.000...100000.000 s | Underload delay time. | 10 = 1 s |
| 79 Pump temperature protection | | Pump temperature protection function. | |
| 79.01 | <i>Temperature protection function</i> | Selects the Pump temperature protection function. See the <i>Pump pressure protection</i> on page 40. | No |
| | No | No reaction on protection condition. Note: However, the PT100 feedback temperature can still be monitored on the keypad at <i>09.10 Measured temperature</i> . | 0 |
| | Warning | Displays warning message. Warning is triggered when the <i>09.10 Measured temperature</i> is greater than <i>79.08 Warning temperature limit</i> for 5 sec or the Klixon digital input is false. | 1 |
| | Fault | Protection condition triggers fault condition and displays fault message. Fault is triggered when the <i>09.10 Measured temperature</i> is greater than <i>79.09 Fault temperature limit</i> for 5 sec or the Klixon digital input is false. Note: Fault condition means, that fault is triggered after pump stops. | 2 |
| 79.02 | <i>Temperature protection device</i> | Selects <i>79.01 Temperature protection function</i> feedback source. | Klixon |
| | Klixon | Using digital sensor. | 0 |
| | PT-100 | Using analog sensor. | 1 |
| | Both | Using both sensors simultaneously. | 2 |
| 79.03 | <i>Klixon signal source</i> | Digital feedback source for the Klixon device. | FALSE |
| | FALSE | Disables digital feedback functionality. | 0 |
| | TRUE | Enables digital feedback functionality. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 8 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 0). | 9 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 79.04 | <i>PT100 source</i> | Analog feedback source for PT100. | Zero |
| | Zero | Zero. | 0 |

| No. | Name/Value | Description | Def/ FbEq16 |
|----------------------------------|---|--|------------------------|
| | AI1 scaled | 12.12 AI1 scaled value (see page 141). | 1 |
| | AI2 scaled | 12.22 AI2 scaled value (see page 143). | 2 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 79.05 | <i>PT100 excitation source</i> | Feeding current for 1...3 PT100 sensors. | Zero |
| | Zero | Zero. | 0 |
| | Internal selection | See par 79.06 PT100 internal selection . | 1 |
| | <i>Other [bit]</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 79.06 | <i>PT100 internal selection</i> | User defined feeding current. | 9.10 mA |
| | 0.00...20.00 mA | PT100 internal selection. | 100 = 1 mA |
| 79.07 | <i>Number of PT100 sensors in series</i> | Number of connected PT100 sensors. | 1 |
| | 1...3 | Number of PT100 sensors connected in series. | 1 = 1 |
| 79.08 | <i>Warning temperature limit</i> | Temperature limit for displaying warning message. | 0.00 °C |
| | 0.00...200.00 °C | Warning temperature limit. | 10 = 1 °C |
| 79.09 | <i>Fault temperature limit</i> | Temperature limit, that triggers a fault. | 0.00 °C |
| | 0.00...200.00 °C | Fault temperature limit. | 10 = 1 °C |
| 80 Pump backspin control | | | |
| Basic functions of applications. | | | |
| 80.01 | <i>Backspin enable</i> | Enables the Backspin function. See section Pump backspin control on page 47. | Disable |
| | Disable | Disable backspin function. | 0 |
| | Enable | Enable backspin function. | 1 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 80.02 | <i>Backspin ref limit</i> | Defines the reference speed/frequency limit for the Backspin function. See section Pump backspin control on page 47.  WARNING! If Backspin ref limit is set to 0, the Pump backspin control procedure is ineffective. | 0.00 Prpm, rpm or Hz |
| | -500.00...0.00 | Reference limit | 10 = 1 Prpm, rpm or Hz |
| 80.03 | <i>Backspin acc time</i> | Defines the acceleration time for the Backspin function: from zero speed to 80.02 Backspin ref limit . | 0.000 s |
| | 0.000...10000.000 s | Acceleration time | 10 = 1 s |
| 80.04 | <i>Backspin stop torque</i> | Defines a torque limit for the Backspin function. See section Pump backspin control on page 47. When the actual torque is below the limit, Backspin function is complete and it gives coast to stop command to the drive. Note: This setting eliminates excessive shut down times. | 0.00 N•m or lbf |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------------|---|-----------------------|
| | 0.00...10000.00 N•m or lbft | Torque limit | 10 = 1 N•m or lbft |
| 80.05 | <i>Backspin speed range trim</i> | <p>Sets the speed reference regulation range for the Backspin function. The figure below illustrates how the range changes depending on the load and the speed range setting.</p> <p>Note: Default = 0% is recommended because it is the safest range of backspin operation to avoid rod damages and drive overvoltage.</p> | 0.00% |
| | 0.00...100.00% | Speed reference in percent of <i>80.02 Backspin ref limit</i> . | 100 = 1% |
| 80.11 | <i>Start delay enable</i> | Enables start delay function. See <i>Pump backspin control</i> on page 47. | Disable |
| | Disable | Disables start delay function. | 0 |
| | Enable | Enables start delay function. | 1 |
| | DI1 | Digital input DI1. | 2 |
| | DI2 | Digital input DI2. | 3 |
| | DI3 | Digital input DI3. | 4 |
| | DI4 | Digital input DI4. | 5 |
| | DI5 | Digital input DI5. | 6 |
| | DI6 | Digital input DI6. | 7 |
| | DIO1 | Digital input/output DIO1. | 8 |
| | DIO2 | Digital input/output DIO2. | 9 |
| | Other [bit] | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 80.12 | <i>Start delay time</i> | Defines the time delay from the previous drive stop to the next possible start. During this time drive is not allowed to start. | 3600.000s |
| | 0.000...4294967.295s | Start delay time | 10 = 1s |

| No. | Name/Value | Description | Def/ FbEq16 |
|----------------------------------|--------------------------------|---|-----------------------|
| 90 Feedback selection | | | |
| 90.01 | <i>Motor speed for control</i> | <p>Motor and load feedback configuration. See also sections <i>Encoder support</i> (page 63) and <i>Position counter</i> (page 66), and the diagram on page 480.</p> <p>Displays the estimated or measured motor speed that is used for motor control, ie. final motor speed feedback selected by parameter <i>90.41 Motor feedback selection</i> and filtered by <i>90.42 Motor speed filter time</i>. In case measured feedback is selected, it is also scaled by the motor gear function (<i>90.43 Motor gear numerator</i> and <i>90.44 Motor gear denominator</i>). This parameter is read-only.</p> | - |
| -32768.00 ... 32767.00 rpm | | Motor speed used for control. | See par. <i>46.01</i> |
| 90.02 | <i>Motor position</i> | <p>Displays the motor position (within one revolution) received from the source selected by parameter <i>90.41 Motor feedback selection</i>. In case measured feedback is selected, it is also scaled by the motor gear function (<i>90.43 Motor gear numerator</i> and <i>90.44 Motor gear denominator</i>). This parameter is read-only.</p> | - |
| 0.00000000 ... 1.00000000 rev | | Motor position. | 32767 = 1 rev |
| 90.03 | <i>Load speed</i> | <p>Displays the estimated or measured load speed that is used for motor control, ie. final load speed feedback selected by parameter <i>90.51 Load feedback selection</i> and filtered by parameter <i>90.52 Load speed filter time</i>. In case measured feedback is selected, it is also scaled by the load gear function (<i>90.53 Load gear numerator</i> and <i>90.54 Load gear denominator</i>). In case motor feedback or estimated feedback is used, it is inversely scaled by <i>90.61 Gear numerator</i> and <i>90.62 Gear denominator</i> (ie. <i>90.62</i> divided by <i>90.61</i>). This parameter is read-only.</p> | - |
| -32768.00 ...32767.00 rpm | | Load speed. | See par. <i>46.01</i> |
| 90.04 | <i>Load position</i> | <p>Displays the load position received from the source selected by parameter <i>90.51 Load feedback selection</i>. The value is multiplied as specified by parameter <i>90.57 Load position resolution</i>. In case measured feedback is selected, it is also scaled by the load gear function (<i>90.53 Load gear numerator</i> and <i>90.54 Load gear denominator</i>). In case motor feedback or estimated feedback is used, it is inversely scaled by <i>90.61 Gear numerator</i> and <i>90.62 Gear denominator</i> (ie. <i>90.62</i> divided by <i>90.61</i>). An offset can be defined by <i>90.56 Load position offset</i>. This parameter is read-only.</p> | - |
| -2147483648 ...2147483647 | | Load position. | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|--|-----------------------------------|
| 90.05 | <i>Load position scaled</i> | Displays the scaled load position in decimal format. The position is relative to the initial position set by parameters 90.65 and 90.66 . The number of decimal places is defined by parameter 90.38 Pos counter decimals . Note: This is a floating point parameter, and the accuracy is compromised near the ends of the range. Consider using parameter 90.07 Load position scaled int instead of this parameter. This parameter is read-only. | - |
| | -2147483.648 ...2147483.647 | Scaled load position in decimal format. | - |
| 90.06 | <i>Motor position scaled</i> | Displays the calculated motor position. The axis mode (linear or rollover) and resolution are defined by parameters 90.48 Motor position axis mode and 90.49 Motor position resolution respectively. Note: The position value can be sent on a fast time level to the fieldbus controller by selecting <i>Position</i> in either 50.07 FBA A actual 1 type , 50.08 FBA A actual 2 type , 50.37 FBA B actual 1 type or 50.38 FBA B actual 2 type . This parameter is read-only. | - |
| | -2147483.648 ... 2147483.647 | Motor position. | - |
| 90.07 | <i>Load position scaled int</i> | Displays the output of the position counter function. The position is relative to the initial position set by parameters 90.58 and 90.59 . See section Position counter (page 66), and the block diagram on page 481 . This parameter is read-only. | |
| | -2147483.648 ... 2147483.647 | Motor position. | - |
| 90.10 | <i>Encoder 1 speed</i> | Displays encoder 1 speed in rpm. This parameter is read-only. | - |
| | -32768.00 ...32767.00 rpm | Encoder 1 speed. | See par. 46.01 |
| 90.11 | <i>Encoder 1 position</i> | Displays the actual position of encoder 1 within one revolution. This parameter is read-only. | - |
| | 0.00000000 ...1.00000000 rev | Encoder 1 position within one revolution. | 32767 = 1 rev |
| 90.12 | <i>Encoder 1 multiturn revolutions</i> | Displays the revolutions of (multiturn) encoder 1 within its value range (see parameter 92.14 Revolution data width). This parameter is read-only. | - |
| | 0...16777215 | Encoder 1 revolutions. | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|--|--------------------------------|
| 90.13 | <i>Encoder 1 revolution extension</i> | Displays the revolution count extension for encoder 1. With a single-turn encoder, the counter is incremented when encoder position (parameter 90.11) wraps around in the positive direction, and decremented in the negative direction. With a multiturn encoder, the counter is incremented when the revolutions count (parameter 90.12) exceeds the value range in the positive direction, and decremented in the negative direction. This parameter is read-only. | - |
| | -2147483648 ...2147483647 | Encoder 1 revolution count extension. | - |
| 90.14 | <i>Encoder 1 position raw</i> | Displays the raw measurement data of encoder 1 position (within one revolution) as a 24-bit unsigned integer received from the encoder interface. This parameter is read-only. | - |
| | 0...16777215 | Raw encoder 1 position within one revolution. | - |
| 90.15 | <i>Encoder 1 revolutions raw</i> | Displays the revolutions of (multiturn) encoder 1 within its value range (see parameter 92.14 Revolution data width) as a raw measurement. This parameter is read-only. | - |
| | 0...16777215 | Raw encoder 1 revolution count. | - |
| 90.20 | <i>Encoder 2 speed</i> | Displays encoder 2 speed in rpm. This parameter is read-only. | - |
| | -32768.00 ...32767.00 rpm | Encoder 2 speed. | See par. 46.01 |
| 90.21 | <i>Encoder 2 position</i> | Displays the actual position of encoder 2 within one revolution. This parameter is read-only. | - |
| | 0.00000000 ...1.00000000 rev | Encoder 2 position within one revolution. | - |
| 90.22 | <i>Encoder 2 multiturn revolutions</i> | Displays the revolutions of (multiturn) encoder 2 within its value range (see parameter 93.14 Revolution data width). This parameter is read-only. | - |
| | 0...16777215 | Encoder 2 revolutions. | - |
| 90.23 | <i>Encoder 2 revolution extension</i> | Displays the revolution count extension for encoder 2. With a single-turn encoder, the counter is incremented when encoder position (parameter 90.21) wraps around in the positive direction, and decremented in the negative direction. With a multiturn encoder, the counter is incremented when the revolutions count (parameter 90.22) exceeds the value range in the positive direction, and decremented in the negative direction. This parameter is read-only. | - |
| | -2147483648 ...2147483647 | Encoder 2 revolution count extension. | - |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|-----------------------------------|--|----------------|-----|------|-------|---|--------------------|--|---|--------------------|--|---|----------------------------|--|---|----------------|---|---|------------------------|---|---|-----------------------------------|--|---|--------------------------|--|--------|----------|--|
| 90.24 | <i>Encoder 2 position raw</i> | Displays the raw measurement data of encoder 2 position (within one revolution) as a 24-bit unsigned integer received from the encoder interface. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0...16777215 | Raw encoder 2 position within one revolution. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 90.25 | <i>Encoder 2 revolutions raw</i> | Displays the revolutions of (multiturn) encoder 2 within its value range (see parameter 93.14 Revolution data width) as a raw measurement. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0...16777215 | Raw encoder 2 revolution count. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 90.26 | <i>Motor revolution extension</i> | Displays the motor revolution count extension. The counter is incremented when the position selected by 90.41 Motor feedback selection wraps around in the positive direction, and decremented in the negative direction. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | -2147483648 ...2147483647 | Motor revolution count extension. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 90.27 | <i>Load revolution extension</i> | Displays the load revolution count extension. The counter is incremented when the position selected by 90.51 Load feedback selection wraps around in the positive direction, and decremented in the negative direction. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | -2147483648 ...2147483647 | Load revolution count extension. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 90.35 | <i>Pos counter status</i> | Status information related to the position counter function. See section Position counter (page 66). This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Encoder 1 feedback</td> <td>1 = Encoder 1 selected as load feedback source</td> </tr> <tr> <td>1</td> <td>Encoder 2 feedback</td> <td>1 = Encoder 2 selected as load feedback source</td> </tr> <tr> <td>2</td> <td>Internal position feedback</td> <td>1 = Internal load position estimate selected as load feedback source</td> </tr> <tr> <td>3</td> <td>Motor feedback</td> <td>1 = Motor feedback selected as load feedback source</td> </tr> <tr> <td>4</td> <td>Pos counter init ready</td> <td>1 = Position counter successfully initialized</td> </tr> <tr> <td>5</td> <td>Position counter re-init disabled</td> <td>1 = Position counter initialization is being prevented by par. 90.68</td> </tr> <tr> <td>6</td> <td>Position data inaccurate</td> <td>1 = Encoder feedback intermittent or lost. (If the drive is running, estimated position is used whenever encoder feedback is unavailable. If the drive is in stopped state, position counting will continue based on encoder data after the connection is restored.)</td> </tr> <tr> <td>7...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | | | | Bit | Name | Value | 0 | Encoder 1 feedback | 1 = Encoder 1 selected as load feedback source | 1 | Encoder 2 feedback | 1 = Encoder 2 selected as load feedback source | 2 | Internal position feedback | 1 = Internal load position estimate selected as load feedback source | 3 | Motor feedback | 1 = Motor feedback selected as load feedback source | 4 | Pos counter init ready | 1 = Position counter successfully initialized | 5 | Position counter re-init disabled | 1 = Position counter initialization is being prevented by par. 90.68 | 6 | Position data inaccurate | 1 = Encoder feedback intermittent or lost. (If the drive is running, estimated position is used whenever encoder feedback is unavailable. If the drive is in stopped state, position counting will continue based on encoder data after the connection is restored.) | 7...15 | Reserved | |
| Bit | Name | Value | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Encoder 1 feedback | 1 = Encoder 1 selected as load feedback source | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Encoder 2 feedback | 1 = Encoder 2 selected as load feedback source | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Internal position feedback | 1 = Internal load position estimate selected as load feedback source | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Motor feedback | 1 = Motor feedback selected as load feedback source | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Pos counter init ready | 1 = Position counter successfully initialized | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Position counter re-init disabled | 1 = Position counter initialization is being prevented by par. 90.68 | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | Position data inaccurate | 1 = Encoder feedback intermittent or lost. (If the drive is running, estimated position is used whenever encoder feedback is unavailable. If the drive is in stopped state, position counting will continue based on encoder data after the connection is restored.) | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0000h...FFFFh | | Position counter status word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | |

322 Parameters

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------------|---|-----------------|
| 90.38 | <i>Pos counter decimals</i> | Scales the values of parameters <i>90.05 Load position scaled</i> and <i>90.65 Pos counter init value</i> when written from or read to from an external source (eg. fieldbus). The setting corresponds to the number of decimal places. For example, with the setting of 3, an integer value of 66770 written into <i>90.65 Pos counter init value</i> is divided by 1000, so the final value applied will be 66.770. Likewise, the value of <i>90.05 Load position scaled</i> is multiplied by 1000 when read. | 3 |
| | 0...9 | Number of position counter decimal places. | 1 = 1 |
| 90.41 | <i>Motor feedback selection</i> | Selects the motor speed feedback value used during motor control. | <i>Estimate</i> |
| | Estimate | A calculated speed estimate generated from the DTC core is used. | 0 |
| | Encoder 1 | Actual speed measured by encoder 1. The encoder is set up by the parameters in group <i>92 Encoder 1 configuration</i> . | 1 |
| | Encoder 2 | Actual speed measured by encoder 2. The encoder is set up by the parameters in group <i>93 Encoder 2 configuration</i> . | 2 |
| 90.42 | <i>Motor speed filter time</i> | Defines a filter time for motor speed feedback used for control (<i>90.01 Motor speed for control</i>). | 3 ms |
| | 0 ... 10000 ms | Motor speed filter time. | 1 = 1 ms |
| 90.43 | <i>Motor gear numerator</i> | Parameters <i>90.43</i> and <i>90.44</i> define a gear function between the motor speed feedback and motor control. The gear is used to correct a difference between the motor and encoder speeds for example if the encoder is not mounted directly on the motor shaft. $\frac{90.43 \text{ Motor gear numerator}}{90.44 \text{ Motor gear denominator}} = \frac{\text{Motor speed}}{\text{Encoder speed}}$ | 1 |
| | -2147483648 ...2147483647 | Motor gear numerator. | - |
| 90.44 | <i>Motor gear denominator</i> | See parameter <i>90.43 Motor gear numerator</i> . | 1 |
| | -2147483648 ...2147483647 | Motor gear denominator. | - |
| 90.45 | <i>Motor feedback fault</i> | Selects how the drive reacts to loss of measured motor feedback. | <i>Fault</i> |
| | Fault | Drive trips on a <i>7301 Motor speed feedback</i> or <i>7381 Encoder 1</i> fault. | 0 |
| | Warning | Drive generates a <i>A7B0 Motor speed feedback</i> or <i>A7E1 Encoder</i> warning and continues operation using estimated feedbacks. Note: Before using this setting, test the stability of the speed control loop with estimated feedback by running the drive on estimated feedback (see <i>90.41 Motor feedback selection</i>). | 1 |
| 90.46 | <i>Force open loop</i> | Defines the speed feedback used by the DTC motor model. | <i>No</i> |
| | No | The motor model uses the feedback selected by <i>90.41 Motor feedback selection</i> . | 0 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------|---|---|--------------------------|
| | Yes | The motor model uses the calculated speed estimate (regardless of the setting of 90.41 Motor feedback selection , which in this case only selects the source of feedback for the speed controller). | 1 |
| 90.48 | Motor position axis mode | Selects the axis type for motor position measurement. | Rollover |
| | Linear | Linear. | 0 |
| | Rollover | The value is between 0 and 1 revolutions, and rolls over at 360 degrees. | 1 |
| 90.49 | Motor position resolution | Defines how many bits are used for motor position count within one revolution. For example, with the setting of 24, the position value is multiplied by 16777216 for display in parameter 90.06 Motor position scaled (or for fieldbus). | 24 |
| | 0...31 | Motor position resolution. | - |
| 90.51 | Load feedback selection | Selects the source of load speed and position feedbacks used in control. | None |
| | None | No load feedback selected. | 0 |
| | Encoder 1 | Load feedbacks are updated based on the speed and position values read from encoder 1. The values are scaled by the load gear function (90.53 Load gear numerator and 90.54 Load gear denominator). The encoder is set up by the parameters in group 92 Encoder 1 configuration . | 1 |
| | Encoder 2 | Load feedbacks are updated based on the speed and position values read from encoder 2. The values are scaled by the load gear function (90.53 Load gear numerator and 90.54 Load gear denominator). The encoder is set up by the parameters in group 93 Encoder 2 configuration . | 2 |
| | Estimate | Calculated speed and position estimates are used. The values are scaled from the motor side to the load side using the inverted ratio between 90.61 Gear numerator and 90.62 Gear denominator (ie. 90.62 divided by 90.61). | 3 |
| | Motor feedback | The source selected by parameter 90.41 Motor feedback selection for motor feedback is also used for load feedback. Any difference between the motor and load speeds (and positions) can be compensated by using the inverted ratio between 90.61 Gear numerator and 90.62 Gear denominator (90.62 divided by 90.61). | 4 |
| 90.52 | Load speed filter time | Defines a filter time for load speed feedback (90.03 Load speed). | 4 ms |
| | 0...10000 ms | Load speed filter time. | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---|--|-----------------------------------|
| 90.53 | Load gear numerator | Parameters 90.53 and 90.54 define a gear function between the load (ie. driven equipment) speed and the encoder feedback selected by parameter 90.51 Load feedback selection . The gear can be used to correct a difference between the load and encoder speeds for example if the encoder is not mounted directly on the rotated machinery. $\frac{90.53 \text{ Load gear numerator}}{90.54 \text{ Load gear denominator}} = \frac{\text{Load speed}}{\text{Encoder speed}}$ | 1 |
| | -2147483648 ...2147483647 | Load gear numerator. | - |
| 90.54 | Load gear denominator | See parameter 90.53 Load gear numerator . | 1 |
| | -2147483648 ... 2147483647 | Load gear denominator. | - |
| 90.55 | Load feedback fault | Selects how the drive reacts to loss of load feedback. | <i>Fault</i> |
| | Fault | Drive trips on a 73A1 Load feedback fault. | 0 |
| | Warning | Drive generates a A7B1 Load speed feedback warning and continues operation using estimated feedbacks. | 1 |
| 90.56 | Load position offset | Defines a load-side position offset. The resolution is determined by parameter 90.57 Load position resolution . | 0 rev |
| | -2147483648...21474 83647 rev | Load-side position offset. | - |
| 90.57 | Load position resolution | Defines how many bits are used for load position count within one revolution. For example, with the setting of 16, the position value is multiplied by 65536 for display in parameter 90.04 Load position . | 16 |
| | 0...31 | Load position resolution. | - |
| | | | |
| 90.58 | Pos counter init value int | Defines an initial position (or distance) for the position counter (as an integer value) when parameter 90.59 Pos counter init value int source is set to Pos counter init value int . See also section Position counter (page 66). | 0 |
| | -2147483648 ... 2147483647 | Initial integer value for position counter. | - |
| 90.59 | Pos counter init value int source | Selects the source of the initial position integer value. When the source selected by 90.67 Pos counter init cmd source activates, the value selected in this parameter is assumed to be the position of the load. | <i>Pos counter init value int</i> |
| | Zero | 0. | 0 |
| | Pos counter init value int | Parameter 90.58 Pos counter init value int . | 1 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--------------------------------------|---|-------------------------------|
| 90.61 | <i>Gear numerator</i> | Parameters 90.61 and 90.62 define a gear function between the motor and load speeds. $\frac{90.61 \text{ Gear numerator}}{90.62 \text{ Gear denominator}} = \frac{\text{Motor speed}}{\text{Load speed}}$ | 1 |
| | -2147483648 ...2147483647 | Gear numerator (motor-side). | - |
| 90.62 | <i>Gear denominator</i> | See parameter 90.61 <i>Gear numerator</i> . | 1 |
| | -2147483648 ...2147483647 | Gear denominator (load-side). | - |
| 90.63 | <i>Feed constant numerator</i> | Parameters 90.63 and 90.64 define the feed constant for the position calculation: $\frac{90.63 \text{ Feed constant numerator}}{90.64 \text{ Feed constant denominator}}$ The feed constant converts rotational motion into translatory motion. The feed constant is the distance the load moves during one turn of the motor shaft. The translatory load position is shown by parameter 90.05 <i>Load position scaled</i> . | 1 |
| | -2147483648 ...2147483647 | Feed constant numerator. | - |
| 90.64 | <i>Feed constant denominator</i> | See parameter 90.63 <i>Feed constant numerator</i> . | 1 |
| | -2147483648 ...2147483647 | Feed constant denominator. | - |
| 90.65 | <i>Pos counter init value</i> | Defines an initial position (or distance) for the position counter (as a decimal number) when parameter 90.66 <i>Pos counter init value source</i> is set to <i>Pos counter init value</i> . See also section <i>Position counter</i> (page 66). The number of decimal places is defined by parameter 90.38 <i>Pos counter decimals</i> . | 0.000 |
| | -2147483.648 ...2147483.647 | Initial value for position counter. | - |
| 90.66 | <i>Pos counter init value source</i> | Selects the source of the initial position value. When the source selected by 90.67 <i>Pos counter init cmd source</i> activates, the value selected in this parameter is assumed to be the position of the load (in decimal format). | <i>Pos counter init value</i> |
| | Zero | 0. | 0 |
| | Pos counter init value | Parameter 90.65 <i>Pos counter init value</i> . | 1 |
| | <i>Other</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---|--|---------------------|
| 90.67 | <i>Pos counter init cmd source</i> | Selects a digital source (for example, a limit switch connected to a digital input) that initializes the position counter. When the digital source activates, the value selected by <i>90.66 Pos counter init value source</i> is assumed to be the position of the load. Note: Position counter initialization can be prevented by parameter <i>90.68 Disable pos counter initialization</i> . | <i>Not selected</i> |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 90.68 | <i>Disable pos counter initialization</i> | Selects a source that prevents the initialization of the position counter. | <i>Not selected</i> |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |
| 90.69 | <i>Reset pos counter init ready</i> | Selects a source that enables a new initialization of the position counter, ie. resets bit 4 of <i>90.35 Pos counter status</i> . | <i>Not selected</i> |
| | Not selected | 0. | 0 |
| | Selected | 1. | 1 |
| | DI1 | Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0). | 2 |
| | DI2 | Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1). | 3 |
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----|--------------------|---|----------------|
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - |

| 91 Encoder module settings | | Configuration of encoder interface modules. | | | | | | | | | | | | | | | | | | | | | | |
|---|------------------------------|---|-------|-----|------|-------------|---|---------------|---|---|---------------|---|-------|----------|--|---|---------------|---|---|---------------|---|--------|----------|--|
| 91.01 | <i>FEN DI status</i> | Displays the status of the digital inputs of FEN-xx encoder interface modules. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>DI1 /module 1</td> <td>DI1 of interface module 1 (see parameters <i>91.11</i> and <i>91.12</i>)</td> </tr> <tr> <td>1</td> <td>DI2 /module 1</td> <td>DI2 of interface module 1 (see parameters <i>91.11</i> and <i>91.12</i>)</td> </tr> <tr> <td>2...3</td> <td colspan="2">Reserved</td> </tr> <tr> <td>4</td> <td>DI1 /module 2</td> <td>DI1 of interface module 2 (see parameters <i>91.13</i> and <i>91.14</i>)</td> </tr> <tr> <td>5</td> <td>DI2 /module 2</td> <td>DI2 of interface module 2 (see parameters <i>91.13</i> and <i>91.14</i>)</td> </tr> <tr> <td>6...15</td> <td colspan="2">Reserved</td> </tr> </tbody> </table> | | | | Bit | Name | Information | 0 | DI1 /module 1 | DI1 of interface module 1 (see parameters <i>91.11</i> and <i>91.12</i>) | 1 | DI2 /module 1 | DI2 of interface module 1 (see parameters <i>91.11</i> and <i>91.12</i>) | 2...3 | Reserved | | 4 | DI1 /module 2 | DI1 of interface module 2 (see parameters <i>91.13</i> and <i>91.14</i>) | 5 | DI2 /module 2 | DI2 of interface module 2 (see parameters <i>91.13</i> and <i>91.14</i>) | 6...15 | Reserved | |
| Bit | Name | Information | | | | | | | | | | | | | | | | | | | | | | |
| 0 | DI1 /module 1 | DI1 of interface module 1 (see parameters <i>91.11</i> and <i>91.12</i>) | | | | | | | | | | | | | | | | | | | | | | |
| 1 | DI2 /module 1 | DI2 of interface module 1 (see parameters <i>91.11</i> and <i>91.12</i>) | | | | | | | | | | | | | | | | | | | | | | |
| 2...3 | Reserved | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | DI1 /module 2 | DI1 of interface module 2 (see parameters <i>91.13</i> and <i>91.14</i>) | | | | | | | | | | | | | | | | | | | | | | |
| 5 | DI2 /module 2 | DI2 of interface module 2 (see parameters <i>91.13</i> and <i>91.14</i>) | | | | | | | | | | | | | | | | | | | | | | |
| 6...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000 0000b ... 0011 0011b | Status word of digital inputs on FEN-xx modules. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | |
| 91.02 | <i>Module 1 status</i> | Displays the type of the interface module found in the location specified by parameter <i>91.12 Module 1 location</i> . This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | |
| | No option | No module detected in the specified slot. | 0 | | | | | | | | | | | | | | | | | | | | | |
| | No communication | A module has been detected but cannot be communicated with. | 1 | | | | | | | | | | | | | | | | | | | | | |
| | Unknown | The module type is unknown. | 2 | | | | | | | | | | | | | | | | | | | | | |
| | FEN-01 | An FEN-01 module has been detected and is active. | 16 | | | | | | | | | | | | | | | | | | | | | |
| | FEN-11 | An FEN-11 module has been detected and is active. | 17 | | | | | | | | | | | | | | | | | | | | | |
| | FEN-21 | An FEN-21 module has been detected and is active. | 18 | | | | | | | | | | | | | | | | | | | | | |
| | FEN-31 | An FEN-31 module has been detected and is active. | 21 | | | | | | | | | | | | | | | | | | | | | |
| | FSE-31 | An FSE-31 module has been detected and is active. | 25 | | | | | | | | | | | | | | | | | | | | | |
| 91.03 | <i>Module 2 status</i> | Displays the type of the interface module found in the location specified by parameter <i>91.14 Module 2 location</i> . For the indications, see parameter <i>91.02 Module 1 status</i> . This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | |
| 91.04 | <i>Module 1 temperature</i> | Displays the temperature measured through the sensor input of interface module 1. The unit is selected by parameter <i>96.16 Unit selection</i> . Note: With a PTC sensor, the unit is ohms. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | |
| | 0...1000 °C, °F or ohm | Temperature measured through interface module 1. | - | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------------|--|----------------|
| 91.06 | <i>Module 2 temperature</i> | Displays the temperature measured through the sensor input of interface module 2. The unit is selected by parameter <i>96.16 Unit selection</i> . Note: With a PTC sensor, the unit is ohms. This parameter is read-only. | - |
| | 0...1000 °C, °F or ohm | Temperature measured through interface module 2. | - |
| 91.10 | <i>Encoder parameter refresh</i> | Validates any changed encoder interface module parameters. This is needed for any parameter changes in groups 90...93 to take effect. After refreshing, the value reverts automatically to <i>Done</i> . Note: The parameter cannot be changed while the drive is running. | <i>Done</i> |
| | Done | Refreshing done. | 0 |
| | Refresh | Refreshing. | 1 |
| 91.11 | <i>Module 1 type</i> | Defines the type of the module used as interface module 1. | <i>None</i> |
| | None | None (communication disabled). | 0 |
| | FEN-01 | FEN-01. | 1 |
| | FEN-11 | FEN-11. | 2 |
| | FEN-21 | FEN-21. | 3 |
| | FEN-31 | FEN-31. | 4 |
| | FSE-31 | FSE-31. | 5 |
| 91.12 | <i>Module 1 location</i> | Specifies the slot (1...3) on the control unit of the drive into which the interface module is installed. Alternatively, specifies the node ID of the slot on an FEA-0x extension adapter. | <i>Slot 2</i> |
| | Slot 1 | Slot 1. | 1 |
| | Slot 2 | Slot 2. | 2 |
| | Slot 3 | Slot 3. | 3 |
| | 4...254 | Node ID of the slot on the FEA-0x extension adapter. | 1 = 1 |
| 91.13 | <i>Module 2 type</i> | Defines the type of the module used as interface module 2. | <i>None</i> |
| | None | None (communication disabled). | 0 |
| | FEN-01 | FEN-01. | 1 |
| | FEN-11 | FEN-11. | 2 |
| | FEN-21 | FEN-21. | 3 |
| | FEN-31 | FEN-31. | 4 |
| | FSE-31 | FSE-31. | 5 |
| 91.14 | <i>Module 2 location</i> | Specifies the slot (1...3) on the control unit of the drive into which the interface module is installed. Alternatively, specifies the node ID of the slot on an FEA-0x extension adapter. | <i>Slot 3</i> |
| | Slot 1 | Slot 1. | 1 |
| | Slot 2 | Slot 2. | 2 |
| | Slot 3 | Slot 3. | 3 |
| | 4...254 | Node ID of the slot on the FEA-0x extension adapter. | 1 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---|--|---------------------|
| 91.21 | <i>Module 1 temp sensor type</i> | Specifies the type of temperature sensor connected to interface module 1. | <i>None</i> |
| | None | None. | 0 |
| | PTC | PTC. (The unit is ohms.) | 1 |
| | KTY-84 | KTY84. (The unit is selected by parameter 96.16 Unit selection.) | 2 |
| 91.22 | <i>Module 1 temp filter time</i> | Defines a filtering time for the temperature measurement through interface module 1. | 1500 ms |
| | 0...10000 ms | Filtering time for temperature measurement. | - |
| 91.24 | <i>Module 2 temp sensor type</i> | Specifies the type of temperature sensor connected to interface module 2. | <i>None</i> |
| | None | None. | 0 |
| | PTC | PTC. (The unit is ohms.) | 1 |
| | KTY-84 | KTY84. (The unit is selected by parameter 96.16 Unit selection.) | 2 |
| 91.25 | <i>Module 2 temp filter time</i> | Defines a filtering time for the temperature measurement through interface 2. | 1500 ms |
| | 0...10000 ms | Filtering time for temperature measurement. | - |
| 91.31 | <i>Module 1 TTL output source</i> | Selects the encoder input on interface module 1 whose signal is echoed by or emulated to the TTL output. See also section Encoder support (page 63). | <i>Not selected</i> |
| | Not selected | TTL output not in use. | 0 |
| | Module input 1 | Input 1 is echoed by or emulated to the TTL output. | 1 |
| | Module input 2 | Input 2 is echoed by or emulated to the TTL output. | 2 |
| 91.32 | <i>Module 1 emulation pulses/rev</i> | Defines the number of TTL pulses per revolution for encoder emulation output of interface module 1. | 0 |
| | 0...65535 | Number of TTL pulses for emulation. | 1 = 1 |
| 91.33 | <i>Module 1 emulated Z-pulse offset</i> | With interface module 1, defines when zero pulses are emulated in relation to zero position received from the encoder. For example, with a value of 0.50000, a zero pulse is emulated whenever the encoder position passes 0.5 revolutions. With a value of 0.00000, a zero pulse is emulated whenever the encoder position passes zero position. | 0.00000 |
| | 0.00000 ... 1.00000 rev | Position of emulated zero pulses. | 32767 = 1 rev |
| 91.41 | <i>Module 2 TTL output source</i> | Selects the encoder input on interface module 2 whose signal is echoed by or emulated to the TTL output. See also section Encoder support (page 63). | <i>Not selected</i> |
| | Not selected | TTL output not in use. | 0 |
| | Module input 1 | Input 1 is echoed by or emulated to the TTL output. | 1 |
| | Module input 2 | Input 2 is echoed by or emulated to the TTL output. | 2 |
| 91.42 | <i>Module 2 emulation pulses/rev</i> | Defines the number of TTL pulses per revolution for encoder emulation output of interface module 2. | 0 |
| | 0...65535 | Number of TTL pulses for emulation. | 1 = 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------------------|---|--|------------------------|
| 91.43 | <i>Module 2 emulated Z-pulse offset</i> | With interface module 2, defines when zero pulses are emulated in relation to zero position received from the encoder. For example, with a value of 0.50000, a zero pulse is emulated whenever the encoder position passes 0.5 revolutions. With a value of 0.00000, a zero pulse is emulated whenever the encoder position passes zero position. | 0 |
| | 0.00000 ... 1.00000 rev | Position of emulated zero pulses. | 32767 = 1 rev |
| 92 Encoder 1 configuration | | Settings for encoder 1. Notes: <ul style="list-style-type: none"> The contents of the parameter group vary according to the selected encoder type. It is recommended that encoder connection 1 (this group) is used whenever possible since the data received through that interface is fresher than the data received through connection 2 (group 93 Encoder 2 configuration). | |
| 92.01 | <i>Encoder 1 type</i> | Selects the type of encoder/resolver 1. | <i>None configured</i> |
| | None configured | None. | 0 |
| | TTL | TTL. Module type (input): FEN-01 (X31), FEN-11 (X41) or FEN-21 (X51). | 1 |
| | TTL+ | TTL+ (with commutation signals). Module type (input): FEN-01 (X32). | 2 |
| | Absolute encoder | Absolute encoder. Module type (input): FEN-11 (X42). | 3 |
| | Resolver | Resolver. Module type (input): FEN-21 (X52). | 4 |
| | HTL | HTL. Module type (input): FEN-31 (X82). | 5 |
| | HTL 1 | HTL. Module type (input): FSE-31 (X31). | 6 |
| | HTL 2 | HTL. Module type (input): FSE-31 (X32). | 7 |
| | TTL 1 | TTL. Module type (input): FSE-31 (X31). | 8 |
| | TTL 2 | TTL. Module type (input): FSE-31 (X32). | 9 |
| 92.02 | <i>Encoder 1 source</i> | Selects the interface module that the encoder is connected to. (The physical locations and types of encoder interface modules are defined in parameter group 91 Encoder module settings .) | <i>Module 1</i> |
| | Module 1 | Interface module 1. | 0 |
| | Module 2 | Interface module 2. | 1 |
| 92.10 | <i>Pulses/revolution</i> | (Visible when TTL, TTL+ or HTL encoder is selected) Defines the pulse number per revolution. | 2048 |
| | 0...65535 | Number of pulses. | - |
| 92.10 | <i>Sine/cosine number</i> | (Visible when an Absolute encoder is selected) Defines the number of sine/cosine wave cycles within one revolution. Note: This parameter need not be set when an EnDat or SSI encoder is used in continuous mode. See parameter 92.30 Serial link mode . | 0 |
| | 0...65535 | Number of sine/cosine wave cycles within one revolution. | - |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | |
|----------------|------------------------------------|--|-----------------------------------|-----------|-----------|--------------------|----------------|--------------|-----------|-----------------|--|
| 92.10 | <i>Excitation signal frequency</i> | (Visible when a resolver is selected) Defines the frequency of the excitation signal. | 1 kHz | | | | | | | | |
| | 1...20 kHz | Excitation signal frequency. | 1 = 1 kHz | | | | | | | | |
| 92.11 | <i>Pulse encoder type</i> | (Visible when a TTL, TTL+ or HTL encoder is selected) Selects the type of encoder. | <i>Quadrature</i> | | | | | | | | |
| | Quadrature | Quadrature encoder (with two channels, A and B) | 0 | | | | | | | | |
| | Single track | Single-track encoder (with one channel, A). Note: With this setting, the measured speed value is always positive regardless of direction of rotation. | 1 | | | | | | | | |
| 92.11 | <i>Absolute position source</i> | (Visible when absolute encoder is selected) Selects the source of the absolute position information. | <i>None</i> | | | | | | | | |
| | None | Not selected. | 0 | | | | | | | | |
| | Commut signals | Commutation signals. | 1 | | | | | | | | |
| | EnDat | Serial interface: EnDat encoder. | 2 | | | | | | | | |
| | Hiperface | Serial interface: HIPERFACE encoder. | 3 | | | | | | | | |
| | SSI | Serial interface: SSI encoder. | 4 | | | | | | | | |
| | Tamagawa | Serial interface: Tamagawa 17/33-bit encoder. | 5 | | | | | | | | |
| | | | | | | | | | | | |
| 92.11 | <i>Excitation signal amplitude</i> | (Visible when a resolver is selected) Defines the amplitude of the excitation signal. | 4.0 V | | | | | | | | |
| | 4.0...12.0 V | Excitation signal amplitude. | 10 = 1 V | | | | | | | | |
| 92.12 | <i>Speed calculation mode</i> | (Visible when a TTL, TTL+ or HTL is selected) Selects the speed calculation mode. *With a single-track encoder (parameter 92.11 <i>Pulse encoder type</i> is set to <i>Single track</i>), the speed is always positive. | <i>Auto rising</i> | | | | | | | | |
| | A&B all | Channels A and B: Rising and falling edges are used for speed calculation. *Channel B: Defines the direction of rotation. Note: With a single-track encoder (parameter 92.11 <i>Pulse encoder type</i>), this setting acts like setting <i>A all</i> . | 0 | | | | | | | | |
| | A all | Channel A: Rising and falling edges are used for speed calculation. *Channel B: Defines the direction of rotation. | 1 | | | | | | | | |
| | A rising | Channel A: Rising edges are used for speed calculation. *Channel B: Defines the direction of rotation. | 2 | | | | | | | | |
| | A falling | Channel A: Falling edges are used for speed calculation. *Channel B: Defines the direction of rotation. | 3 | | | | | | | | |
| | Auto rising | One of the above modes is selected automatically depending on the pulse frequency as follows: | 4 | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Pulse frequency of the channel(s)</th> <th>Used mode</th> </tr> </thead> <tbody> <tr> <td>< 2442 Hz</td> <td><i>A&B all</i></td> </tr> <tr> <td>2442...4884 Hz</td> <td><i>A all</i></td> </tr> <tr> <td>> 4884 Hz</td> <td><i>A rising</i></td> </tr> </tbody> </table> | Pulse frequency of the channel(s) | Used mode | < 2442 Hz | <i>A&B all</i> | 2442...4884 Hz | <i>A all</i> | > 4884 Hz | <i>A rising</i> | |
| | Pulse frequency of the channel(s) | Used mode | | | | | | | | | |
| < 2442 Hz | <i>A&B all</i> | | | | | | | | | | |
| 2442...4884 Hz | <i>A all</i> | | | | | | | | | | |
| > 4884 Hz | <i>A rising</i> | | | | | | | | | | |
| | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | |
|-----------------------------------|-----------------------------------|--|-----------------------------------|-----------|-----------|--------------------|----------------|--------------|-----------|------------------|---|
| | Auto falling | One of the above modes is selected automatically depending on the pulse frequency as follows: <table border="1" data-bbox="389 256 813 387"> <thead> <tr> <th>Pulse frequency of the channel(s)</th> <th>Used mode</th> </tr> </thead> <tbody> <tr> <td>< 2442 Hz</td> <td><i>A&B all</i></td> </tr> <tr> <td>2442...4884 Hz</td> <td><i>A all</i></td> </tr> <tr> <td>> 4884 Hz</td> <td><i>A falling</i></td> </tr> </tbody> </table> | Pulse frequency of the channel(s) | Used mode | < 2442 Hz | <i>A&B all</i> | 2442...4884 Hz | <i>A all</i> | > 4884 Hz | <i>A falling</i> | 5 |
| Pulse frequency of the channel(s) | Used mode | | | | | | | | | | |
| < 2442 Hz | <i>A&B all</i> | | | | | | | | | | |
| 2442...4884 Hz | <i>A all</i> | | | | | | | | | | |
| > 4884 Hz | <i>A falling</i> | | | | | | | | | | |
| 92.12 | <i>Zero pulse enable</i> | <i>(Visible when an absolute encoder is selected)</i> Enables the encoder zero pulse for the absolute encoder input (X42) of the FEN-11 interface module. Note: No zero pulse exists with serial interfaces, ie. when parameter <i>92.11 Absolute position source</i> is set to <i>EnDat</i> , <i>Hiperface</i> , <i>SSI</i> or <i>Tamagawa</i> . | <i>Disable</i> | | | | | | | | |
| | Disable | Zero pulse disabled. | 0 | | | | | | | | |
| | Enable | Zero pulse enabled. | 1 | | | | | | | | |
| 92.12 | <i>Resolver polepairs</i> | <i>(Visible when is resolver is selected)</i> Defines the number of pole pairs of the resolver. | 1 | | | | | | | | |
| | 1...32 | Number of resolver pole pairs. | 1 = 1 | | | | | | | | |
| 92.13 | <i>Position estimation enable</i> | <i>(Visible when TTL, TTL+ or HTL is selected)</i> Selects whether position estimation is used with encoder 1 to increase position data resolution or not. | <i>Enable</i> | | | | | | | | |
| | Disable | Measured position used. (The resolution is 4 × pulses per revolution for quadrature encoders, 2 × pulses per revolution for single-track encoders.) | 0 | | | | | | | | |
| | Enable | Estimated position used. (Uses position interpolation; extrapolated at the time of data request.) | 1 | | | | | | | | |
| 92.13 | <i>Position data width</i> | <i>(Visible when an absolute encoder is selected)</i> Defines the number of bits used to indicate position within one revolution. For example, a setting of 15 bits corresponds to 32768 positions per revolution. The value is used when parameter <i>92.11 Absolute position source</i> is set to <i>EnDat</i> , <i>Hiperface</i> or <i>SSI</i> . When parameter <i>92.11 Absolute position source</i> is set to <i>Tamagawa</i> , this parameter is internally set to 17. | 0 | | | | | | | | |
| | 0...32 | Number of bits used in position indication within one revolution. | 1 = 1 | | | | | | | | |
| 92.14 | <i>Speed estimation enable</i> | <i>(Visible when TTL, TTL+ or HTL is selected)</i> Selects whether calculated or estimated speed is used. Estimation increases the speed ripple in steady state operation, but improves the dynamics. | <i>Disable</i> | | | | | | | | |
| | Disable | Last calculated speed used. (The calculation interval is 62.5 microseconds to 4 milliseconds.) | 0 | | | | | | | | |
| | Enable | Estimated speed (estimated at the time of data request) is used. | 1 | | | | | | | | |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---|--|-------------------------|
| 92.14 | <i>Revolution data width</i> | (Visible when an absolute encoder is selected) Defines the number of bits used in revolution counting with a multiturn encoder. For example, a setting of 12 bits would support counting up to 4096 revolutions. The value is used when parameter 92.11 <i>Absolute position source</i> is set to <i>EnDat</i> , <i>Hiperface</i> or <i>SSI</i> . When parameter 92.11 <i>Absolute position source</i> is set to <i>Tamagawa</i> , setting this parameter to a non-zero value activates multiturn data requesting. | 0 |
| | 0...32 | Number of bits used in revolution count. | 1 = 1 |
| 92.15 | <i>Transient filter</i> | (Visible when a TTL, TTL+ or HTL is selected) Activates transient filtering for the encoder (changes in direction of rotation are ignored above the selected pulse frequency). | 4880 Hz |
| | 4880 Hz | Change in direction of rotation allowed below 4880 Hz. | 0 |
| | 2440 Hz | Change in direction of rotation allowed below 2440 Hz. | 1 |
| | 1220 Hz | Change in direction of rotation allowed below 1220 Hz. | 2 |
| | Disabled | Change in direction of rotation allowed at any pulse frequency. | 3 |
| 92.16 | <i>Encoder 1 supply voltage</i> | (Visible when parameter 92.01 <i>Encoder 1 type</i> = <i>HTL 1</i> , <i>HTL 2</i> , <i>TTL 1</i> or <i>TTL 2</i>) Selects the power supply voltage for encoder 1. | 0V |
| | 0V | Disabled. | 0 |
| | 5V | 5 V. | 1 |
| | 24V | 24 V. | 2 |
| 92.17 | <i>Accepted pulse freq of encoder 1</i> | (Visible when parameter 92.01 <i>Encoder 1 type</i> = <i>HTL 1</i> , <i>HTL 2</i> , <i>TTL 1</i> or <i>TTL 2</i>) Defines the maximum pulse frequency of encoder 1. | 0 kHz |
| | 0...300 kHz | Pulse frequency. | 1 = 1 kHz |
| 92.21 | <i>Encoder cable fault mode</i> | (Visible when a TTL, TTL+ or HTL is selected) Selects which encoder cable channels and wires are monitored for wiring faults. | A, B |
| | A, B | A and B. | 0 |
| | A, B, Z | A, B and Z. | 1 |
| | A+, A-, B+, B- | A+, A-, B+ and B-. | 2 |
| | A+, A-, B+, B-, Z+, Z- | A+, A-, B+, B-, Z+ and Z-. | 3 |
| 92.30 | <i>Serial link mode</i> | (Visible when an absolute encoder is selected) Selects the serial link mode with an EnDat or SSI encoder. | <i>Initial position</i> |
| | Initial position | Single position transfer mode (initial position). | 0 |
| | Continuous | Continuous position data transfer mode. | 1 |
| | Continuous speed and position | Continuous speed and position data transfer mode. This setting is intended for EnDat 2.2 encoders without sin/cos signals. Note: This setting requires an FEN-11 interface revision H or later. | 2 |


| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-----------------------------------|---|-------------------|
| 92.31 | <i>EnDat max calculation time</i> | <i>(Visible when an absolute encoder is selected)</i> Selects the maximum encoder calculation time for an EnDat encoder. Note: This parameter needs to be set only when an EnDat encoder is used in continuous mode, ie. without incremental sin/cos signals (supported only as encoder 1). See also parameter 92.30 Serial link mode . | <i>50 ms</i> |
| | 10 us | 10 microseconds. | 0 |
| | 100 us | 100 microseconds. | 1 |
| | 1 ms | 1 millisecond. | 2 |
| | 50 ms | 50 milliseconds. | 3 |
| 92.32 | <i>SSI cycle time</i> | <i>(Visible when an absolute encoder is selected)</i> Selects the transmission cycle for an SSI encoder. Note: This parameter needs to be set only when an SSI encoder is used in continuous mode, ie. without incremental sin/cos signals (supported only as encoder 1). See also parameter 92.30 Serial link mode . | <i>100 us</i> |
| | 50 us | 50 microseconds. | 0 |
| | 100 us | 100 microseconds. | 1 |
| | 200 us | 200 microseconds. | 2 |
| | 500 us | 500 microseconds. | 3 |
| | 1 ms | 1 millisecond. | 4 |
| | 2 ms | 2 milliseconds. | 5 |
| 92.33 | <i>SSI clock cycles</i> | <i>(Visible when an absolute encoder is selected)</i> Defines the length of an SSI message. The length is defined as the number of clock cycles. The number of cycles can be calculated by adding 1 to the number of bits in an SSI message frame. | 2 |
| | 2...127 | SSI message length. | - |
| 92.34 | <i>SSI position msb</i> | <i>(Visible when an absolute encoder is selected)</i> With an SSI encoder, defines the location of the MSB (most significant bit) of the position data within an SSI message. | 1 |
| | 1...126 | Position data MSB location (bit number). | - |
| 92.35 | <i>SSI revolution msb</i> | <i>(Visible when an absolute encoder is selected)</i> With an SSI encoder, defines the location of the MSB (most significant bit) of the revolution count within an SSI message. | 1 |
| | 1...126 | Revolution count MSB location (bit number). | - |
| 92.36 | <i>SSI data format</i> | <i>(Visible when an absolute encoder is selected)</i> Selects the data format for an SSI encoder. | <i>Binary</i> |
| | Binary | Binary code. | 0 |
| | Gray | Gray code. | 1 |
| 92.37 | <i>SSI baud rate</i> | <i>(Visible when an absolute encoder is selected)</i> Selects the baud rate for an SSI encoder. | <i>100 kBit/s</i> |
| | 10 kBit/s | 10 kbit/s. | 0 |
| | 50 kBit/s | 50 kbit/s. | 1 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-------------------------------|---|--------------------|
| | 100 kBit/s | 100 kbit/s. | 2 |
| | 200 kBit/s | 200 kbit/s. | 3 |
| | 500 kBit/s | 500 kbit/s. | 4 |
| | 1000 kBit/s | 1000 kbit/s. | 5 |
| 92.40 | <i>SSI zero phase</i> | <i>(Visible when an absolute encoder is selected)</i> Defines the phase angle within one sine/cosine signal period that corresponds to the value of zero on the SSI serial link data. The parameter is used to adjust the synchronization of the SSI position data and the position based on sine/cosine incremental signals. Incorrect synchronization may cause an error of ± 1 incremental period. Note: This parameter needs to be set only when an SSI encoder is used in initial position mode (see parameter 92.30 Serial link mode). | <i>315-45 deg</i> |
| | 315-45 deg | 315-45 degrees. | 0 |
| | 45-135 deg | 45-135 degrees. | 1 |
| | 135-225 deg | 135-225 degrees. | 2 |
| | 225-315 deg | 225-315 degrees. | 3 |
| 92.45 | <i>Hiperface parity</i> | <i>(Visible when an absolute encoder is selected)</i> Defines the use of parity and stop bits with a HIPERFACE encoder. Typically this parameter need not be set. | <i>Odd</i> |
| | Odd | Odd parity indication bit, one stop bit. | 0 |
| | Even | Even parity indication bit, one stop bit. | 1 |
| 92.46 | <i>Hiperface baud rate</i> | <i>(Visible when an absolute encoder is selected)</i> Defines the transfer rate of the link with a HIPERFACE encoder. Typically this parameter need not be set. | <i>4800 bits/s</i> |
| | 4800 bits/s | 4800 bit/s. | 0 |
| | 9600 bits/s | 9600 bit/s. | 1 |
| | 19200 bits/s | 19200 bit/s. | 2 |
| | 38400 bits/s | 38400 bit/s. | 3 |
| 92.47 | <i>Hiperface node address</i> | <i>(Visible when an absolute encoder is selected)</i> Defines the node address for a HIPERFACE encoder. Typically this parameter need not be set. | 64 |
| | 0...255 | HIPERFACE encoder node address. | - |

| No. | Name/Value | Description | Def/ FbEq16 |
|--|-----------------|---|------------------------|
| 93 Encoder 2 configuration | | Settings for encoder 2. Note: <ul style="list-style-type: none"> The contents of the parameter group vary according to the selected encoder type. It is recommended that encoder connection 1 (group 92 Encoder 1 configuration) is used whenever possible since the data received through that interface is fresher than the data received through connection 2 (this group). | |
| 93.01 Encoder 2 type | | Selects the type of encoder/resolver 2. | <i>None configured</i> |
| | None configured | None. | 0 |
| | TTL | TTL. Module type (input): FEN-01 (X31), FEN-11 (X41) or FEN-21 (X51). | 1 |
| | TTL+ | TTL+ (with commutation signals). Module type (input): FEN-01 (X32). | 2 |
| | Abs enc | Absolute encoder. Module type (input): FEN-11 (X42). | 3 |
| | Resolver | Resolver. Module type (input): FEN-21 (X52). | 4 |
| | HTL | HTL. Module type (input): FEN-31 (X82). | 5 |
| | HTL 1 | HTL. Module type (input): FSE-31 (X31). | 6 |
| | HTL 2 | HTL. Module type (input): FSE-31 (X32). | 7 |
| | TTL 1 | TTL. Module type (input): FSE-31 (X31). | 8 |
| | TTL 2 | TTL. Module type (input): FSE-31 (X32). | 9 |
| 93.02 Encoder 2 source | | Selects the interface module that the encoder is connected to. (The physical locations and types of encoder interface modules are defined in parameter group 91 Encoder module settings .) | <i>Module 1</i> |
| | Module 1 | Interface module 1. | 1 |
| | Module 2 | Interface module 2. | 2 |
| 93.10 Pulses/revolution | | (Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.10 Pulses/revolution . | 2048 |
| 93.10 Sine/cosine number | | (Visible when an absolute encoder is selected) See parameter 92.10 Sine/cosine number . | 0 |
| 93.10 Excitation signal frequency | | (Visible when a resolver is selected) See parameter 92.10 Excitation signal frequency . | 1 kHz |
| 93.11 Pulse encoder type | | (Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.11 Pulse encoder type . | <i>Quadrature</i> |
| 93.11 Absolute position source | | (Visible when an absolute encoder is selected) See parameter 92.11 Absolute position source . | <i>None</i> |
| 93.11 Excitation signal amplitude | | (Visible when a resolver is selected) See parameter 92.11 Excitation signal amplitude . | 4.0 V |
| 93.12 Speed calculation mode | | (Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.12 Speed calculation mode . | <i>Auto rising</i> |
| 93.12 Zero pulse enable | | (Visible when an absolute encoder is selected) See parameter 92.12 Zero pulse enable . | <i>Disable</i> |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---|--|-------------------------|
| 93.12 | <i>Resolver polepairs</i> | (Visible when a resolver is selected) See parameter 92.12 Resolver polepairs . | 1 |
| 93.13 | <i>Position estimation enable</i> | (Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.13 Position estimation enable . | <i>Enable</i> |
| 93.13 | <i>Position data width</i> | (Visible when an absolute encoder is selected) See parameter 92.13 Position data width . | 0 |
| 93.14 | <i>Speed estimation enable</i> | (Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.14 Speed estimation enable . | <i>Disable</i> |
| 93.14 | <i>Revolution data width</i> | (Visible when an absolute encoder is selected) See parameter 92.14 Revolution data width . | 0 |
| 93.15 | <i>Transient filter</i> | (Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.15 Transient filter . | 4880 Hz |
| 93.16 | <i>Encoder 2 supply voltage</i> | (Visible when parameter 93.01 Encoder 2 type = HTL 1, HTL 2, TTL 1 or TTL 2) See parameter 92.16 Encoder 1 supply voltage . | 0V |
| 93.17 | <i>Accepted pulse freq of encoder 2</i> | (Visible when parameter 93.01 Encoder 2 type = HTL 1, HTL 2, TTL 1 or TTL 2) See parameter 92.17 Accepted pulse freq of encoder 1 . | 0 kHz |
| 93.21 | <i>Encoder cable fault mode</i> | (Visible when TTL, TTL+ or HTL encoder is selected) See parameter 92.21 Encoder cable fault mode . | A, B |
| 93.30 | <i>Serial link mode</i> | (Visible when an absolute encoder is selected) See parameter 92.30 Serial link mode . | <i>Initial position</i> |
| 93.31 | <i>EnDat calc time</i> | (Visible when an absolute encoder is selected) See parameter 92.31 EnDat max calculation time . | 50 ms |
| 93.32 | <i>SSI cycle time</i> | (Visible when an absolute encoder is selected) See parameter 92.32 SSI cycle time . | 100 us |
| 93.33 | <i>SSI clock cycles</i> | (Visible when an absolute encoder is selected) See parameter 92.33 SSI clock cycles . | 2 |
| 93.34 | <i>SSI position msb</i> | (Visible when an absolute encoder is selected) See parameter 92.34 SSI position msb . | 1 |
| 93.35 | <i>SSI revolution msb</i> | (Visible when an absolute encoder is selected) See parameter 92.35 SSI revolution msb . | 1 |
| 93.36 | <i>SSI data format</i> | (Visible when an absolute encoder is selected) See parameter 92.36 SSI data format . | <i>Binary</i> |
| 93.37 | <i>SSI baud rate</i> | (Visible when an absolute encoder is selected) See parameter 92.37 SSI baud rate . | 100 kBit/s |
| 93.40 | <i>SSI zero phase</i> | (Visible when an absolute encoder is selected) See parameter 92.40 SSI zero phase . | 315-45 deg |
| 93.45 | <i>Hiperface parity</i> | (Visible when an absolute encoder is selected) See parameter 92.45 Hiperface parity . | <i>Odd</i> |
| 93.46 | <i>Hiperface baud rate</i> | (Visible when an absolute encoder is selected) See parameter 92.46 Hiperface baud rate . | 4800 bits/s |
| 93.47 | <i>Hiperface node address</i> | (Visible when an absolute encoder is selected) See parameter 92.47 Hiperface node address . | 64 |

| No. | Name/Value | Description | Def/ FbEq16 |
|----------------------------|--------------------------------|---|--|
| 95 HW configuration | | Various hardware-related settings. | |
| 95.01 | <i>Supply voltage</i> | <p>Selects the supply voltage range. This parameter is used by the drive to determine the nominal voltage of the supply network. The parameter also affects the current ratings and the DC voltage control functions (trip and brake chopper activation limits) of the drive.</p> <p> WARNING! An incorrect setting may cause the motor to rush uncontrollably, or the brake chopper or resistor to overload.</p> <p>Note: The selections shown depend on the hardware of the drive. If only one voltage range is valid for the drive in question, it is selected by default.</p> | - |
| | Not given | No voltage range selected. The drive will not start modulating before a range is selected. | 0 |
| | 208...240 V | 208...240 V | 1 |
| | 380...415 V | 380...415 V | 2 |
| | 440...480 V | 440...480 V | 3 |
| | 500 V | 500 V | 4 |
| | 525...600 V | 525...600 V | 5 |
| | 660...690 V | 660...690 V | 6 |
| 95.02 | <i>Adaptive voltage limits</i> | <p>Enables adaptive voltage limits.</p> <p>Adaptive voltage limits can be used if, for example, an IGBT supply unit is used to raise the DC voltage level. If the communication between the inverter and IGBT supply unit is active, the voltage limits are related to the DC voltage reference from the IGBT supply unit. Otherwise the limits are calculated based on the measured DC voltage at the end of the pre-charging sequence.</p> <p>This function is also useful if the AC supply voltage to the drive is high, as the warning levels are raised accordingly.</p> | <i>Disable</i> |
| | Disable | Adaptive voltage limits disabled. | 0 |
| | Enable | Adaptive voltage limits enabled. | 1 |
| 95.04 | <i>Control board supply</i> | Specifies how the control unit of the drive is powered. | <i>Internal 24V; External 24V (95.20 b4)</i> |
| | Internal 24V | The drive control unit is powered from the drive power unit it is connected to. | 0 |
| | External 24V | The drive control unit is powered from an external power supply. | 1 |
| | Redundant external 24V | (Type BCU control units only) The drive control unit is powered from two redundant external power supplies. The loss of one of the supplies generates a warning (<i>AFEC External power signal missing</i>). | 2 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-----------------------------|---|--|
| 95.08 | <i>DC switch monitoring</i> | <p>Enables/disables DC switch monitoring via the DIIL input. This setting is intended for use with inverter modules with an internal charging circuit that are connected to the DC bus through a DC switch.</p> <p>An auxiliary contact of the DC switch must be wired to the DIIL input so that the input switches off when the DC switch is opened.</p>  <p>If the DC switch is opened with the inverter running, the inverter is given a coast-to-stop command, and its charging circuit activated. Starting the inverter is prevented until the DC switch is closed and the DC circuit in the inverter unit recharged.</p> <p>Notes:</p> <ul style="list-style-type: none"> • By default, DIIL is the input for the Run enable signal. Adjust 20.12 Run enable 1 source if necessary. • An internal charging circuit is standard on some inverter module types but optional on others; check with your local ABB representative. | <i>Disable;</i> <i>Enable</i> (95.20 b5) |
| | Disable | DC switch monitoring through the DIIL input disabled. | 0 |
| | Enable | DC switch monitoring through the DIIL input enabled. | 1 |
| 95.09 | <i>Fuse switch control</i> | <p>Activates communication to a xSFC charging controller. This setting is intended for use with inverter modules that are connected to a DC bus through a DC switch/charging circuit controlled by a charging controller.</p> <p>The charging controller monitors the charging of the inverter unit, and sends an enable command when the charging has finished. When the DC switch is opened, the charging controller stops the inverter.</p> <p>For more information, see xSFC documentation.</p> | <i>Disable;</i> <i>Enable</i> (95.20 b7) |
| | Disable | Communication with xSFC disabled. | 0 |
| | Enable | Communication with xSFC enabled. | 1 |
| | 0000h...FFFFh | Inverter modules connected. | 1 = 1 |

340 Parameters

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | |
|--|----------------------------|--|----------------|-----|------|-------------|---|----------|--|---|-----------------|--|---|-----------------|---|--------|----------|--|
| 95.15 | <i>Special HW settings</i> | <p>Contains hardware-related settings that can be enabled and disabled by toggling the specific bits.</p> <p>Note: The installation of the hardware specified by this parameter may require derating of drive output, or impose other limitations. Refer to the hardware manual of the drive.</p> | - | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th data-bbox="170 371 247 400">Bit</th> <th data-bbox="247 371 412 400">Name</th> <th data-bbox="412 371 971 400">Information</th> </tr> </thead> <tbody> <tr> <td data-bbox="170 400 247 472">0</td> <td data-bbox="247 400 412 472">EX motor</td> <td data-bbox="412 400 971 472">1 = An 'Ex' motor is connected to the output of the drive/inverter. To be activated if an 'Ex' motor is used, and located in a potentially explosive atmosphere.</td> </tr> <tr> <td data-bbox="170 472 247 517">1</td> <td data-bbox="247 472 412 517">ABB Sine filter</td> <td data-bbox="412 472 971 517">1 = An ABB sine filter is connected to the output of the drive/inverter.</td> </tr> <tr> <td data-bbox="170 517 247 588">2</td> <td data-bbox="247 517 412 588">High speed mode</td> <td data-bbox="412 517 971 588">1 = Switching frequency adaptation to output frequency active. This setting improves control performance at high output frequencies (typically above 112 Hz).</td> </tr> <tr> <td data-bbox="170 588 247 619">3...15</td> <td data-bbox="247 588 412 619">Reserved</td> <td data-bbox="412 588 971 619"></td> </tr> </tbody> </table> | | | | Bit | Name | Information | 0 | EX motor | 1 = An 'Ex' motor is connected to the output of the drive/inverter. To be activated if an 'Ex' motor is used, and located in a potentially explosive atmosphere. | 1 | ABB Sine filter | 1 = An ABB sine filter is connected to the output of the drive/inverter. | 2 | High speed mode | 1 = Switching frequency adaptation to output frequency active. This setting improves control performance at high output frequencies (typically above 112 Hz). | 3...15 | Reserved | |
| Bit | Name | Information | | | | | | | | | | | | | | | | |
| 0 | EX motor | 1 = An 'Ex' motor is connected to the output of the drive/inverter. To be activated if an 'Ex' motor is used, and located in a potentially explosive atmosphere. | | | | | | | | | | | | | | | | |
| 1 | ABB Sine filter | 1 = An ABB sine filter is connected to the output of the drive/inverter. | | | | | | | | | | | | | | | | |
| 2 | High speed mode | 1 = Switching frequency adaptation to output frequency active. This setting improves control performance at high output frequencies (typically above 112 Hz). | | | | | | | | | | | | | | | | |
| 3...15 | Reserved | | | | | | | | | | | | | | | | | |
| 0000b...0111b | | Hardware options configuration word. | 1 = 1 | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---------------------------------------|--|----------------|-----|------|-------------|---|------------------------|--|---|----------------------|--|---|----------------------|--|---|---------------------------------|---|---|---------------------------------|--|---|------------------|---|---|------------------|---|---|--------------------------------|--|---|----------------|--|---|------------------|--|----|---------------------------------------|--|----|-----------------------|--|----|----------|--|----|-------------------------|---|----|--------------------|----------|----|-----------------------|---|
| 95.20 | <i>HW options word 1</i> | Specifies hardware-related options that require differentiated parameter defaults. Activating a bit in this parameter makes the necessary changes in other parameters – for example, activating an emergency stop option reserves a digital input. In most cases, the differentiated parameters will also be write-protected. This parameter, as well as the changes in other parameters implemented by it, are not affected by a parameter restore. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Supply frequency 60 Hz</td> <td>0 = 50 Hz; 1 = 60 Hz. Affects parameters 11.45, 11.59, 12.20, 13.18, 30.11, 30.12, 30.13, 30.14, 31.26, 31.27, 46.01, 46.02.</td> </tr> <tr> <td>1</td> <td>Emergency stop Cat 0</td> <td>Emergency stop, Category 0, without FSO module. Affects parameters 21.04, 21.05, 23.11.</td> </tr> <tr> <td>2</td> <td>Emergency stop Cat 1</td> <td>Emergency stop, Category 1, without FSO module. Affects parameters 10.24, 21.04, 21.05, 23.11.</td> </tr> <tr> <td>3</td> <td>RO2 for -07 cabinet cooling fan</td> <td>1 = Control of cabinet cooling fan (used only with specific ACS880-07 hardware). Affects parameters 10.27, 10.28, 10.29.</td> </tr> <tr> <td>4</td> <td>Externally powered control unit</td> <td>1 = Control unit powered externally. Affects parameter 95.04.</td> </tr> <tr> <td>5</td> <td>DC supply switch</td> <td>1 = DC switch monitoring active. Affects parameters 20.12, 31.03, 95.08. Note: Setting this bit activates the Run enable signal. Recheck 20.12 and adjust if necessary</td> </tr> <tr> <td>6</td> <td>DOL motor switch</td> <td>1 = Motor fan control active. Affects parameters 10.24, 35.100, 35.103, 35.104.</td> </tr> <tr> <td>7</td> <td>xSFC-01 fuse switch controller</td> <td>1 = xSFC charging controller used. Affects parameter 95.09.</td> </tr> <tr> <td>8</td> <td>Service switch</td> <td>1 = Service switch connected. Affects parameters 31.01, 31.02.</td> </tr> <tr> <td>9</td> <td>Output contactor</td> <td>1 = Output contactor present. Affects parameters 10.24, 20.12.</td> </tr> <tr> <td>10</td> <td>Brake resistor, sine filter, IP54 fan</td> <td>1 = Status (eg. thermal) switches connected to DI11 input. Affects 20.11, 20.12.</td> </tr> <tr> <td>11</td> <td>INU-DSU communication</td> <td>Supply unit control by inverter unit. 1 = Yes (activates communication through RDCO module CH1)</td> </tr> <tr> <td>12</td> <td>Reserved</td> <td></td> </tr> <tr> <td>13</td> <td>Du/dt filter activation</td> <td>1 = A du/dt filter is connected to the drive/inverter output. Note: This bit is to be left at 0 if the drive/inverter module is equipped with internal du/dt filtering (for example, frame R8i inverter modules with option +E205).</td> </tr> <tr> <td>14</td> <td>DOL fan activation</td> <td>Reserved</td> </tr> <tr> <td>15</td> <td>INU-ISU communication</td> <td>1 = IGBT supply unit control by inverter unit active.</td> </tr> </tbody> </table> | | | | Bit | Name | Information | 0 | Supply frequency 60 Hz | 0 = 50 Hz; 1 = 60 Hz. Affects parameters 11.45 , 11.59 , 12.20 , 13.18 , 30.11 , 30.12 , 30.13 , 30.14 , 31.26 , 31.27 , 46.01 , 46.02 . | 1 | Emergency stop Cat 0 | Emergency stop, Category 0, without FSO module. Affects parameters 21.04 , 21.05 , 23.11 . | 2 | Emergency stop Cat 1 | Emergency stop, Category 1, without FSO module. Affects parameters 10.24 , 21.04 , 21.05 , 23.11 . | 3 | RO2 for -07 cabinet cooling fan | 1 = Control of cabinet cooling fan (used only with specific ACS880-07 hardware). Affects parameters 10.27 , 10.28 , 10.29 . | 4 | Externally powered control unit | 1 = Control unit powered externally. Affects parameter 95.04 . | 5 | DC supply switch | 1 = DC switch monitoring active. Affects parameters 20.12 , 31.03 , 95.08 . Note: Setting this bit activates the Run enable signal. Recheck 20.12 and adjust if necessary | 6 | DOL motor switch | 1 = Motor fan control active. Affects parameters 10.24 , 35.100 , 35.103 , 35.104 . | 7 | xSFC-01 fuse switch controller | 1 = xSFC charging controller used. Affects parameter 95.09 . | 8 | Service switch | 1 = Service switch connected. Affects parameters 31.01 , 31.02 . | 9 | Output contactor | 1 = Output contactor present. Affects parameters 10.24 , 20.12 . | 10 | Brake resistor, sine filter, IP54 fan | 1 = Status (eg. thermal) switches connected to DI11 input. Affects 20.11 , 20.12 . | 11 | INU-DSU communication | Supply unit control by inverter unit. 1 = Yes (activates communication through RDCO module CH1) | 12 | Reserved | | 13 | Du/dt filter activation | 1 = A du/dt filter is connected to the drive/inverter output. Note: This bit is to be left at 0 if the drive/inverter module is equipped with internal du/dt filtering (for example, frame R8i inverter modules with option +E205). | 14 | DOL fan activation | Reserved | 15 | INU-ISU communication | 1 = IGBT supply unit control by inverter unit active. |
| Bit | Name | Information | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Supply frequency 60 Hz | 0 = 50 Hz; 1 = 60 Hz. Affects parameters 11.45 , 11.59 , 12.20 , 13.18 , 30.11 , 30.12 , 30.13 , 30.14 , 31.26 , 31.27 , 46.01 , 46.02 . | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Emergency stop Cat 0 | Emergency stop, Category 0, without FSO module. Affects parameters 21.04 , 21.05 , 23.11 . | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Emergency stop Cat 1 | Emergency stop, Category 1, without FSO module. Affects parameters 10.24 , 21.04 , 21.05 , 23.11 . | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | RO2 for -07 cabinet cooling fan | 1 = Control of cabinet cooling fan (used only with specific ACS880-07 hardware). Affects parameters 10.27 , 10.28 , 10.29 . | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Externally powered control unit | 1 = Control unit powered externally. Affects parameter 95.04 . | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | DC supply switch | 1 = DC switch monitoring active. Affects parameters 20.12 , 31.03 , 95.08 . Note: Setting this bit activates the Run enable signal. Recheck 20.12 and adjust if necessary | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | DOL motor switch | 1 = Motor fan control active. Affects parameters 10.24 , 35.100 , 35.103 , 35.104 . | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | xSFC-01 fuse switch controller | 1 = xSFC charging controller used. Affects parameter 95.09 . | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | Service switch | 1 = Service switch connected. Affects parameters 31.01 , 31.02 . | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | Output contactor | 1 = Output contactor present. Affects parameters 10.24 , 20.12 . | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Brake resistor, sine filter, IP54 fan | 1 = Status (eg. thermal) switches connected to DI11 input. Affects 20.11 , 20.12 . | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | INU-DSU communication | Supply unit control by inverter unit. 1 = Yes (activates communication through RDCO module CH1) | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | Du/dt filter activation | 1 = A du/dt filter is connected to the drive/inverter output. Note: This bit is to be left at 0 if the drive/inverter module is equipped with internal du/dt filtering (for example, frame R8i inverter modules with option +E205). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | DOL fan activation | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | INU-ISU communication | 1 = IGBT supply unit control by inverter unit active. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0000h...FFFFh | | Hardware options configuration word 1. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | |
|---|---------------------------|---|----------------|-----|------|-------------|---|----------|--|--------|----------|--|
| 95.21 | <i>HW options word 2</i> | Specifies more hardware-related options that require differentiated parameter defaults. See parameter 95.20 HW options word 1 . | - | | | | | | | | | |
| <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Dual use</td> <td>1 = Dual use active. For drives with option +N8200. (Allows higher output frequencies and frequency reference limits.)</td> </tr> <tr> <td>1...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | | | | Bit | Name | Information | 0 | Dual use | 1 = Dual use active. For drives with option +N8200. (Allows higher output frequencies and frequency reference limits.) | 1...15 | Reserved | |
| Bit | Name | Information | | | | | | | | | | |
| 0 | Dual use | 1 = Dual use active. For drives with option +N8200. (Allows higher output frequencies and frequency reference limits.) | | | | | | | | | | |
| 1...15 | Reserved | | | | | | | | | | | |
| 0000h...FFFFh | | Hardware options configuration word 2. | 1 = 1 | | | | | | | | | |
| 96 System | | | | | | | | | | | | |
| 96 System | | Language selection; access levels; macro selection; parameter save and restore; control unit reboot; user parameter sets; unit selection. | | | | | | | | | | |
| 96.01 | <i>Language</i> | Selects the language of the parameter interface and other displayed information when viewed on the control panel. Note: <ul style="list-style-type: none"> Not all languages listed below are necessarily supported. This parameter does not affect the languages visible in the Drive composer PC tool. (Those are specified under View – Settings.) | - | | | | | | | | | |
| | Not selected | None. | 0 | | | | | | | | | |
| | English | English. | 1033 | | | | | | | | | |
| | Deutsch | German. | 1031 | | | | | | | | | |
| | Italiano | Italian. | 1040 | | | | | | | | | |
| | Español | Spanish. | 3082 | | | | | | | | | |
| | Portugues | Portuguese. | 2070 | | | | | | | | | |
| | Nederlands | Dutch. | 1043 | | | | | | | | | |
| | Français | French. | 1036 | | | | | | | | | |
| | Dansk | Danish. | 1030 | | | | | | | | | |
| | Suomi | Finnish. | 1035 | | | | | | | | | |
| | Svenska | Swedish. | 1053 | | | | | | | | | |
| | Russki | Russian. | 1049 | | | | | | | | | |
| | Polski | Polish. | 1045 | | | | | | | | | |
| | Czech | Czech. | 1029 | | | | | | | | | |
| | Chinese (Simplified, PRC) | Simplified Chinese. | 2052 | | | | | | | | | |
| | Türkçe | Turkish. | 1055 | | | | | | | | | |
| 96.02 | <i>Pass code</i> | Pass codes can be entered into this parameter to activate further access levels, for example additional parameters, parameter lock, etc. See parameter 96.03 Access levels active . Entering "358" toggles the parameter lock, which prevents the changing of all other parameters through the control panel or the Drive composer PC tool. | 0 | | | | | | | | | |
| | 0...99999999 | Pass code. | - | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | |
|--------|-----------------------------|---|----------------|------|---|----------|---|---------|---|---------------------|--------|----------|----|--------------------|----|--------------------|----|--------------------|----|----------------|----|----------|-------|
| 96.03 | <i>Access levels active</i> | Shows which access levels have been activated by pass codes entered into parameter 96.02 Pass code . This parameter is read-only. <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>End user</td> </tr> <tr> <td>1</td> <td>Service</td> </tr> <tr> <td>2</td> <td>Advanced programmer</td> </tr> <tr> <td>3...10</td> <td>Reserved</td> </tr> <tr> <td>11</td> <td>OEM access level 1</td> </tr> <tr> <td>12</td> <td>OEM access level 2</td> </tr> <tr> <td>13</td> <td>OEM access level 3</td> </tr> <tr> <td>14</td> <td>Parameter lock</td> </tr> <tr> <td>15</td> <td>Reserved</td> </tr> </tbody> </table> | Bit | Name | 0 | End user | 1 | Service | 2 | Advanced programmer | 3...10 | Reserved | 11 | OEM access level 1 | 12 | OEM access level 2 | 13 | OEM access level 3 | 14 | Parameter lock | 15 | Reserved | 0001h |
| Bit | Name | | | | | | | | | | | | | | | | | | | | | | |
| 0 | End user | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Service | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Advanced programmer | | | | | | | | | | | | | | | | | | | | | | |
| 3...10 | Reserved | | | | | | | | | | | | | | | | | | | | | | |
| 11 | OEM access level 1 | | | | | | | | | | | | | | | | | | | | | | |
| 12 | OEM access level 2 | | | | | | | | | | | | | | | | | | | | | | |
| 13 | OEM access level 3 | | | | | | | | | | | | | | | | | | | | | | |
| 14 | Parameter lock | | | | | | | | | | | | | | | | | | | | | | |
| 15 | Reserved | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Active access levels. | - | | | | | | | | | | | | | | | | | | | | |
| 96.04 | <i>Macro select</i> | Selects the application macro. For more information, see <i>ACS880 primary control program firmware manual (3AUA0000085967[English])</i> . After a selection is made, the parameter reverts automatically to <i>Done</i> . | <i>Done</i> | | | | | | | | | | | | | | | | | | | | |
| | Done | Macro selection complete; normal operation. | 0 | | | | | | | | | | | | | | | | | | | | |
| | Factory | Factory macro | 1 | | | | | | | | | | | | | | | | | | | | |
| | Hand/Auto | Hand/Auto macro | 2 | | | | | | | | | | | | | | | | | | | | |
| | Sequence control | Sequential control macro | 5 | | | | | | | | | | | | | | | | | | | | |
| | FIELDBUS | Reserved. | 6 | | | | | | | | | | | | | | | | | | | | |
| 96.05 | <i>Macro active</i> | Shows which application macro is currently selected. For more information, see <i>ACS880 primary control program firmware manual (3AUA0000085967[English])</i> . To change the macro, use parameter 96.04 Macro select . | <i>Factory</i> | | | | | | | | | | | | | | | | | | | | |
| | Factory | Factory macro | 1 | | | | | | | | | | | | | | | | | | | | |
| | Hand/Auto | Hand/Auto macro | 2 | | | | | | | | | | | | | | | | | | | | |
| | Sequence control | Sequential control macro | 5 | | | | | | | | | | | | | | | | | | | | |
| | FIELDBUS | Fieldbus control macro | 6 | | | | | | | | | | | | | | | | | | | | |
| 96.06 | <i>Parameter restore</i> | Restores the original settings of the control program, ie. parameter default values. Note: This parameter cannot be changed while the drive is running. | <i>Done</i> | | | | | | | | | | | | | | | | | | | | |
| | Done | Restoring is completed. | 0 | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----------------------|---|--|-----------------------|
| | Restore defaults | All editable parameter values are restored to default values, except <ul style="list-style-type: none"> • motor data and ID run results • parameter 31.42 Overcurrent fault limit • control panel/PC communication settings • I/O extension module settings • fieldbus adapter settings • encoder configuration data • application macro selection and the parameter defaults implemented by it • parameter 95.01 Supply voltage • parameter 95.20 HW options word 1 and the differentiated defaults implemented by it. | 8 |
| | Clear all | All editable parameter values are restored to default values, except <ul style="list-style-type: none"> • control panel/PC communication settings • fieldbus adapter settings • application macro selection and the parameter defaults implemented by it • parameter 95.01 Supply voltage • parameter 95.20 HW options word 1 and the differentiated defaults implemented by it. PC tool communication is interrupted during the restoring. | 62 |
| 96.07 | Parameter save manually | Saves the valid parameter values to permanent memory. This parameter should be used to store values sent from a fieldbus, or when using an external power supply to the control board as the supply might have a very short hold-up time when powered off. Note: A new parameter value is saved automatically when changed from the PC tool or control panel but not when altered through a fieldbus adapter connection. | Done |
| | Done | Save completed. | 0 |
| | Save | Save in progress. | 1 |
| 96.08 | Control board boot | Changing the value of this parameter to 1 reboots the control unit (without requiring a power off/on cycle of the complete drive module). The value reverts to 0 automatically. | 0 |
| | 0...1 | 1 = Reboot the control unit. | 1 = 1 |
| 96.09 | FSO reboot | Changing the value of (or the source selected by) this parameter to 1 reboots the optional FSO-xx safety functions module. Note: The value does not reverts to 0 automatically. | FALSE |
| | FALSE | 0. | 0 |
| | True | 1. | 1 |
| | Other [bit] | Source selection (see Terms and abbreviations on page 101). | - |
| 96.10 | User set status | Shows the status of the user parameter sets. This parameter is read-only. See also section User parameter sets (page 92). | - |
| | n/a | No user parameter sets have been saved. | 0 |
| | Loading | A user set is being loaded. | 1 |



| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | |
|--|--|--|--|--|-----------------------------|---|---|-------|---|---|-------|---|---|-------|---|---|-------|---------------------|
| | Saving | A user set is being saved. | 2 | | | | | | | | | | | | | | | |
| | Faulted | Invalid or empty parameter set. | 3 | | | | | | | | | | | | | | | |
| | User set 1 | User set 1 has been loaded. | 4 | | | | | | | | | | | | | | | |
| | User set 2 | User set 2 has been loaded. | 5 | | | | | | | | | | | | | | | |
| | User set 3 | User set 3 has been loaded. | 6 | | | | | | | | | | | | | | | |
| | User set 4 | User set 4 has been loaded. | 7 | | | | | | | | | | | | | | | |
| 96.11 | <i>User set save/load</i> | <p>Enables the saving and restoring of up to four custom sets of parameter settings. See section User parameter sets (page 92).</p> <p>The set that was in use before powering down the drive is in use after the next power-up.</p> <p>Notes:</p> <ul style="list-style-type: none"> Hardware configuration settings such as I/O extension module, fieldbus and encoder configuration parameters (groups 14...16, 47, 51...56, 58 and 92...93) are forced input/output values (such as 10.03 and 10.04) are not included in user parameter sets. Parameter changes made after loading a set are not automatically stored – they must be saved using this parameter. | <i>No action</i> | | | | | | | | | | | | | | | |
| | No action | Load or save operation complete; normal operation. | 0 | | | | | | | | | | | | | | | |
| | User set I/O mode | Load user parameter set using parameters 96.12 User set IO sel in1 and 96.13 User set IO sel in2 . | 1 | | | | | | | | | | | | | | | |
| | Load set 1 | Load user parameter set 1. | 2 | | | | | | | | | | | | | | | |
| | Load set 2 | Load user parameter set 2. | 3 | | | | | | | | | | | | | | | |
| | Load set 3 | Load user parameter set 3. | 4 | | | | | | | | | | | | | | | |
| | Load set 4 | Load user parameter set 4. | 5 | | | | | | | | | | | | | | | |
| | Save to set 1 | Save user parameter set 1. | 18 | | | | | | | | | | | | | | | |
| | Save to set 2 | Save user parameter set 2. | 19 | | | | | | | | | | | | | | | |
| | Save to set 3 | Save user parameter set 3. | 20 | | | | | | | | | | | | | | | |
| | Save to set 4 | Save user parameter set 4. | 21 | | | | | | | | | | | | | | | |
| 96.12 | <i>User set IO sel in1</i> | <p>When parameter 96.11 User set save/load is set to User set I/O mode, selects the user parameter set together with parameter 96.13 User set IO sel in2 as follows:</p> <table border="1" data-bbox="415 1129 893 1347"> <thead> <tr> <th>Status of source defined by par. 96.12</th> <th>Status of source defined by par. 96.13</th> <th>User parameter set selected</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Set 1</td> </tr> <tr> <td>1</td> <td>0</td> <td>Set 2</td> </tr> <tr> <td>0</td> <td>1</td> <td>Set 3</td> </tr> <tr> <td>1</td> <td>1</td> <td>Set 4</td> </tr> </tbody> </table> | Status of source defined by par. 96.12 | Status of source defined by par. 96.13 | User parameter set selected | 0 | 0 | Set 1 | 1 | 0 | Set 2 | 0 | 1 | Set 3 | 1 | 1 | Set 4 | <i>Not selected</i> |
| Status of source defined by par. 96.12 | Status of source defined by par. 96.13 | User parameter set selected | | | | | | | | | | | | | | | | |
| 0 | 0 | Set 1 | | | | | | | | | | | | | | | | |
| 1 | 0 | Set 2 | | | | | | | | | | | | | | | | |
| 0 | 1 | Set 3 | | | | | | | | | | | | | | | | |
| 1 | 1 | Set 4 | | | | | | | | | | | | | | | | |
| | Not selected | 0. | 0 | | | | | | | | | | | | | | | |
| | Selected | 1. | 1 | | | | | | | | | | | | | | | |
| | DI1 | Digital input DI1 (10.02 DI delayed status , bit 0). | 2 | | | | | | | | | | | | | | | |
| | DI2 | Digital input DI2 (10.02 DI delayed status , bit 1). | 3 | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | |
|--------------|-------------------------------------|---|------------------------|------|-------------|---|------------|------------------|---|----------|--|---|------------------|--------------------------|---|----------|--|---|-------------|----------------------------------|--------|----------|--|------------|
| | DI3 | Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2). | 4 | | | | | | | | | | | | | | | | | | | | | |
| | DI4 | Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3). | 5 | | | | | | | | | | | | | | | | | | | | | |
| | DI5 | Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4). | 6 | | | | | | | | | | | | | | | | | | | | | |
| | DI6 | Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5). | 7 | | | | | | | | | | | | | | | | | | | | | |
| | DIO1 | Digital input/output DIO1 (<i>11.02 DIO delayed status</i> , bit 0). | 10 | | | | | | | | | | | | | | | | | | | | | |
| | DIO2 | Digital input/output DIO2 (<i>11.02 DIO delayed status</i> , bit 1). | 11 | | | | | | | | | | | | | | | | | | | | | |
| | <i>Other [bit]</i> | Source selection (see <i>Terms and abbreviations</i> on page 101). | - | | | | | | | | | | | | | | | | | | | | | |
| <i>96.13</i> | <i>User set IO sel in2</i> | See parameter <i>96.12 User set IO sel in1</i> . | <i>Not selected</i> | | | | | | | | | | | | | | | | | | | | | |
| <i>96.16</i> | <i>Unit selection</i> | Selects the unit of parameters indicating power, temperature and torque. <table border="1" data-bbox="412 555 797 821"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Power unit</td> <td>0 = kW 1 = hp</td> </tr> <tr> <td>1</td> <td>Reserved</td> <td></td> </tr> <tr> <td>2</td> <td>Temperature unit</td> <td>0 = C (°C) 1 = F (°F)</td> </tr> <tr> <td>3</td> <td>Reserved</td> <td></td> </tr> <tr> <td>4</td> <td>Torque unit</td> <td>0 = Nm (N·m) 1 = lbft (lb·ft)</td> </tr> <tr> <td>5...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> | Bit | Name | Information | 0 | Power unit | 0 = kW 1 = hp | 1 | Reserved | | 2 | Temperature unit | 0 = C (°C) 1 = F (°F) | 3 | Reserved | | 4 | Torque unit | 0 = Nm (N·m) 1 = lbft (lb·ft) | 5...15 | Reserved | | 0000 0000b |
| Bit | Name | Information | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Power unit | 0 = kW 1 = hp | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Reserved | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Temperature unit | 0 = C (°C) 1 = F (°F) | | | | | | | | | | | | | | | | | | | | | | |
| 3 | Reserved | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Torque unit | 0 = Nm (N·m) 1 = lbft (lb·ft) | | | | | | | | | | | | | | | | | | | | | | |
| 5...15 | Reserved | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000 0000b...0001 0101b | Unit selection word. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | |
| <i>96.20</i> | <i>Time sync primary source</i> | Defines the 1st priority external source for synchronization of the drive's time and date. | <i>DDCS Controller</i> | | | | | | | | | | | | | | | | | | | | | |
| | Internal | No external source selected. | 0 | | | | | | | | | | | | | | | | | | | | | |
| | DDCS Controller | External controller. | 1 | | | | | | | | | | | | | | | | | | | | | |
| | Fieldbus A or B | Fieldbus interface A or B. | 2 | | | | | | | | | | | | | | | | | | | | | |
| | Fieldbus A | Fieldbus interface A. | 3 | | | | | | | | | | | | | | | | | | | | | |
| | Fieldbus B | Fieldbus interface B. | 4 | | | | | | | | | | | | | | | | | | | | | |
| | Embedded FB | Reserved. | 6 | | | | | | | | | | | | | | | | | | | | | |
| | Embedded Ethernet | Ethernet port on type BCU control unit. | 7 | | | | | | | | | | | | | | | | | | | | | |
| | Panel link | Control panel, or Drive composer PC tool connected to the control panel. | 8 | | | | | | | | | | | | | | | | | | | | | |
| | Ethernet tool link | Drive composer PC tool through an FENA module. | 9 | | | | | | | | | | | | | | | | | | | | | |
| <i>96.24</i> | <i>Full days since 1st Jan 1980</i> | Number of full days passed since beginning of the year 1980. This parameter, together with <i>96.25 Time in minutes within 24 h</i> and <i>96.26 Time in ms within one minute</i> makes it possible to set the date and time in the drive via the parameter interface from a fieldbus or application program. This may be necessary if the fieldbus protocol does not support time synchronization. | - | | | | | | | | | | | | | | | | | | | | | |
| | 1...59999 | Days since beginning of 1980. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-------|-------------------------------------|--|----------------|------|-------------|---|--------------------|--|---|------------------------|--|---|---------------------------|---|---|-----------------|--|---|-----------------|---|---|----------|--|---|-----|--|---|-------|---|---|-------|---|---|-----|--|----|----------|---|----|------------|---|----|--------------------|---|----|-------------------|--|----|-----|---|----|---------------|---|--|
| 96.25 | <i>Time in minutes within 24 h</i> | Number of full minutes passed since midnight. For example, the value 860 corresponds to 2:20 pm. See parameter 96.24 Full days since 1st Jan 1980 . | 0 min | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 1...1439 | Minutes since midnight. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 96.26 | <i>Time in ms within one minute</i> | Number of milliseconds passed since last minute. See parameter 96.24 Full days since 1st Jan 1980 . | 0 ms | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0...59999 | Number of milliseconds since last minute. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 96.29 | <i>Time sync source status</i> | Time source status word. This parameter is read-only. | - | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | | <table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Time tick received</td> <td>1 = 1st priority tick received: Tick has been received from 1st priority source.</td> </tr> <tr> <td>1</td> <td>Aux Time tick received</td> <td>1 = 2nd priority tick received: Tick has been received from 2nd priority source.</td> </tr> <tr> <td>2</td> <td>Tick interval is too long</td> <td>1 = Yes: Tick interval too long (accuracy compromised).</td> </tr> <tr> <td>3</td> <td>DDCS controller</td> <td>1 = Tick received: Tick has been received from an external controller.</td> </tr> <tr> <td>4</td> <td>Master/Follower</td> <td>1 = Tick received: Tick has been received through the master/follower link.</td> </tr> <tr> <td>5</td> <td>Reserved</td> <td></td> </tr> <tr> <td>6</td> <td>D2D</td> <td>1 = Tick received: Tick has been received through the drive-to-drive link.</td> </tr> <tr> <td>7</td> <td>FbusA</td> <td>1 = Tick received: Tick has been received through fieldbus interface A.</td> </tr> <tr> <td>8</td> <td>FbusB</td> <td>1 = Tick received: Tick has been received through fieldbus interface B.</td> </tr> <tr> <td>9</td> <td>EFB</td> <td>1 = Tick received: Tick has been received through the embedded fieldbus interface.</td> </tr> <tr> <td>10</td> <td>Ethernet</td> <td>1 = Tick received: Tick has been received through the Ethernet port on type BCU control unit.</td> </tr> <tr> <td>11</td> <td>Panel link</td> <td>1 = Tick received: Tick has been received from the control panel, or Drive composer PC tool connected to the control panel.</td> </tr> <tr> <td>12</td> <td>Ethernet tool link</td> <td>1 = Tick received: Tick has been received from Drive composer PC tool through an FENA module.</td> </tr> <tr> <td>13</td> <td>Parameter setting</td> <td>1 = Tick received: Tick has been set by parameters 96.24...96.26.</td> </tr> <tr> <td>14</td> <td>RTC</td> <td>1 = RTC time in use: Time and date have been read from the real-time clock.</td> </tr> <tr> <td>15</td> <td>Drive On-Time</td> <td>1 = Drive on-time in use: Time and date are displaying drive on-time.</td> </tr> </tbody> </table> | Bit | Name | Description | 0 | Time tick received | 1 = 1st priority tick received: Tick has been received from 1st priority source. | 1 | Aux Time tick received | 1 = 2nd priority tick received: Tick has been received from 2nd priority source. | 2 | Tick interval is too long | 1 = Yes: Tick interval too long (accuracy compromised). | 3 | DDCS controller | 1 = Tick received: Tick has been received from an external controller. | 4 | Master/Follower | 1 = Tick received: Tick has been received through the master/follower link. | 5 | Reserved | | 6 | D2D | 1 = Tick received: Tick has been received through the drive-to-drive link. | 7 | FbusA | 1 = Tick received: Tick has been received through fieldbus interface A. | 8 | FbusB | 1 = Tick received: Tick has been received through fieldbus interface B. | 9 | EFB | 1 = Tick received: Tick has been received through the embedded fieldbus interface. | 10 | Ethernet | 1 = Tick received: Tick has been received through the Ethernet port on type BCU control unit. | 11 | Panel link | 1 = Tick received: Tick has been received from the control panel, or Drive composer PC tool connected to the control panel. | 12 | Ethernet tool link | 1 = Tick received: Tick has been received from Drive composer PC tool through an FENA module. | 13 | Parameter setting | 1 = Tick received: Tick has been set by parameters 96.24...96.26 . | 14 | RTC | 1 = RTC time in use: Time and date have been read from the real-time clock. | 15 | Drive On-Time | 1 = Drive on-time in use: Time and date are displaying drive on-time. | |
| Bit | Name | Description | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0 | Time tick received | 1 = 1st priority tick received: Tick has been received from 1st priority source. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1 | Aux Time tick received | 1 = 2nd priority tick received: Tick has been received from 2nd priority source. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | Tick interval is too long | 1 = Yes: Tick interval too long (accuracy compromised). | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 3 | DDCS controller | 1 = Tick received: Tick has been received from an external controller. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 4 | Master/Follower | 1 = Tick received: Tick has been received through the master/follower link. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 5 | Reserved | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 6 | D2D | 1 = Tick received: Tick has been received through the drive-to-drive link. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 7 | FbusA | 1 = Tick received: Tick has been received through fieldbus interface A. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 8 | FbusB | 1 = Tick received: Tick has been received through fieldbus interface B. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 9 | EFB | 1 = Tick received: Tick has been received through the embedded fieldbus interface. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 10 | Ethernet | 1 = Tick received: Tick has been received through the Ethernet port on type BCU control unit. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 11 | Panel link | 1 = Tick received: Tick has been received from the control panel, or Drive composer PC tool connected to the control panel. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 12 | Ethernet tool link | 1 = Tick received: Tick has been received from Drive composer PC tool through an FENA module. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 13 | Parameter setting | 1 = Tick received: Tick has been set by parameters 96.24...96.26 . | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 14 | RTC | 1 = RTC time in use: Time and date have been read from the real-time clock. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 15 | Drive On-Time | 1 = Drive on-time in use: Time and date are displaying drive on-time. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0000h...FFFFh | Time source status word 1. | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 96.31 | <i>Drive ID number</i> | Specifies an ID number for the drive. The ID can be read by an external controller through DDCS, for example, for comparison with an ID contained by the controller's application. | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 0...32767 | Drive ID number | 1 = 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------------------------|------------------------------|--|----------------------------|
| 97 Motor control | | Motor model settings. | |
| 97.03 | <i>Slip gain</i> | Defines the slip gain which is used to improve the estimated motor slip. 100% means full slip gain; 0% means no slip gain. The default value is 100%. Other values can be used if a static speed error is detected despite having the setting at full slip gain. Example (with nominal load and nominal slip of 40 rpm): A 1000 rpm constant speed reference is given to the drive. Despite having full slip gain (= 100%), a manual tachometer measurement from the motor axis gives a speed value of 998 rpm. The static speed error is 1000 rpm - 998 rpm = 2 rpm. To compensate the error, the slip gain should be increased to 105% (2 rpm / 40 rpm = 5%). | 100% |
| | 0...200% | Slip gain. | 1 = 1% |
| 97.04 | <i>Voltage reserve</i> | Defines the minimum allowed voltage reserve. When the voltage reserve has decreased to the set value, the drive enters the field weakening area. Note: This is an expert level parameter and should not be adjusted without appropriate skill. If the intermediate circuit DC voltage $U_{dc} = 550$ V and the voltage reserve is 5%, the RMS value of the maximum output voltage in steady-state operation is $0.95 \times 550 \text{ V} / \sqrt{2} = 369$ V The dynamic performance of the motor control in the field weakening area can be improved by increasing the voltage reserve value, but the drive enters the field weakening area earlier. | -2% |
| | -4...50% | Voltage reserve. | 1 = 1% |
| 97.05 | <i>Flux braking</i> | Defines the level of flux braking power. (Other stopping and braking modes can be configured in parameter group 21 Start/stop mode). See section Flux braking (page 75). Note: This is an expert level parameter and should not be adjusted without appropriate skill. | <i>Disabled</i> |
| | Disabled | Flux braking is disabled. | 0 |
| | Moderate | Flux level is limited during the braking. Deceleration time is longer compared to full braking. | 1 |
| | Full | Maximum braking power. Almost all available current is used to convert the mechanical braking energy to thermal energy in the motor. | 2 |
| 97.06 | <i>Flux reference select</i> | Defines the source of flux reference. Note: This is an expert level parameter and should not be adjusted without appropriate skill. | <i>User flux reference</i> |
| | Zero | None. | 0 |
| | User flux reference | Parameter 97.07 User flux reference . | 1 |
| | <i>Other</i> | Source selection (see Terms and abbreviations on page 101). | - |
| 97.07 | <i>User flux reference</i> | Defines the flux reference when parameter 97.06 Flux reference select is set to User flux reference . | 100.00% |
| | 0.00...200.00% | User-defined flux reference. | 100 = 1% |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|----------------------------|--|-----------------|
| 97.09 | <i>Switching freq mode</i> | An optimization setting for balancing between control performance and motor noise level. Note: This is an expert level parameter and should not be adjusted without appropriate skill. | <i>Normal</i> |
| | Normal | Control performance optimized for long motor cables. | 0 |
| | Low noise | Minimizes motor noise. Note: This setting requires derating. Refer to the rating data in the <i>Hardware manual</i> . | 1 |
| | Cyclic | Control performance optimized for cyclic load applications. Note: This setting is not suitable for long motor cables. | 2 |
| | Custom | This setting is to be used by ABB-authorized service personnel only. Note: This setting may require derating. Refer to the rating data in the <i>Hardware manual</i> . | 3 |
| 97.10 | <i>Signal injection</i> | Enables the anti-cogging function: a high-frequency alternating signal is injected to the motor in the low speed region to improve the stability of torque control. This removes the "cogging" that can sometimes be seen as the rotor passes the motor magnetic poles. Anti-cogging can be enabled with different amplitude levels. Notes: <ul style="list-style-type: none"> • This is an expert level parameter and should not be adjusted without appropriate skill. • Use as low a level as possible that gives satisfactory performance. • Signal injection cannot be applied to asynchronous motors. | <i>Disabled</i> |
| | Disabled | Anti-cogging disabled. | 0 |
| | Enabled (5 %) | Anti-cogging enabled with amplitude level of 5%. | 1 |
| | Enabled (10 %) | Anti-cogging enabled with amplitude level of 10%. | 2 |
| | Enabled (15 %) | Anti-cogging enabled with amplitude level of 15%. | 3 |
| | Enabled (20 %) | Anti-cogging enabled with amplitude level of 20%. | 4 |
| 97.11 | <i>TR tuning</i> | Rotor time constant tuning. This parameter can be used to improve torque accuracy in closed-loop control of an induction motor. Normally, the motor identification run provides sufficient torque accuracy, but manual fine-tuning can be applied in exceptionally demanding applications to achieve optimal performance. Note: This is an expert level parameter and should not be adjusted without appropriate skill. | 100% |
| | 25...400% | Rotor time constant tuning. | 1 = 1% |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---|--|----------------|
| 97.12 | <p><i>IR comp step-up frequency</i></p> <p>IR compensation (ie. output voltage boost) can be used in step-up applications to compensate for resistive losses in the step-up transformer, cabling and motor. As voltage cannot be fed through a step-up transformer at 0 Hz, a specific type of IR compensation should be used. This parameter adds a frequency breakpoint for parameter 97.13 IR compensation as shown below.</p>  <p>0.0 Hz = Breakpoint disabled</p> | 0.0 Hz | |
| | 0.0...50.0 Hz | IR compensation breakpoint for step-up applications. | 1 = 1 Hz |
| 97.13 | <p><i>IR compensation</i></p> <p>Defines the relative output voltage boost at zero speed (IR compensation). The function is useful in applications with a high break-away torque where direct torque control (DTC mode) cannot be applied.</p>  <p>50% of nominal frequency</p> <p>See also section IR compensation for scalar motor control on page 72.</p> | 0.00% | |
| | 0.00...50.00% | Voltage boost at zero speed in percent of nominal motor voltage. | 1 = 1% |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---|---|-----------------|
| 97.15 | <i>Motor model temperature adaptation</i> | Selects whether the temperature-dependent parameters (such as stator or rotor resistance) of the motor model adapt to actual (measured or estimated) temperature or not. See parameter group 35 Motor thermal protection for selection of temperature measurement sources. | <i>Disabled</i> |
| | Disabled | Temperature adaptation of motor model disabled. | 0 |
| | Estimated temperature | Estimated temperature (35.01 Motor estimated temperature) used for adaptation of motor model. | 1 |
| | Measured temperature 1 | Measured temperature 1 (35.02 Measured temperature 1) used for adaptation of motor model. | 2 |
| | Measured temperature 2 | Measured temperature 2 (35.03 Measured temperature 2) used for adaptation of motor model. | 3 |
| 97.32 | <i>Motor torque unfiltered</i> | Unfiltered motor torque in percent of the nominal motor torque | |
| | -1600.0 ... 1600.0% | Unfiltered motor torque. | |
| 97.33 | <i>Speed estimate filter time</i> | Defines a filtering time for estimated speed. See the diagram on page 480 . | 5.00 ms |
| | 0.00 ... 100.00 ms | Filtering time for estimated speed. | 1 = 1 ms |

| | | | |
|---------------------------------|------------------------------------|--|---------------------|
| 98 User motor parameters | | Motor values supplied by the user that are used in the motor model. These parameters are useful for non-standard motors, or to just get more accurate motor control of the motor on site. A better motor model always improves the shaft performance. | |
| 98.01 | <i>User motor model mode</i> | Activates the motor model parameters 98.02...98.14 and the rotor angle offset parameter 98.15 . Notes: <ul style="list-style-type: none"> Parameter value is automatically set to zero when ID run is selected by parameter 99.13 ID run requested. The values of parameters 98.02...98.15 are then updated according to the motor characteristics identified during the ID run. Measurements made directly from the motor terminals during the ID run are likely to produce slightly different values than those on a datasheet from a motor manufacturer. This parameter cannot be changed while the drive is running. | <i>Not selected</i> |
| | Not selected | Parameters 98.02...98.15 inactive. | 0 |
| | Motor parameters | The values of parameters 98.02...98.14 are used as the motor model. | 1 |
| | Position offset | The value of parameter 98.15 is used as the rotor angle offset. Parameters 98.02...98.14 are inactive. | 2 |
| | Motor parameters & position offset | The values of parameters 98.02...98.14 are used as the motor model, and the value of parameter 98.15 is used as the rotor angle offset. | 3 |

352 Parameters



| No. | Name/Value | Description | Def/ FbEq16 |
|-------|-----------------------------|--|----------------|
| 98.02 | <i>Rs user</i> | Defines the stator resistance R_S of the motor model. With a star-connected motor, R_S is the resistance of one winding. With a delta-connected motor, R_S is one-third of the resistance of one winding. | 0.00000 p.u. |
| | 0.00000 ...0.50000 p.u. | Stator resistance in per unit. | - |
| 98.03 | <i>Rr user</i> | Defines the rotor resistance R_R of the motor model. Note: This parameter is valid only for asynchronous motors. | 0.00000 p.u. |
| | 0.00000 ...0.50000 p.u. | Rotor resistance in per unit. | - |
| 98.04 | <i>Lm user</i> | Defines the main inductance L_M of the motor model. Note: This parameter is valid only for asynchronous motors. | 0.00000 p.u. |
| | 0.00000 ...10.00000 p.u. | Main inductance in per unit. | - |
| 98.05 | <i>SigmaL user</i> | Defines the leakage inductance σL_S . Note: This parameter is valid only for asynchronous motors. | 0.00000 p.u. |
| | 0.00000 ...1.00000 p.u. | Leakage inductance in per unit. | - |
| 98.06 | <i>Ld user</i> | Defines the direct axis (synchronous) inductance. Note: This parameter is valid only for permanent magnet motors. | 0.00000 p.u. |
| | 0.00000 ...10.00000 p.u | Direct axis inductance in per unit. | - |
| 98.07 | <i>Lq user</i> | Defines the quadrature axis (synchronous) inductance. Note: This parameter is valid only for permanent magnet motors. | 0.00000 p.u. |
| | 0.00000 ...10.00000 p.u | Quadrature axis inductance in per unit. | - |
| 98.08 | <i>PM flux user</i> | Defines the permanent magnet flux. Note: This parameter is valid only for permanent magnet motors. | 0.00000 p.u. |
| | 0.00000 ...2.00000 p.u | Permanent magnet flux in per unit. | - |
| 98.09 | <i>Rs user SI</i> | Defines the stator resistance R_S of the motor model. | 0.00000 ohm |
| | 0.00000 ...100.00000 ohm | Stator resistance. | - |
| 98.10 | <i>Rr user SI</i> | Defines the rotor resistance R_R of the motor model. Note: This parameter is valid only for asynchronous motors. | 0.00000 ohm |
| | 0.00000 ...100.00000 ohm | Rotor resistance. | - |
| 98.11 | <i>Lm user SI</i> | Defines the main inductance L_M of the motor model. Note: This parameter is valid only for asynchronous motors. | 0.00 mH |
| | 0.00...100000.01 mH | Main inductance. | 1 = 10000 mH |


| No. | Name/Value | Description | Def/ FbEq16 |
|----------------------|-----------------------------|--|---------------------------|
| 98.12 | <i>SigmaL user SI</i> | Defines the leakage inductance σL_S . Note: This parameter is valid only for asynchronous motors. | 0.00 mH |
| | 0.00...100000.01 mH | Leakage inductance. | 1 = 10000 mH |
| 98.13 | <i>Ld user SI</i> | Defines the direct axis (synchronous) inductance. Note: This parameter is valid only for permanent magnet motors. | 0.00 mH |
| | 0.00...100000.01 mH | Direct axis inductance. | 1 = 10000 mH |
| 98.14 | <i>Lq user SI</i> | Defines the quadrature axis (synchronous) inductance. Note: This parameter is valid only for permanent magnet motors. | 0.00 mH |
| | 0.00...100000.01 mH | Quadrature axis inductance. | 1 = 10000 mH |
| 98.15 | <i>Position offset user</i> | Defines an angle offset between the zero position of the synchronous motor and the zero position of the position sensor. This value is initially set by the autophasing routine when parameter 21.13 Autophasing mode is set to <i>Turning with Z-pulse</i> , and can be fine-tuned later on. Notes: <ul style="list-style-type: none"> The value is in electrical degrees. The electrical angle equals the mechanical angle multiplied by the number of motor pole pairs. This parameter is valid only for permanent magnet motors. | 0 deg |
| | 0...360 deg | Angle offset. | 1 = 1 deg |
| 99 Motor data | | Motor configuration settings. | |
| 99.03 | <i>Motor type</i> | Selects the motor type. Note: This parameter cannot be changed while the drive is running. | <i>Asynchronous motor</i> |
| | Asynchronous motor | Standard squirrel cage AC induction motor (asynchronous induction motor). | 0 |
| | Permanent magnet motor | Permanent magnet motor. Three-phase AC synchronous motor with permanent magnet rotor and sinusoidal BackEMF voltage. | 1 |
| | SynRM | (Only visible with option +N7502) Synchronous reluctance motor. Three-phase AC synchronous motor with salient pole rotor without permanent magnets. | 2 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|------------------------------|---|----------------|
| 99.04 | <i>Motor ctrl mode</i> | Selects the motor control mode. | <i>DTC</i> |
| | DTC | <p>Direct torque control. This mode is suitable for most applications.</p> <p>Note: Instead of direct torque control, scalar control is also available, and should be used in the following situations:</p> <ul style="list-style-type: none"> • with multimotor applications 1) if the load is not equally shared between the motors, 2) if the motors are of different sizes, or 3) if the motors are going to be changed after the motor identification (ID run) • if the nominal current of the motor is less than 1/6 of the nominal output current of the drive • if the drive is used with no motor connected (for example, for test purposes). <p>See also section <i>Operating modes of the drive</i> (page 53).</p> | 0 |
| | Scalar | <p>Scalar control. The outstanding motor control accuracy of DTC cannot be achieved in scalar control.</p> <p>Refer to the <i>DTC</i> selection above for a list of applications where scalar control should definitely be used.</p> <p>Note:</p> <ul style="list-style-type: none"> • Correct motor operation requires that the magnetizing current of the motor does not exceed 90% of the nominal current of the inverter. • Some standard features are disabled in scalar control mode. <p>See also section <i>Scalar motor control</i> (page 71), and section <i>Operating modes of the drive</i> (page 53).</p> | 1 |
| 99.06 | <i>Motor nominal current</i> | <p>Defines the nominal motor current. Must be equal to the value on the motor rating plate. If multiple motors are connected to the drive, enter the total current of the motors.</p> <p>For ESP with sine filter and step-up transformer instead of using the motor rating plate data, set the motor nominal current according to the calculated current. See the description of current calculation in section <i>Faults: D105 Brake confirmation fault</i> on page 50.</p> <p>Note:</p> <ul style="list-style-type: none"> • Correct motor operation requires that the magnetizing current of the motor does not exceed 90% of the nominal current of the drive. • This parameter cannot be changed while the drive is running. | 0.0 A |
| | 0.0...6400.0 A | Nominal current of the motor. The allowable range is $1/6 \dots 2 \times I_N$ (nominal current) of the drive ($0 \dots 2 \times I_N$ with scalar control mode). | 1 = 1 A |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|--|--|----------------|
| 99.07 | <i>Motor nominal voltage</i> | <p>Defines the nominal motor voltage supplied to the motor. This setting must match the value on the rating plate of the motor.</p> <p>For ESP with sine filter and step-up transformer instead of using the motor rating plate data, set the motor nominal voltage according to the nominal supply voltage of the drive (example: 690 V). For more information, see section Faults: D105 Brake confirmation fault on page 50.</p> <p>Note:</p> <ul style="list-style-type: none"> • With permanent magnet motors, the nominal voltage is the BackEMF voltage at nominal speed of the motor. If the voltage is given as voltage per rpm, e.g. 60 V per 1000 rpm, the voltage for a nominal speed of 3000 rpm is $3 \times 60 \text{ V} = 180 \text{ V}$. Note that the nominal voltage is not equal to the equivalent DC motor voltage (EDCM) specified by some motor manufacturers. The nominal voltage can be calculated by dividing the EDCM voltage by 1.7 (or square root of 3). • The stress on the motor insulation is always dependent on the drive supply voltage. This also applies to the case where the motor voltage rating is lower than that of the drive and the supply. • This parameter cannot be changed while the drive is running. | 0.0 V |
| | 0.0...800.0 V | Nominal voltage of the motor. The allowable range is $1/6...2 \times U_N$ (nominal voltage) of the drive. U_N equals the upper bound of the supply voltage range selected by parameter 95.01 Supply voltage . | 10 = 1 V |
| 99.08 | <i>Motor nominal frequency</i> | <p>Defines the nominal motor frequency. This setting must match the value on the rating plate of the motor.</p> <p>Note: This parameter cannot be changed while the drive is running.</p> | 50.00 Hz |
| | 0.00...500.00 Hz | Nominal frequency of the motor. | 10 = 1 Hz |
| 99.09 | <i>Motor nominal speed</i> | <p>Defines the nominal motor speed. The setting must match the value on the rating plate of the motor.</p> <p>Note: This parameter cannot be changed while the drive is running.</p> | 0 rpm |
| | 0...30000 rpm | Nominal speed of the motor. | 1 = 1 rpm |
| 99.10 | <i>Motor nominal power</i> | <p>Defines the nominal motor power. The setting must match the value on the rating plate of the motor. If nominal power is not shown on the rating plate, nominal torque can be entered instead in parameter 99.12.</p> <p>If multiple motors are connected to the drive, enter the total power of the motors.</p> <p>The unit is selected by parameter 96.16 Unit selection.</p> <p>Note: This parameter cannot be changed while the drive is running.</p> | 0.00 kW or hp |
| | 0.00 ... 10000.00 kW or 0.00 ... 13404.83 hp | Nominal power of the motor. | 1 = 1 unit |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------------------------------------|---|--|-----------------------|
| 99.11 | <i>Motor nominal cos Φ</i> | <p>Defines the cosphi of the motor for a more accurate motor model. The value is not obligatory, but is useful with an asynchronous motor, especially when performing a standstill identification run. The setting should match the value on the rating plate of the motor.</p> <p>With a permanent magnet or synchronous reluctance motor, this value is not needed.</p> <p>Note: This parameter cannot be changed while the drive is running.</p> | 0.00 |
| 0.00...1.00 | Cosphi of the motor. | 100 = 1 | |
| 99.12 | <i>Motor nominal torque</i> | <p>Defines the nominal motor shaft torque. This value can be given instead of nominal power (99.10) if shown on the rating plate of the motor.</p> <p>The unit is selected by parameter 96.16 <i>Unit selection</i>.</p> <p>Note:</p> <ul style="list-style-type: none"> • This setting is an alternative to the nominal power value (99.10). If both are entered, 99.12 takes priority. • This parameter cannot be changed while the drive is running. | 0.000 N·m or lb·ft |
| 0.000...4000000.000 N·m or lb·ft | Nominal motor torque. | 1 = 1 unit | |
| 99.13 | <i>ID run requested</i> | <p>Selects the type of the motor identification routine (ID run) performed at the next start of the drive. During the ID run, the drive will identify the characteristics of the motor for optimum motor control.</p> <p>If no ID run has been performed yet (or if default parameter values have been restored using parameter 96.06 <i>Parameter restore</i>), this parameter is automatically set to <i>Standstill</i>, signifying that an ID run must be performed.</p> <p>After the ID run, the drive stops and this parameter is automatically set to <i>None</i>.</p> <p>Note:</p> <ul style="list-style-type: none"> • For the <i>Advanced</i> ID run, the machinery must always be de-coupled from the motor. • With a permanent magnet or synchronous reluctance motor, a <i>Normal</i>, <i>Reduced</i> or <i>Standstill</i> ID run requires that the motor shaft is NOT locked and the load torque is less than 10%. • With scalar control mode (99.04 <i>Motor ctrl mode</i> = <i>Scalar</i>), only the <i>Current measurement calibration</i> ID run mode is possible. • Once the ID run is activated, it can be canceled by stopping the drive. • The ID run must be performed every time any of the motor parameters (99.04, 99.06...99.12) have been changed. • Ensure that the Safe torque off and emergency stop circuits (if any) are closed during the ID run. • Mechanical brake (if present) is not opened by the logic for the ID run. • This parameter cannot be changed while the drive is running. | <i>None</i> |
| None | No motor ID run is requested. This mode can be selected only if the ID run (<i>Normal</i> , <i>Reduced</i> , <i>Standstill</i> , <i>Advanced</i> , <i>Advanced Standstill</i>) has already been performed once. | 0 | |

| No. | Name/Value | Description | Def/ FbEq16 |
|-----|------------|---|----------------|
| | Normal | <p>Normal ID run. Guarantees good control accuracy for all cases. The ID run takes about 90 seconds. This mode should be selected whenever it is possible.</p> <p>Note:</p> <ul style="list-style-type: none"> • If the load torque will be higher than 20% of motor nominal torque, or if the machinery is not able to withstand the nominal torque transient during the ID run, then the driven machinery must be de-coupled from the motor during a Normal ID run. • Check the direction of rotation of the motor before starting the ID run. During the run, the motor will rotate in the forward direction. <p> WARNING! The motor will run at up to approximately 50...100% of the nominal speed during the ID run.</p> <p>ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!</p> | 1 |
| | Reduced | <p>Reduced ID run. This mode should be selected instead of the <i>Normal</i> or <i>Advanced</i> ID Run if</p> <ul style="list-style-type: none"> • mechanical losses are higher than 20% (i.e. the motor cannot be de-coupled from the driven equipment), or if • flux reduction is not allowed while the motor is running (i.e. in case of a motor with an integrated brake supplied from the motor terminals). <p>With this ID run mode, the resultant motor control in the field weakening area or at high torques is not necessarily as accurate as motor control following a Normal ID run. Reduced ID run is completed faster than the Normal ID Run (< 90 seconds).</p> <p>Note: Check the direction of rotation of the motor before starting the ID run. During the run, the motor will rotate in the forward direction.</p> <p> WARNING! The motor will run at up to approximately 50...100% of the nominal speed during the ID run.</p> <p>ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!</p> | 2 |
| | Standstill | <p>Standstill ID run. The motor is injected with DC current. With an AC induction (asynchronous) motor, the motor shaft is not rotated. With a permanent magnet motor or synchronous reluctance motor, the shaft can rotate up to half a revolution.</p> <p>Note: A standstill ID run should be selected only if the <i>Normal</i>, <i>Reduced</i> or <i>Advanced</i> ID run is not possible due to the restrictions caused by the connected mechanics. For example, with lift or crane applications.</p> <p>See also selection <i>Advanced Standstill</i>.</p> | 3 |

| No. | Name/Value | Description | Def/ FbEq16 |
|-------|---------------------------------|---|----------------|
| | Autophasing | <p>The autophasing routine determines the start angle of a permanent magnet or synchronous reluctance motor (see page 73). Autophasing does not update the other motor model values.</p> <p>Autophasing is automatically performed as part of the <i>Normal</i>, <i>Reduced</i>, <i>Standstill</i>, <i>Advanced</i> or <i>Advanced Standstill</i> ID runs. Using this setting, it is possible to perform autophasing alone. This is useful after changes in the feedback configuration, such as the replacement or addition of an absolute encoder, resolver, or pulse encoder with commutation signals.</p> <p>Note:</p> <ul style="list-style-type: none"> This setting can only be used after a <i>Normal</i>, <i>Reduced</i>, <i>Standstill</i>, <i>Advanced</i> or <i>Advanced Standstill</i> ID run has already been performed. Depending on the selected autophasing mode, the shaft can rotate during autophasing. See parameter 21.13 <i>Autophasing mode</i>. | 4 |
| | Current measurement calibration | <p>Requests current measurement calibration, ie. identification of current measurement offset and gain errors.</p> <p>The calibration will be performed at next start.</p> | 5 |
| | Advanced | <p>Advanced ID run. Guarantees the best possible control accuracy. The ID run can take a couple of minutes. This mode should be selected when top performance is needed across the whole operating area.</p> <p>Note: The driven machinery must be de-coupled from the motor because of high torque and speed transients that are applied.</p> <p> WARNING! The motor will run at up to approximately 50...100% of the nominal speed during the ID run. Several accelerations and decelerations are done. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!</p> | 6 |
| | Advanced Standstill | <p>Advanced Standstill ID run.</p> <p>This selection is recommended with AC induction motors up to 75 kW instead of the <i>Standstill</i> ID run if</p> <ul style="list-style-type: none"> the exact nominal ratings of the motor are not known, or the control performance of the motor is not satisfactory after a <i>Standstill</i> ID run. <p>Note: The time it takes for the <i>Advanced Standstill</i> ID run to complete varies according to motor size. With a small motor, the ID run typically completes within 5 minutes; with a large motor, the ID run may take up to an hour.</p> | 7 |
| 99.14 | <i>Last ID run performed</i> | Shows the type of ID run that was performed last. For more information about the different modes, see the selections of parameter 99.13 <i>ID run requested</i> . | <i>None</i> |
| | None | No ID run has been performed. | 0 |
| | Normal | <i>Normal</i> ID run. | 1 |
| | Reduced | <i>Reduced</i> ID run. | 2 |
| | Standstill | <i>Standstill</i> ID run. | 3 |
| | Autophasing | <i>Autophasing</i> . | 4 |

| No. | Name/Value | Description | Def/ FbEq16 |
|--|-----------------------------------|--|----------------|
| | Current measurement calibration | <i>Current measurement calibration.</i> | 5 |
| | Advanced | <i>Advanced</i> ID run. | 6 |
| | Advanced Standstill | <i>Advanced Standstill</i> ID run. | 7 |
| 99.15 | <i>Motor polepairs calculated</i> | Calculated number of pole pairs in the motor. | 0 |
| | 0...1000 | Number of pole pairs. | 1 = 1 |
| 99.16 | <i>Motor phase order</i> | Switches the rotation direction of motor. This parameter can be used if the motor turns in the wrong direction (for example, because of the wrong phase order in the motor cable), and correcting the cabling is considered impractical. Note: <ul style="list-style-type: none"> Changing this parameter does not affect speed reference polarities, so positive speed reference will rotate the motor forward. The phase order selection just ensures that "forward" is in fact the correct direction. After changing this parameter, the sign of encoder feedback (if any) must be checked. This can be done by setting parameter <i>90.41 Motor feedback selection</i> to <i>Estimate</i>, and comparing the sign of <i>90.01 Motor speed for control</i> to <i>90.10 Encoder 1 speed</i> (or <i>90.20 Encoder 2 speed</i>). If the sign of the measurement is incorrect, the encoder wiring must be corrected or the sign of <i>90.43 Motor gear numerator</i> reversed. | <i>U V W</i> |
| | U V W | Normal. | 0 |
| | U W V | Reversed rotation direction. | 1 |
| 200 Safety | | FSO-xx settings. | |
| This group contains parameters related to the optional FSO-xx safety functions module. For details on the parameters in this group, refer to the documentation of the FSO-xx module. | | | |

9

Additional parameter data

Contents of this chapter

This chapter lists the parameters with some additional data. For parameter descriptions, see chapter [Parameters](#) (page 101).

Terms and abbreviations

| Term | Definition |
|---------------|--|
| Actual signal | Signal measured or calculated by the drive. Usually can only be monitored but not adjusted; some counter-type signals can however be reset. |
| Analog src | The parameter can be set to the value of another parameter by choosing "Other", and selecting the source parameter from a list. Note: The source parameter must be a 32-bit real (floating point) number. To use a 16-bit integer (for example, received in DDCS data sets) as the source, data storage parameters 47.01...47.08 (see page 281) can be used. In addition to the "Other" selection, the parameter may offer other pre-selected settings. |
| Binary src | The value of the parameter can be taken from a specific bit in another parameter value ("Other"). Sometimes the value can be fixed to 0 (false) or 1 (true). In addition, the parameter may offer other pre-selected settings. |
| Data | Data parameter. |
| FbEq32 | 32-bit fieldbus equivalent: The scaling between the value shown on the panel and the integer used in fieldbus communication when a 32-bit value is selected in parameter group 52 FBA A data in or 53 FBA A data out . The corresponding 16-bit scaling are listed in chapter Parameters (page 101). |
| List | Selection list. |
| No. | Parameter number. |
| PB | Packed Boolean (bit list). |
| Real | Real number. |
| Type | Parameter type. See Analog src , Binary src , List , PB , Real . |

Fieldbus addresses

Refer to the *User's Manual* of the fieldbus adapter.

Parameter groups 1...9

| No. | Name | Type | Range | Unit | FbEq32 |
|-------------------------|-----------------------------|-------------|------------------------|--------------|---------------|
| 01 Actual values | | | | | |
| 01.01 | Motor speed used | <i>Real</i> | -30000.00... 30000.00 | rpm | 100 = 1 rpm |
| 01.02 | Motor speed estimated | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 01.03 | Motor speed % | <i>Real</i> | -1000.00...1000.00 | % | 100 = 1 % |
| 01.04 | Encoder 1 speed filtered | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 01.05 | Encoder 2 speed filtered | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 01.06 | Output frequency | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 01.07 | Motor current | <i>Real</i> | 0.00...30000.00 | A | 100 = 1 A |
| 01.10 | Motor torque | <i>Real</i> | -1600.0...1600.0 | % | 10 = 1 % |
| 01.11 | DC voltage | <i>Real</i> | 0.00... 2000.00 | V | 100 = 1 V |
| 01.13 | Output voltage | <i>Real</i> | 0...2000 | V | 1 = 1 V |
| 01.14 | Output power | <i>Real</i> | -32768.00...32767.00 | kW or hp | 100 = 1 unit |
| 01.15 | Output power % of motor nom | <i>Real</i> | -300.00...300.00 | % | 10 = 1 % |
| 01.17 | Motor shaft power | <i>Real</i> | -32768.00...32767.00 | kW or hp | 100 = 1 unit |
| 01.18 | Inverter GWh motoring | <i>Real</i> | 0...32767 | GWh | 1 = 1 GWh |
| 01.19 | Inverter MWh motoring | <i>Real</i> | 0...1000 | MWh | 1 = 1 MWh |
| 01.20 | Inverter kWh motoring | <i>Real</i> | 0...1000 | kWh | 1 = 1 kWh |
| 01.21 | U-phase current | <i>Real</i> | -30000.00 ... 30000.00 | A | 100 = 1 A |
| 01.22 | V-phase current | <i>Real</i> | -30000.00 ... 30000.00 | A | 100 = 1 A |
| 01.23 | W-phase current | <i>Real</i> | -30000.00 ... 30000.00 | A | 100 = 1 A |
| 01.24 | Flux actual % | <i>Real</i> | 0...200 | % | 1 = 1 % |
| 01.29 | Speed change rate | <i>Real</i> | -15000...15000 | rpm/s | 1 = 1 rpm/s |
| 01.30 | Nominal torque scale | <i>Real</i> | 0.000...4000000.000 | N*m or lb.ft | 1000 = 1 unit |
| 01.31 | Ambient temperature | <i>Real</i> | -40...120 | °C or °F | 10 = 1 ° |
| 01.32 | Inverter GWh regenerating | <i>Real</i> | 0...32767 | GWh | 1 = 1 GWh |
| 01.33 | Inverter MWh regenerating | <i>Real</i> | 0...1000 | MWh | 1 = 1 MWh |
| 01.34 | Inverter kWh regenerating | <i>Real</i> | 0...1000 | kWh | 1 = 1 kWh |
| 01.35 | Mot - regen energy GWh | <i>Real</i> | -32768 ... 32767 | GWh | 1 = 1 GWh |
| 01.36 | Mot - regen energy MWh | <i>Real</i> | -1000...1000 | MWh | 1 = 1 MWh |
| 01.37 | Mot - regen energy kWh | <i>Real</i> | -1000...1000 | kWh | 1 = 1 kWh |
| 01.61 | Abs motor speed used | <i>Real</i> | 0.00 ... 30000.00 | rpm | 100 = 1 rpm |
| 01.62 | Abs motor speed % | <i>Real</i> | 0.00 ... 1000.00 | % | 100 = 1 rpm |
| 01.63 | Abs output frequency | <i>Real</i> | 0.00 ... 500.00 | Hz | 100 = 1 Hz |
| 01.64 | Abs motor torque | <i>Real</i> | 0.0 ... 1600.0 | % | 10 = 1 % |
| 01.65 | Abs output power | <i>Real</i> | 0.00 ... 32767.00 | kW or hp | 100 = 1 unit |

| No. | Name | Type | Range | Unit | FbEq32 |
|-------------------------------|------------------------------|-------------|---------------------------|----------|--------------|
| 01.66 | Abs output power % motor nom | <i>Real</i> | 0.00 ... 300.00 | % | 10 = 1% |
| 01.68 | Abs motor shaft power | <i>Real</i> | 0.00 ... 32767.00 | kW or hp | 100 = 1 unit |
| 03 Input references | | | | | |
| 03.01 | Panel reference | <i>Real</i> | -100000.00...100000.00 | - | 100 = 1 |
| 03.05 | FB A reference 1 | <i>Real</i> | -100000.00...100000.00 | - | 100 = 1 |
| 03.06 | FB A reference 2 | <i>Real</i> | -100000.00...100000.00 | - | 100 = 1 |
| 03.07 | FB B reference 1 | <i>Real</i> | -100000.00...100000.00 | - | 100 = 1 |
| 03.08 | FB B reference 2 | <i>Real</i> | -100000.00...100000.00 | - | 100 = 1 |
| 03.09 | EFB reference 1 | <i>Real</i> | -30000.00 ... 30000.00 | - | 100 = 1 |
| 03.10 | EFB reference 2 | <i>Real</i> | -30000.00 ... 30000.00 | - | 100 = 1 |
| 04 Warnings and faults | | | | | |
| 04.01 | Tripping fault | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.02 | Active fault 2 | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.03 | Active fault 3 | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.04 | Active fault 4 | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.05 | Active fault 5 | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.06 | Active warning 1 | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.07 | Active warning 2 | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.08 | Active warning 3 | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.09 | Active warning 4 | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.10 | Active warning 5 | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.11 | Latest fault | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.12 | 2nd latest fault | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.13 | 3rd latest fault | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.14 | 4th latest fault | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.15 | 5th latest fault | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.16 | Latest warning | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.17 | 2nd latest warning | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.18 | 3rd latest warning | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.19 | 4th latest warning | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.20 | 5th latest warning | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.21 | Fault word 1 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.22 | Fault word 2 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.31 | Warning word 1 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.32 | Warning word 2 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.40 | Event word 1 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.41 | Event word 1 bit 0 code | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.42 | Event word 1 bit 0 aux code | <i>Data</i> | 0000 0000h ... FFFF FFFFh | - | 1 = 1 |
| 04.43 | Event word 1 bit 1 code | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|------------------------------------|----------------------------------|-------------------|---------------------------|------|---------|
| 04.44 | Event word 1 bit 1 aux code | <i>Data</i> | 0000 0000h ... FFFF FFFFh | - | 1 = 1 |
| ... | ... | ... | ... | ... | |
| 04.71 | Event word 1 bit 15 code | <i>Data</i> | 0000h...FFFFh | - | 1 = 1 |
| 04.72 | Event word 1 bit 15 aux code | <i>Data</i> | 0000 0000h ... FFFF FFFFh | - | 1 = 1 |
| 04.120 | Fault/Warning word compatibility | <i>List</i> | 0...1 | - | 1 = 1 |
| 05 Diagnostics | | | | | |
| 05.01 | On-time counter | <i>Real</i> | 0...65535 | d | 1 = 1 d |
| 05.02 | Run-time counter | <i>Real</i> | 0...65535 | d | 1 = 1 d |
| 05.04 | Fan on-time counter | <i>Real</i> | 0...65535 | d | 1 = 1 d |
| 05.11 | Inverter temperature | <i>Real</i> | -40.0...160.0 | % | 10 = 1% |
| 05.22 | Diagnostic word 3 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 05.41 | Main fan service counter | <i>Real</i> | 0...150 | % | 1 = 1% |
| 05.42 | Aux. fan service counter | <i>Real</i> | 0...150 | % | 1 = 1% |
| 06 Control and status words | | | | | |
| 06.01 | Main control word | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 06.02 | Application control word | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 06.03 | FBA A transparent control word | <i>PB</i> | 00000000h...FFFFFFFFh | - | 1 = 1 |
| 06.04 | FBA B transparent control word | <i>PB</i> | 00000000h...FFFFFFFFh | - | 1 = 1 |
| 06.05 | EFB transparent control word | <i>PB</i> | 00000000h...FFFFFFFFh | - | |
| 06.11 | Main status word | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 06.16 | Drive status word 1 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 06.17 | Drive status word 2 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 06.18 | Start inhibit status word | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 06.19 | Speed control status word | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 06.29 | MSW bit 10 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.30 | MSW bit 11 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.31 | MSW bit 12 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.32 | MSW bit 13 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.33 | MSW bit 14 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.50 | User status word 1 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 06.60 | User status word 1 bit 0 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.61 | User status word 1 bit 1 sel | <i>Binary src</i> | - | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|-----------------------|----------------------------------|-------------------|---------------|------|--------|
| 06.62 | User status word 1 bit 2 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.63 | User status word 1 bit 3 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.64 | User status word 1 bit 4 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.65 | User status word 1 bit 5 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.66 | User status word 1 bit 6 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.67 | User status word 1 bit 7 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.68 | User status word 1 bit 8 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.69 | User status word 1 bit 9 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.70 | User status word 1 bit 10 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.71 | User status word 1 bit 11 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.72 | User status word 1 bit 12 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.73 | User status word 1 bit 13 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.74 | User status word 1 bit 14 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.75 | User status word 1 bit 15 sel | <i>Binary src</i> | - | - | 1 = 1 |
| 06.100 | User control word 1 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 06.101 | User control word 2 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 07 System info | | | | | |
| 07.03 | Drive rating id | <i>List</i> | - | - | 1 = 1 |
| 07.04 | Firmware name | <i>List</i> | - | - | 1 = 1 |
| 07.05 | Firmware version | <i>Data</i> | - | - | 1 = 1 |
| 07.06 | Loading package name | <i>List</i> | - | - | 1 = 1 |
| 07.07 | Loading package version | <i>Data</i> | - | - | 1 = 1 |
| 07.11 | Cpu usage | <i>Real</i> | 0...100 | % | 1 = 1% |
| 07.13 | PU logic version number | <i>Data</i> | - | - | 1 = 1 |
| 07.21 | Application environment status 1 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 07.22 | Application environment status 2 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 07.23 | Application name | <i>Data</i> | - | - | 1 = 1 |
| 07.24 | Application version | <i>Data</i> | - | - | 1 = 1 |
| 07.25 | Customization package name | <i>Data</i> | - | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|------------------------|-------------------------------|-------------|------------------------|-----------------|-------------------------|
| 07.26 | Customization package version | <i>Data</i> | - | - | 1 = 1 |
| 09 Pump actuals | | | | | |
| 09.01 | Rod torque | <i>Real</i> | -100000.00...100000.00 | N•m or lbft | 100 = 1 Nm or lbft |
| 09.02 | Maximum rod torque | <i>Real</i> | -100000.00...100000.00 | N•m or lbft | 100 = 1 Nm or lbft |
| 09.03 | Motor torque | <i>Real</i> | -100000.00...100000.00 | N•m or lbft | 100 = 1 Nm or lbft |
| 09.04 | Maximum motor torque | <i>Real</i> | -100000.00...100000.00 | N•m or lbft | 100 = 1 Nm or lbft |
| 09.05 | Rod speed | <i>Real</i> | -100000.00...100000.00 | Prpm, rpm or Hz | 100 = 1 Prpm, rpm or Hz |
| 09.06 | Motor speed reference | <i>Real</i> | -100000.00...100000.00 | rpm or Hz | 100 = 1 rpm or Hz |
| 09.07 | Run-time hours | <i>Real</i> | 0.00...100000.00 | h | 100 = 1 h |
| 09.08 | Fluid level | <i>Real</i> | -100000.00...100000.00 | m, ft or Joints | 100 = 1 m, ft or Joints |
| 09.09 | Pressure | <i>Real</i> | -100000.00...100000.00 | kPa or psi | 100 = 1 kPa or psi |
| 09.10 | Measured temperature | <i>Real</i> | -100000.00...100000.00 | °C | 100 = 1 °C |
| 09.11 | Backspin speed reference | <i>Real</i> | -100000.00...100000.00 | Prpm, rpm or Hz | 100 = 1 Prpm, rpm or Hz |
| 09.12 | Start delay remain | <i>Real</i> | 0...4294967.295 | s | 1000 = 1 s |
| 09.13 | Backspin status word | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 09.14 | Pump status word | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 09.15 | Sleep feedback value | <i>Real</i> | -100000.00...100000.00 | Source Unit | 100 = 1 SourceUnit |
| 09.16 | Sleep time | <i>Real</i> | 0.000...10000.000 | s | 1000 = 1 s |

Parameter groups 10...99

| No. | Name | Type | Range | Unit | FbEq32 |
|---------------------------|--------------------|-------------|---------------|------|----------|
| 10 Standard DI, RO | | | | | |
| 10.01 | DI status | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 10.02 | DI delayed status | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 10.03 | DI force selection | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 10.04 | DI force data | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 10.05 | DI1 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.06 | DI1 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.07 | DI2 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.08 | DI2 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.09 | DI3 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |

| No. | Name | Type | Range | Unit | FbEq32 |
|--------------------------------|-------------------------|-------------------|------------------------|------|-----------|
| 10.10 | DI3 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.11 | DI4 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.12 | DI4 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.13 | DI5 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.14 | DI5 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.15 | DI6 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.16 | DI6 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.21 | RO status | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 10.24 | RO1 source | <i>Binary src</i> | - | - | 1 = 1 |
| 10.25 | RO1 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.26 | RO1 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.27 | RO2 source | <i>Binary src</i> | - | - | 1 = 1 |
| 10.28 | RO2 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.29 | RO2 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.30 | RO3 source | <i>Binary src</i> | - | - | 1 = 1 |
| 10.31 | RO3 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.32 | RO3 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 10.51 | DI filter time | <i>Real</i> | 0.3...100.0 | ms | 10 = 1 ms |
| 10.99 | RO/DIO control word | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 11 Standard DIO, FI, FO | | | | | |
| 11.01 | DIO status | <i>PB</i> | 0000b...0011b | - | 1 = 1 |
| 11.02 | DIO delayed status | <i>PB</i> | 0000b...0011b | - | 1 = 1 |
| 11.05 | DIO1 function | <i>List</i> | 0...2 | - | 1 = 1 |
| 11.06 | DIO1 output source | <i>Binary src</i> | - | - | 1 = 1 |
| 11.07 | DIO1 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 11.08 | DIO1 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 11.09 | DIO2 function | <i>List</i> | 0...2 | - | 1 = 1 |
| 11.10 | DIO2 output source | <i>Binary src</i> | - | - | 1 = 1 |
| 11.11 | DIO2 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 11.12 | DIO2 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 11.38 | Freq in 1 actual value | <i>Real</i> | 0...16000 | Hz | 1 = 1 Hz |
| 11.39 | Freq in 1 scaled | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 11.42 | Freq in 1 min | <i>Real</i> | 0...16000 | Hz | 1 = 1 Hz |
| 11.43 | Freq in 1 max | <i>Real</i> | 0...16000 | Hz | 1 = 1 Hz |
| 11.44 | Freq in 1 at scaled min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 11.45 | Freq in 1 at scaled max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 11.54 | Freq out 1 actual value | <i>Real</i> | 0...16000 | Hz | 1 = 1 Hz |

| No. | Name | Type | Range | Unit | FbEq32 |
|-----------------------|--------------------------|-------------------|------------------------|---------|------------------|
| 11.55 | Freq out 1 source | <i>Analog src</i> | - | - | 1 = 1 |
| 11.58 | Freq out 1 src min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 11.59 | Freq out 1 src max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 11.60 | Freq out 1 at src min | <i>Real</i> | 0...16000 | Hz | 1 = 1 Hz |
| 11.61 | Freq out 1 at src max | <i>Real</i> | 0...16000 | Hz | 1 = 1 Hz |
| 11.81 | DIO filter time | <i>Real</i> | 0.3 ... 100.0 | ms | 10 = 1 ms |
| 12 Standard AI | | | | | |
| 12.01 | AI tune | enum | 0..4 | - | |
| 12.03 | AI supervision function | <i>List</i> | 0..4 | - | 1 = 1 |
| 12.04 | AI supervision selection | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 12.11 | AI1 actual value | <i>Real</i> | -22.000...22.000 | V or mA | 1000 = 1 unit |
| 12.12 | AI1 scaled value | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 12.15 | AI1 unit selection | <i>List</i> | - | - | 1 = 1 |
| 12.16 | AI1 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 12.17 | AI1 min | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 12.18 | AI1 max | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 12.19 | AI1 scaled at AI1 min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 12.20 | AI1 scaled at AI1 max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 12.21 | AI2 actual value | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 12.22 | AI2 scaled value | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 12.25 | AI2 unit selection | <i>List</i> | - | - | 1 = 1 |
| 12.26 | AI2 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 12.27 | AI2 min | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 12.28 | AI2 max | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 12.29 | AI2 scaled at AI2 min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 12.30 | AI2 scaled at AI2 max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 13 Standard AO | | | | | |
| 13.11 | AO1 actual value | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 13.12 | AO1 source | <i>Analog src</i> | - | - | 1 = 1 |
| 13.16 | AO1 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 13.17 | AO1 source min | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 13.18 | AO1 source max | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 13.19 | AO1 out at AO1 src min | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 13.20 | AO1 out at AO1 src max | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 13.21 | AO2 actual value | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |

370 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|--|---|-------------------|------------------------|---------|-------------|
| 13.22 | AO2 source | <i>Analog src</i> | - | - | 1 = 1 |
| 13.26 | AO2 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 13.27 | AO2 source min | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 13.28 | AO2 source max | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 13.29 | AO2 out at AO2 src min | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 13.30 | AO2 out at AO2 src max | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 13.91 | AO1 data storage | <i>Real</i> | -327.68 ... 327.67 | - | 100 = 1 |
| 13.92 | AO2 data storage | <i>Real</i> | -327.68 ... 327.67 | - | 100 = 1 |
| 14 I/O extension module 1 | | | | | |
| 14.01 | Module 1 type | <i>List</i> | - | - | 1 = 1 |
| 14.02 | Module 1 location | <i>Real</i> | 1...254 | - | 1 = 1 |
| 14.03 | Module 1 status | <i>List</i> | 0...4 | - | 1 = 1 |
| Common parameters for DIOx (<i>14.01 Module 1 type = FIO-01 or FIO-11</i>) | | | | | |
| 14.05 | DIO status | <i>PB</i> | 0000b...1111b | - | 1 = 1 |
| 14.06 | DIO delayed status | <i>PB</i> | 0000b...1111b | - | 1 = 1 |
| DIO1/DIO2 (<i>14.01 Module 1 type = FIO-01 or FIO-11</i>) | | | | | |
| 14.08 | DIO filter time | <i>Real</i> | 0.8...100.0 | ms | 10 = 1 ms |
| 14.09 | DIO1 function | <i>List</i> | 0...1 | - | 1 = 1 |
| 14.10 | DIO1 filter gain (Not visible when <i>14.01 Module 1 type = FIO-01</i>) | <i>List</i> | 0...3 | - | 1 = 1 |
| 14.11 | DIO1 output source | <i>Binary src</i> | - | - | 1 = 1 |
| 14.12 | DIO1 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 14.13 | DIO1 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 14.14 | DIO2 function | <i>List</i> | 0...1 | - | 1 = 1 |
| 14.15 | DIO2 filter gain (Not visible when <i>14.01 Module 1 type = FIO-01</i>) | <i>List</i> | 0...3 | - | 1 = 1 |
| 14.16 | DIO2 output source | <i>Binary src</i> | - | - | 1 = 1 |
| 14.17 | DIO2 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 14.18 | DIO2 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| DIO3/DIO4 (<i>14.01 Module 1 type = FIO-01</i>) | | | | | |
| 14.19 | DIO3 function | <i>List</i> | 0...1 | - | 1 = 1 |
| 14.21 | DIO3 output source | <i>Binary src</i> | - | - | 1 = 1 |
| 14.22 | DIO3 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 14.23 | DIO3 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 14.24 | DIO4 function | <i>List</i> | 0...1 | - | 1 = 1 |
| 14.26 | DIO4 output source | <i>Binary src</i> | -22.000...22.000 | mA or V | 1 = 1 |
| 14.27 | DIO4 ON delay | <i>Real</i> | -32768.000...32767.000 | s | 10 = 1 s |

| No. | Name | Type | Range | Unit | FbEq32 |
|---|--------------------------|-------------------|---|---------|------------------|
| 14.28 | DIO4 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| <i>RO1/RO2 (14.01 Module 1 type = FIO-01)</i> | | | | | |
| 14.31 | RO status | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 14.34 | RO1 source | <i>Binary src</i> | - | - | 1 = 1 |
| 14.35 | RO1 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 14.36 | RO1 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 14.37 | RO2 source | <i>Binary src</i> | - | - | 1 = 1 |
| 14.38 | RO2 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 14.39 | RO2 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| <i>Common parameter for AIx (14.01 Module 1 type = FIO-11 or FAIO-01)</i> | | | | | |
| 14.19 | AI supervision function | <i>List</i> | 0...4 | - | 1 = 1 |
| 14.20 | AI supervision selection | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 14.21 | AI tune | <i>List</i> | 0...6 (<i>FIO-11</i> or <i>FAIO-01</i>) | - | 1 = 1 |
| 14.22 | AI force selection | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| <i>AI1/AI2 (14.01 Module 1 type = FIO-11 or FAIO-01)</i> | | | | | |
| 14.26 | AI1 actual value | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 14.27 | AI1 scaled value | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 14.28 | AI1 force data | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 14.29 | AI1 HW switch pos | <i>List</i> | - | - | 1 = 1 |
| 14.30 | AI1 unit selection | <i>List</i> | - | - | 1 = 1 |
| 14.31 | AI1 filter gain | <i>List</i> | 0...7 | - | 1 = 1 |
| 14.32 | AI1 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 14.33 | AI1 min | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 14.34 | AI1 max | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 14.35 | AI1 scaled at AI1 min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 14.36 | AI1 scaled at AI1 max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 14.41 | AI2 actual value | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 14.42 | AI2 scaled value | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 14.43 | AI2 force data | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 14.44 | AI2 HW switch pos | <i>List</i> | - | - | 1 = 1 |
| 14.45 | AI2 unit selection | <i>List</i> | - | - | 1 = 1 |
| 14.46 | AI2 filter gain | <i>List</i> | 0...7 | - | 1 = 1 |
| 14.47 | AI2 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 14.48 | AI2 min | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 14.49 | AI2 max | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 14.50 | AI2 scaled at AI2 min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 14.51 | AI2 scaled at AI2 max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |

372 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|--|------------------------|-------------------|------------------------|---------|---------------------|
| <i>AI3 (14.01 Module 1 type = FIO-11)</i> | | | | | |
| 14.56 | AI3 actual value | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 14.57 | AI3 scaled value | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 14.58 | AI3 force data | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 14.59 | AI3 HW switch pos | <i>List</i> | - | - | 1 = 1 |
| 14.60 | AI3 unit selection | <i>List</i> | - | - | 1 = 1 |
| 14.61 | AI3 filter gain | <i>List</i> | 0...7 | - | 1 = 1 |
| 14.62 | AI3 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 14.63 | AI3 min | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 14.64 | AI3 max | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 14.65 | AI3 scaled at AI3 min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 14.66 | AI3 scaled at AI3 max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| <i>Common parameters for AOx (14.01 Module 1 type = FIO-11 or FAIO-01)</i> | | | | | |
| 14.71 | AO force selection | <i>PB</i> | 00000000h...FFFFFFFh | - | 1 = 1 |
| <i>AO1 (14.01 Module 1 type = FIO-11 or FAIO-01)</i> | | | | | |
| 14.76 | AO1 actual value | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 14.77 | AO1 source | <i>Analog src</i> | - | - | 1 = 1 |
| 14.78 | AO1 force data | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 14.79 | AO1 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 14.80 | AO1 source min | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 14.81 | AO1 source max | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 14.82 | AO1 out at AO1 src min | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 14.83 | AO1 out at AO1 src max | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| <i>AO2 (14.01 Module 1 type = FAIO-01)</i> | | | | | |
| 14.86 | AO2 actual value | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 14.87 | AO2 source | <i>Analog src</i> | - | - | 1 = 1 |
| 14.88 | AO2 force data | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 14.89 | AO2 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 14.90 | AO2 source min | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 14.91 | AO2 source max | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 14.92 | AO2 out at AO2 src min | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 14.93 | AO2 out at AO2 src max | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 15 I/O extension module 2 | | | | | |
| 15.01 | Module 2 type | <i>List</i> | - | - | 1 = 1 |
| 15.02 | Module 2 location | <i>Real</i> | 1...254 | - | 1 = 1 |
| 15.03 | Module 2 status | <i>List</i> | 0...2 | - | 1 = 1 |
| <i>Common parameters for DIOx (15.01 Module 2 type = FIO-01 or FIO-11)</i> | | | | | |
| 15.05 | DIO status | <i>PB</i> | 00000000h...FFFFFFFh | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|---|--|-------------------|-----------------------------------|------|-----------|
| 15.06 | DIO delayed status | <i>PB</i> | 00000000h...FFFFFFFh | - | 1 = 1 |
| DIO1/DIO2 (15.01 Module 2 type = FIO-01 or FIO-11) | | | | | |
| 15.08 | DIO filter time | <i>Real</i> | 0.8...100.0 | ms | 10 = 1 ms |
| 15.09 | DIO1 function | <i>List</i> | 0...1 | - | 1 = 1 |
| 15.11 | DIO1 output source | <i>Binary src</i> | - | - | 1 = 1 |
| 15.12 | DIO1 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 15.13 | DIO1 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 15.14 | DIO2 function | <i>List</i> | 0...1 | - | 1 = 1 |
| 15.15 | DIO2 filter gain (Not visible when 15.01 Module 2 type = FIO-01) | <i>List</i> | 0...3 | - | 1 = 1 |
| 15.16 | DIO2 output source | <i>Binary src</i> | - | - | 1 = 1 |
| 15.17 | DIO2 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 15.18 | DIO2 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| DIO3/DIO4 (15.01 Module 2 type = FIO-01) | | | | | |
| 15.19 | DIO3 configuration | <i>List</i> | 0...1 | - | 1 = 1 |
| 15.21 | DIO3 output source | <i>Binary src</i> | - | - | 1 = 1 |
| 15.22 | DIO3 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 15.23 | DIO3 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 15.24 | DIO4 configuration | <i>List</i> | 0...1 | - | 1 = 1 |
| 15.26 | DIO4 output source | <i>Binary src</i> | - | - | 1 = 1 |
| 15.27 | DIO4 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 15.28 | DIO4 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| RO1/RO2 (15.01 Module 2 type = FIO-01) | | | | | |
| 15.31 | RO status | <i>PB</i> | 0000h...FFFFFFh | - | 1 = 1 |
| 15.34 | RO1 source | <i>Binary src</i> | - | - | 1 = 1 |
| 15.35 | RO1 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 15.36 | RO1 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 15.37 | RO2 source | <i>Binary src</i> | - | - | 1 = 1 |
| 15.38 | RO2 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 15.39 | RO2 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| Common parameters for Alx (15.01 Module 2 type = FIO-11 or FAIO-01) | | | | | |
| 15.19 | AI supervision function | <i>List</i> | 0...4 | - | 1 = 1 |
| 15.20 | AI supervision selection | <i>PB</i> | 0000h...FFFFFFh | - | 1 = 1 |
| 15.21 | AI tune | <i>List</i> | 0.6...(FIO-11) 0.4...(FAIO-01) | - | 1 = 1 |
| 15.22 | AI force selection | <i>PB</i> | 00000000h...FFFFFFFh | - | 1 = 1 |
| AI1/AI2 (15.01 Module 2 type = FIO-11 or FAIO-01) | | | | | |

374 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|--|------------------------|-------------|------------------------|---------|---------------------|
| 15.26 | AI1 actual value | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 15.27 | AI1 scaled value | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 15.28 | AI1 force data | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 15.29 | AI1 HW switch pos | <i>List</i> | - | - | 1 = 1 |
| 15.30 | AI1 unit selection | <i>List</i> | - | - | 1 = 1 |
| 15.31 | AI1 filter gain | <i>List</i> | 0...7 | - | 1 = 1 |
| 15.32 | AI1 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 15.33 | AI1 min | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 15.34 | AI1 max | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 15.35 | AI1 scaled at AI1 min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 15.36 | AI1 scaled at AI1 max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 15.41 | AI2 actual value | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 15.42 | AI2 scaled value | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 15.43 | AI2 force data | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 15.44 | AI2 HW switch position | <i>List</i> | - | - | 1 = 1 |
| 15.45 | AI2 unit selection | <i>List</i> | - | - | 1 = 1 |
| 15.46 | AI2 filter gain | <i>List</i> | 0...7 | - | 1 = 1 |
| 15.47 | AI2 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 15.48 | AI2 min | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 15.49 | AI2 max | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 15.50 | AI2 scaled at AI2 min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 15.51 | AI2 scaled at AI2 max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| <i>AI3 (15.01 Module 2 type = FIO-11 or FAIO-01)</i> | | | | | |
| 15.56 | AI3 actual value | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 15.57 | AI3 scaled value | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 15.58 | AI3 force data | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 15.59 | AI3 HW switch position | <i>List</i> | - | - | 1 = 1 |
| 15.60 | AI3 unit selection | <i>List</i> | - | - | 1 = 1 |
| 15.61 | AI3 filter gain | <i>List</i> | 0...7 | - | 1 = 1 |
| 15.62 | AI3 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 15.63 | AI3 min | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 15.64 | AI3 max | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 15.65 | AI3 scaled at AI3 min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 15.66 | AI3 scaled at AI3 max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| <i>Common parameters for AOx (15.01 Module 2 type = FIO-11 or FAIO-01)</i> | | | | | |
| 15.71 | AO force selection | <i>PB</i> | 00000000h...FFFFFFFh | - | 1 = 1 |
| <i>AO1 (15.01 Module 2 type = FIO-11 or FAIO-01)</i> | | | | | |

| No. | Name | Type | Range | Unit | FbEq32 |
|--|------------------------|-------------------|-----------------------|------|-------------|
| 15.76 | AO1 actual value | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 15.77 | AO1 source | <i>Analog src</i> | - | - | 1 = 1 |
| 15.78 | AO1 force data | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 15.79 | AO1 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 15.80 | AO1 source min | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 15.81 | AO1 source max | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 15.82 | AO1 out at AO1 src min | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 15.83 | AO1 out at AO1 src max | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| <i>AO2 (15.01 Module 2 type = FIO-11 or FAIO-01)</i> | | | | | |
| 15.86 | AO2 actual value | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 15.87 | AO2 source | <i>Analog src</i> | - | - | 1 = 1 |
| 15.88 | AO2 force data | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 15.89 | AO2 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 15.90 | AO2 source min | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 15.91 | AO2 source max | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 15.92 | AO2 out at AO1 src min | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 15.93 | AO2 out at AO1 src max | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 16 I/O extension module 3 | | | | | |
| 16.01 | Module 3 type | <i>List</i> | - | - | 1 = 1 |
| 16.02 | Module 3 location | <i>Real</i> | 1...254 | - | 1 = 1 |
| 16.03 | Module 3 status | <i>List</i> | 0...2 | - | 1 = 1 |
| <i>Common parameters for DIOx (16.01 Module 3 type = FIO-01 or FIO-11)</i> | | | | | |
| 16.05 | DIO status | <i>PB</i> | 00000000h...FFFFFFFFh | - | 1 = 1 |
| 16.06 | DIO delayed status | <i>PB</i> | 00000000h...FFFFFFFFh | - | 1 = 1 |
| <i>DIO1/DIO2 (16.01 Module 3 type = FIO-01 or FIO-11)</i> | | | | | |
| 16.08 | DIO filter time | <i>Real</i> | 0.8...100.0 | ms | 10 = 1 ms |
| 16.09 | DIO1 function | <i>List</i> | 0...1 | - | 1 = 1 |
| 16.11 | DIO1 output source | <i>Binary src</i> | - | - | 1 = 1 |
| 16.12 | DIO1 ON delay | <i>Real</i> | 0.0 ... 3000.0 | s | 10 = 1 s |
| 16.13 | DIO1 OFF delay | <i>Real</i> | 0.0 ... 3000.0 | s | 10 = 1 s |
| 16.14 | DIO2 function | <i>List</i> | 0...1 | - | 1 = 1 |
| 16.16 | DIO2 output source | <i>Binary src</i> | - | - | 1 = 1 |
| 16.17 | DIO2 ON delay | <i>Real</i> | 0.0 ... 3000.0 | s | 10 = 1 s |
| 16.18 | DIO2 OFF delay | <i>Real</i> | 0.0 ... 3000.0 | s | 10 = 1 s |
| <i>DIO3/DIO4 (16.01 Module 3 type = FIO-01)</i> | | | | | |
| 16.19 | DIO3 function | <i>List</i> | 0...1 | - | 1 = 1 |
| 16.21 | DIO3 output source | <i>Binary src</i> | - | - | 1 = 1 |

376 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|--|--------------------------|-------------------|-----------------------------------|---------|---------------------|
| 16.22 | DIO3 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 16.23 | DIO3 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 16.24 | DIO4 configuration | <i>List</i> | 0...1 | - | 1 = 1 |
| 16.26 | DIO4 output source | <i>Binary src</i> | - | - | 1 = 1 |
| 16.27 | DIO4 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 16.28 | DIO4 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| RIO1/RO2 (16.01 Module 3 type = FIO-01) | | | | | |
| 16.31 | RO status | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 16.34 | RO1 source | <i>Binary src</i> | - | - | 1 = 1 |
| 16.35 | RO1 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 16.36 | RO1 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 16.37 | RO2 source | <i>Binary src</i> | - | - | 1 = 1 |
| 16.38 | RO2 ON delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| 16.39 | RO2 OFF delay | <i>Real</i> | 0.0...3000.0 | s | 10 = 1 s |
| Common parameters for Alx (16.01 Module 3 type = FIO-11 or FAIO-01) | | | | | |
| 16.19 | AI supervision function | <i>List</i> | 0...4 | - | 1 = 1 |
| 16.20 | AI supervision selection | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 16.21 | AI tune | <i>List</i> | 0.6...(FIO-11) 0.4...(FAIO-01) | - | 1 = 1 |
| 16.22 | AI force selection | <i>PB</i> | 00000000h...FFFFFFFFh | - | 1 = 1 |
| AI1/AI2 (16.01 Module 3 type = FIO-11 or FAIO-01) | | | | | |
| 16.26 | AI1 actual value | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 16.27 | AI1 scaled value | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 16.28 | AI1 force data | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 16.29 | AI1 HW switch position | <i>List</i> | - | - | 1 = 1 |
| 16.30 | AI1 unit selection | <i>List</i> | - | - | 1 = 1 |
| 16.31 | AI1 filter gain | <i>List</i> | 0...7 | - | 1 = 1 |
| 16.32 | AI1 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 16.33 | AI1 min | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 16.34 | AI1 max | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 16.35 | AI1 scaled at AI1 min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 16.36 | AI1 scaled at AI1 max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 16.41 | AI2 actual value | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 16.42 | AI2 scaled value | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 16.43 | AI2 force data | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 16.44 | AI2 HW switch pos | <i>List</i> | - | - | 1 = 1 |
| 16.45 | AI2 unit selection | <i>List</i> | - | - | 1 = 1 |
| 16.46 | AI2 filter gain | <i>List</i> | 0...7 | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|--|------------------------|-------------------|------------------------|---------|---------------------|
| 16.47 | AI2 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 16.48 | AI2 min | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 16.49 | AI2 max | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 16.50 | AI2 scaled at AI2 min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 16.51 | AI2 scaled at AI2 max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| AI13 (16.01 Module 3 type = FIO-11) | | | | | |
| 16.56 | AI3 actual value | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 16.57 | AI3 scaled value | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 16.58 | AI3 force data | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 unit |
| 16.59 | AI3 HW switch position | <i>List</i> | - | - | 1 = 1 |
| 16.60 | AI3 unit selection | <i>List</i> | - | - | 1 = 1 |
| 16.61 | AI3 filter gain | <i>List</i> | 0...7 | - | 1 = 1 |
| 16.62 | AI3 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 16.63 | AI3 min | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 16.64 | AI3 max | <i>Real</i> | -22.000...22.000 | mA or V | 1000 = 1 mA or V |
| 16.65 | AI3 scaled at AI3 min | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| 16.66 | AI3 scaled at AI3 max | <i>Real</i> | -32768.000...32767.000 | - | 1000 = 1 |
| Common parameters for AOx (16.01 Module 3 type = FIO-11 or FAIO-01) | | | | | |
| 16.71 | AO force selection | <i>PB</i> | 00000000h...FFFFFFFh | - | 1 = 1 |
| AO1 (16.01 Module 3 type = FIO-11 or FAIO-01) | | | | | |
| 16.76 | AO1 actual value | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 16.77 | AO1 source | <i>Analog src</i> | - | - | 1 = 1 |
| 16.78 | AO1 force data | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 16.79 | AO1 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 16.80 | AO1 source min | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 16.81 | AO1 source max | <i>Real</i> | -32768.0...32767.0 | - | 10 = 1 |
| 16.82 | AO1 out at AO1 src min | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| 16.83 | AO1 out at AO1 src max | <i>Real</i> | 0.000...22.000 | mA | 1000 = 1 mA |
| AO2 (16.01 Module 3 type = FAIO-01) | | | | | |
| 16.86 | AO2 actual value | <i>Real</i> | 0.000 ... 22.000 | mA | 1000 = 1 mA |
| 16.87 | AO2 source | <i>Analog src</i> | - | - | 1 = 1 |
| 16.88 | AO2 force data | <i>Real</i> | 0.000 ... 22.000 | mA | 1000 = 1 mA |
| 16.89 | AO2 filter time | <i>Real</i> | 0.000 ... 30.000 | s | 1000 = 1 s |
| 16.90 | AO2 source min | <i>Real</i> | -32768.0 ... 32767.0 | - | 10 = 1 |
| 16.91 | AO2 source max | <i>Real</i> | -32768.0 ... 32767.0 | - | 10 = 1 |
| 16.92 | AO2 out at AO2 src min | <i>Real</i> | 0.000 ... 22.000 | mA | 1000 = 1 mA |
| 16.93 | AO2 out at AO2 src max | <i>Real</i> | 0.000 ... 22.000 | mA | 1000 = 1 mA |

| No. | Name | Type | Range | Unit | FbEq32 |
|--------------------------------|---------------------------------|------------|-----------|------|--------|
| 19 Operation mode | | | | | |
| 19.01 | Actual operation mode | List | - | - | 1 = 1 |
| 19.11 | Ext1/Ext2 selection | Binary src | - | - | 1 = 1 |
| 19.12 | Ext1 control mode 1 | List | 1...6 | - | 1 = 1 |
| 19.14 | Ext2 control mode 1 | List | 1...6 | - | 1 = 1 |
| 19.16 | Local control mode | List | 0...1 | - | 1 = 1 |
| 19.17 | Local control disable | List | 0...1 | - | 1 = 1 |
| 19.20 | Scalar control reference unit | List | 0...1 | - | 1 = 1 |
| 20 Start/stop/direction | | | | | |
| 20.01 | Ext1 commands | List | - | - | 1 = 1 |
| 20.02 | Ext1 start trigger type | List | 0...1 | - | 1 = 1 |
| 20.03 | Ext1 in1 source | Binary src | - | - | 1 = 1 |
| 20.04 | Ext1 in2 source | Binary src | - | - | 1 = 1 |
| 20.05 | Ext1 in3 source | Binary src | - | - | 1 = 1 |
| 20.06 | Ext2 commands | List | - | - | 1 = 1 |
| 20.07 | Ext2 start trigger type | List | 0...1 | - | 1 = 1 |
| 20.08 | Ext2 in1 source | Binary src | - | - | 1 = 1 |
| 20.09 | Ext2 in2 source | Binary src | - | - | 1 = 1 |
| 20.10 | Ext2 in3 source | Binary src | - | - | 1 = 1 |
| 20.11 | Run enable stop mode | List | 0...2 | - | 1 = 1 |
| 20.12 | Run enable 1 source | Binary src | - | - | 1 = 1 |
| 20.19 | Enable start command | Binary src | - | - | 1 = 1 |
| 20.23 | Positive speed enable | Binary src | - | - | 1 = 1 |
| 20.24 | Negative speed enable | Binary src | - | - | 1 = 1 |
| 20.25 | Jogging enable | Binary src | - | - | 1 = 1 |
| 20.26 | Jogging 1 start source | Binary src | - | - | 1 = 1 |
| 20.27 | Jogging 2 start source | Binary src | - | - | 1 = 1 |
| 20.30 | Enable signals warning function | PB | 00b...11b | - | 1 = 1 |
| 21 Start/stop mode | | | | | |
| 21.01 | Start mode | List | 0...2 | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|-------------------------------------|----------------------------------|-------------------|------------------------|------|-------------|
| 21.02 | Magnetization time | <i>Real</i> | 0...10000 | ms | 1 = 1 ms |
| 21.03 | Stop mode | <i>List</i> | 0...1 | - | 1 = 1 |
| 21.04 | Emergency stop mode | <i>List</i> | 0...2 | - | 1 = 1 |
| 21.05 | Emergency stop source | <i>Binary src</i> | - | - | 1 = 1 |
| 21.06 | Zero speed limit | <i>Real</i> | 0.00 ... 30000.00 | rpm | 100 = 1 rpm |
| 21.07 | Zero speed delay | <i>Real</i> | 0...30000 | ms | 1 = 1 ms |
| 21.08 | DC current control | <i>PB</i> | 0000b...0011b | - | 1 = 1 |
| 21.09 | DC hold speed | <i>Real</i> | 0.00...1000.00 | rpm | 100 = 1 rpm |
| 21.10 | DC current reference | <i>Real</i> | 0.0...100.0 | % | 10 = 1% |
| 21.11 | Post magnetization time | <i>Real</i> | 0...30000 | ms | 1 = 1 ms |
| 21.12 | Continuous magnetization command | | | - | |
| 21.13 | Autophasing mode | <i>List</i> | 0...2 | - | 1 = 1 |
| 21.18 | Auto restart time | <i>Real</i> | 0.0, 0.1...5.0 | s | 10 = 1 s |
| 21.19 | Scalar start mode | <i>List</i> | 0...2 | - | 1 = 1 |
| 22 Speed reference selection | | | | | |
| 22.01 | Speed ref unlimited | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.11 | Speed ref1 source | <i>Analog src</i> | - | - | 1 = 1 |
| 22.12 | Speed ref2 source | <i>Analog src</i> | - | - | 1 = 1 |
| 22.13 | Speed ref1 function | <i>List</i> | 0...5 | - | 1 = 1 |
| 22.14 | Speed ref1/2 selection | <i>Binary src</i> | - | - | 1 = 1 |
| 22.15 | Speed additive 1 source | <i>Analog src</i> | - | - | 1 = 1 |
| 22.16 | Speed share | <i>Real</i> | -8.000...8.000 | - | 1000 = 1 |
| 22.17 | Speed additive 2 source | <i>Analog src</i> | - | - | 1 = 1 |
| 22.21 | Constant speed function | <i>PB</i> | 0000b...0011b | - | 1 = 1 |
| 22.22 | Constant speed sel1 | <i>Binary src</i> | - | - | 1 = 1 |
| 22.23 | Constant speed sel2 | <i>Binary src</i> | - | - | 1 = 1 |
| 22.24 | Constant speed sel3 | <i>Binary src</i> | - | - | 1 = 1 |
| 22.26 | Constant speed 1 | <i>Real</i> | -30000.00 ... 30000.00 | rpm | 100 = 1 rpm |
| 22.27 | Constant speed 2 | <i>Real</i> | -30000.00 ... 30000.00 | rpm | 100 = 1 rpm |
| 22.28 | Constant speed 3 | <i>Real</i> | -30000.00 ... 30000.00 | rpm | 100 = 1 rpm |
| 22.29 | Constant speed 4 | <i>Real</i> | -30000.00 ... 30000.00 | rpm | 100 = 1 rpm |
| 22.30 | Constant speed 5 | <i>Real</i> | -30000.00 ... 30000.00 | rpm | 100 = 1 rpm |
| 22.31 | Constant speed 6 | <i>Real</i> | -30000.00 ... 30000.00 | rpm | 100 = 1 rpm |
| 22.32 | Constant speed 7 | <i>Real</i> | -30000.00 ... 30000.00 | rpm | 100 = 1 rpm |

| No. | Name | Type | Range | Unit | FbEq32 |
|--------------------------------|-----------------------------------|-------------------|------------------------|------|-------------|
| 22.41 | Speed ref safe | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.42 | Jogging 1 ref | <i>Real</i> | -30000.00 ... 30000.00 | rpm | 100 = 1 rpm |
| 22.43 | Jogging 2 ref | <i>Real</i> | -30000.00 ... 30000.00 | rpm | 100 = 1 rpm |
| 22.51 | Critical speed function | <i>PB</i> | 0000b...0011b | - | 1 = 1 |
| 22.52 | Critical speed 1 low | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.53 | Critical speed 1 high | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.54 | Critical speed 2 low | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.55 | Critical speed 2 high | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.56 | Critical speed 3 low | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.57 | Critical speed 3 high | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.71 | Motor potentiometer function | <i>List</i> | 0...2 | - | 1 = 1 |
| 22.72 | Motor potentiometer initial value | <i>Real</i> | -32768.00 ... 32767.00 | - | 100 = 1 |
| 22.73 | Motor potentiometer up source | <i>Binary src</i> | - | - | 1 = 1 |
| 22.74 | Motor potentiometer down source | <i>Binary src</i> | - | - | 1 = 1 |
| 22.75 | Motor potentiometer ramp time | <i>Real</i> | 0.0 ... 3600.0 | s | 10 = 1 s |
| 22.76 | Motor potentiometer min value | <i>Real</i> | -32768.00 ... 32767.00 | - | 100 = 1 |
| 22.77 | Motor potentiometer max value | <i>Real</i> | -32768.00 ... 32767.00 | - | 100 = 1 |
| 22.80 | Motor potentiometer ref act | <i>Real</i> | -32768.00 ... 32767.00 | - | 100 = 1 |
| 22.81 | Speed reference act 1 | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.82 | Speed reference act 2 | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.83 | Speed reference act 3 | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.84 | Speed reference act 4 | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.85 | Speed reference act 5 | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.86 | Speed reference act 6 | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 22.87 | Speed reference act 7 | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 23 Speed reference ramp | | | | | |
| 23.01 | Speed ref ramp input | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 23.02 | Speed ref ramp output | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 23.11 | Ramp set selection | <i>Binary src</i> | - | - | 1 = 1 |
| 23.12 | Acceleration time 1 | <i>Real</i> | 0.000...1800.000 | s | 1000 = 1 s |
| 23.13 | Deceleration time 1 | <i>Real</i> | 0.000 ...1800.000 | s | 1000 = 1 s |
| 23.14 | Acceleration time 2 | <i>Real</i> | 0.000 ...1800.000 | s | 1000 = 1 s |
| 23.15 | Deceleration time 2 | <i>Real</i> | 0.000 ...1800.000 | s | 1000 = 1 s |
| 23.16 | Shape time acc 1 | <i>Real</i> | 0.000 ...1800.000 | s | 1000 = 1 s |
| 23.17 | Shape time acc 2 | <i>Real</i> | 0.000 ...1800.000 | s | 1000 = 1 s |
| 23.18 | Shape time dec 1 | <i>Real</i> | 0.000 ...1800.000 | s | 1000 = 1 s |
| 23.19 | Shape time dec 2 | <i>Real</i> | 0.000 ...1800.000 | s | 1000 = 1 s |

| No. | Name | Type | Range | Unit | FbEq32 |
|--|-----------------------------------|-------------------|----------------------|------|-------------|
| 23.20 | Acc time jogging | <i>Real</i> | 0.000 ...1800.000 | s | 1000 = 1 s |
| 23.21 | Dec time jogging | <i>Real</i> | 0.000 ...1800.000 | s | 1000 = 1 s |
| 23.23 | Emergency stop time | <i>Real</i> | 0.000 ...1800.000 | s | 1000 = 1 s |
| 23.24 | Speed ramp in zero source | <i>Binary src</i> | - | - | 1 = 1 |
| 23.26 | Ramp out balancing enable | <i>Binary src</i> | - | - | 1 = 1 |
| 23.27 | Ramp out balancing ref | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 23.28 | Variable slope enable | <i>List</i> | 0...1 | - | 1 = 1 |
| 23.29 | Variable slope rate | <i>Real</i> | 2...30000 | ms | 1 = 1 ms |
| 23.39 | Follower speed correction out | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 23.40 | Follower speed correction enable | <i>Binary src</i> | - | - | 1 = 1 |
| 23.41 | Follower speed correction gain | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 24 Speed reference conditioning | | | | | |
| 24.01 | Used speed reference | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 24.02 | Used speed feedback | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 24.03 | Speed error filtered | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 24.04 | Speed error inverted | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 24.11 | Speed correction | <i>Real</i> | -10000.00...10000.00 | - | 100 = 1 |
| 24.12 | Speed error filter time | <i>Real</i> | 0...10000 | ms | 1 = 1 ms |
| 24.41 | Speed error window control enable | <i>List</i> | 0...1 | - | 1 = 1 |
| 24.42 | Speed window control mode | <i>List</i> | 0...1 | - | 1 = 1 |
| 24.43 | Speed error window high | <i>Real</i> | 0.00...3000.00 | rpm | 100 = 1 rpm |
| 24.44 | Speed error window low | <i>Real</i> | 0.00...3000.00 | rpm | 100 = 1 rpm |
| 24.46 | Speed error step | <i>Real</i> | -3000.00...3000.00 | rpm | 100 = 1 rpm |
| 25 Speed control | | | | | |
| 25.01 | Torque reference speed control | <i>Real</i> | -1600.0...1600.0 | % | 10 = 1% |
| 25.02 | Speed proportional gain | <i>Real</i> | 0.00...250.00 | - | 100 = 1 |
| 25.03 | Speed integration time | <i>Real</i> | 0.00...1000.00 | s | 100 = 1 s |
| 25.04 | Speed derivation time | <i>Real</i> | 0.000...10000.000 | s | 1000 = 1 s |
| 25.05 | Derivation filter time | <i>Real</i> | 0...10000 | ms | 1 = 1 ms |
| 25.06 | Acc comp derivation time | <i>Real</i> | 0.00...1000.00 | s | 100 = 1 s |
| 25.07 | Acc comp filter time | <i>Real</i> | 0.0...1000.0 | ms | 10 = 1 ms |
| 25.08 | Drooping rate | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 25.09 | Speed ctrl balancing enable | <i>Binary src</i> | - | - | 1 = 1 |
| 25.10 | Speed ctrl balancing ref | <i>Real</i> | -300.0...300.0 | % | 10 = 1% |
| 25.11 | Speed control min torque | <i>Real</i> | -1600.0...0.0 | % | 10 = 1% |
| 25.12 | Speed control max torque | <i>Real</i> | 0.0...1600.0 | % | 10 = 1% |
| 25.13 | Min torq sp ctrl em stop | <i>Real</i> | -1600...0 | % | 10 = 1% |

| No. | Name | Type | Range | Unit | FbEq32 |
|-------------------------------------|--------------------------------|-------------------|------------------------|------|------------|
| 25.14 | Max torq sp ctrl em stop | <i>Real</i> | 0...1600 | % | 10 = 1% |
| 25.15 | Proportional gain em stop | <i>Real</i> | 1.00...250.00 | - | 100 = 1 |
| 25.18 | Speed adapt min limit | <i>Real</i> | 0...30000 | rpm | 1 = 1 rpm |
| 25.19 | Speed adapt max limit | <i>Real</i> | 0...30000 | rpm | 1 = 1 rpm |
| 25.21 | Kp adapt coef at min speed | <i>Real</i> | 0.000...10.000 | - | 1000 = 1 |
| 25.22 | Ti adapt coef at min speed | <i>Real</i> | 0.000...10.000 | - | 1000 = 1 |
| 25.25 | Torque adapt max limit | <i>Real</i> | 0.0...1600.0 | % | 10 = 1% |
| 25.26 | Torque adapt filt time | <i>Real</i> | 0.000...100.000 | s | 1000 = 1 s |
| 25.27 | Kp adapt coef at min torque | <i>Real</i> | 0.000...10.000 | - | 1000 = 1 |
| 25.30 | Flux adaptation enable | <i>List</i> | 0...1 | - | 1 = 1 |
| 25.33 | Speed controller autotune | <i>Binary src</i> | - | - | 1 = 1 |
| 25.34 | Speed controller autotune mode | <i>List</i> | 0...2 | - | 1 = 1 |
| 25.37 | Mechanical time constant | <i>Real</i> | 0.00...1000.00 | s | 100 = 1 s |
| 25.38 | Autotune torque step | <i>Real</i> | 0.00...100.00 | % | 100 = 1 % |
| 25.39 | Autotune speed step | <i>Real</i> | 0.00...100.00 | % | 100 = 1 % |
| 25.40 | Autotune repeat times | <i>Real</i> | 1...10 | - | 1 = 1 |
| 25.53 | Torque prop reference | <i>Real</i> | -30000.0... 30000.0 | % | 10 = 1% |
| 25.54 | Torque integral reference | <i>Real</i> | -30000.0... 30000.0 | % | 10 = 1% |
| 25.55 | Torque deriv reference | <i>Real</i> | -30000.0... 30000.0 | % | 10 = 1% |
| 25.56 | Torque acc compensation | <i>Real</i> | -30000.0... 30000.0 | % | 10 = 1% |
| 25.57 | Torque reference unbalanced | <i>Real</i> | -30000.0... 30000.0 | % | 10 = 1% |
| 26 Torque reference chain | | | | | |
| 26.01 | Torque reference to TC | <i>Real</i> | -1600.0 ... 1600.0 | % | 10 = 1% |
| 26.02 | Torque reference used | <i>Real</i> | -1600.0 ... 1600.0 | % | 10 = 1% |
| 26.51 | Oscillation damping | <i>Binary src</i> | - | - | 1 = 1 |
| 26.52 | Oscillation damping out enable | <i>Binary src</i> | - | - | 1 = 1 |
| 26.53 | Oscillation compensation input | <i>List</i> | 0...1 | - | 1 = 1 |
| 26.55 | Oscillation damping frequency | <i>Real</i> | 0.1 ... 60.0 | Hz | 10 = 1 Hz |
| 26.56 | Oscillation damping phase | <i>Real</i> | 0...360 | deg | 1 = 1 deg |
| 26.57 | Oscillation damping gain | <i>Real</i> | 0.0 ... 100.0 | % | 10 = 1% |
| 26.58 | Oscillation damping output | <i>Real</i> | -1600.000 ... 1600.000 | % | 1000 = 1% |
| 26.81 | Rush control gain | <i>Real</i> | 0.0 ... 10000.0 | - | 10 = 1 |
| 26.82 | Rush control integration time | <i>Real</i> | 0.0 ... 10.0 | s | 10 = 1 s |
| 28 Frequency reference chain | | | | | |
| 28.01 | Frequency ref ramp input | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.02 | Frequency ref ramp output | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.11 | Frequency ref1 source | <i>Analog src</i> | - | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|-------|-----------------------------------|-------------------|--------------------|------|------------|
| 28.12 | Frequency ref2 source | <i>Analog src</i> | - | - | 1 = 1 |
| 28.13 | Frequency ref1 function | <i>List</i> | 0...5 | - | 1 = 1 |
| 28.14 | Frequency ref1/2 selection | <i>Binary src</i> | - | - | 1 = 1 |
| 28.21 | Constant frequency function | <i>PB</i> | 0000b...0011b | - | 1 = 1 |
| 28.22 | Constant frequency sel1 | <i>Binary src</i> | - | - | 1 = 1 |
| 28.23 | Constant frequency sel2 | <i>Binary src</i> | - | - | 1 = 1 |
| 28.24 | Constant frequency sel3 | <i>Binary src</i> | - | - | 1 = 1 |
| 28.26 | Constant frequency 1 | <i>Real</i> | -500.00 ... 500.00 | Hz | 100 = 1 Hz |
| 28.27 | Constant frequency 2 | <i>Real</i> | -500.00 ... 500.00 | Hz | 100 = 1 Hz |
| 28.28 | Constant frequency 3 | <i>Real</i> | -500.00 ... 500.00 | Hz | 100 = 1 Hz |
| 28.29 | Constant frequency 4 | <i>Real</i> | -500.00 ... 500.00 | Hz | 100 = 1 Hz |
| 28.30 | Constant frequency 5 | <i>Real</i> | -500.00 ... 500.00 | Hz | 100 = 1 Hz |
| 28.31 | Constant frequency 6 | <i>Real</i> | -500.00 ... 500.00 | Hz | 100 = 1 Hz |
| 28.32 | Constant frequency 7 | <i>Real</i> | -500.00 ... 500.00 | Hz | 100 = 1 Hz |
| 28.41 | Frequency ref safe | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.51 | Critical frequency function | <i>PB</i> | 0000b...0011b | - | 1 = 1 |
| 28.52 | Critical frequency 1 low | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.53 | Critical frequency 1 high | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.54 | Critical frequency 2 low | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.55 | Critical frequency 2 high | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.56 | Critical frequency 3 low | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.57 | Critical frequency 3 high | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.71 | Freq ramp set selection | <i>Binary src</i> | - | - | 1 = 1 |
| 28.72 | Freq acceleration time 1 | <i>Real</i> | 0.000 ... 1800.000 | s | 1000 = 1 s |
| 28.73 | Freq deceleration time 1 | <i>Real</i> | 0.000 ... 1800.000 | s | 1000 = 1 s |
| 28.74 | Freq acceleration time 2 | <i>Real</i> | 0.000 ... 1800.000 | s | 1000 = 1 s |
| 28.75 | Freq deceleration time 2 | <i>Real</i> | 0.000 ... 1800.000 | s | 1000 = 1 s |
| 28.76 | Freq ramp in zero source | <i>Binary src</i> | - | - | 1 = 1 |
| 28.77 | Freq ramp hold | <i>Binary src</i> | - | - | 1 = 1 |
| 28.78 | Freq ramp output balancing | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.79 | Freq ramp output balancing enable | <i>Binary src</i> | - | - | 1 = 1 |
| 28.90 | Frequency ref act 1 | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.91 | Frequency ref act 2 | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.92 | Frequency ref act 3 | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 28.96 | Frequency ref act 7 | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |

| No. | Name | Type | Range | Unit | FbEq32 |
|---------------------------|------------------------------|-------------------|----------------------|------|-------------|
| 28.97 | Frequency ref unlimited | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 30 Limits | | | | | |
| 30.01 | Limit word 1 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 30.02 | Torque limit status | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 30.11 | Minimum speed | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 30.12 | Maximum speed | <i>Real</i> | -30000.00...30000.00 | rpm | 100 = 1 rpm |
| 30.13 | Minimum frequency | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 30.14 | Maximum frequency | <i>Real</i> | -500.00...500.00 | Hz | 100 = 1 Hz |
| 30.15 | Maximum start current enable | <i>List</i> | 0...1 | - | 1 = 1 |
| 30.16 | Maximum start current | <i>Real</i> | 0.00...30000.00 | A | 100 = 1 A |
| 30.17 | Maximum current | <i>Real</i> | 0.00...30000.00 | A | 100 = 1 A |
| 30.18 | Minimum torque sel | <i>Binary src</i> | - | - | 1 = 1 |
| 30.19 | Minimum torque 1 | <i>Real</i> | -1600.0...0.0 | % | 10 = 1% |
| 30.20 | Maximum torque 1 | <i>Real</i> | 0.0...1600.0 | % | 10 = 1% |
| 30.21 | Minimum torque 2 source | <i>Analog src</i> | - | - | 1 = 1 |
| 30.22 | Maximum torque 2 source | <i>Analog src</i> | - | - | 1 = 1 |
| 30.23 | Minimum torque 2 | <i>Real</i> | -1600.0...0.0 | % | 10 = 1% |
| 30.24 | Maximum torque 2 | <i>Real</i> | 0.0...1600.0 | % | 10 = 1% |
| 30.25 | Maximum torque sel | <i>Binary src</i> | - | - | 1 = 1 |
| 30.26 | Power motoring limit | <i>Real</i> | 0.00...600.00 | % | 100 = 1% |
| 30.27 | Power generating limit | <i>Real</i> | -600.00...0.00 | % | 100 = 1% |
| 30.30 | Overvoltage control | <i>List</i> | 0...1 | - | 1 = 1 |
| 30.31 | Undervoltage control | <i>List</i> | 0...1 | - | 1 = 1 |
| 31 Fault functions | | | | | |
| 31.01 | External event 1 source | <i>Binary src</i> | - | - | 1 = 1 |
| 31.02 | External event 1 type | <i>List</i> | 0...1 | - | 1 = 1 |
| 31.03 | External event 2 source | <i>Binary src</i> | - | - | 1 = 1 |
| 31.04 | External event 2 type | <i>List</i> | 0...1 | - | 1 = 1 |
| 31.05 | External event 3 source | <i>Binary src</i> | - | - | 1 = 1 |
| 31.06 | External event 3 type | <i>List</i> | 0...1 | - | 1 = 1 |
| 31.07 | External event 4 source | <i>Binary src</i> | - | - | 1 = 1 |
| 31.08 | External event 4 type | <i>List</i> | 0...1 | - | 1 = 1 |
| 31.09 | External event 5 source | <i>Binary src</i> | - | - | 1 = 1 |
| 31.10 | External event 5 type | <i>List</i> | 0...1 | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|-----------------------|----------------------------------|-------------------|--------------------------------|------|-------------|
| 31.11 | Fault reset selection | <i>Binary src</i> | - | - | 1 = 1 |
| 31.12 | Autoreset selection | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 31.13 | User selectable fault | <i>Real</i> | 0000h...FFFFh | - | 1 = 1 |
| 31.14 | Number of trials | <i>Real</i> | 0...5 | - | 1 = 1 |
| 31.15 | Total trials time | <i>Real</i> | 1.0...600.0 | s | 10 = 1 s |
| 31.16 | Delay time | <i>Real</i> | 0.0...120.0 | s | 10 = 1 s |
| 31.19 | Motor phase loss | <i>List</i> | 0...1 | - | 1 = 1 |
| 31.20 | Earth fault | <i>List</i> | 0...2 | - | 1 = 1 |
| 31.21 | Supply phase loss | <i>List</i> | 0...1 | - | 1 = 1 |
| 31.22 | STO indication run/stop | <i>List</i> | 0...5 | - | 1 = 1 |
| 31.23 | Wiring or earth fault | <i>List</i> | 0...1 | - | 1 = 1 |
| 31.24 | Stall function | <i>List</i> | 0...2 | - | 1 = 1 |
| 31.25 | Stall current limit | <i>Real</i> | 0.0...1600.0 | % | 10 = 1% |
| 31.26 | Stall speed limit | <i>Real</i> | 0.0...10000.0 | rpm | 100 = 1 rpm |
| 31.27 | Stall frequency limit | <i>Real</i> | 0.00...500.00 | Hz | 100 = 1 Hz |
| 31.28 | Stall time | <i>Real</i> | 0...3600 | s | 1 = 1 s |
| 31.30 | Overspeed trip margin | <i>Real</i> | 0...10000 | rpm | 100 = 1 rpm |
| 31.32 | Emergency ramp supervision | <i>Real</i> | 0...300 | % | 1 = 1% |
| 31.33 | Emergency ramp supervision delay | <i>Real</i> | 0...32767 | s | 1 = 1 s |
| 31.35 | Main fan fault function | <i>List</i> | 0...2 | - | 1 = 1 |
| 31.36 | Aux fan fault bypass | <i>List</i> | 0...1 | - | 1 = 1 |
| 31.37 | Ramp stop supervision | <i>Real</i> | 0...300 | % | 1 = 1% |
| 31.38 | Ramp stop supervision delay | <i>Real</i> | 0...32767 | s | 1 = 1 s |
| 31.40 | Disable warnings | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 31.42 | Overcurrent fault limit | <i>Real</i> | 0.00...30000.00 | A | 100 = 1 A |
| 32 Supervision | | | | | |
| 32.01 | Supervision status | <i>PB</i> | 0000...0111b | - | 1 = 1 |
| 32.05 | Supervision 1 function | <i>List</i> | 0...6 | - | 1 = 1 |
| 32.06 | Supervision 1 action | <i>List</i> | 0...2 | - | 1 = 1 |
| 32.07 | Supervision 1 signal | <i>Analog src</i> | - | - | 1 = 1 |
| 32.08 | Supervision 1 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 32.09 | Supervision 1 low | <i>Real</i> | -21474830.00 ...21474830.00 | - | 100 = 1 |
| 32.10 | Supervision 1 high | <i>Real</i> | -21474830.00 ...21474830.00 | - | 100 = 1 |
| 32.15 | Supervision 2 function | <i>List</i> | 0...6 | - | 1 = 1 |
| 32.16 | Supervision 2 action | <i>List</i> | 0...2 | - | 1 = 1 |
| 32.17 | Supervision 2 signal | <i>Analog src</i> | - | - | 1 = 1 |
| 32.18 | Supervision 2 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |

386 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|---------------------------------------|-----------------------------|-----------------------|--------------------------------|------|------------|
| 32.19 | Supervision 2 low | <i>Real</i> | -21474830.00 ...21474830.00 | - | 100 = 1 |
| 32.20 | Supervision 2 high | <i>Real</i> | -21474830.00 ...21474830.00 | - | 100 = 1 |
| 32.25 | Supervision 3 function | <i>List</i> | 0...6 | - | 1 = 1 |
| 32.26 | Supervision 3 action | <i>List</i> | 0...2 | - | 1 = 1 |
| 32.27 | Supervision 3 signal | <i>Analog src</i> | - | - | 1 = 1 |
| 32.28 | Supervision 3 filter time | <i>Real</i> | 0.000...30.000 | s | 1000 = 1 s |
| 32.29 | Supervision 3 low | <i>Real</i> | -21474830.00 ...21474830.00 | - | 100 = 1 |
| 32.30 | Supervision 3 high | <i>Real</i> | -21474830.00 ...21474830.00 | - | 100 = 1 |
| 33 Generic timer & counter | | | | | |
| 33.01 | Counter status | <i>PB</i> | 0000 0000b...0011 1111b | - | 1 = 1 |
| 33.10 | On-time 1 actual | <i>Real</i> | 0...4294967295 | s | 1 = 1 s |
| 33.11 | On-time 1 warn limit | <i>Real</i> | 0...4294967295 | s | 1 = 1 s |
| 33.12 | On-time 1 function | <i>PB</i> | 0000b...0011b | - | 1 = 1 |
| 33.13 | On-time 1 source | <i>Binary src</i> | - | - | 1 = 1 |
| 33.14 | On-time 1 warn message | <i>List</i> | - | - | 1 = 1 |
| 33.20 | On-time 2 actual | <i>Real</i> | 0...4294967295 | s | 1 = 1 s |
| 33.21 | On-time 2 warn limit | <i>Real</i> | 0...4294967295 | s | 1 = 1 s |
| 33.22 | On-time 2 function | <i>PB</i> | 0000b...0011b | - | 1 = 1 |
| 33.23 | On-time 2 source | <i>Binary src</i> | - | - | 1 = 1 |
| 33.24 | On-time 2 warn message | <i>List</i> | - | - | 1 = 1 |
| 33.30 | Edge counter 1 actual | <i>Real</i> | 0...4294967295 | - | 1 = 1 |
| 33.31 | Edge counter 1 warn limit | <i>Real</i> | 0...4294967295 | - | 1 = 1 |
| 33.32 | Edge counter 1 function | <i>PB</i> | 0000b...1111b | - | 1 = 1 |
| 33.33 | Edge counter 1 source | <i>Binary src</i> | - | - | 1 = 1 |
| 33.34 | Edge counter 1 divider | <i>Real</i> | 1...4294967295 | - | 1 = 1 |
| 33.35 | Edge counter 1 warn message | <i>List</i> | - | - | 1 = 1 |
| 33.40 | Edge counter 2 actual | <i>Real</i> | 0...4294967295 | - | 1 = 1 |
| 33.41 | Edge counter 2 warn limit | <i>Real</i> | 0...4294967295 | - | 1 = 1 |
| 33.42 | Edge counter 2 function | <i>PB</i> | 0000b...1111b | - | 1 = 1 |
| 33.43 | Edge counter 2 source | <i>Binary src</i> | - | - | 1 = 1 |
| 33.44 | Edge counter 2 divider | <i>Real</i> | 1...4294967295 | - | 1 = 1 |
| 33.45 | Edge counter 2 warn message | <i>List</i> | - | - | 1 = 1 |
| 33.50 | Value counter 1 actual | <i>Real</i> | -2147483008 ...2147483008 | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|------------------------------------|--------------------------------------|-------------------|--|------------------|------------|
| 33.51 | Value counter 1 warn limit | <i>Real</i> | -2147483008 ...2147483008 | - | 1 = 1 |
| 33.52 | Value counter 1 function | <i>PB</i> | 0000b...0011b | - | 1 = 1 |
| 33.53 | Value counter 1 source | <i>Analog src</i> | - | - | 1 = 1 |
| 33.54 | Value counter 1 divider | <i>Real</i> | 0.001...2147483.000 | - | 1000 = 1 |
| 33.55 | Value counter 1 warn message | <i>List</i> | - | - | 1 = 1 |
| 33.60 | Value counter 2 actual | <i>Real</i> | -2147483008 ...2147483008 | - | 1 = 1 |
| 33.61 | Value counter 2 warn limit | <i>Real</i> | -2147483008 ...2147483008 | - | 1 = 1 |
| 33.62 | Value counter 2 function | <i>PB</i> | 0000b...0011b | - | 1 = 1 |
| 33.63 | Value counter 2 source | <i>Analog src</i> | - | - | 1 = 1 |
| 33.64 | Value counter 2 divider | <i>Real</i> | 0.001...2147483.000 | - | 1000 = 1 |
| 33.65 | Value counter 2 warn message | <i>List</i> | - | - | 1 = 1 |
| 35 Motor thermal protection | | | | | |
| 35.01 | Motor estimated temperature | <i>Real</i> | -60...1000 | °C | 1 = 1 °C |
| 35.02 | Measured temperature 1 | <i>Real</i> | -60 ... 5000 °C, -76 ... 9032 °F, 0 ohm or [35.12] ohm | °C, °F or ohm | 1 = 1 unit |
| 35.03 | Measured temperature 2 | <i>Real</i> | -60 ... 5000 °C, -76 ... 9032 °F, 0 ohm or [35.22] ohm | °C, °F or ohm | 1 = 1 unit |
| 35.04 | FEX-01/FPTC-01 status word | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 35.11 | Temperature 1 source | <i>List</i> | 0...11 | - | 1 = 1 |
| 35.12 | Temperature 1 fault limit | <i>Real</i> | -60 ... 5000 °C or ohm, or -76 ... 9032 °F | °C, °F or ohm | 1 = 1 unit |
| 35.13 | Temperature 1 warning limit | <i>Real</i> | -60 ... 5000 °C or ohm, or -76 ... 9032 °F | °C, °F or ohm | 1 = 1 unit |
| 35.14 | Temperature 1 AI source | <i>Analog src</i> | - | - | 1 = 1 |
| 35.21 | Temperature 2 source | <i>List</i> | 0...11 | - | 1 = 1 |
| 35.22 | Temperature 2 fault limit | <i>Real</i> | -60 ... 5000 °C or ohm, or -76 ... 9032 °F | °C, °F or ohm | 1 = 1 unit |
| 35.23 | Temperature 2 warning limit | <i>Real</i> | -60 ... 5000 °C or ohm, or -76 ... 9032 °F | °C, °F or ohm | 1 = 1 unit |
| 35.24 | Temperature 2 AI source | <i>Analog src</i> | - | - | 1 = 1 |
| 35.30 | FEX-01/FPTC-01 configuration word | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 35.50 | Motor ambient temperature | <i>Real</i> | -60 ... 100 °C or -76 ... 212 °F | °C or °F | 1 = 1 ° |
| 35.51 | Motor load curve | <i>Real</i> | 50...150 | % | 1 = 1% |
| 35.52 | Zero speed load | <i>Real</i> | 50...150 | % | 1 = 1% |

388 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|-------------------------|--------------------------------|-------------------|----------------------|------|-------------|
| 35.53 | Break point | <i>Real</i> | 1.00...500.00 | Hz | 100 = 1 Hz |
| 35.54 | Motor nominal temperature rise | <i>Real</i> | 0...300 | °C | 1 = 1 °C |
| 35.55 | Motor thermal time constant | <i>Real</i> | 100...10000 | s | 1 = 1 s |
| 35.60 | Cable temperature | <i>Real</i> | 00...200.0 | % | 10 = 1% |
| 35.61 | Cable nominal current | <i>Real</i> | 0.00...10000.0 | A | 100 = 1 A |
| 35.62 | Cable thermal rise time | <i>Real</i> | 0...50000 | s | 1 = 1 s |
| 35.100 | DOL starter control source | <i>Binary src</i> | - | - | 1 = 1 |
| 35.101 | DOL starter on delay | <i>Real</i> | 0...42949673 | s | 1 = 1 s |
| 35.102 | DOL starter off delay | <i>Real</i> | 0...715828 | min | 1 = 1 min |
| 35.103 | DOL starter feedback source | <i>Binary src</i> | - | - | 1 = 1 |
| 35.104 | DOL starter feedback delay | <i>Real</i> | 0...42949673 | s | 1 = 1 s |
| 35.105 | DOL starter status word | <i>PB</i> | 0000b...1111b | - | 1 = 1 |
| 35.106 | DOL starter event type | <i>List</i> | 0...2 | - | 1 = 1 |
| 36 Load analyzer | | | | | |
| 36.01 | PVL signal source | <i>Analog src</i> | - | - | 1 = 1 |
| 36.02 | PVL filter time | <i>Real</i> | 0.00...120.00 | s | 100 = 1 s |
| 36.06 | AL2 signal source | <i>Analog src</i> | - | - | 1 = 1 |
| 36.07 | AL2 signal scaling | <i>Real</i> | 0.00...32767.00 | - | 100 = 1 |
| 36.09 | Reset loggers | <i>List</i> | 0...3 | - | 1 = 1 |
| 36.10 | PVL peak value | <i>Real</i> | -32768.00...32767.00 | - | 100 = 1 |
| 36.11 | PVL peak date | <i>Data</i> | - | - | 1 = 1 |
| 36.12 | PVL peak time | <i>Data</i> | - | - | 1 = 1 |
| 36.13 | PVL current at peak | <i>Real</i> | -32768.00...32767.00 | A | 100 = 1 A |
| 36.14 | PVL DC voltage at peak | <i>Real</i> | 0.00...2000.00 | V | 100 = 1 V |
| 36.15 | PVL speed at peak | <i>Real</i> | -32768.00...32767.00 | rpm | 100 = 1 rpm |
| 36.16 | PVL reset date | <i>Data</i> | - | - | 1 = 1 |
| 36.17 | PVL reset time | <i>Data</i> | - | - | 1 = 1 |
| 36.20 | AL1 0 to 10% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.21 | AL1 10 to 20% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.22 | AL1 20 to 30% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.23 | AL1 30 to 40% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.24 | AL1 40 to 50% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.25 | AL1 50 to 60% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.26 | AL1 60 to 70% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.27 | AL1 70 to 80% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.28 | AL1 80 to 90% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.29 | AL1 over 90% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |

| No. | Name | Type | Range | Unit | FbEq32 |
|-----------------------------|------------------------------|-------------------|-------------------------|----------------|----------------------|
| 36.40 | AL2 0 to 10% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.41 | AL2 10 to 20% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.42 | AL2 20 to 30% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.43 | AL2 30 to 40% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.44 | AL2 40 to 50% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.45 | AL2 50 to 60% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.46 | AL2 60 to 70% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.47 | AL2 70 to 80% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.48 | AL2 80 to 90% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.49 | AL2 over 90% | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 36.50 | AL2 reset date | <i>Data</i> | - | - | 1 = 1 |
| 36.51 | AL2 reset time | <i>Data</i> | - | - | 1 = 1 |
| 43 Brake chopper | | | | | |
| 43.01 | Braking resistor temperature | <i>Real</i> | 0.0...120.0 | % | 10 = 1% |
| 43.06 | Brake chopper enable | <i>List</i> | 0...2 | - | 1 = 1 |
| 43.07 | Brake chopper runtime enable | <i>Binary src</i> | - | - | 1 = 1 |
| 43.08 | Brake resistor thermal tc | <i>Real</i> | 0...10000 | s | 1 = 1 s |
| 43.09 | Brake resistor Pmax cont | <i>Real</i> | 0.00...10000.00 | kW | 100 = 1 kW |
| 43.10 | Brake resistance | <i>Real</i> | 0...1000 | ohm | 10 = 1 ohm |
| 43.11 | Brake resistor fault limit | <i>Real</i> | 0...150 | % | 1 = 1% |
| 43.12 | Brake resistor warning limit | <i>Real</i> | 0...150 | % | 1 = 1% |
| 45 Energy efficiency | | | | | |
| 45.01 | Saved GW hours | <i>Real</i> | 0...65535 | GWh | 1 = 1 GWh |
| 45.02 | Saved MW hours | <i>Real</i> | 0...999 | MWh | 1 = 1 MWh |
| 45.03 | Saved kW hours | <i>Real</i> | 0.0...999.9 | kWh | 10 = 1 kWh |
| 45.05 | Saved money x1000 | <i>Real</i> | 0...4294967295 | thousand | 1 = 1 thousand |
| 45.06 | Saved money | <i>Real</i> | 0.00...999.99 | (selectable) | 100 = 1 unit |
| 45.08 | CO2 reduction in kilotons | <i>Real</i> | 0...65535 | metric kiloton | 1 = 1 metric kiloton |
| 45.09 | CO2 reduction in tons | <i>Real</i> | 0.0...999.9 | metric ton | 10 = 1 metric ton |
| 45.11 | Energy optimizer | <i>List</i> | 0...1 | - | 1 = 1 |
| 45.12 | Energy tariff 1 | <i>Real</i> | 0.000 ...4294966.296 | (selectable) | 1000 = 1 unit |
| 45.13 | Energy tariff 2 | <i>Real</i> | 0.000...4294966.296 | (selectable) | 1000 = 1 unit |
| 45.14 | Tariff selection | <i>Binary src</i> | - | - | 1 = 1 |
| 45.17 | Tariff currency unit | <i>List</i> | 100...102 | - | 1 = 1 |

390 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|---------------------------------------|---------------------------|-------------|--------------------------------|-------------------|-------------------------------|
| 45.18 | CO2 conversion factor | <i>Real</i> | 0.000...65.535 | metricton/ MWh | 1000 = 1 metric ton/MWh |
| 45.19 | Comparison power | <i>Real</i> | 0.0...100000.0 | kW | 10 = 1 kW |
| 45.21 | Energy calculations reset | <i>List</i> | 0...1 | - | 1 = 1 |
| 46 Monitoring/scaling settings | | | | | |
| 46.01 | Speed scaling | <i>Real</i> | 0.10...30000.00 | rpm | 100 = 1 rpm |
| 46.02 | Frequency scaling | <i>Real</i> | 0.10...1000.00 | Hz | 100 = 1 Hz |
| 47 Data storage | | | | | |
| 47.01 | Data storage 1 real32 | <i>Real</i> | -2147483.000 ...2147483.000 | - | 1000 = 1 |
| 47.02 | Data storage 2 real32 | <i>Real</i> | -2147483.000 ...2147483.000 | - | 1000 = 1 |
| 47.03 | Data storage 3 real32 | <i>Real</i> | -2147483.000 ...2147483.000 | - | 1000 = 1 |
| 47.04 | Data storage 4 real32 | <i>Real</i> | -2147483.000 ...2147483.000 | - | 1000 = 1 |
| 47.05 | Data storage 5 real32 | <i>Real</i> | -2147483.000 ...2147483.000 | - | 1000 = 1 |
| 47.06 | Data storage 6 real32 | <i>Real</i> | -2147483.000 ...2147483.000 | - | 1000 = 1 |
| 47.07 | Data storage 7 real32 | <i>Real</i> | -2147483.000 ...2147483.000 | - | 1000 = 1 |
| 47.08 | Data storage 8 real32 | <i>Real</i> | -2147483.000 ...2147483.000 | - | 1000 = 1 |
| 47.11 | Data storage 1 int32 | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 47.12 | Data storage 2 int32 | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 47.13 | Data storage 3 int32 | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 47.14 | Data storage 4 int32 | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 47.15 | Data storage 5 int32 | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 47.16 | Data storage 6 int32 | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 47.17 | Data storage 7 int32 | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 47.18 | Data storage 8 int32 | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 47.21 | Data storage 1 int16 | <i>Real</i> | -32768...32767 | - | 1 = 1 |
| 47.22 | Data storage 2 int16 | <i>Real</i> | -32768...32767 | - | 1 = 1 |
| 47.23 | Data storage 3 int16 | <i>Real</i> | -32768...32767 | - | 1 = 1 |
| 47.24 | Data storage 4 int16 | <i>Real</i> | -32768...32767 | - | 1 = 1 |
| 47.25 | Data storage 5 int16 | <i>Real</i> | -32768...32767 | - | 1 = 1 |
| 47.26 | Data storage 6 int16 | <i>Real</i> | -32768...32767 | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|------------------------------------|-------------------------------|-------------------|------------------------------|------|----------|
| 47.27 | Data storage 7 int16 | <i>Real</i> | -32768...32767 | - | 1 = 1 |
| 47.28 | Data storage 8 int16 | <i>Real</i> | -32768...32767 | - | 1 = 1 |
| 47.31 | Data storage 1 real32 type | <i>List</i> | 0...5 | - | 1 = 1 |
| 47.32 | Data storage 2 real32 type | <i>List</i> | 0...5 | - | 1 = 1 |
| 47.33 | Data storage 3 real32 type | <i>List</i> | 0...5 | - | 1 = 1 |
| 47.34 | Data storage 4 real32 type | <i>List</i> | 0...5 | - | 1 = 1 |
| 47.35 | Data storage 5 real32 type | <i>List</i> | 0...5 | - | 1 = 1 |
| 47.36 | Data storage 6 real32 type | <i>List</i> | 0...5 | - | 1 = 1 |
| 47.37 | Data storage 7 real32 type | <i>List</i> | 0...5 | - | 1 = 1 |
| 47.38 | Data storage 8 real32 type | <i>List</i> | 0...5 | - | 1 = 1 |
| 49 Panel port communication | | | | | |
| 49.01 | Node ID number | <i>Real</i> | 1...32 | - | 1 = 1 |
| 49.03 | Baud rate | <i>List</i> | 1...5 | - | 1 = 1 |
| 49.04 | Communication loss time | <i>Real</i> | 0.1...3000.0 | s | 10 = 1 s |
| 49.05 | Communication loss action | <i>List</i> | 0...3 | - | 1 = 1 |
| 49.06 | Refresh settings | <i>List</i> | 0...1 | - | 1 = 1 |
| 50 Fieldbus adapter (FBA) | | | | | |
| 50.01 | FBA A enable | <i>List</i> | 0...1 | - | 1 = 1 |
| 50.02 | FBA A comm loss func | <i>List</i> | 0...3 | - | 1 = 1 |
| 50.03 | FBA A comm loss t out | <i>Real</i> | 0.3...6553.5 | s | 10 = 1 s |
| 50.04 | FBA A ref1 type | <i>List</i> | 0...10 | - | 1 = 1 |
| 50.05 | FBA A ref2 type | <i>List</i> | 0...10 | - | 1 = 1 |
| 50.07 | FBA A actual 1 type | <i>List</i> | 0...6 | - | 1 = 1 |
| 50.08 | FBA A actual 2 type | <i>List</i> | 0...6 | - | 1 = 1 |
| 50.09 | FBA A SW transparent source | <i>Analog src</i> | - | - | 1 = 1 |
| 50.10 | FBA A act1 transparent source | <i>Analog src</i> | - | - | 1 = 1 |
| 50.11 | FBA A act2 transparent source | <i>Analog src</i> | - | - | 1 = 1 |
| 50.12 | FBA A debug mode | <i>List</i> | 0...1 | - | 1 = 1 |
| 50.13 | FBA A control word | <i>Data</i> | 00000000h...FFFFFFFh | - | 1 = 1 |
| 50.14 | FBA A reference 1 | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 50.15 | FBA A reference 2 | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 50.16 | FBA A status word | <i>Data</i> | 00000000h...FFFFFFFh | - | 1 = 1 |
| 50.17 | FBA A actual value 1 | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 50.18 | FBA A actual value 2 | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 50.21 | FBA A timelevel sel | <i>List</i> | 0...3 | - | 1 = 1 |
| 50.31 | FBA B enable | <i>List</i> | 0...1 | - | 1 = 1 |

392 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|--------------------------|-------------------------------|------------|-------------------------------|------|----------|
| 50.32 | FBA B comm loss func | List | 0...3 | - | 1 = 1 |
| 50.33 | FBA B comm loss timeout | Real | 0.3...6553.5 | s | 10 = 1 s |
| 50.34 | FBA B ref1 type | List | 0...10 | - | 1 = 1 |
| 50.35 | FBA B ref2 type | List | 0...10 | - | 1 = 1 |
| 50.37 | FBA B actual 1 type | List | 0...6 | - | 1 = 1 |
| 50.38 | FBA B actual 2 type | List | 0...6 | - | 1 = 1 |
| 50.39 | FBA B SW transparent source | Analog src | - | - | 1 = 1 |
| 50.40 | FBA B act1 transparent source | Analog src | - | - | 1 = 1 |
| 50.41 | FBA B act2 transparent source | Analog src | - | - | 1 = 1 |
| 50.42 | FBA B debug mode | List | 0...1 | - | 1 = 1 |
| 50.43 | FBA B control word | Data | 00000000h...FFFFFFFFh | - | 1 = 1 |
| 50.44 | FBA B reference 1 | Real | -2147483648 ...2147483647 | - | 1 = 1 |
| 50.45 | FBA B reference 2 | Real | -2147483648 ...2147483647 | - | 1 = 1 |
| 50.46 | FBA B status word | Data | 00000000h...FFFFFFFFh | - | 1 = 1 |
| 50.47 | FBA B actual value 1 | Real | -2147483648 ...2147483647 | - | 1 = 1 |
| 50.48 | FBA B actual value 2 | Real | -2147483648 ... 2147483647 | - | 1 = 1 |
| 50.51 | FBA B timelevel sel | List | 0...3 | - | 1 = 1 |
| 51 FBA A settings | | | | | |
| 51.01 | FBA A type | List | - | - | 1 = 1 |
| 51.02 | FBA A Par2 | Real | 0...65535 | - | 1 = 1 |
| ... | ... | ... | ... | ... | |
| 51.26 | FBA A Par26 | Real | 0...65535 | - | 1 = 1 |
| 51.27 | FBA A par refresh | List | 0...1 | - | 1 = 1 |
| 51.28 | FBA A par table ver | Data | - | - | 1 = 1 |
| 51.29 | FBA A drive type code | Real | 0...65535 | - | 1 = 1 |
| 51.30 | FBA A mapping file ver | Real | 0...65535 | - | 1 = 1 |
| 51.31 | D2FBA A comm status | List | 0...6 | - | 1 = 1 |
| 51.32 | FBA A comm SW ver | Data | - | - | 1 = 1 |
| 51.33 | FBA A appl SW ver | Data | - | - | 1 = 1 |
| 52 FBA A data in | | | | | |
| 52.01 | FBA A data in1 | List | - | - | 1 = 1 |
| ... | ... | ... | ... | ... | |
| 52.12 | FBA A data in12 | List | - | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|-----------------------------|---------------------------|--------|----------------|------|----------|
| 53 FBA A data out | | | | | |
| 53.01 | FBA A data out1 | List | - | - | 1 = 1 |
| ... | ... | ... | ... | ... | |
| 53.12 | FBA A data out12 | List | - | - | 1 = 1 |
| 54 FBA B settings | | | | | |
| 54.01 | FBA B type | | | | |
| 54.02 | FBA B Par2 | UINT16 | 0...65535 | - | |
| ... | ... | ... | ... | ... | |
| 54.26 | FBA B Par26 | UINT16 | 0...65535 | - | |
| 54.27 | FBA B par refresh | List | 0...1 | - | |
| 54.28 | FBA B par table ver | UINT16 | - | - | |
| 54.29 | FBA B drive type code | UINT16 | 0...65535 | - | |
| 54.30 | FBA B mapping file ver | UINT16 | 0...65535 | - | |
| 54.31 | D2FBA B comm status | List | 0...6 | - | |
| 54.32 | FBA B comm SW ver | UINT16 | - | - | |
| 54.33 | FBA B appl SW ver | UINT16 | - | - | |
| 55 FBA B data in | | | | | |
| 55.01 | FBA B data in1 | List | - | - | 1 = 1 |
| ... | ... | ... | ... | | |
| 55.12 | FBA B data in12 | List | - | - | 1 = 1 |
| 56 FBA B data out | | | | | |
| 56.01 | FBA B data out1 | List | - | - | 1 = 1 |
| ... | ... | ... | ... | | |
| 56.12 | FBA B data out12 | List | - | - | 1 = 1 |
| 58 Embedded fieldbus | | | | | |
| 58.01 | Protocol enable | List | - | - | 1 = 1 |
| 58.02 | Protocol ID | Real | 0000h...FFFFh | - | 1 = 1 |
| 58.03 | Node address | Real | 0...255 | - | 1 = 1 |
| 58.04 | Baud rate | List | 2...7 | - | 1 = 1 |
| 58.05 | Parity | List | 0...3 | - | 1 = 1 |
| 58.06 | Communication control | List | 0...2 | - | 1 = 1 |
| 58.07 | Communication diagnostics | PB | 0000h...FFFFh | - | 1 = 1 |
| 58.08 | Received packets | Real | 0...4294967295 | - | 1 = 1 |
| 58.09 | Transmitted packets | Real | 0...4294967295 | - | 1 = 1 |
| 58.10 | All packets | Real | 0...4294967295 | - | 1 = 1 |
| 58.11 | UART errors | Real | 0...4294967295 | - | 1 = 1 |
| 58.12 | CRC errors | Real | 0...4294967295 | - | 1 = 1 |
| 58.14 | Communication loss action | List | 0...5 | - | 1 = 1 |
| 58.15 | Communication loss mode | List | 1...2 | - | 1 = 1 |
| 58.16 | Communication loss time | Real | 0.0 ... 6000.0 | s | 10 = 1 s |
| 58.17 | Transmit delay | Real | 0...65535 | ms | 1 = 1 ms |

394 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|----------------------|------------------------------------|-------------------|----------------------|-----------------|-------------------------|
| 58.18 | EFB control word | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 58.19 | EFB status word | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 58.25 | Control profile | <i>List</i> | 0, 2 | - | 1 = 1 |
| 58.26 | EFB ref1 type | <i>List</i> | 0...5 | - | 1 = 1 |
| 58.27 | EFB ref2 type | <i>List</i> | 0...5 | - | 1 = 1 |
| 58.28 | EFB act1 type | <i>List</i> | 0...6 | - | 1 = 1 |
| 58.29 | EFB act2 type | <i>List</i> | 0...6 | - | 1 = 1 |
| 58.30 | EFB status word transparent source | <i>Analog src</i> | - | - | 1 = 1 |
| 58.31 | EFB act1 transparent source | <i>Analog src</i> | - | - | 1 = 1 |
| 58.32 | EFB act2 transparent source | <i>Analog src</i> | - | - | 1 = 1 |
| 58.33 | Addressing mode | <i>List</i> | 0...2 | - | 1 = 1 |
| 58.34 | Word order | <i>List</i> | 0...1 | - | 1 = 1 |
| 58.101 | Data I/O 1 | <i>Analog src</i> | - | - | 1 = 1 |
| 58.102 | Data I/O 2 | <i>Analog src</i> | - | - | 1 = 1 |
| 58.103 | Data I/O 3 | <i>Analog src</i> | - | - | 1 = 1 |
| 58.104 | Data I/O 4 | <i>Analog src</i> | - | - | 1 = 1 |
| 58.105 | Data I/O 5 | <i>Analog src</i> | - | - | 1 = 1 |
| 58.106 | Data I/O 6 | <i>Analog src</i> | - | - | 1 = 1 |
| 58.107 | Data I/O 7 | <i>Analog src</i> | - | - | 1 = 1 |
| ... | ... | ... | ... | ... | |
| 58.124 | Data I/O 24 | <i>Analog src</i> | - | - | 1 = 1 |
| 74 Pump setup | | | | | |
| 74.01 | Pump enable | <i>Binary src</i> | - | - | 1 = 1 |
| 74.02 | Run-time hours reset source | <i>Binary src</i> | - | - | 1 = 1 |
| 74.03 | Gear reduction ratio | <i>Real</i> | 1.00...1000.00 | - | 1000 = 1 |
| 74.04 | Speed ref type | <i>List</i> | - | - | 1 = 1 |
| 74.05 | Speed ref source | <i>Analog src</i> | - | Prpm, rpm or Hz | 1 = 1 |
| 74.06 | Speed ref | <i>Real</i> | 0.00...30000.00 | Prpm, rpm or Hz | 100 = 1 Prpm, rpm or Hz |
| 74.07 | Minimum rod speed | <i>Real</i> | -10000.00...10000.00 | Prpm, rpm or Hz | 100 = 1 Prpm, rpm or Hz |

| No. | Name | Type | Range | Unit | FbEq32 |
|------------------------------|------------------------------|-----------------------|----------------------|--------------------|----------------------------|
| 74.08 | Maximum rod speed | <i>Real</i> | -10000.00...10000.00 | Prpm, rpm or Hz | 100 = 1 Prpm, rpm or Hz |
| 74.10 | Rod acc time | <i>Real</i> | 0.000...10000.000 | s | 1000 = 1 s |
| 74.11 | Rod dec time | <i>Real</i> | 0.000...10000.000 | s | 1000 = 1 s |
| 74.12 | Starting speed enable | <i>Binary src</i> | - | - | 1 = 1 |
| 74.13 | Starting speed | <i>Real</i> | -10000.00...10000.00 | Prpm, rpm or Hz | 100 = 1 Prpm, rpm or Hz |
| 74.14 | Starting speed acc time | <i>Real</i> | 0.000...10000.000 | s | 1000 = 1 s |
| 74.15 | Starting speed time delay | <i>Real</i> | 0.000...10000.000 | s | 1000 = 1 s |
| 74.18 | Minimum rod torq ref | <i>Real</i> | -10000.00...0.00 | N•m or lbft | 100 = 1 N•m or lbft |
| 74.19 | Maximum rod torq ref | <i>Real</i> | 0.00...10000.00 | N•m or lbft | 100 = 1 N•m or lbft |
| 74.21 | Brake confirmation enable | <i>Binary src</i> | - | - | 1 = 1 |
| 74.22 | Brake confirmation source | <i>Analog src</i> | - | - | 1 = 1 |
| 74.23 | Brake confirmation limit | <i>Real</i> | 0.00...100.00 | % | 100 = 1% |
| 74.24 | Brake confirmation speed | <i>Real</i> | -500.00...0.00 | Prpm, rpm or Hz | 100 = 1 Prpm, rpm or Hz |
| 74.25 | Brake confirmation time | <i>Real</i> | 1.000...30.000 | s | 1000 = 1 s |
| 74.26 | Pressure unit selection | <i>List</i> | - | - | 1 = 1 |
| 74.27 | Depth unit selection | <i>List</i> | - | - | 1 = 1 |
| 75 Pump level control | | | | | |
| 75.01 | Level control enable | - | - | - | 1 = 1 |
| 75.02 | Fluid level ref | <i>Real</i> | 0.00...100000.00 | m, ft or Joints | 100 = 1 m, ft or Joints |
| 75.03 | Fluid level source function | <i>List</i> | 0...5 | m | 1 = 1 |
| 75.04 | Fluid level source 1 | <i>Analog src</i> | - | m | 1 = 1 |
| 75.05 | Fluid level source 2 | <i>Analog src</i> | - | m | 1 = 1 |
| 75.06 | Level meas range | <i>Real</i> | 0.00...100000.00 | m, ft or Joints | 100 = 1 m, ft or Joints |
| 75.07 | Fluid level p-gain | <i>Real</i> | 0.00...5.00 | - | 100 = 1 |
| 75.08 | Fluid level i-time | <i>Real</i> | 1.000...3600.000 | s | 1000 = 1 s |
| 75.09 | Level control invert | - | - | - | 1 = 1 |
| 75.10 | Sleep control enable | <i>Binary src</i> | - | - | 1 = 1 |
| 75.11 | Sleep warning enable | <i>Binary src</i> | - | - | 1 = 1 |
| 75.12 | Sleep limit type | <i>List</i> | - | - | 1 = 1 |
| 75.13 | Sleep signal source function | <i>List</i> | 0...5 | - | 1 = 1 |

396 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|------------------------------------|----------------------------------|------------|---------------------|-----------------|-------------------------|
| 75.14 | Sleep signal source 1 | Analog src | - | - | 1 = 1 |
| 75.15 | Sleep signal source 2 | Analog src | - | - | 1 = 1 |
| 75.16 | Sleep level | Real | 0.00...100000000.00 | % | 100 = 1% |
| 75.17 | Sleep delay time | Real | 0.000...10000.000 | s | 1000 = 1 s |
| 75.18 | Wakeup level | Real | 0.00...100000000.00 | % | 100 = 1% |
| 75.19 | Wakeup delay time | Real | 0.000...10000.000 | s | 1000 = 1 s |
| 75.20 | Maximum sleep time | Real | 0.000...100000.000 | s | 1000 = 1 s |
| 76 Pump pressure protection | | | | | |
| 76.01 | Pressure protection function | List | - | - | 1 = 1 |
| 76.02 | Pressure protection latching | List | 0..2 | - | 1 = 1 |
| 76.03 | Digital feedback source enable | Binary src | - | - | 1 = 1 |
| 76.04 | Digital feedback source | Binary src | - | - | 1 = 1 |
| 76.05 | Analog feedback source enable | Binary src | - | - | 1 = 1 |
| 76.06 | Analog feedback source | Analog src | - | - | 1 = 1 |
| 76.07 | Analog feedback limit | Real | 0.00...10000.00 | kPa or psi | 100 = 1 kPa or psi |
| 76.08 | Analog feedback limit delay time | Real | 0.000...3600.000 | s | 1000 = 1 s |
| 77 Pump torque protection | | | | | |
| 77.01 | Rod torq limit display | List | - | - | 1 = 1 |
| 77.02 | Rod torq1 function | Binary src | - | - | 1 = 1 |
| 77.03 | Rod torq1 limit type | List | - | - | 1 = 1 |
| 77.04 | Rod torq1 limit | Real | 0.00...10000.00 | N•m, lbft or A | 100 = 1 N•m, lbft or A |
| 77.05 | Rod torq1 speed | Real | -3600.00...3600.00 | Prpm, rpm or Hz | 100 = 1 Prpm, rpm or Hz |
| 77.06 | Rod torq1 delay time | Real | 0.000...10000.000 | s | 1000 = 1 s |
| 77.07 | Rod torq2 function | Binary src | - | - | 1 = 1 |
| 77.08 | Rod torq2 limit type | List | - | - | 1 = 1 |
| 77.09 | Rod torq2 limit | Real | 0.00...10000.00 | N•m, lbft or A | 100 = 1 N•m, lbft or A |
| 77.10 | Rod torq2 delay time | Real | 0.000...10000.000 | s | 100 = 1 s |
| 77.11 | Rod torq2 additive speed ref | Real | -3600.00...3600.00 | Prpm, rpm or Hz | 100 = 1 Prpm, rpm or Hz |
| 77.12 | Rod torq2 speed delay time | Real | 0.000...100000.000 | s | 1000 = 1 s |
| 77.13 | Rod torq2 limit counter | Real | 0..100 | - | 1 = 1 |
| 77.14 | Rod torq2 time window | Real | 0.000...72000.000 | s | 1000 = 1 s |

| No. | Name | Type | Range | Unit | FbEq32 |
|---------------------------------------|-----------------------------------|------------|-------------------------|-----------------|-------------------------|
| 78 Pump underload protection | | | | | |
| 78.01 | Underload limit display | List | - | - | 1 = 1 |
| 78.02 | Underload function | Binary src | - | - | 1 = 1 |
| 78.03 | Torque1 | Real | 0.00...10000.00 | T(%) or A(%) | 100 = 1 T(%) or A(%) |
| 78.04 | Speed1 | Real | -3600.00...3600.00 | Prpm, rpm or Hz | 100 = 1 Prpm, rpm or Hz |
| 78.05 | Torque2 | Real | 0.00...10000.00 | T(%) or A(%) | 100 = 1 T(%) or A(%) |
| 78.06 | Speed2 | Real | -3600.00...3600.00 | rpm or Hz | 100 = 1 Prpm, rpm, Hz |
| 78.07 | Torque3 | Real | 0.00...10000.00 | T(%) or A(%) | 100 = 1 T(%) or A(%) |
| 78.08 | Speed3 | Real | -3600.00...3600.00 | Prpm, rpm or Hz | 100 = 1 Prpm, rpm or Hz |
| 78.09 | Underload delay time | Real | 0.000...100000.000 | s | 1000 = 1 s |
| 79 Pump temperature protection | | | | | |
| 79.01 | Temperature protection function | Binary src | - | - | 1 = 1 |
| 79.02 | Temperature protection device | List | 0...2 | - | 1 = 1 |
| 79.03 | Klixon signal source | Binary src | - | - | 1 = 1 |
| 79.04 | PT100 source | Analog src | - | F,C | 1 = 1 |
| 79.05 | PT100 excitation source | Analog src | - | mA | 1 = 1 |
| 79.06 | PT100 internal selection | List | 0.00...20.00 | mA | 100 = 1 mA |
| 79.07 | Number of PT100 sensors in series | List | 1...3 | - | 1 = 1 |
| 79.08 | Warning temperature limit | Real | 0.00...200.00 | °C or °F | 100 = 1 ° |
| 79.09 | Fault temperature limit | Real | 0.00...200.00 | °C or °F | 100 = 1 ° |
| 80 Pump backspin control | | | | | |
| 80.01 | Backspin enable | Binary src | - | - | 1 = 1 |
| 80.02 | Backspin ref limit | Real | -500.00...0.00 | Prpm | 1 = 1 |
| 80.03 | Backspin acc time | Real | 0.000...10000.000 | s | 1 = 1 |
| 80.04 | Backspin stop torque | Real | 0.00...10000.00 | Nm | 1 = 1 |
| 80.05 | Backspin speed range trim | Real | 0.00...100.00 | % | 1 = 1 |
| 80.11 | Start delay enable | Binary src | - | - | 1 = 1 mA |
| 80.12 | Start delay time | Real | 0 ... 4294967.295 | s | 1000 = 1 s |
| 90 Feedback selection | | | | | |
| 90.01 | Motor speed for control | Real | -32768.00...32767.00 | rpm | 100 = 1 rpm |
| 90.02 | Motor position | Real | 0.00000000...1.00000000 | rev | 100000000 = 1 rev |

398 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|-------|------------------------------------|-------------|--------------------------------|------|----------------------|
| 90.03 | Load speed | <i>Real</i> | -32768.00...32767.00 | rpm | 100 = 1 rpm |
| 90.04 | Load position | <i>Real</i> | -2147483648 ...2147483647 | rev | 1 = 1 |
| 90.05 | Load position scaled | <i>Real</i> | -2147483.250 ...2147483.250 | - | 100000 = 1 |
| 90.06 | Motor position scaled | <i>Real</i> | -2147483.648 ...2147483.647 | - | 1000 = 1 |
| 90.07 | Load position scaled int | <i>Real</i> | -2147483648 ... 2147483647 | - | 1 = 1 |
| 90.10 | Encoder 1 speed | <i>Real</i> | -32768.00...32767.00 | rpm | 100 = 1 rpm |
| 90.11 | Encoder 1 position | <i>Real</i> | 0.00000000...1.00000000 | rev | 100000000 = 1 rev |
| 90.12 | Encoder 1 multiturn revolutions | <i>Real</i> | 0...16777215 | - | 1 = 1 |
| 90.13 | Encoder 1 revolution extension | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 90.14 | Encoder 1 position raw | <i>Real</i> | 0...16777215 | - | 1 = 1 |
| 90.15 | Encoder 1 revolutions raw | <i>Real</i> | 0...16777215 | - | 1 = 1 |
| 90.20 | Encoder 2 speed | <i>Real</i> | -32768.00...32767.00 | rpm | 100 = 1 rpm |
| 90.21 | Encoder 2 position | <i>Real</i> | 0.00000000...1.00000000 | rev | 100000000 = 1 rev |
| 90.22 | Encoder 2 multiturn revolutions | <i>Real</i> | 0...16777215 | - | 1 = 1 |
| 90.23 | Encoder 2 revolution extension | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 90.24 | Encoder 2 position raw | <i>Real</i> | 0...16777215 | - | 1 = 1 |
| 90.25 | Encoder 2 revolutions raw | <i>Real</i> | 0...16777215 | - | 1 = 1 |
| 90.26 | Motor revolution extension | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 90.27 | Load revolution extension | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 90.35 | Pos counter status | <i>PB</i> | 000000b...111111b | - | 1 = 1 |
| 90.38 | Pos counter decimals | <i>List</i> | 0...9 | - | 1 = 1 |
| 90.41 | Motor feedback selection | <i>List</i> | 0...2 | - | 1 = 1 |
| 90.42 | Motor speed filter time | <i>Real</i> | 0...10000 | ms | 1 = 1 ms |
| 90.43 | Motor gear numerator | <i>Real</i> | -2147483648... 2147483647 | - | 1 = 1 |
| 90.44 | Motor gear denominator | <i>Real</i> | -2147483648... 2147483647 | - | 1 = 1 |
| 90.45 | Motor feedback fault | <i>List</i> | 0...1 | - | 1 = 1 |
| 90.46 | Force open loop | <i>List</i> | 0...1 | - | 1 = 1 |
| 90.48 | Motor position axis mode | <i>List</i> | 0...1 | - | 1 = 1 |
| 90.49 | Motor position resolution | <i>Real</i> | 0...31 | - | 1 = 1 |
| 90.51 | Load feedback selection | <i>List</i> | 0...4 | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|-----------------------------------|------------------------------------|-------------------|--------------------------------|------|-----------|
| 90.52 | Load speed filter time | <i>Real</i> | 0...10000 | ms | 1 = 1 ms |
| 90.53 | Load gear numerator | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 90.54 | Load gear denominator | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 90.55 | Load feedback fault | <i>List</i> | 0...1 | - | 1 = 1 |
| 90.56 | Load position offset | <i>Real</i> | -2147483648 ... 2147483647 | rev | 1 = 1 rev |
| 90.57 | Load position resolution | <i>Real</i> | 0...31 | - | 1 = 1 |
| 90.58 | Pos counter init value int | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 90.59 | Pos counter init value int source | <i>Binary src</i> | - | - | 1 = 1 |
| 90.61 | Gear numerator | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 90.62 | Gear denominator | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 90.63 | Feed constant numerator | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 90.64 | Feed constant denominator | <i>Real</i> | -2147483648 ...2147483647 | - | 1 = 1 |
| 90.65 | Pos counter init value | <i>Real</i> | -2147483.648 ...2147483.647 | - | 1 = 1 |
| 90.66 | Pos counter init value source | <i>Binary src</i> | - | - | 1 = 1 |
| 90.67 | Pos counter init cmd source | <i>Binary src</i> | - | - | 1 = 1 |
| 90.68 | Disable pos counter initialization | <i>Binary src</i> | - | - | 1 = 1 |
| 90.69 | Reset pos counter init ready | <i>Binary src</i> | - | - | 1 = 1 |
| 91 Encoder module settings | | | | | |
| 91.01 | FEN DI status | <i>PB</i> | 0000 0000b ...0011 0011b | - | 1 = 1 |
| 91.02 | Module 1 status | <i>List</i> | - | - | 1 = 1 |
| 91.03 | Module 2 status | <i>List</i> | - | - | 1 = 1 |
| 91.04 | Module 1 temperature | <i>Real</i> | 0...1000 | °C | 1 = 1 °C |
| 91.06 | Module 2 temperature | <i>Real</i> | 0...1000 | °C | 1 = 1 °C |
| 91.10 | Encoder parameter refresh | <i>List</i> | 0...1 | - | 1 = 1 |
| 91.11 | Module 1 type | <i>List</i> | 0...4 | - | 1 = 1 |
| 91.12 | Module 1 location | <i>Real</i> | 4...254 | - | 1 = 1 |
| 91.13 | Module 2 type | <i>List</i> | 0...4 | - | 1 = 1 |
| 91.14 | Module 2 location | <i>Real</i> | 4...254 | - | 1 = 1 |
| 91.21 | Module 1 temp sensor type | <i>List</i> | 0...2 | - | 1 = 1 |
| 91.22 | Module 1 temp filter time | <i>Real</i> | 0...10000 | ms | 1 = 1 ms |
| 91.24 | Module 2 temp sensor type | <i>List</i> | 0...2 | - | 1 = 1 |

400 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|--|----------------------------------|-------------|---------------------|------|----------------|
| 91.25 | Module 2 temp filter time | <i>Real</i> | 0...10000 | ms | 1 = 1 ms |
| 91.31 | Module 1 TTL output source | <i>List</i> | 0...2 | - | 1 = 1 |
| 91.32 | Module 1 emulation pulses/rev | <i>Real</i> | 0...65535 | - | 1 = 1 |
| 91.33 | Module 1 emulated Z-pulse offset | <i>Real</i> | 0.00000 ... 1.00000 | rev | 100000 = 1 rev |
| 91.41 | Module 2 TTL output source | <i>List</i> | 0...2 | - | 1 = 1 |
| 91.42 | Module 2 emulation pulses/rev | <i>Real</i> | 0...65535 | - | 1 = 1 |
| 91.43 | Module 2 emulated Z-pulse offset | <i>Real</i> | 0.00000 ... 1.00000 | rev | 100000 = 1 rev |
| 92 Encoder 1 configuration | | | | | |
| 92.01 | Encoder 1 type | <i>List</i> | 0.9 | - | 1 = 1 |
| 92.02 | Encoder 1 source | <i>List</i> | 1...2 | - | 1 = 1 |
| Other parameters in this group when parameter <i>92.01 Encoder 1 type</i> = <i>TTL</i> , <i>TTL+</i> or <i>HTL</i> | | | | | |
| 92.10 | Pulses/revolution | <i>Real</i> | 0...65535 | - | 1 = 1 |
| 92.11 | Pulse encoder type | <i>List</i> | 0...1 | - | 1 = 1 |
| 92.12 | Speed calculation mode | <i>List</i> | 0...5 | - | 1 = 1 |
| 92.13 | Position estimation enable | <i>List</i> | 0...1 | - | 1 = 1 |
| 92.14 | Speed estimation enable | <i>List</i> | 0...1 | - | 1 = 1 |
| 92.15 | Transient filter | <i>List</i> | 0...3 | - | 1 = 1 |
| 92.16 | Encoder 1 supply voltage | <i>List</i> | 0...2 | - | 1 = 1 |
| 92.17 | Accepted pulse freq of encoder 1 | <i>Real</i> | 0...300 | kHz | 1 = 1 kHz |
| 92.21 | Encoder cable fault mode | <i>List</i> | 0...3 | - | 1 = 1 |
| Other parameters in this group when parameter <i>92.01 Encoder 1 type</i> = <i>Absolute encoder</i> | | | | | |
| 92.10 | Sine/cosine number | <i>Real</i> | 0...65535 | - | 1 = 1 |
| 92.11 | Absolute position source | <i>List</i> | 0...5 | - | 1 = 1 |
| 92.12 | Zero pulse enable | <i>List</i> | 0...1 | - | 1 = 1 |
| 92.13 | Position data width | <i>Real</i> | 0...32 | - | 1 = 1 |
| 92.14 | Revolution data width | <i>Real</i> | 0...32 | - | 1 = 1 |
| 92.30 | Serial link mode | <i>List</i> | 0...2 | - | 1 = 1 |
| 92.31 | EnDat max calculation time | <i>List</i> | 0...3 | - | 1 = 1 |
| 92.32 | SSI cycle time | <i>List</i> | 0...5 | - | 1 = 1 |
| 92.33 | SSI clock cycles | <i>Real</i> | 2...127 | - | 1 = 1 |
| 92.34 | SSI position msb | <i>Real</i> | 1...126 | - | 1 = 1 |
| 92.35 | SSI revolution msb | <i>Real</i> | 1...126 | - | 1 = 1 |
| 92.36 | SSI data format | <i>List</i> | 0...1 | - | 1 = 1 |
| 92.37 | SSI baud rate | <i>List</i> | 0...5 | - | 1 = 1 |
| 92.40 | SSI zero phase | <i>List</i> | 0...3 | - | 1 = 1 |
| 92.45 | Hiperface parity | <i>List</i> | 0...1 | - | 1 = 1 |
| 92.46 | Hiperface baud rate | <i>List</i> | 0...3 | - | 1 = 1 |
| 92.47 | Hiperface node address | <i>Real</i> | 0...255 | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|--|----------------------------------|-------------|------------|------|-----------|
| Other parameters in this group when parameter <i>92.01 Encoder 1 type = Resolver</i> | | | | | |
| 92.10 | Excitation signal frequency | <i>Real</i> | 1...20 | kHz | 1 = 1 kHz |
| 92.11 | Excitation signal amplitude | <i>Real</i> | 4.0...12.0 | V | 10 = 1 V |
| 92.12 | Resolver polepairs | <i>List</i> | 1...32 | - | 1 = 1 |
| 93 Encoder 2 configuration | | | | | |
| 93.01 | Encoder 2 type | <i>List</i> | 0.9 | - | 1 = 1 |
| 93.02 | Encoder 2 source | <i>List</i> | 1...2 | - | 1 = 1 |
| Other parameters in this group when parameter <i>93.01 Encoder 2 type = TTL, TTL+ or HTL</i> | | | | | |
| 93.10 | Pulses/revolution | <i>Real</i> | 0...65535 | - | 1 = 1 |
| 93.11 | Pulse encoder type | <i>List</i> | 0...1 | - | 1 = 1 |
| 93.12 | Speed calculation mode | <i>List</i> | 0...5 | - | 1 = 1 |
| 93.13 | Position estimation enable | <i>List</i> | 0...1 | - | 1 = 1 |
| 93.14 | Speed estimation enable | <i>List</i> | 0...1 | - | 1 = 1 |
| 93.15 | Transient filter | <i>List</i> | 0...3 | - | 1 = 1 |
| 93.16 | Encoder 2 supply voltage | <i>List</i> | 0...2 | - | 1 = 1 |
| 93.17 | Accepted pulse freq of encoder 2 | <i>Real</i> | 0...300 | kHz | 1 = 1 kHz |
| 93.21 | Encoder cable fault mode | <i>List</i> | 0...3 | - | 1 = 1 |
| Other parameters in this group when parameter <i>93.01 Encoder 2 type = Abs enc</i> | | | | | |
| 93.10 | Sine/cosine number | <i>Real</i> | 0...65535 | - | 1 = 1 |
| 93.11 | Absolute position source | <i>List</i> | 0...5 | - | 1 = 1 |
| 93.12 | Zero pulse enable | <i>List</i> | 0...1 | - | 1 = 1 |
| 93.13 | Position data width | <i>Real</i> | 0...32 | - | 1 = 1 |
| 93.14 | Revolution data width | <i>Real</i> | 0...32 | - | 1 = 1 |
| 93.30 | Serial link mode | <i>List</i> | 0...2 | - | 1 = 1 |
| 93.31 | EnDat calc time | <i>List</i> | 0...3 | - | 1 = 1 |
| 93.32 | SSI cycle time | <i>List</i> | 0...5 | - | 1 = 1 |
| 93.33 | SSI clock cycles | <i>Real</i> | 2...127 | - | 1 = 1 |
| 93.34 | SSI position msb | <i>Real</i> | 1...126 | - | 1 = 1 |
| 93.35 | SSI revolution msb | <i>Real</i> | 1...126 | - | 1 = 1 |
| 93.36 | SSI data format | <i>List</i> | 0...1 | - | 1 = 1 |
| 93.37 | SSI baud rate | <i>List</i> | 0...5 | - | 1 = 1 |
| 93.40 | SSI zero phase | <i>List</i> | 0...3 | - | 1 = 1 |
| 93.45 | Hiperface parity | <i>List</i> | 0...1 | - | 1 = 1 |
| 93.46 | Hiperface baud rate | <i>List</i> | 0...3 | - | 1 = 1 |
| 93.47 | Hiperface node address | <i>Real</i> | 0...255 | - | 1 = 1 |
| Other parameters in this group when parameter <i>93.01 Encoder 2 type = Resolver</i> | | | | | |
| 93.10 | Excitation signal frequency | <i>Real</i> | 1...20 | kHz | 1 = 1 kHz |
| 93.11 | Excitation signal amplitude | <i>Real</i> | 4.0...12.0 | V | 10 = 1 V |
| 93.12 | Resolver polepairs | <i>List</i> | 1...32 | - | 1 = 1 |

402 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|----------------------------|------------------------------|-------------------|-------------------------|------|----------|
| 95 HW configuration | | | | | |
| 95.01 | Supply voltage | <i>List</i> | 0...6 | - | 1 = 1 |
| 95.02 | Adaptive voltage limits | <i>List</i> | 0...1 | - | 1 = 1 |
| 95.04 | Control board supply | <i>List</i> | 0...2 | - | 1 = 1 |
| 95.08 | DC switch monitoring | <i>List</i> | 0...1 | - | 1 = 1 |
| 95.09 | Fuse switch control | <i>List</i> | 0...1 | - | 1 = 1 |
| 95.15 | Special HW settings | <i>PB</i> | 0000b...0111b | - | 1 = 1 |
| 95.20 | HW options word 1 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 95.21 | HW options word 2 | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 96 System | | | | | |
| 96.01 | Language | <i>List</i> | - | - | 1 = 1 |
| 96.02 | Pass code | <i>Data</i> | 0...99999999 | - | 1 = 1 |
| 96.03 | Access levels active | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 96.04 | Macro select | <i>List</i> | 0...6 | - | 1 = 1 |
| 96.05 | Macro active | <i>List</i> | 1...6 | - | 1 = 1 |
| 96.06 | Parameter restore | <i>List</i> | - | - | 1 = 1 |
| 96.07 | Parameter save manually | <i>List</i> | 0...1 | - | 1 = 1 |
| 96.08 | Control board boot | <i>Real</i> | 0...1 | - | 1 = 1 |
| 96.09 | FSO reboot | <i>Binary src</i> | - | - | - |
| 96.10 | User set status | <i>List</i> | - | - | - |
| 96.11 | User set save/load | <i>List</i> | - | - | - |
| 96.12 | User set IO sel in1 | <i>Binary src</i> | - | - | - |
| 96.13 | User set IO sel in2 | <i>Binary src</i> | - | - | - |
| 96.16 | Unit selection | <i>PB</i> | 0000 0000b...0001 0101b | - | 1 = 1 |
| 96.20 | Time sync primary source | <i>List</i> | 0...9 | - | 1 = 1 |
| 96.24 | Full days since 1st Jan 1980 | <i>Real</i> | 1...59999 | - | 1 = 1 |
| 96.25 | Time in minutes within 24 h | <i>Real</i> | 0...1439 | - | 1 = 1 |
| 96.26 | Time in ms within one minute | <i>Real</i> | 0...59999 | - | 1 = 1 |
| 96.29 | Time sync source status | <i>PB</i> | 0000h...FFFFh | - | 1 = 1 |
| 96.31 | Drive ID number | <i>Real</i> | 0...32767 | - | 1 = 1 |
| 97 Motor control | | | | | |
| 97.03 | Slip gain | <i>Real</i> | 0...200 | % | 1 = 1% |
| 97.04 | Voltage reserve | <i>Real</i> | -4...50 | % | 1 = 1% |
| 97.05 | Flux braking | <i>List</i> | 0...2 | - | 1 = 1 |
| 97.06 | Flux reference select | <i>Binary src</i> | - | - | 1 = 1 |
| 97.07 | User flux reference | <i>Real</i> | 0...200 | % | 100 = 1% |
| 97.09 | Switching freq mode | <i>List</i> | 0...3 | - | 1 = 1 |
| 97.10 | Signal injection | <i>List</i> | 0...4 | - | 1 = 1 |

| No. | Name | Type | Range | Unit | FbEq32 |
|---------------------------------|------------------------------------|-------------|---|-----------------|-------------------|
| 97.11 | TR tuning | <i>Real</i> | 25...400 | % | 1 = 1% |
| 97.12 | IR comp step-up frequency | <i>Real</i> | 0.0...50.0 | Hz | 10 = 1 Hz |
| 97.13 | IR compensation | <i>Real</i> | 0.00...50.00 | % | 100 = 1% |
| 97.15 | Motor model temperature adaptation | <i>List</i> | 0...1 | - | 1 = 1 |
| 97.32 | Motor torque unfiltered | <i>Real</i> | -1600.0...1600.0 | % | 10 = 1% |
| 97.33 | Speed estimate filter time | <i>Real</i> | 0.00...100.00 | ms | 100 = 1 ms |
| 98 User motor parameters | | | | | |
| 98.01 | User motor model mode | <i>List</i> | 0...3 | - | 1 = 1 |
| 98.02 | Rs user | <i>Real</i> | 0.0000...0.50000 | p.u. | 100000 = 1 p.u. |
| 98.03 | Rr user | <i>Real</i> | 0.0000...0.50000 | p.u. | 100000 = 1 p.u. |
| 98.04 | Lm user | <i>Real</i> | 0.00000...10.00000 | p.u. | 100000 = 1 p.u. |
| 98.05 | SigmaL user | <i>Real</i> | 0.00000...1.00000 | p.u. | 100000 = 1 p.u. |
| 98.06 | Ld user | <i>Real</i> | 0.00000...10.00000 | p.u. | 100000 = 1 p.u. |
| 98.07 | Lq user | <i>Real</i> | 0.00000...10.00000 | p.u. | 100000 = 1 p.u. |
| 98.08 | PM flux user | <i>Real</i> | 0.00000...2.00000 | p.u. | 100000 = 1 p.u. |
| 98.09 | Rs user SI | <i>Real</i> | 0.00000...100.00000 | ohm | 100000 = 1 p.u. |
| 98.10 | Rr user SI | <i>Real</i> | 0.00000...100.00000 | ohm | 100000 = 1 p.u. |
| 98.11 | Lm user SI | <i>Real</i> | 0.00...100000.01 | mH | 100 = 1 mH |
| 98.12 | SigmaL user SI | <i>Real</i> | 0.00...100000.01 | mH | 100 = 1 mH |
| 98.13 | Ld user SI | <i>Real</i> | 0.00...100000.01 | mH | 100 = 1 mH |
| 98.14 | Lq user SI | <i>Real</i> | 0.00...100000.01 | mH | 100 = 1 mH |
| 98.15 | Position offset user | <i>Real</i> | 0...360 | ° electrical | 1 = 1° electrical |
| 99 Motor data | | | | | |
| 99.03 | Motor type | <i>List</i> | 0...1 | - | 1 = 1 |
| 99.04 | Motor ctrl mode | <i>List</i> | 0...1 | - | 1 = 1 |
| 99.06 | Motor nominal current | <i>Real</i> | 0.0...6400.0 | A | 10 = 1 A |
| 99.07 | Motor nominal voltage | <i>Real</i> | 0.0...800.0 | V | 10 = 1 V |
| 99.08 | Motor nominal frequency | <i>Real</i> | 0.00...500.00 | Hz | 10 = 1 Hz |
| 99.09 | Motor nominal speed | <i>Real</i> | 0...30000 | rpm | 1 = 1 rpm |
| 99.10 | Motor nominal power | <i>Real</i> | 0.00...10000.00 kW or 0.00...13404.83 hp | kW or hp | 100 = 1 unit |
| 99.11 | Motor nominal cos Φ | <i>Real</i> | 0.00...1.00 | - | 100 = 1 |
| 99.12 | Motor nominal torque | <i>Real</i> | 0.000...4000000.000 | N·m or lb.ft | 1000 = 1 unit |

404 Additional parameter data

| No. | Name | Type | Range | Unit | FbEq32 |
|-------|----------------------------|-------------|----------|------|--------|
| 99.13 | ID run requested | <i>List</i> | 0...7 | - | 1 = 1 |
| 99.14 | Last ID run performed | <i>List</i> | 0...7 | - | 1 = 1 |
| 99.15 | Motor polepairs calculated | <i>Real</i> | 0...1000 | - | 1 = 1 |
| 99.16 | Motor phase order | <i>List</i> | 0...1 | - | 1 = 1 |

200 Safety

This group contains parameters related to the optional FSO-xx safety functions module. For details on the parameters in this group, refer to the documentation of the FSO-xx module.



Fault tracing

Contents of this chapter

The chapter lists the warning and fault messages including possible causes and corrective actions. The causes of most warnings and faults can be identified and corrected using the information in this chapter. If not, an ABB service representative should be contacted.

Warnings and faults are listed below in separate tables. Each table is sorted by warning/fault code.

Safety



WARNING! Only qualified electricians are allowed to service the drive. Read the *Safety instructions* on the first pages of the Hardware manual before working on the drive.

Indications

Warnings and faults indicate an abnormal drive status. The codes and names of active warnings/faults are displayed on the control panel of the drive as well as the Drive composer PC tool. Only the codes of warnings/faults are available over fieldbus.

In addition to warnings and faults, there are pure events that are only recorded in the event log of the drive. The codes of these events are included in the [Warning messages](#) table.

For some warnings and faults, the message text are edited and instructions and contact information added. To edit these messages, choose **Settings - Edit texts** on the control panel.

How to reset faults

After the cause of a fault has been corrected, the fault can be reset from a selectable source (see parameter [31.11 Fault reset selection](#)) such as the control panel, Drive composer PC tool, the digital inputs of the drive, or fieldbus. After the fault is removed, the drive can be restarted.

Warning/fault history

■ Event logs

When a warning or fault is detected, it is stored in the event log with a time stamp and other information. The event log can be accessed from the main Menu on the control panel. It can also be accessed (and reset) using the Drive composer PC tool.

One of the logs contains faults and fault resets. The other log lists warnings and pure events, as well as clearing entries. Both logs contain 32 most recent events.

Auxiliary codes

Some events generate an auxiliary code that often helps in pinpointing the problem. The auxiliary code is displayed on the control panel together with the message. It is also stored in the event log details. In the Drive composer PC tool, the auxiliary code (if any) is shown in the event listing.

■ Parameters warning/fault information

The codes of active warnings and faults (maximum five each), and five previously occurred warnings and faults are stored in the parameters of group [04 Warnings and faults](#) (page [109](#)).

Event word (parameters [04.40...04.72](#))

Parameter [04.40 Event word 1](#) can be configured by the user to indicate the status of 16 selectable events (ie. faults, warnings or pure events). It is possible to specify an auxiliary code for each event to filter out other auxiliary codes.

QR code generation for mobile service application

A QR code (or a series of QR codes) can be generated by the drive for display on the control panel. The QR code contains drive identification data, information on the latest events, and values of status and counter parameters. The code can be read with a mobile device containing the ABB service application, which then sends the data to ABB for analysis. For more information on the application, contact your local ABB service representative.

The QR code can be generated by choosing **Menu - Assistants - QR code** on the control panel.

Warning messages

Note: The list also contains events that only appear in the Event log.

| Code (hex) | Warning | Cause | What to do |
|------------|----------------------|--|---|
| A2A1 | Current calibration | Current measurement calibration will occur at next start. | Informative warning. |
| A2B1 | Overcurrent | Output current has exceeded internal fault limit. | <p>Check motor load.</p> <p>Check acceleration times in parameter group 23 Speed reference ramp (speed control) or 28 Frequency reference chain (frequency control). Also check parameters 46.01 Speed scaling, 46.02 Frequency scaling and 46.03 Torque scaling.</p> <p>Check motor and motor cable (including phasing and delta/star connection).</p> <p>Check that the start-up data in parameter group 99 corresponds to the motor rating plate.</p> <p>Check that there are no power factor correction capacitors or surge absorbers in motor cable.</p> <p>Check encoder cable (including phasing).</p> |
| A2B3 | Earth leakage | Drive has detected load unbalance typically due to earth fault in motor or motor cable. | <p>Check there are no power factor correction capacitors or surge absorbers in motor cable.</p> <p>Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable.</p> <p>If no earth fault can be detected, contact your local ABB representative.</p> |
| A2B4 | Short circuit | Short-circuit in motor cable(s) or motor. | <p>Check motor and motor cable.</p> <p>Check there are no power factor correction capacitors or surge absorbers in motor cable.</p> |
| A2BA | IGBT overload | Excessive IGBT junction to case temperature. This warning protects the IGBT(s) and can be activated by a short circuit in the motor cable. | Check motor cable. |
| A3A1 | DC link overvoltage | Intermediate circuit DC voltage too high (when the drive is stopped). | <p>Check the supply voltage setting (parameter 95.01 Supply voltage). Note that the wrong setting of the parameter may cause the motor to rush uncontrollably, or the overloading of the brake chopper or resistor.</p> <p>Check the supply voltage.</p> |
| A3A2 | DC link undervoltage | Intermediate circuit DC voltage too low (when the drive is stopped). | Check the supply voltage. |
| A3AA | DC not charged | The voltage of the intermediate DC circuit has not yet risen to operating level. | If the problem persists, contact your local ABB representative. |

| Code (hex) | Warning | Cause | What to do |
|------------|--|---|---|
| A3C1 | DC voltage difference | Difference in DC voltages between parallel-connected inverter modules. | Contact your local ABB representative. |
| A480 | Motor cable overload | Calculated motor cable temperature has exceeded warning limit. | Check the settings of parameters 35.61 and 35.62 . Check the dimensioning of the motor cable in regard to required load. |
| A490 | Incorrect temperature sensor setup | Sensor type mismatch or | Check the settings of supervision source parameters 35.11 and 35.21 against 91.21 and 91.24 . Check the wiring of the sensor. The auxiliary code identifies the interface module. (0 = Module 1, 1 = Module 2). |
| | | Faulty wiring between an encoder interface module and the temperature sensor. | |
| A491 | External temperature (Editable message text) | Measured temperature 1 or 2 has exceeded warning limit. | Check the values of parameters 35.02 Measured temperature 1 and 35.03 Measured temperature 2 . Check the cooling of the motor (or other equipment whose temperature is being measured). Check the warning limits for measured temperatures 1 and 2 in parameter group 35 Motor thermal protection . |
| A492 | External temperature 2 (Editable message text) | Measured temperature 2 has exceeded warning limit. | Check the value of parameter 35.03 Measured temperature 2 . Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of 35.23 Temperature 2 warning limit . |
| A4A0 | Control board temperature | Control unit temperature is excessive. | Check the auxiliary code. See actions for each code below. |
| | (none) | Temperature above warning limit | Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. |
| | | 1 Thermistor broken | Contact an ABB service representative for control unit replacement. |
| A4A1 | IGBT overtemperature | Estimated drive IGBT temperature is excessive. | Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power. |
| A4A9 | Cooling | Drive module temperature is excessive. | Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity of drive. See appropriate <i>Hardware Manual</i> . Check drive module cooling air flow and fan operation. Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary. |

| Code (hex) | Warning | Cause | What to do |
|------------|---|--|--|
| A4B0 | Excess temperature | Power unit module temperature is excessive. | Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power. |
| A4B1 | Excess temperature difference | High temperature difference between the IGBTs of different phases. | Check the motor cabling. Check cooling of drive module(s). |
| A4B2 | PCB space cooling | Temperature difference between ambient and drive module PCB space is excessive. | Check the cooling fan inside the PCB space. Check the auxiliary code. |
| A4F6 | IGBT temperature | Drive IGBT temperature is excessive. | Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power. |
| A580 | PU communication | Communication errors detected between the drive control unit and the power unit. | Check the connections between the drive control unit and the power unit. |
| A581 | Fan | Cooling fan stuck or disconnected. | Check fan operation and connection. Replace fan if faulty. |
| A582 | Auxiliary fan missing | An auxiliary cooling fan (connected to the fan connectors on the control unit) is stuck or disconnected. | Check auxiliary fan(s) and connection(s). Replace faulty fan. Make sure the front cover of the drive module is in place and tightened. If the commissioning of the drive requires that the cover is off, this warning will be generated even if the corresponding fault is defeated. See fault 5081 Auxiliary fan broken (page 424). |
| A5A0 | Safe torque off Programmable warning: 31.22 STO indication run/stop | Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is lost. | Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop (page 245). |
| A5EA | Measurement circuit temperature | Problem with internal temperature measurement of the drive. | Check the auxiliary code. |
| A5EB | PU board powerfail | Power unit power supply failure. | Contact your local ABB representative. |
| A5EC | PU communication internal | Communication errors detected between the drive control unit and the power unit. | Check the connections between the drive control unit and the power unit. |
| A5ED | Measurement circuit ADC | Measurement circuit fault. | Contact your local ABB representative. |
| A5EE | Measurement circuit DFF | Measurement circuit fault. | Contact your local ABB representative. |

| Code (hex) | Warning | Cause | What to do |
|------------|-----------------------------|---|--|
| A5EF | PU state feedback | State feedback from output phases does not match control signals. | Contact your local ABB representative. |
| A5F0 | Charging feedback | Charging feedback signal missing. | Check the feedback signal coming from the charging system. |
| A683 | Data saving to power unit | An error in saving data to the power unit. | Check the auxiliary code. See actions for each code below. |
| | | 0 An error is preventing saving from initializing. | Cycle the power to the drive. If the control unit is externally powered, also reboot the control unit (using parameter 96.08 Control board boot) or by cycling its power. If the problem persists, contact your local ABB representative. |
| | | 1 | |
| | | 2 Write error. | |
| A684 | SD card | Error related to SD card used to store data (BCU control unit only). | Check the auxiliary code. See actions for each code below. |
| | | 1 No SD card | Insert a compatible, writable SD card into the SD CARD slot of the BCU control unit. |
| | | 2 SD card write-protected | |
| | | 3 SD card unreadable | |
| A685 | Power fail saving | Power fail saving is requested too frequently due to oscillating power supply to the control unit. Some of the requests may have been discarded, potentially causing data loss. | Check the power supply of the control unit. If powered internally from the drive, check the supply voltage of the drive. |
| A6A4 | Motor nominal value | The motor parameters are set incorrectly. | Check the settings of the motor configuration parameters in group 99. |
| | | The drive is not dimensioned correctly. | Check that the drive is sized correctly for the motor. |
| A6A5 | No motor data | Parameters in group 99 have not been set. | Check that all the required parameters in group 99 have been set. Note: It is normal for this warning to appear during the start-up until the motor data is entered. |
| A6A6 | Voltage category unselected | The supply voltage range has not been defined. | Define supply voltage range (parameter 95.01 Supply voltage). |
| A6D1 | FBA A parameter conflict | The drive does not have a functionality requested by PLC, or requested functionality has not been activated. | Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 51 FBA A settings . |
| A6D2 | FBA B parameter conflict | The drive does not have a functionality requested by a PLC, or requested functionality has not been activated. | Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 54 FBA B settings . |

412 Fault tracing

| Code (hex) | Warning | Cause | What to do |
|------------|---|---|---|
| A6E5 | AI parametrization | The current/voltage jumper setting of an analog input does not correspond to parameter settings. | Check the auxiliary code. The code identifies the analog input whose settings are in conflict. Adjust either the jumper setting (on the drive control unit) or parameter 12.15/12.25 . Note: Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the jumper settings. |
| A780 | Motor stall Programmable warning: 35.106 Stall function | Motor is operating in stall region because of e.g. excessive load or insufficient motor power. | Check motor load and drive ratings. Check fault function parameters. |
| A781 | Motor fan Programmable warning: 35.106 DOL starter event type | No feedback received from external fan. | Check external fan (or other equipment controlled) by the logic. Check settings of parameters 35.100...35.106 . |
| A782 | FEN temperature | Error in temperature measurement when temperature sensor (KTY or PTC) connected to encoder interface FEN-xx is used. | Check that parameter 35.11 Temperature 1 source / 35.21 Temperature 2 source setting corresponds to actual encoder interface installation. |
| | | Error in temperature measurement when KTY sensor connected to encoder interface FEN-01 is used. | FEN-01 does not support temperature measurement with KTY sensor. Use PTC sensor or other encoder interface module. |
| A791 | Brake resistor | Brake resistor broken or not connected. | Check that a brake resistor has been connected. Check the condition of the brake resistor. |
| A793 | BR excess temperature | Brake resistor temperature has exceeded warning limit defined by parameter 43.12 Brake resistor warning limit . | Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check warning limit setting, parameter 43.12 Brake resistor warning limit . Check that braking cycle meets allowed limits. |
| A794 | BR data | Brake resistor data has not been given. | Check the resistor data settings (parameters 43.08...43.10). The parameter is specified by the auxiliary code. |
| | 0000 0001 | Resistance value too low. | Check value of 43.10 . |
| | 0000 0002 | Thermal time constant not given. | Check value of 43.08 . |
| | 0000 0003 | Maximum continuous power not given. | Check value of 43.09 . |

| Code (hex) | Warning | Cause | What to do |
|------------|------------------------------|--|--|
| A797 | Speed feedback configuration | Speed feedback configuration has changed. | Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings. |
| | | 0001 Adapter not found in specified slot. | Check module location (91.12 or 91.14). |
| | | 0002 Detected type of interface module does not match parameter setting. | Check the module type (91.11 or 91.13) against status (91.02 or 91.03). |
| | | 0003 Logic version too old. | Contact your local ABB representative. |
| | | 0004 Software version too old. | Contact your local ABB representative. |
| | | 0006 Encoder type incompatible with interface module type. | Check module type (91.11 or 91.13) against encoder type (92.01 or 93.01). |
| | | 0007 Adapter not configured. | Check module location (91.12 or 91.14). |
| | | 0008 Speed feedback configuration has changed. | Use parameter 91.10 Encoder parameter refresh) to validate any changes in the settings. |
| | | 0009 No encoders configured to encoder module | Configure the encoder in group 92 Encoder 1 configuration or 93 Encoder 2 configuration . |
| | | 000A Non-existing emulation input. | Check input selection (91.31 or 91.41). |
| | | 000B Echo not supported by selected input (for example, resolver or absolute encoder). | Check input selection (91.31 or 91.41), interface module type, and encoder type. |
| | | 000C Emulation in continuous mode not supported. | Check input selection (91.31 or 91.41) and serial link mode (92.30 or 93.30) settings. |
| A79B | BC short circuit | Short circuit in brake chopper IGBT | Replace brake chopper. Ensure brake resistor is connected and not damaged. |
| A79C | BC IGBT excess temperature | Brake chopper IGBT temperature has exceeded internal warning limit. | Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet. Check resistor overload protection function settings (parameters 43.06...43.10). Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive. |

| Code (hex) | Warning | Cause | What to do |
|------------|---|--|--|
| A7AA | FIO-11 AI parametrization | The hardware current/voltage setting of an analog input (on an FIO-11 I/O extension module) does not correspond to parameter settings. | Adjust either the setting on the FIO-11 module or parameter 14.30/15.30/16.30 . (The hardware switch settings detected by the control program are shown in parameters 14.29 , 15.29 and 16.29 .) Note: Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the jumper settings. |
| A7AB | Extension I/O configuration failure | The I/O extension module types and locations specified by parameters do not match the detected configuration. | Check the auxiliary code. The code indicates which I/O extension module is affected. Check the type and location settings of the modules (parameters 14.01 , 14.02 , 15.01 , 15.02 , 16.01 and 16.02). Check that the modules are properly installed. |
| A7B0 | Motor speed feedback Programmable warning: 90.45 Motor feedback fault | No motor speed feedback is received. | Check the auxiliary code (format XYY ZZZZ). "XX" specifies the number of the encoder interface module (01 : 91.11/91.12 , 02 : 91.13/91.14), "YY" specifies the encoder (01 : 92 Encoder 1 configuration , 02 : 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below). |
| | | 0001 Motor gear definition invalid or outside limits. | Check motor gear settings (90.43 and 90.44). |
| | | 0002 Encoder not configured. | Check encoder settings (92 Encoder 1 configuration or 93 Encoder 2 configuration). Use parameter 91.10 Encoder parameter refresh to validate any changes in the settings. |
| | | 0003 Encoder stopped working. | Check encoder status. |
| | | 0004 Encoder drift detected. | Check for slippage between encoder and motor. |
| A7B1 | Load speed feedback Programmable warning: 90.55 Load feedback fault | No load speed feedback is received. | Check the auxiliary code (format XYY ZZZZ). "XX" specifies the number of the encoder interface module (01 : 91.11/91.12 , 02 : 91.13/91.14), "YY" specifies the encoder (01 : 92 Encoder 1 configuration , 02 : 93 Encoder 2 configuration). "ZZZZ" indicates the problem (see actions for each code below). |
| | | 0001 Load gear definition invalid or outside limits. | Check load gear settings (90.53 and 90.54). |
| | | 0002 Feed constant definition invalid or outside limits. | Check feed constant settings (90.63 and 90.64). |
| | | 0003 Encoder stopped working. | Check encoder status. |

| Code (hex) | Warning | Cause | What to do |
|------------|--|--|---|
| A7C1 | FBA A communication Programmable warning: 50.02 FBA A comm loss func | Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost. | Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 Fieldbus adapter (FBA) , 51 FBA A settings , 52 FBA A data in and 53 FBA A data out . Check cable connections. Check if communication master is able to communicate. |
| A7C2 | FBA B communication Programmable warning: 50.32 FBA B comm loss func | Cyclical communication between drive and fieldbus adapter module B or between PLC and fieldbus adapter module B is lost. | Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter group 50 Fieldbus adapter (FBA) . Check cable connections. Check if communication master is able to communicate. |
| A7CE | EFB comm loss Programmable warning: 58.14 Communication loss action | Communication break in embedded fieldbus (EFB) communication. | Check the status of the fieldbus master (online/offline/error etc.). Check cable connections to the XD2D connector on the control unit. |
| A7E1 | Encoder Programmable warning: 90.45 Motor feedback fault | Encoder 1 error. | Check that the parameter settings in groups 92 Encoder 1 configuration are correct. Note: New settings will only take effect after parameter 91.10 Encoder parameter refresh is used or after the drive control unit is powered up the next time. Check the auxiliary code. See appropriate actions for each code below. |
| | Aux code: 1020 | Overspeed | Contact your local ABB representative. |
| | Aux code: 1021 | Pulse overfrequency | |
| | Aux code: 1022 | Cable fault | Check the wiring of the encoder. See also parameter 92.21 Encoder cable fault mode . |
| | Aux code: 1023 | Resolver ID run fault | Contact your local ABB representative. |
| | Aux code: 1024 | Encoder fault | Refer to encoder documentation. |
| | Aux code: 1025 | Encoder warning | |
| | Aux code: 1026 | Unsupported cable fault detection mode. | Try a different setting in 92.21 Encoder cable fault mode . |
| | Aux code: 1027 | Resolver SW version | Contact your local ABB representative. |
| | Aux code: 1028 | Resolver speed scale | |

| Code (hex) | Warning | Cause | What to do |
|------------|---|---|---|
| A7E2 | Encoder 2 | Encoder 2 error. | Check that the parameter settings in groups 93 Encoder 2 configuration are correct. Note: New settings will only take effect after parameter 91.10 Encoder parameter refresh is used or after the drive control unit is powered up the next time. Check the auxiliary code. See appropriate actions for each code below. |
| | Aux code: 1030 | Overspeed | Contact your local ABB representative. |
| | Aux code: 1031 | Pulse overfrequency | |
| | Aux code: 1032 | Cable fault | Check the wiring of the encoder. See also parameters 93.31 Encoder cable fault mode . |
| | Aux code: 1033 | Resolver ID run fault | Contact your local ABB representative. |
| | Aux code: 1034 | Encoder fault | Refer to encoder documentation. |
| | Aux code: 1035 | Encoder warning | |
| | Aux code: 1036 | Unsupported cable fault detection mode. | Try a different setting in 93.31 Encoder cable fault mode . |
| | Aux code: 1037 | Resolver SW version | Contact your local ABB representative. |
| | Aux code: 1038 | Resolver speed scale | |
| A7EE | Panel loss Programmable warning: 49.05 Communication loss action | Control panel or PC tool selected as active control location for drive has ceased communicating. | Check PC tool or control panel connection. Check control panel connector. Disconnect and reconnect the control panel. |
| A880 | Motor bearing Programmable warnings: 33.14 On-time 1 warn message 33.24 On-time 2 warn message 33.55 Value counter 1 warn message 33.65 Value counter 2 warn message | Warning generated by an on-time timer or a value counter. | Check the auxiliary code. Check the source of the warning corresponding to the code: 0: 33.13 On-time 1 source 1: 33.23 On-time 2 source 4: 33.53 Value counter 1 source 5: 33.63 Value counter 2 source . |
| A881 | Output relay | Warning generated by an edge counter. Programmable warnings: 33.35 Edge counter 1 warn message 33.45 Edge counter 2 warn message | Check the auxiliary code. Check the source of the warning corresponding to the code: 2: 33.33 Edge counter 1 source 3: 33.43 Edge counter 2 source . |
| A882 | Motor starts | | |
| A883 | Power ups | | |
| A884 | Main contactor | | |
| A885 | DC charge | | |
| A886 | On-time 1 (Editable message text) Programmable warning: 33.14 On-time 1 warn message | Warning generated by on-time timer 1. | Check the source of the warning (parameter 33.13 On-time 1 source). |
| A887 | On-time 2 (Editable message text) Programmable warning: 33.24 On-time 2 warn message | Warning generated by on-time timer 2. | Check the source of the warning (parameter 33.23 On-time 2 source). |

| Code (hex) | Warning | Cause | What to do |
|------------|---|--|---|
| A888 | Edge counter 1 (Editable message text) Programmable warning: 33.35 Edge counter 1 warn message | Warning generated by edge counter 1. | Check the source of the warning (parameter 33.33 Edge counter 1 source). |
| A889 | Edge counter 2 (Editable message text) Programmable warning: 33.45 Edge counter 2 warn message | Warning generated by edge counter 2. | Check the source of the warning (parameter 33.43 Edge counter 2 source). |
| A88A | Value counter 1 (Editable message text) Programmable warning: 33.55 Value counter 1 warn message | Warning generated by value counter 1. | Check the source of the warning (parameter 33.53 Value counter 1 source). |
| A88B | Value counter 2 (Editable message text) Programmable warning: 33.65 Value counter 2 warn message | Warning generated by value counter 2. | Check the source of the warning (parameter 33.63 Value counter 2 source). |
| A88C | Device clean | Warning generated by an on-time timer. Programmable warnings: 33.14 On-time 1 warn message 33.24 On-time 2 warn message | Check the auxiliary code. Check the source of the warning corresponding to the code: 0: 33.13 On-time 1 source 1: 33.23 On-time 2 source 10: 05.04 Fan on-time counter . |
| A88D | DC capacitor | | |
| A88E | Cabinet fan | | |
| A88F | Cooling fan | | |
| A890 | Additional cooling | | |
| A8A0 | AI supervision Programmable warning: 12.03 AI supervision function | An analog signal is outside the limits specified for the analog input. | Check signal level at the analog input. Check the wiring connected to the input. Check the minimum and maximum limits of the input in parameter group 12 Standard AI . |
| A8B0 | Signal supervision (Editable message text) Programmable warning: 32.06 Supervision 1 action | Warning generated by a signal supervision function. | Check the source of the warning (parameter 32.07 , 32.17 or 32.28). |
| A8B1 | Signal supervision 2 (Editable message text) Programmable warning: 32.16 Supervision 2 action | Warning generated by the signal supervision 2 function. | Check the source of the warning (parameter 32.17 Supervision 2 signal). |
| A8B2 | Signal supervision 3 (Editable message text) Programmable warning: 32.26 Supervision 3 action | Warning generated by the signal supervision 3 function. | Check the source of the warning (parameter 32.27 Supervision 3 signal). |
| A8C0 | Fan service counter | A cooling fan has reached the end of its estimated lifetime. See parameters 05.41 and 05.42 . | Check the auxiliary code. The code indicates which fan is to be replaced. 0: Main cooling fan 1: Auxiliary cooling fan 2: Auxiliary cooling fan 2 3: Cabinet cooling fan 4: PCB compartment fan Refer to the hardware manual of the drive for fan replacement instructions. |

| Code (hex) | Warning | Cause | What to do |
|------------|--|--|---|
| A981 | External warning 1 (Editable message text) Programmable warning: 31.01 External event 1 source 31.02 External event 1 type | Fault in external device 1. | Check the external device. Check setting of parameter 31.01 External event 1 source . |
| A982 | External warning 2 (Editable message text) Programmable warning: 31.03 External event 2 source 31.04 External event 2 type | Fault in external device 2. | Check the external device. Check setting of parameter 31.03 External event 2 source . |
| A983 | External warning 3 (Editable message text) Programmable warning: 31.05 External event 3 source 31.06 External event 3 type | Fault in external device 3. | Check the external device. Check setting of parameter 31.05 External event 3 source . |
| A984 | External warning 4 (Editable message text) Programmable warning: 31.07 External event 4 source 31.08 External event 4 type | Fault in external device 4. | Check the external device. Check setting of parameter 31.07 External event 4 source . |
| A985 | External warning 5 (Editable message text) Programmable warning: 31.09 External event 5 source 31.10 External event 5 type | Fault in external device 5. | Check the external device. Check setting of parameter 31.09 External event 5 source . |
| AF90 | Speed controller autotuning | The speed controller autotune routine did not complete successfully. | Check the auxiliary code (format XXXX YYYY). "YYYY" indicates the problem (see actions for each code below). |
| | | 0000 The drive was stopped before the autotune routine finished. | Repeat autotune until successful. |
| | | 0001 The drive was started but was not ready to follow the autotune command. | Make sure the prerequisites of the autotune run are fulfilled. See section Before activating the autotune routine (page 60). |
| | | 0002 Required torque reference could not be reached before the drive reached maximum speed. | Decrease torque step (parameter 25.38) or increase speed step (25.39). |
| | | 0003 Motor could not accelerate/decelerate to maximum/minimum speed. | Increase torque step (parameter 25.38) or decrease speed step (25.39). |
| | | 0005 Motor could not decelerate with full autotune torque. | Decrease torque step (parameter 25.38) or speed step (25.39). |
| AFAA | Autoreset | A fault is about to be autoreset. | Informative warning. See the settings in parameter group 31 Fault functions . |

| Code (hex) | Warning | Cause | What to do |
|------------|--|---|--|
| AFE1 | Emergency stop (off2) | Drive has received an emergency stop (mode selection off2) command. | Check that it is safe to continue operation. Return emergency stop push button to normal position. Restart drive. |
| AFE2 | Emergency stop (off1 or off3) | Drive has received an emergency stop (mode selection off1 or off3) command. | |
| AFEA | Enable start signal missing (Editable message text) | No enable start signal received. | Check the setting of (and the source selected by) parameter 20.19 Enable start command . |
| AFEB | Run enable missing | No run enable signal is received. | Check setting of parameter 20.12 Run enable 1 source . Switch signal on (e.g. in the fieldbus Control Word) or check wiring of selected source. |
| AFEC | External power signal missing | 95.04 Control board supply is set to External 24V but no voltage is connected to the XPOW connector of the control unit. | Check the external 24 V DC power supply to the control unit, or change the setting of parameter 95.04 . |
| AFF6 | Identification run | Motor ID run will occur at next start. | Informative warning. |
| AFF7 | Autophasing | Autophasing will occur at next start. | Informative warning. |
| B5A0 | STO event Programmable event: 31.22 STO indication run/stop | Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is lost. | Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop (page 245). |
| D200 | Overtemperature | 09.10 Measured temperature exceeded 79.07 Warning temperature limit for 5 sec or the Klixon digital input is false. | Check for problem in measurement device. Check for problem in temperature measurement circuit. Check well and discharge pressures (excessive pressure can cause heating). Check warning function setting in parameters. |
| D201 | Pressure | 09.09 Pressure exceeded 76.07 Analog feedback limit for 76.08 Analog feedback limit delay time or 76.04 Digital feedback source is set as false. | Check for problem in measurement device. Check for high gas content. Check warning function setting in parameters. |
| D202 | Underload | 78.02 Underload function is set to warning when 09.01 Rod torque and 09.05 Rod speed actual values are lower than user defined curve (parameters 78.03 - 78.08) for 78.09 Underload delay time . | Check parameter settings. Check setting of 78.02 Underload function . |

420 Fault tracing

| Code (hex) | Warning | Cause | What to do |
|------------|---------------------------|---|---|
| D203 | Check curve | There are identical torque values in parameters 78.03 - 78.08 . | Check parameter settings and set values as required. |
| D204 | Rod torque 1 limit | Actual 09.01 Rod torque is beyond the limits. Warning condition has been fulfilled. Shut-down procedure is active. | See parameters 77.02 - 77.06 . Check warning function setting in parameters and set values as required. |
| D205 | Rod torque 2 speed | Actual speed reference has been modified by 77.07 Rod torq2 function on 77.11 Rod torq2 additive speed ref value. | Check parameter settings and set values as required. |
| D206 | Rod torque 2 limit | 77.11 Rod torq2 additive speed ref has been triggered more than 77.13 Rod torq2 limit counter times during 77.14 Rod torq2 time window . Shut-down procedure is active. | Check parameter settings and set values as required. |
| D207 | Sleep mode | Sleep condition has been fulfilled. | See parameters 75.12 - 75.19 . Or set 75.11 Sleep warning enable as disabled. |
| D208 | Backspin limit | Actual 09.05 Rod speed is faster than 09.11 Backspin speed reference . | Check parameter settings and set values as required. |
| D209 | Backspin active | Pump backspin control procedure is in process. | See parameters 80.01 - 80.05 . Wait till procedure is completed. |
| D20A | Brake confirmation active | 74.21 Brake confirmation enable is active and procedure is in process. | Wait till procedure is completed. |
| D20B | Fault delay active | Fault is triggered and tripping is delayed till the drive is stopped. | Wait till drive is tripped. |
| D20C | Start delay active | Start delay procedure is in progress. It is not allowed to start the drive. | Wait till procedure is completed in time 09.12 Start delay remain . |
| D20D | Replace ZCU battery | ZCU board battery is empty. | Replace ZCU board battery. |

Fault messages

| Code (hex) | Fault | Cause | What to do |
|------------|--|--|--|
| 2281 | Calibration | Measured offset of output phase current measurement or difference between output phase U2 and W2 current measurement is too great (the values are updated during current calibration). | Try performing the current calibration again (select <i>Current measurement calibration</i> at parameter 99.13). If the fault persists, contact your local ABB representative. |
| 2310 | Overcurrent | Output current has exceeded internal fault limit. | Check motor load. Check acceleration times in parameter group 23 Speed reference ramp (speed control) or 28 Frequency reference chain (frequency control). Also check parameters 46.01 Speed scaling and 46.02 Frequency scaling . Check motor and motor cable (including phasing and delta/star connection). Check that the start-up data in parameter group 99 Motor data (page 353) corresponds to the motor rating plate. Check that there are no power factor correction capacitors or surge absorbers in motor cable. Check encoder cable (including phasing). |
| 2330 | Earth leakage Programmable fault: 31.20 Earth fault | Drive has detected load unbalance typically due to earth fault in motor or motor cable. | Check there are no power factor correction capacitors or surge absorbers in motor cable. Check that there is no earth fault in motor or motor cables: Measure insulation resistances of motor and motor cable. If no earth fault can be detected, contact your local ABB representative. |
| 2340 | Short circuit | Short-circuit in motor cable(s) or motor | Check motor and motor cable. Check there are no power factor correction capacitors or surge absorbers in motor cable. |
| 2381 | IGBT overload | Excessive IGBT junction to case temperature. This fault protects the IGBT(s) and can be activated by a short circuit in the motor cable. | Check motor cable. |
| 2392 | BU earth leakage | Total earth leakage of inverter modules is excessive. | Check there are no power factor correction capacitors or surge absorbers in motor cable. Measure insulation resistances of motor cables and motor. Contact your local ABB representative. |

422 Fault tracing

| Code (hex) | Fault | Cause | What to do |
|------------|--|---|---|
| 3130 | Input phase loss Programmable fault: 31.21 Supply phase loss | Intermediate circuit DC voltage is oscillating due to missing input power line phase or blown fuse. | Check input power line fuses. Check for input power supply imbalance. |
| 3180 | Charge relay lost | No acknowledgement received from charge relay. | Contact your local ABB representative. |
| 3181 | Cross connection Programmable fault: 31.23 Wiring or earth fault | Incorrect input power and motor cable connection (i.e. input power cable is connected to drive motor connection). | Check input power connections. |
| 3210 | DC link overvoltage | Excessive intermediate circuit DC voltage. | Check that overvoltage control is on (parameter 30.30 Overvoltage control). Check that the supply voltage matches the nominal input voltage of the drive. Check the supply line for static or transient overvoltage. Check brake chopper and resistor (if present). Check deceleration time. Use coast-to-stop function (if applicable). Retrofit drive with brake chopper and brake resistor. |
| 3220 | DC link undervoltage | Intermediate circuit DC voltage is not sufficient because of a missing supply phase, blown fuse or fault in the rectifier bridge. | Check supply cabling, fuses and switchgear. |
| 3280 | Standby timeout | Automatic restart failed (see section Automatic restart on page 80). | Check the condition of the supply (voltage, cabling, fuses, switchgear). |
| 3291 | DC voltage difference | Difference in DC voltages between parallel-connected inverter modules. | Contact your local ABB representative. |
| 3381 | Output phase loss Programmable fault: 31.19 Motor phase loss | Motor circuit fault due to missing motor connection (all three phases are not connected). | Connect motor cable. |

| Code (hex) | Fault | Cause | What to do |
|------------|-------------------------------|--|---|
| 3385 | Autophasing | Autophasing routine (see section Autophasing on page 73) has failed. | <p>Try other autophasing modes (see parameter 21.13 Autophasing mode) if possible.</p> <p>If the Turning with Z-pulse mode is selected, check the zero pulse given by the encoder.</p> <p>Check that the motor ID run has been successfully completed.</p> <p>Clear parameter 98.15 Position offset user.</p> <p>Check that the encoder is not slipping on the motor shaft.</p> <p>Check that the motor is not already turning when the autophasing routine starts.</p> <p>Check the setting of parameter 99.03 Motor type.</p> |
| 4000 | Motor cable overload | Calculated motor cable temperature has exceeded warning limit. | <p>Check the settings of parameters 35.61 and 35.62.</p> <p>Check the dimensioning of the motor cable in regard to required load.</p> |
| 4210 | IGBT overtemperature | Estimated drive IGBT temperature is excessive. | <p>Check ambient conditions.</p> <p>Check air flow and fan operation.</p> <p>Check heatsink fins for dust pick-up.</p> <p>Check motor power against drive power.</p> |
| 4290 | Cooling | Drive module temperature is excessive. | <p>Check ambient temperature. If it exceeds 40 °C (104 °F), ensure that load current does not exceed derated load capacity of drive. See appropriate <i>Hardware Manual</i>.</p> <p>Check drive module cooling air flow and fan operation.</p> <p>Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.</p> |
| 42F1 | IGBT temperature | Drive IGBT temperature is excessive. | <p>Check ambient conditions.</p> <p>Check air flow and fan operation.</p> <p>Check heatsink fins for dust pick-up.</p> <p>Check motor power against drive power.</p> |
| 4310 | Excess temperature | Power unit module temperature is excessive. | <p>Check ambient conditions.</p> <p>Check air flow and fan operation.</p> <p>Check heatsink fins for dust pick-up.</p> <p>Check motor power against drive power.</p> |
| 4380 | Excess temperature difference | High temperature difference between the IGBTs of different phases. | <p>Check the motor cabling.</p> <p>Check cooling of drive module(s).</p> |

| Code (hex) | Fault | Cause | What to do |
|------------|---|---|---|
| 4981 | External temperature (Editable message text) | Measured temperature 1 or 2 has exceeded fault limit. | <p>Check the values of parameters 35.02 Measured temperature 1 and 35.03 Measured temperature 2.</p> <p>Check the cooling of the motor (or other equipment whose temperature is being measured).</p> <p>Check the fault limits for measured temperatures 1 and 2 in parameter group 35 Motor thermal protection.</p> |
| 4982 | External temperature 2 (Editable message text) | Measured temperature 2 has exceeded fault limit. | <p>Check the value of parameter 35.03 Measured temperature 2.</p> <p>Check the cooling of the motor (or other equipment whose temperature is being measured).</p> <p>Check the value of parameter 35.22 Temperature 2 fault limit.</p> |
| 4990 | FEX-01/FPTC-01 not found | A temperature monitoring module has been activated by parameter 35.30 but cannot be detected. | <p>Power down the control unit and check that the module is properly inserted in the correct slot.</p> <p>The last digit of the auxiliary code identifies the slot.</p> |
| 4991 | Safe motor temperature 1 (Editable message text) | The temperature monitoring module installed in slot 1 indicates overtemperature. | <p>Check the cooling of the motor.</p> <p>Check the motor load and drive ratings.</p> |
| 4992 | Safe motor temperature 2 (Editable message text) | The temperature monitoring module installed in slot 2 indicates overtemperature. | <p>Check the wiring of the temperature sensor. Repair wiring if faulty.</p> <p>Measure the resistance of the sensor. Replace sensor if faulty.</p> |
| 4993 | Safe motor temperature 3 (Editable message text) | The temperature monitoring module installed in slot 3 indicates overtemperature. | |
| 5080 | Fan | Cooling fan stuck or disconnected. | <p>Check fan operation and connection.</p> <p>Replace fan if faulty.</p> |
| 5081 | Auxiliary fan broken | An auxiliary cooling fan (connected to the fan connectors on the control unit) is stuck or disconnected. | <p>Check auxiliary fan(s) and connection(s). Replace faulty fan.</p> <p>Make sure the front cover of the drive module is in place and tightened. If the commissioning of the drive requires that the cover is off, activate parameter 31.36 Aux fan fault bypass within 2 minutes from control unit reboot to temporarily suppress the fault.</p> <p>The auxiliary code identifies the fan (1: Main fan 1, 2: Main fan 2, 3: Main fan 3, 4: Auxiliary fan 1, 5: Auxiliary fan 2, 6: Auxiliary fan 3, 7: Filter fan 1, 8: Filter fan 2, 9: Filter fan 3).</p> |

| Code (hex) | Fault | Cause | What to do |
|------------|---|--|--|
| 5090 | STO hardware failure | Safe torque off hardware failure. | Contact your local ABB representative. The code contains location information, especially with parallel-connected inverter modules. When converted into a 32-bit binary number, the bits of the code indicate the following: 31...28: Number of faulty inverter module (0...11 decimal). 1111: STO_ACT states of control unit and inverter modules in conflict 27: STO_ACT state of inverter modules 26: STO_ACT state of control unit 25: STO1 of control unit 24: STO2 of control unit 23...12: STO1 of inverter modules 12...1 (Bits of non-existing modules set to 1) 11...0: STO2 of inverter modules 12...1 (Bits of non-existing modules set to 1) |
| 5091 | Safe torque off Programmable fault: 31.22 STO indication run/stop | Safe torque off function is active, i.e. safety circuit signal(s) connected to connector XSTO is broken during start or run. | Check safe torque off circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop (page 245). |
| 5092 | PU logic error | Power unit memory has cleared. | Contact your local ABB representative. |
| 5093 | Rating ID mismatch | The hardware of the drive does not match the information stored in the memory unit. This may occur eg. after a firmware update or memory unit replacement. | Cycle the power to the drive. Check the auxiliary code. The auxiliary code categories are as follows: 1 = PU and CU ratings not the same. Rating ID has changed. 2 = Parallel connection rating ID has changed. 3 = PU types not the same in all power units. 4 = Parallel connection rating ID is active in a single power unit setup. 5 = It is not possible to implement the selected rating with the current PUs. 6 = PU rating ID is 0. 7 = Reading PU rating ID or PU type failed on PU connection. With parallel connection faults, the format of the auxiliary code is 0X0Y. "Y" indicates the auxiliary code category, "X" indicates the first faulty PU channel in hexadecimal (1...C). |

| Code (hex) | Fault | Cause | What to do |
|------------|---------------------------------|--|---|
| 5094 | Measurement circuit temperature | Problem with internal temperature measurement of the drive. | See A5EA Measurement circuit temperature (page 410). |
| 5681 | PU communication | Communication errors detected between the drive control unit and the power unit. | Check the connection between the drive control unit and the power unit. |
| 5682 | Power unit lost | Connection between the drive control unit and the power unit is lost. | Check the connection between the control unit and the power unit. |
| 5690 | PU communication internal | Internal communication error. | Contact your local ABB representative. |
| 5691 | Measurement circuit ADC | Measurement circuit fault. | Contact your local ABB representative, quoting the auxiliary code. |
| 5692 | PU board powerfail | Power unit power supply failure. | Check the auxiliary code. |
| 5693 | Measurement circuit DFF | Measurement circuit fault. | Contact your local ABB representative, quoting the auxiliary code. |
| 5694 | PU communication configuration | Version check cannot find a matching power unit FPGA logic. | Update the FPGA logic of the power unit. Contact your local ABB representative. |
| 5696 | PU state feedback | State feedback from output phases does not match control signals. | Contact your local ABB representative, quoting the auxiliary code. |
| 5697 | Charging feedback | Charging feedback signal missing. | Check the feedback signal coming from the charging system. |
| 5698 | Unknown power unit fault | Unidentified power unit logic fault. | Check power unit logic and firmware compatibility. Contact your local ABB representative. |
| 6180 | Internal SW error | Internal error. | Contact your local ABB representative. Quote the auxiliary code (check the event details in the event log). |
| 6181 | FPGA version incompatible | Firmware and FPGA versions are incompatible. | Update power unit FPGA logic or firmware (whichever is older). Contact your local ABB representative. |
| 6306 | FBA A mapping file | Fieldbus adapter A mapping file read error. | Contact your local ABB representative. |
| 6481 | Task overload | Internal fault. Note: This fault cannot be reset. | Contact your local ABB representative. |
| 6487 | Stack overflow | Internal fault. Note: This fault cannot be reset. | Contact your local ABB representative. |

| Code (hex) | Fault | Cause | What to do |
|------------|-------------------------------------|---|--|
| 64A1 | Internal file load | File read error. Note: This fault cannot be reset. | Contact your local ABB representative. |
| 64A2 | Internal record load | Internal record load error. | Contact your local ABB representative. |
| 64A3 | Application loading | Application file incompatible or corrupted. Note: This fault cannot be reset. | Contact your local ABB representative. |
| 64A5 | Licensing fault | Running the control program is prevented either because a restrictive license exists, or because a required license is missing. | Record the auxiliary codes of all active licensing faults and contact your product vendor for further instructions. |
| 64B1 | Internal SSW fault | Internal fault. | Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative. |
| 64B2 | User set fault | Loading of user parameter set failed because requested set does not exist set is not compatible with control program drive was switched off during loading. | Ensure that a valid user parameter set exists. Reload. |
| 64E1 | Kernel overload | Operating system error. Note: This fault cannot be reset. | Contact your local ABB representative. |
| 6581 | Parameter system | Parameter load or save failed. | Try forcing a save using parameter 96.07 Parameter save manually . Retry. |
| 65A1 | FBA A parameter conflict | The drive does not have a functionality requested by PLC, or requested functionality has not been activated. | Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 51 FBA A settings . |
| 6681 | EFB comm loss Programmable fault | Communication break in embedded fieldbus (EFB) communication. | Check the status of the fieldbus master (online/offline/error etc.). Check cable connections to the XD2D connector on the control unit. |
| 6682 | EFB config file | Embedded fieldbus (EFB) configuration file could not be read. | Contact your local ABB representative. |
| 6683 | EFB invalid parameterization | Embedded fieldbus (EFB) parameter settings inconsistent or not compatible with selected protocol. | Check the settings in parameter group 58 Embedded fieldbus . |
| 6684 | EFB load fault | Embedded fieldbus (EFB) protocol firmware could not be loaded. | Contact your local ABB representative. |

| Code (hex) | Fault | Cause | What to do |
|------------|---|--|--|
| | | Version mismatch between EFB protocol firmware and drive firmware. | |
| 6881 | Text data overflow | Internal fault. | Reset the fault. Contact your local ABB representative if the fault persists. |
| 6882 | Text 32-bit table overflow | Internal fault. | Reset the fault. Contact your local ABB representative if the fault persists. |
| 6883 | Text 64-bit table overflow | Internal fault. | Reset the fault. Contact your local ABB representative if the fault persists. |
| 6885 | Text file overflow | Internal fault. | Reset the fault. Contact your local ABB representative if the fault persists. |
| 7080 | Option module comm loss | Communication between drive and option module (FEN-xx and/or FIO-xx) is lost. | Check that the option modules are properly seated in their slots. Check that the option modules or slot connectors are not damaged. To pinpoint the problem, try installing the modules into different slots. |
| 7081 | Panel port communication Programmable fault: 49.05 <i>Communication loss action</i> | Control panel or PC tool selected as active control location for drive has ceased communicating. | Check PC tool or control panel connection. Check control panel connector. Disconnect and reconnect the control panel. Check the auxiliary code. |
| 7082 | Extension I/O type mismatch | The I/O extension module types specified by parameters do not match the detected configuration. | Check the auxiliary code. The code indicates which I/O extension module is affected. Check the type and location settings of the modules (parameters 14.01 , 14.02 , 15.01 , 15.02 , 16.01 and 16.02). Check that the modules are properly installed. |
| 7121 | Motor stall Programmable fault: 31.24 <i>Stall function</i> | Motor is operating in stall region because of e.g. excessive load or insufficient motor power. | Check motor load and drive ratings. Check fault function parameters. |
| 7181 | Brake resistor | Brake resistor broken or not connected. | Check that a brake resistor has been connected. Check the condition of the brake resistor. Check the dimensioning of the brake resistor. |

| Code (hex) | Fault | Cause | What to do |
|------------|--|--|---|
| 7183 | BR excess temperature | Brake resistor temperature has exceeded fault limit defined by parameter 43.11 Brake resistor fault limit . | Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check fault limit setting, parameter 43.11 Brake resistor fault limit . Check that braking cycle meets allowed limits. |
| 7184 | Brake resistor wiring | Brake resistor short circuit or brake chopper control fault. | Check brake chopper and brake resistor connection. Ensure brake resistor is not damaged. |
| 7191 | BC short circuit | Short circuit in brake chopper IGBT. | Ensure brake resistor is connected and not damaged. Check the electrical specifications of the brake resistor against the <i>Hardware manual</i> . Replace brake chopper (if replaceable). |
| 7192 | BC IGBT excess temperature | Brake chopper IGBT temperature has exceeded internal fault limit. | Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check the dimensioning and cooling of the cabinet. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive. |
| 71B1 | Motor fan Programmable fault: 35.106 DOL starter event type | No feedback received from external fan. | Check external fan (or other equipment controlled) by the logic. Check settings of parameters 35.100...35.106 . |
| 7301 | Motor speed feedback Programmable fault: 90.45 Motor feedback fault | No motor speed feedback received. | Check the event log for an auxiliary code. See appropriate actions for each code at A7B0 Motor speed feedback (page 414). |
| 7310 | Overspeed | Motor is turning faster than highest allowed speed due to incorrectly set minimum/maximum speed, insufficient braking torque or changes in load when using torque reference. | Check minimum/maximum speed settings, parameters 30.11 Minimum speed and 30.12 Maximum speed . Check adequacy of motor braking torque. Check need for brake chopper and resistor(s). |

| Code (hex) | Fault | Cause | What to do |
|------------|--|---|---|
| 7358 | Line side converter faulted | The supply unit has tripped on a fault. | If using a control panel or the Drive composer tool, connect to the supply unit to read the fault code. Refer to the firmware manual of the supply unit for instructions related to the code. |
| 7380 | Encoder internal | Internal fault. | Contact your local ABB representative. |
| 7381 | Encoder 1 Programmable fault: 90.45 Motor feedback fault | Encoder 1 feedback fault. | <p>If fault appears during first start-up before encoder feedback is used:</p> <ul style="list-style-type: none"> - Check cable between encoder and encoder interface module (FEN-xx) and order of connector signal wires at both ends of cable. <p>If absolute encoder, EnDat/Hiperface/SSI, with incremental sin/cos pulses is used, incorrect wiring can be located as follows: Disable serial link (zero position) by setting parameter 91.02 to 0 and test encoder operation:</p> <ul style="list-style-type: none"> - If encoder fault is not activated, check serial link data wiring. Note that zero position is not taken into account when serial link is disabled. - If encoder fault is activated, check serial link and sin/cos signal wiring. <p>Note: Because only zero position is requested through serial link and during, position is updated according to sin/cos pulses.</p> <ul style="list-style-type: none"> - Check encoder parameter settings. <p>If fault appears after encoder feedback has already been used or during drive:</p> <ul style="list-style-type: none"> - Check that encoder connection wiring or encoder is not damaged. - Check that encoder interface module (FEN-xx) connection or module is not damaged. - Check earthings (when disturbances are detected in communication between encoder interface module and encoder). <p>For more information on encoders, see parameter groups 90 Feedback selection, 91 Encoder module settings, 92 Encoder 1 configuration and 93 Encoder 2 configuration.</p> <p>Check the event log for an auxiliary code. See appropriate actions for each code at A7E1 Encoder or A7E2 Encoder 2 (page 415).</p> |
| 7391 | Encoder 2 | Encoder 2 feedback fault. | |

| Code (hex) | Fault | Cause | What to do |
|------------|------------------------------|---|---|
| | | EnDat or SSI encoder is used in continuous mode as encoder 2. (I.e. 90.02 Encoder 2 sel = FEN-11 ABS and 91.02 ABS ENC INTERF = EnDat [or 91.02 ABS ENC INTERF = SSI] and 91.30 ENDAT MODE = CONTINUOUS [or 91.25 SSI MODE = CONTINUOUS].) | If possible, use single position transfer instead of continuous position transfer (i.e. if encoder has incremental sin/cos signals): - Change parameter 91.25 SSI MODE / 91.30 ENDAT MODE to value INITIAL POS. Otherwise use Endat/SSI encoder as encoder 1: - Change parameter 90.01 Encoder 1 sel to value FEN-11 ABS and parameter 90.02 Encoder 2 sel to value <i>None</i> . Note: The new setting will only take effect after parameter 91.10 Encoder parameter refresh is used or after the JCU Control Unit is powered up the next time. |
| 73A0 | Speed feedback configuration | Speed feedback configuration incorrect. | Check the feedback source selection parameters in group 90 Feedback selection . In case the source is an encoder interface, check parameter settings in groups 91 Encoder module settings , 92 Encoder 1 configuration and 93 Encoder 2 configuration . Check the event log for an auxiliary code. See appropriate actions for each code below. |
| | Aux code: 1000 | Interface module location settings in conflict. | Check the module location settings (91.12 Module 1 location and 91.14 Module 2 location). |
| | Aux code: 1001 | Detected type of interface module 1 does not match setting. | Check setting of 91.11 Module 1 type against 91.02 Module 1 status . Check setting of 91.12 Module 1 location . |
| | Aux code: 1002 | Detected type of interface module 2 does not match setting. | Check setting of 91.13 Module 2 type against 91.03 Module 2 status . Check setting of 91.14 Module 2 location . |
| | Aux code: 1003 | Interface module 1 type does not match encoder type. | Check settings of 91.11 Module 1 type and 92.01 Encoder 1 type . |
| | Aux code: 1004 | Interface module 2 type does not match encoder type. | Check settings of 91.13 Module 2 type and 93.01 Encoder 2 type . |
| | Aux code: 1005 | Speed feedback configuration has changed. | Use parameter 91.10 Encoder parameter refresh to validate any changes in the settings. |
| 73A1 | Load feedback | No load feedback received. | Check the auxiliary code. See appropriate actions for each code below. |

| Code (hex) | Fault | Cause | What to do |
|------------|--|--|--|
| | Aux code: 1015 | Load feedback configuration error (for example, a nonexistent encoder has been selected as feedback source). | Check the settings of parameter 90.51...90.57 , and the status of the source selected in 90.51 . In case the source is an encoder interface, check parameter settings in groups 91 Encoder module settings , 92 Encoder 1 configuration and 93 Encoder 2 configuration . |
| | Aux code: 1016 | Unexpected load feedback. | Check the settings of parameter 90.51...90.57 , and the status of the source selected in 90.51 . In case the source is an encoder interface, check parameter settings in groups 91 Encoder module settings , 92 Encoder 1 configuration and 93 Encoder 2 configuration . Check that the encoder is mounted so that no slippage is possible. |
| 73B0 | Emergency ramp failed | Emergency stop did not finish within expected time. | Check the settings of parameters 31.32 Emergency ramp supervision and 31.33 Emergency ramp supervision delay . Check the predefined ramp times (23.11...23.19 for mode Off1, 23.23 for mode Off3). |
| 73B1 | Stop failed | Ramp stop did not finish within expected time. | Check the settings of parameters 31.37 Ramp stop supervision and 31.38 Ramp stop supervision delay . Check the predefined ramp times in parameter group 23 Speed reference ramp . |
| 7510 | FBA A communication Programmable fault: 50.02 FBA A comm loss func | Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost. | Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 Fieldbus adapter (FBA) , 51 FBA A settings , 52 FBA A data in and 53 FBA A data out . Check cable connections. Check if communication master is able to communicate. |
| 7520 | FBA B communication Programmable fault: 50.32 FBA B comm loss func | Cyclical communication between drive and fieldbus adapter module B or between PLC and fieldbus adapter module B is lost. | Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter group 50 Fieldbus adapter (FBA) . Check cable connections. Check if communication master is able to communicate. |
| 7583 | Line side unit faulted | The supply unit (or other converter) connected to the inverter unit has generated a fault. | Check fault status of supply unit (or other converter). Refer to the firmware manual of the supply unit. |

| Code (hex) | Fault | Cause | What to do |
|------------|---|--|---|
| 80A0 | AI supervision Programmable fault: 12.03 AI supervision function | An analog signal is outside the limits specified for the analog input. | Check signal level at the analog input. Check the wiring connected to the input. Check the minimum and maximum limits of the input in parameter group 12 Standard AI . Check the auxiliary code. |
| 80B0 | Signal supervision (Editable message text) Programmable fault: 32.06 Supervision 1 action | Fault generated by a signal supervision function. | Check the source of the fault (parameter 32.07 , 32.17 or 32.28). |
| 80B1 | Signal supervision 2 (Editable message text) Programmable fault: 32.16 Supervision 2 action | Fault generated by the signal supervision 2 function. | Check the source of the fault (parameter 32.17 Supervision 2 signal). |
| 80B2 | Signal supervision 3 (Editable message text) Programmable fault: 32.26 Supervision 3 action | Fault generated by the signal supervision 3 function. | Check the source of the fault (parameter 32.27 Supervision 3 signal). |
| 9081 | External fault 1 (Editable message text) Programmable fault: 31.01 External event 1 source 31.02 External event 1 type | Fault in external device 1. | Check the external device. Check setting of parameter 31.01 External event 1 source . |
| 9082 | External fault 2 (Editable message text) Programmable fault: 31.03 External event 2 source 31.04 External event 2 type | Fault in external device 2. | Check the external device. Check setting of parameter 31.03 External event 2 source . |
| 9083 | External fault 3 (Editable message text) Programmable fault: 31.05 External event 3 source 31.06 External event 3 type | Fault in external device 3. | Check the external device. Check setting of parameter 31.05 External event 3 source . |
| 9084 | External fault 4 (Editable message text) Programmable fault: 31.07 External event 4 source 31.08 External event 4 type | Fault in external device 4. | Check the external device. Check setting of parameter 31.07 External event 4 source . |
| 9085 | External fault 5 (Editable message text) Programmable fault: 31.09 External event 5 source 31.10 External event 5 type | Fault in external device 5. | Check the external device. Check setting of parameter 31.09 External event 5 source . |
| FA81 | Safe torque off 1 loss | Safe torque off function is active, ie. STO circuit 1 is broken. | Check safety circuit connections. For more information, see appropriate drive hardware manual and description of parameter 31.22 STO indication run/stop (page 245). |
| FA82 | Safe torque off 2 loss | Safe torque off function is active, ie. STO circuit 2 is broken. | Check the auxiliary code, The code contains location information, especially with parallel-connected inverter modules |

| Code (hex) | Fault | Cause | What to do |
|------------|-----------------------------|---|---|
| FB11 | Memory unit missing | No memory unit is attached to the control unit. | Power down the control unit. Check that the memory unit is properly inserted into the control unit. |
| | | The memory unit attached to the control unit is empty. | Power down the control unit. Attach a memory unit (with the appropriate firmware) to the control unit. |
| FB12 | Memory unit incompatible | The memory unit attached to the control unit is incompatible. | Power down the control unit. Attach a compatible memory unit. |
| FB13 | Memory unit FW incompatible | The firmware on the attached memory unit is incompatible with the drive. | Power down the control unit. Attach a memory unit with compatible firmware. |
| FB14 | Memory unit FW load failed | The firmware on the attached memory unit could not be loaded to the drive. | Power down the control unit. Check that the memory unit is properly inserted into the control unit. If the problem persists, replace the memory unit. |
| FF61 | ID run | Motor ID run was not completed successfully. | Check the nominal motor values in parameter group 99 Motor data . Check that no external control system is connected to the drive. Cycle the power to the drive (and its control unit, if powered separately). Check that no operation limits prevent the completion of the ID run. Restore parameters to default settings and try again. Check that the motor shaft is not locked. Check the auxiliary code. |
| FF81 | FB A force trip | A fault trip command has been received through fieldbus adapter A. | Check the fault information provided by the PLC. |
| FF82 | FB B force trip | A fault trip command has been received through fieldbus adapter B. | Check the fault information provided by the PLC. |
| FF8E | EFB force trip | A fault trip command has been received through the embedded fieldbus interface. | Check the fault information provided by the Modbus controller. |
| D100 | Overtemperature fault | 09.10 Measured temperature exceeded 79.08 Fault temperature limit for 3 sec or the Klixon digital input is false. | Check for problem in measurement device. Check for problem in temperature measurement circuit. Check well and discharge pressures (excessive pressure can cause heating). Check warning function setting in parameters. |

| Code (hex) | Fault | Cause | What to do |
|------------|--------------------------|--|--|
| D101 | Pressure fault | Measured 09.09 Pressure is over than defined limits. Fault condition has been fulfilled. | Check for problem in measurement device. Check for high gas content. Check warning function setting in parameters. See 76.02 Pressure protection latching . |
| D102 | Underload fault | 78.02 Underload function is set to fault. Point of actual 09.01 Rod torque / 09.05 Rod speed values falls below user defined curve (parameters 78.03 - 78.08) for a time period defined by parameter 78.08 Underload delay time . | Check parameter settings. Check setting of 78.02 Underload function . Check mechanical condition of the pump. Check fluid condition. |
| D103 | Rod torque 1 limit fault | 09.01 Rod torque is lower or higher than 77.04 Rod torq1 limit and 09.05 Rod speed is lower than 77.05 Rod torq1 speed for a period of time defined by parameter 77.06 Rod torq1 delay time . | See parameters 77.02 - 77.06 . Check warning function setting in parameters and set values as required. Check mechanical condition of the pump. |
| D104 | Rod torque 2 limit fault | 77.07 Rod torq2 function has been triggered more than 77.13 Rod torq2 limit counter times during 77.14 Rod torq2 time window . | Check parameter settings and set values as required. |
| D105 | Brake confirmation fault | Mechanical brake (if present) did not pass Pump backspin control procedure. | Check operational condition of mechanical brake (if present). Check parameters 74.21...74.25 . |



Fieldbus control through the embedded fieldbus interface (EFB)

What this chapter contains


The chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) using the embedded fieldbus interface.

System overview

The drive can be connected to an external control system through a communication link using either a fieldbus adapter or the embedded fieldbus interface.

The embedded fieldbus interface supports the Modbus RTU protocol. The drive control program can handle 10 Modbus registers in a 10-millisecond time level. For example, if the drive receives a request to read 20 registers, it will start its response within 22 ms of receiving the request – 20 ms for processing the request and 2 ms overhead for handling the bus. The actual response time depends on other factors as well, such as the baud rate (a parameter setting in the drive).

The drive can be set to receive all of its control information through the fieldbus interface, or the control can be distributed between the embedded fieldbus interface and other available sources, for example, digital and analog inputs.



Connecting the fieldbus to the drive

Connect the fieldbus to terminal XD2D on the control unit of the drive. See the appropriate *Hardware Manual* for more information on the connection, chaining and termination of the link.

Note: If the XD2D connector is reserved by the embedded fieldbus interface (parameter *58.01 Protocol enable* is set to *Modbus RTU*), the drive-to-drive link functionality is automatically disabled.

Setting up the embedded fieldbus interface

Set the drive up for the embedded fieldbus communication with the parameters shown in the table below. The **Setting for fieldbus control** column gives either the value to use or the default value. The **Function/Information** column gives a description of the parameter.

| Parameter | Setting for fieldbus control | Function/Information |
|---|---|--|
| COMMUNICATION INITIALIZATION | | |
| 58.01 <i>Protocol enable</i> | <i>Modbus RTU</i> | Initializes embedded fieldbus communication. Drive-to-drive link operation is automatically disabled. |
| EMBEDDED MODBUS CONFIGURATION | | |
| 58.03 <i>Node address</i> | 1 (default) | Node address. There must be no two nodes with the same node address online. |
| 58.04 <i>Baud rate</i> | 19.2 <i>kbps</i> (default) | Defines the communication speed of the link. Use the same setting as in the master station. |
| 58.05 <i>Parity</i> | 8 <i>EVEN 1</i> (default) | Selects the parity and stop bit setting. Use the same setting as in the master station. |
| 58.14 <i>Communication loss action</i> | <i>Fault</i> (default) | Defines the action taken when a communication loss is detected. |
| 58.15 <i>Communication loss mode</i> | <i>Cw / Ref1 / Ref2</i> (default) | Enables/disables communication loss monitoring and defines the means for resetting the counter of the communication loss delay. |
| 58.16 <i>Communication loss time</i> | 3.0 s (default) | Defines the timeout limit for the communication monitoring. |
| 58.17 <i>Transmit delay</i> | 0 ms (default) | Defines a response delay for the drive. |
| 58.25 <i>Control profile</i> | <i>ABB Drives</i> (default), <i>Transparent</i> | Selects the control profile used by the drive. See section <i>Basics of the embedded fieldbus interface</i> (page 442). |
| 58.26 <i>EFB ref1 type</i> | <i>Speed or frequency</i> , <i>Transparent</i> , | Selects the reference and actual value types. With the <i>Speed or frequency</i> setting, the type is selected automatically according to the currently active drive control mode. |
| 58.29 <i>EFB act2 type</i> | <i>General, Torque, Speed, Frequency</i> | |
| 58.30 <i>EFB status word transparent source</i> | <i>Other</i> | Defines the source of status word when 58.25 <i>Control profile</i> = <i>Transparent</i> . |
| 58.31 <i>EFB act1 transparent source</i> | <i>Other</i> | Defines the source of actual value 1 when 58.28 <i>EFB act1 type</i> = <i>Transparent</i> or <i>General</i> . |
| 58.32 <i>EFB act2 transparent source</i> | <i>Other</i> | Defines the source of actual value 2 when 58.29 <i>EFB act2 type</i> = <i>Transparent</i> or <i>General</i> . |

| Parameter | Setting for fieldbus control | Function/Information |
|--|--|--|
| 58.33 <i>Addressing mode</i> | <i>Mode 1</i> (default) | Defines the mapping between parameters and holding registers in the 400001...465536 (100...65535) Modbus register range. |
| 58.34 <i>Word order</i> | <i>LO-HI</i> (default) | Defines the order of the data words in the Modbus message frame. |
| 58.101 <i>Data I/O 1</i> ... 58.124 <i>Data I/O 24</i> | For example, the default settings (I/Os 1...6 contain the control word, the status word, two references and two actual values) <i>RO/DIO control word, AO1 data storage, AO2 data storage, Feedback data storage, Setpoint data storage</i> | Define the address of the drive parameter which the Modbus master accesses when it reads from or writes to the register address corresponding to Modbus In/Out parameters. Select the parameters that you want to read or write through the Modbus I/O words. These settings write the incoming data into storage parameters 10.99 <i>RO/DIO control word</i> , 13.91 <i>AO1 data storage</i> , 13.92 <i>AO2 data storage</i> . |
| 58.06 <i>Communication control</i> | <i>Refresh settings</i> | Validates the settings of the configuration parameters. |

The new settings will take effect when the drive is powered up the next time, or when they are validated by parameter [58.06](#) *Communication control*.

Setting the drive control parameters

After the embedded fieldbus interface has been set up, check and adjust the drive control parameters listed in the table below. The **Setting for fieldbus control** column gives the value or values to use when the embedded fieldbus signal is the desired source or destination for that particular drive control signal. The **Function/Information** column gives a description of the parameter.

| Parameter | Setting for fieldbus control | Function/Information |
|--|------------------------------------|--|
| CONTROL COMMAND SOURCE SELECTION | | |
| 20.01 <i>Ext1 commands</i> | <i>Embedded fieldbus</i> | Selects fieldbus as the source for the start and stop commands when EXT1 is selected as the active control location. |
| 20.02 <i>Ext2 commands</i> | <i>Embedded fieldbus</i> | Selects fieldbus as the source for the start and stop commands when EXT2 is selected as the active control location. |
| SPEED REFERENCE SELECTION | | |
| 22.11 <i>Speed ref1 source</i> | <i>EFB ref1</i> or <i>EFB ref2</i> | Selects a reference received through the embedded fieldbus interface as speed reference 1. |

| Parameter | Setting for fieldbus control | Function/Information |
|---|--|--|
| 22.12 Speed ref2 source | EFB ref1 or EFB ref2 | Selects a reference received through the embedded fieldbus interface as speed reference 2. |

FREQUENCY REFERENCE SELECTION

| | | |
|---|--|--|
| 28.11 Frequency ref1 source | EFB ref1 or EFB ref2 | Selects a reference received through the embedded fieldbus interface as frequency reference 1. |
| 28.12 Frequency ref2 source | EFB ref1 or EFB ref2 | Selects a reference received through the embedded fieldbus interface as frequency reference 2. |

PCP/ESP REFERENCE SELECTION

| | | |
|--------------------------------------|--|---|
| 74.05 Speedrefsource | EFB1 ref or EFB2 ref | Selects a reference received through the embedded fieldbus interface as speed reference 1 or reference 2. |
|--------------------------------------|--|---|

OTHER SELECTIONS

EFB references can be selected as the source at virtually any signal selector parameter by selecting [Other](#), then either [03.09 EFB reference 1](#) or [03.10 EFB reference 2](#).

CONTROL OF RELAY OUTPUTS, ANALOG OUTPUTS AND DIGITAL INPUT/OUTPUTS

| | | |
|--|--|---|
| 10.24 RO1 source | RO/DIO control word bit0 | Connects bit 0 of storage parameter 10.99 RO/DIO control word to relay output RO1. |
| 10.27 RO2 source | RO/DIO control word bit1 | Connects bit 1 of storage parameter 10.99 RO/DIO control word to relay output RO2. |
| 10.30 RO3 source | RO/DIO control word bit2 | Connects bit 2 of storage parameter 10.99 RO/DIO control word to relay output RO3. |
| 11.05 DIO1 function 11.09 DIO2 function | Output (default) | Sets the digital input/output to output mode. |
| 11.06 DIO1 output source | RO/DIO control word bit8 | Connects bit 8 of storage parameter 10.99 RO/DIO control word to digital input/output DIO1. |
| 11.10 DIO2 output source | RO/DIO control word bit9 | Connects bit 9 of storage parameter 10.99 RO/DIO control word to digital input/output DIO2. |
| 13.12 AO1 source | AO1 data storage | Connects storage parameter 13.91 AO1 data storage to analog output AO1. |
| 13.22 AO2 source | AO2 data storage | Connects storage parameter 13.92 AO2 data storage to analog output AO2. |


SYSTEM CONTROL INPUTS

| | | |
|---|---|--|
| 96.07 Parameter save manually | Save (reverts to Done) | Saves parameter value changes (including those made through fieldbus control) to permanent memory. |
|---|---|--|

Basics of the embedded fieldbus interface

The cyclic communication between a fieldbus system and the drive consists of 16-bit data words or 32-bit data words (with the transparent control profiles).

The diagram below illustrates the operation of the embedded fieldbus interface. The signals transferred in the cyclic communication are explained further below the diagram.



1. See also other parameters which can be controlled through fieldbus.
2. Data conversion if parameter **58.25 Control profile** is set to **ABB Drives**. See section **About the control profiles** (page 446).
3. If parameter **58.25 Control profile** is set to **Transparent**,
 - the sources of the status word and actual values are selected by parameters **58.30...58.32** (otherwise, actual values 1 and 2 are automatically selected according to reference type), and the control word is displayed by **06.05 EFB transparent control word**.

■ Control word and Status word

The Control Word (CW) is a 16-bit or 32-bit packed boolean word. It is the principal means of controlling the drive from a fieldbus system. The CW is sent by the fieldbus controller to the drive. By drive parameters, the user selects the EFB CW as the source of drive control commands (such as start/stop, emergency stop, selection between external control locations 1/2, or fault reset). The drive switches between its states according to the bit-coded instructions of the CW.

The fieldbus CW is either written to the drive as it is (see parameter [06.05 EFB transparent control word](#)) or the data is converted. See section [About the control profiles](#) (page 446).

The fieldbus Status Word (SW) is a 16-bit or 32-bit packed boolean word. It contains status information from the drive to the fieldbus controller. The drive SW is either written to the fieldbus SW as it is or the data is converted. See section [About the control profiles](#) (page 446).

■ References

EFB references 1 and 2 are 16-bit or 32-bit signed integers. The contents of each reference word can be used as the source of virtually any signal, such as the speed, frequency, torque or process reference. In embedded fieldbus communication, references 1 and 2 are displayed by [03.09 EFB reference 1](#) and [03.10 EFB reference 2](#) respectively. Whether the references are scaled or not depends on the settings of [58.26 EFB ref1 type](#) and [58.27 EFB ref2 type](#). See section [About the control profiles](#) (page 446).

■ Actual values

Fieldbus actual signals (ACT1 and ACT2) are 16-bit or 32-bit signed integers. They convey selected drive parameter values from the drive to the master. Whether the actual values are scaled or not depends on the settings of [58.28 EFB act1 type](#) and [58.29 EFB act2 type](#). See section [About the control profiles](#) (page 446).

■ Data input/outputs

Data input/outputs are 16-bit or 32-bit words containing selected drive parameter values. Parameters [58.101 Data I/O 1](#) ... [58.124 Data I/O 24](#) define the addresses from which the master either reads data (input) or to which it writes data (output).

Control of drive outputs through EFB

The address selection parameters of the data input/outputs have a setting with which the data can be written into a storage parameter in the drive. These storage parameters are readily selectable as signal sources of the drive outputs.

The desired values of the relay outputs (RO) and digital input/outputs (DIO) can be written in a 16-bit word into [10.99 RO/DIO control word](#), which is then selected as the source of those outputs. Each of the analog outputs (AO) of the drive have a

dedicated storage parameter ([13.91 AO1 data storage](#) and [13.92 AO2 data storage](#)), which are available in the source selection parameters [13.12 AO1 source](#) and [13.22 AO2 source](#).

■ Register addressing

The address field of Modbus requests for accessing holding registers is 16 bits. This allows the Modbus protocol to support addressing of 65536 holding registers.

Historically, Modbus master devices used 5-digit decimal addresses from 40001 to 49999 to represent holding register addresses. The 5-digit decimal addressing limited to 9999 the number of holding registers that could be addressed.

Modern Modbus master devices typically provide a means to access the full range of 65536 Modbus holding registers. One of these methods is to use 6-digit decimal addresses from 400001 to 465536. This manual uses 6-digit decimal addressing to represent Modbus holding register addresses.

Modbus master devices that are limited to the 5-digit decimal addressing may still access registers 400001 to 409999 by using 5-digit decimal addresses 40001 to 49999. Registers 410000 to 465536 are inaccessible to these masters.


Note: Register addresses of 32-bit parameters cannot be accessed by using 5-digit register numbers.

About the control profiles

A control profile defines the rules for data transfer between the drive and the fieldbus master, for example:

- if packed boolean words are converted and how
- how drive register addresses are mapped for the fieldbus master.

You can configure the drive to receive and send messages according to the ABB Drives profile or the Transparent profile. With the ABB Drives profile, the embedded fieldbus interface of the drive converts the control word and status word to and from the native data used in the drive. The Transparent profile involves no data conversion. The figure below illustrates the effect of the profile selection.



Control profile selection with parameter [58.25 Control profile](#):

- (0) *ABB Drives*
- (2) *Transparent*

Note that scaling of references and actual values can be selected independent of the profile selection by parameters [58.26...58.29](#).

The ABB Drives profile

■ Control Word

The table below shows the contents of the fieldbus Control Word for the ABB Drives control profile. The embedded fieldbus interface converts this word to the form in which it is used in the drive. The upper case boldface text refers to the states shown in *State transition diagram* on page 450.

| Bit | Name | Value | STATE/Description |
|-----|-----------------------|-------|---|
| 0 | OFF1_ CONTROL | 1 | Proceed to READY TO OPERATE. |
| | | 0 | Stop along currently active deceleration ramp. Proceed to OFF1 ACTIVE ; proceed to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active. |
| 1 | OFF2_ CONTROL | 1 | Continue operation (OFF2 inactive). |
| | | 0 | Emergency OFF, coast to stop. Proceed to OFF2 ACTIVE , proceed to SWITCH-ON INHIBITED . |
| 2 | OFF3_ CONTROL | 1 | Continue operation (OFF3 inactive). |
| | | 0 | Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE; proceed to SWITCH-ON INHIBITED. Warning: Ensure that the motor and driven machine can be stopped using this stop mode. |
| 3 | INHIBIT_ OPERATION | 1 | Proceed to OPERATION ENABLED . Note: Run enable signal must be active; see the drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal. |
| | | 0 | Inhibit operation. Proceed to OPERATION INHIBITED . |
| 4 | RAMP_OUT_ ZERO | 1 | Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT ENABLED . |
| | | 0 | Force Ramp Function Generator output to zero. Drive ramps to stop (current and DC voltage limits in force). |
| 5 | RAMP_HOLD | 1 | Enable ramp function. Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR ENABLED . |
| | | 0 | Halt ramping (Ramp Function Generator output held). |
| 6 | RAMP_IN_ ZERO | 1 | Normal operation. Proceed to OPERATING . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters. |
| | | 0 | Force Ramp Function Generator input to zero. |
| 7 | RESET | 0=>1 | Fault reset if an active fault exists. Proceed to SWITCH-ON INHIBITED . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters. |
| | | 0 | Continue normal operation. |

| Bit | Name | Value | STATE/Description |
|---------|--------------|-------|--|
| 8 | JOGGING_1 | 1 | Accelerate to jogging 1 reference. Notes: <ul style="list-style-type: none"> • Bits 4...6 must be 0. • See also section <i>Jogging</i> (page 69). |
| | | 0 | Jogging 1 disabled. |
| 9 | JOGGING_2 | 1 | Accelerate to jogging 2 reference. See notes at bit 8. |
| | | 0 | Jogging 2 disabled. |
| 10 | REMOTE_CMD | 1 | Fieldbus control enabled. |
| | | 0 | Control Word <> 0 or Reference <> 0: Retain last Control Word and Reference. Control Word = 0 and Reference = 0: Fieldbus control enabled. Reference and deceleration/acceleration ramp are locked. |
| 11 | EXT_CTRL_LOC | 1 | Select External Control Location EXT2. Effective if the control location is parameterized to be selected from the fieldbus. |
| | | 0 | Select External Control Location EXT1. Effective if the control location is parameterized to be selected from the fieldbus. |
| 12...15 | Reserved | | |


■ Status Word

The table below shows the fieldbus Status Word for the ABB Drives control profile. The embedded fieldbus interface converts the drive Status Word into this form for the fieldbus. The upper case boldface text refers to the states shown in [State transition diagram](#) on page 450.

| Bit | Name | Value | STATE/Description |
|---------|----------------|-------|---|
| 0 | RDY_ON | 1 | READY TO SWITCH ON. |
| | | 0 | NOT READY TO SWITCH ON. |
| 1 | RDY_RUN | 1 | READY TO OPERATE. |
| | | 0 | OFF1 ACTIVE. |
| 2 | RDY_REF | 1 | OPERATION ENABLED. |
| | | 0 | OPERATION INHIBITED. |
| 3 | TRIPPED | 1 | FAULT. |
| | | 0 | No fault. |
| 4 | OFF_2_STA | 1 | OFF2 inactive. |
| | | 0 | OFF2 ACTIVE. |
| 5 | OFF_3_STA | 1 | OFF3 inactive. |
| | | 0 | OFF3 ACTIVE. |
| 6 | SWC_ON_INHIB | 1 | SWITCH-ON INHIBITED. |
| | | 0 | – |
| 7 | ALARM | 1 | Warning/Alarm. |
| | | 0 | No warning/alarm. |
| 8 | AT_SETPOINT | 1 | OPERATING. Actual value equals Reference = is within tolerance limits, i.e. in speed control, speed error is 10% max. of nominal motor speed. |
| | | 0 | Actual value differs from Reference = is outside tolerance limits. |
| 9 | REMOTE | 1 | Drive control location: REMOTE (EXT1 or EXT2). |
| | | 0 | Drive control location: LOCAL. |
| 10 | ABOVE_LIMIT | 1 | Actual frequency or speed equals or exceeds supervision limit (set by drive parameter). Valid in both directions of rotation. |
| | | 0 | Actual frequency or speed within supervision limit. |
| 11 | USER_0 | | S |
| 12 | EXT_RUN_ENABLE | 1 | External Run enable signal received. |
| | | 0 | No external Run enable signal received. |
| 13...15 | Reserved | | |

State transition diagram


The diagram below shows the state transitions in the drive when the drive is using the ABB Drives profile, and configured to follow the commands of the control word from the embedded fieldbus interface. The upper case texts refer to the states which are used in the tables representing the fieldbus Control and Status words. See sections [Control Word](#) on page 447 and [Status Word](#) on page 449.



References

The ABB drives profile supports the use of two references, EFB reference 1 and EFB reference 2. The references are 16-bit words each containing a sign bit and a 15-bit integer. A negative reference is formed by calculating the two's complement from the corresponding positive reference.

The references are scaled as defined by parameters [46.01... 46.07](#); which scaling is in use depends on the setting of [58.26 EFB ref1 type](#) and [58.27 EFB ref2 type](#) (see page [301](#)).




The scaled references are shown by parameters [03.09 EFB reference 1](#) and [03.10 EFB reference 2](#).

■ Actual values

The ABB Drives profile supports the use of two fieldbus actual values, ACT1 and ACT2. The actual values are 16-bit words each containing a sign bit and a 15-bit integer. A negative value is formed by calculating the two's complement from the corresponding positive value.

The actual values are scaled as defined by parameters *46.01...46.04*; which scaling is in use depends on the setting of parameters *58.28 EFB act1 type* and *58.29 EFB act2 type* (see page 301).



■ Modbus holding register addresses

The table below shows the default Modbus holding register addresses for drive data. This profile provides a converted 16-bit access to the data.

| Register address | Register data (16-bit words) |
|------------------|---|
| 400001 | Control word. See section Control Word (page 447). The selection can be changed using parameter 58.101 Data I/O 1 . |
| 400002 | Reference 1 (REF1). The selection can be changed using parameter 58.102 Data I/O 2 . |
| 400003 | Reference 2 (REF2). The selection can be changed using parameter 58.103 Data I/O 3 . |
| 400004 | Status Word (SW). See section Status Word (page 449). The selection can be changed using parameter 58.104 Data I/O 4 . |
| 400005 | Actual value 1 (ACT1). The selection can be changed using parameter 58.105 Data I/O 5 . |
| 400006 | Actual value 2 (ACT2). The selection can be changed using parameter 58.106 Data I/O 6 . |
| 400007...400024 | Data in/out 7...24. Selected by parameters 58.107 Data I/O 7 ... 58.124 Data I/O 24 . |
| 400025...400089 | Unused |
| 400090...400100 | Error code access. See section Error code registers (holding registers 400090...400100) (page 460). |
| 400101...465536 | Parameter read/write. Parameters are mapped to register addresses according to parameter 58.33 Addressing mode . |

The Transparent profile

The Transparent profile enables a customizable access to the drive.

The contents of the control word are user-definable. The control word received from the fieldbus is visible in parameter [06.05 EFB transparent control word](#), and can be used to control the drive using pointer parameters and/or application programming.

The status word to be sent to the fieldbus controller is selected by parameter [58.30 EFB status word transparent source](#). This can be, for example, the user-configurable status word in [06.50 User status word 1](#).

The Transparent profile involves no data conversion of the control or status word. Whether references or actual values are scaled depends on the setting of parameters [58.26...58.29](#). The references received from the fieldbus are visible in parameters [03.09 EFB reference 1](#) and [03.10 EFB reference 2](#).

The Modbus holding register addresses for the Transparent profile are as with the ABB Drives profile (see page [453](#)).

Modbus function codes

The table below shows the Modbus function codes supported by the embedded fieldbus interface.

| Code | Function name | Description |
|------|-------------------------------|---|
| 01h | Read Coils | Reads the 0/1 status of coils (0X references). |
| 02h | Read Discrete Inputs | Reads the 0/1 status of discrete inputs (1X references). |
| 03h | Read Holding Registers | Reads the binary contents of holding registers (4X references). |
| 05h | Write Single Coil | Forces a single coil (0X reference) to 0 or 1. |
| 06h | Write Single Register | Writes a single holding register (4X reference). |
| 08h | Diagnostics | Provides a series of tests for checking the communication, or for checking various internal error conditions. Supported subcodes: <ul style="list-style-type: none"> • 00h Return Query Data: Echo/loopback test. • 01h Restart Comm Option: Restarts and initializes the EFB, clears communications event counters. • 04h Force Listen Only Mode • 0Ah Clear Counters and Diagnostic Register • 0Bh Return Bus Message Count • 0Ch Return Bus Comm. Error Count • 0Dh Return Bus Exception Error Count • 0Eh Return Slave Message Count • 0Fh Return Slave No Response Count • 10h Return Slave NAK (negative acknowledge) Count • 11h Return Slave Busy Count • 12h Return Bus Character Overrun Count • 14h Clear Overrun Counter and Flag |
| 0Bh | Get Comm Event Counter | Returns a status word and an event count. |
| 0Fh | Write Multiple Coils | Forces a sequence of coils (0X references) to 0 or 1. |
| 10h | Write Multiple Registers | Writes the contents of a contiguous block of holding registers (4X references). |
| 16h | Mask Write Register | Modifies the contents of a 4X register using a combination of an AND mask, an OR mask, and the register's current contents. |
| 17h | Read/Write Multiple Registers | Writes the contents of a contiguous block of 4X registers, then reads the contents of another group of registers (the same or different than those written) in a server device. |

| Code | Function name | Description |
|-----------|----------------------------------|---|
| 2Bh / 0Eh | Encapsulated Interface Transport | <p>Supported subcodes:</p> <ul style="list-style-type: none"> • 0Eh Read Device Identification: Allows reading the identification and other information. <p>Supported ID codes (access type):</p> <ul style="list-style-type: none"> • 00h: Request to get the basic device identification (stream access) • 04h: Request to get one specific identification object (individual access) <p>Supported Object IDs:</p> <ul style="list-style-type: none"> • 00h: Vendor Name (“ABB”) • 01h: Product Code (for example, “AINFX”) • 02h: Major Minor Revision (combination of contents of parameters 07.05 Firmware version and 58.02 Protocol ID). • 03h: Vendor URL (“www.abb.com”) • 04h: Product name (for example, “ACS880”) |

Exception codes

The table below shows the Modbus exception codes supported by the embedded fieldbus interface.

| Code | Name | Description |
|------|----------------------|--|
| 01h | ILLEGAL FUNCTION | The function code received in the query is not an allowable action for the server. |
| 02h | ILLEGAL DATA ADDRESS | The data address received in the query is not an allowable address for the server. |
| 03h | ILLEGAL DATA VALUE | <p>The requested Quantity of Registers is larger than the drive can handle.</p> <p>Note: This error does not mean that a value written to a drive parameter is outside the valid range.</p> |
| 04h | SLAVE DEVICE FAILURE | The value written to a drive parameter is outside the valid range. See section Error code registers (holding registers 400090...400100) on page 460. |
| 06h | SLAVE DEVICE BUSY | The server is engaged in processing a long-duration program command. |

Coils (0xxxx reference set)

Coils are 1-bit read/write values. Control Word bits are exposed with this data type. The table below summarizes the Modbus coils (0xxxx reference set).

| Reference | ABB drives profile | Transparent profile |
|-----------|--------------------|---|
| 00001 | OFF1_CONTROL | Control Word bit 0 |
| 00002 | OFF2_CONTROL | Control Word bit 1 |
| 00003 | OFF3_CONTROL | Control Word bit 2 |
| 00004 | INHIBIT_OPERATION | Control Word bit 3 |
| 00005 | RAMP_OUT_ZERO | Control Word bit 4 |
| 00006 | RAMP_HOLD | Control Word bit 5 |
| 00007 | RAMP_IN_ZERO | Control Word bit 6 |
| 00008 | RESET | Control Word bit 7 |
| 00009 | JOGGING_1 | Control Word bit 8 |
| 00010 | JOGGING_2 | Control Word bit 9 |
| 00011 | REMOTE_CMD | Control Word bit 10 |
| 00012 | EXT_CTRL_LOC | Control Word bit 11 |
| 00013 | User-defined (0) | Control Word bit 12 |
| 00014 | User-defined (1) | Control Word bit 13 |
| 00015 | User-defined (2) | Control Word bit 14 |
| 00016 | User-defined (3) | Control Word bit 15 |
| 00017 | Reserved | Control Word bit 16 |
| 00018 | Reserved | Control Word bit 17 |
| 00019 | Reserved | Control Word bit 18 |
| 00020 | Reserved | Control Word bit 19 |
| 00021 | Reserved | Control Word bit 20 |
| 00022 | Reserved | Control Word bit 21 |
| 00023 | Reserved | Control Word bit 22 |
| 00024 | Reserved | Control Word bit 23 |
| 00025 | Reserved | Control Word bit 24 |
| 00026 | Reserved | Control Word bit 25 |
| 00027 | Reserved | Control Word bit 26 |
| 00028 | Reserved | Control Word bit 27 |
| 00029 | Reserved | Control Word bit 28 |
| 00030 | Reserved | Control Word bit 29 |
| 00031 | Reserved | Control Word bit 30 |
| 00032 | Reserved | Control Word bit 31 |
| 00033 | Reserved | <i>10.99 RO/DIO control word, bit 0</i> |
| 00034 | Reserved | <i>10.99 RO/DIO control word, bit 1</i> |

| Reference | ABB drives profile | Transparent profile |
|-----------|--------------------|--|
| 00035 | Reserved | <i>10.99 RO/DIO control word</i> , bit 2 |
| 00036 | Reserved | <i>10.99 RO/DIO control word</i> , bit 3 |
| 00037 | Reserved | <i>10.99 RO/DIO control word</i> , bit 4 |
| 00038 | Reserved | <i>10.99 RO/DIO control word</i> , bit 5 |
| 00039 | Reserved | <i>10.99 RO/DIO control word</i> , bit 6 |
| 00040 | Reserved | <i>10.99 RO/DIO control word</i> , bit 7 |
| 00041 | Reserved | <i>10.99 RO/DIO control word</i> , bit 8 |
| 00042 | Reserved | <i>10.99 RO/DIO control word</i> , bit 9 |

Discrete inputs (1xxxx reference set)

Discrete inputs are 1-bit read-only values. Status Word bits are exposed with this data type. The table below summarizes the Modbus discrete inputs (1xxxx reference set).

| Reference | ABB drives profile | Transparent profile |
|-----------|--------------------|---------------------|
| 10001 | RDY_ON | Status Word bit 0 |
| 10002 | RDY_RUN | Status Word bit 1 |
| 10003 | RDY_REF | Status Word bit 2 |
| 10004 | TRIPPED | Status Word bit 3 |
| 10005 | OFF_2_STA | Status Word bit 4 |
| 10006 | OFF_3_STA | Status Word bit 5 |
| 10007 | SWC_ON_INHIB | Status Word bit 6 |
| 10008 | ALARM | Status Word bit 7 |
| 10009 | AT_SETPOINT | Status Word bit 8 |
| 10010 | REMOTE | Status Word bit 9 |
| 10011 | ABOVE_LIMIT | Status Word bit 10 |
| 10012 | User-defined (0) | Status Word bit 11 |
| 10013 | User-defined (1) | Status Word bit 12 |
| 10014 | User-defined (2) | Status Word bit 13 |
| 10015 | User-defined (3) | Status Word bit 14 |
| 10016 | Reserved | Status Word bit 15 |
| 10017 | Reserved | Status Word bit 16 |
| 10018 | Reserved | Status Word bit 17 |
| 10019 | Reserved | Status Word bit 18 |
| 10020 | Reserved | Status Word bit 19 |
| 10021 | Reserved | Status Word bit 20 |
| 10022 | Reserved | Status Word bit 21 |
| 10023 | Reserved | Status Word bit 22 |
| 10024 | Reserved | Status Word bit 23 |

| Reference | ABB drives profile | Transparent profile |
|-----------|--------------------|---|
| 10025 | Reserved | Status Word bit 24 |
| 10026 | Reserved | Status Word bit 25 |
| 10027 | Reserved | Status Word bit 26 |
| 10028 | Reserved | Status Word bit 27 |
| 10029 | Reserved | Status Word bit 28 |
| 10030 | Reserved | Status Word bit 29 |
| 10031 | Reserved | Status Word bit 30 |
| 10032 | Reserved | Status Word bit 31 |
| 10033 | Reserved | <i>10.02 DI delayed status</i> , bit 0 |
| 10034 | Reserved | <i>10.02 DI delayed status</i> , bit 1 |
| 10035 | Reserved | <i>10.02 DI delayed status</i> , bit 2 |
| 10036 | Reserved | <i>10.02 DI delayed status</i> , bit 3 |
| 10037 | Reserved | <i>10.02 DI delayed status</i> , bit 4 |
| 10038 | Reserved | <i>10.02 DI delayed status</i> , bit 5 |
| 10039 | Reserved | <i>10.02 DI delayed status</i> , bit 6 |
| 10040 | Reserved | <i>10.02 DI delayed status</i> , bit 7 |
| 10041 | Reserved | <i>10.02 DI delayed status</i> , bit 8 |
| 10042 | Reserved | <i>10.02 DI delayed status</i> , bit 9 |
| 10043 | Reserved | <i>10.02 DI delayed status</i> , bit 10 |
| 10044 | Reserved | <i>10.02 DI delayed status</i> , bit 11 |
| 10045 | Reserved | <i>10.02 DI delayed status</i> , bit 12 |
| 10046 | Reserved | <i>10.02 DI delayed status</i> , bit 13 |
| 10047 | Reserved | <i>10.02 DI delayed status</i> , bit 14 |
| 10048 | Reserved | <i>10.02 DI delayed status</i> , bit 15 |

Error code registers (holding registers 400090...400100)

These registers contain information about the last query. The error register is cleared when a query has finished successfully.

| Reference | Name | Description |
|-----------|------------------------------------|--|
| 89 | Reset Error Registers | 1 = Reset internal error registers (91...95). |
| 90 | Error Function Code | Function code of the failed query. |
| 91 | Error Code | Set when exception code 04h is generated (see table above). <ul style="list-style-type: none"> • 00h No error • 02h Low/High limit exceeded • 03h Faulty Index: Unavailable index of an array parameter • 05h Incorrect Data Type: Value does not match the data type of the parameter • 65h General Error: Undefined error when handling query |
| 92 | Failed Register | The last register (discrete input, coil, or holding register) that failed to be read or written. |
| 93 | Last Register Written Successfully | The last register that was written successfully. |
| 94 | Last Register Read Successfully | The last register that was read successfully. |



Fieldbus control through a fieldbus adapter


Contents of this chapter

This chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) through an optional fieldbus adapter module.


The fieldbus control interface of the drive is described first, followed by a configuration example.

System overview

The drive can be connected to an external control system through a serial communication link using a fieldbus adapter. The fieldbus adapter can be installed into any free drive slot.



Data Flow



The drive can be set to receive all of its control information through the fieldbus interface, or the control can be distributed between the fieldbus interface and other available sources such as digital and analog inputs.


Fieldbus adapters are available for various serial communication systems and protocols, for example

- CANopen (FCAN-01 adapter)
 - ControlNet (FCNA-01 adapter)
 - DeviceNet (FDNA-01 adapter)
 - EtherCAT® (FECA-01 adapter)
 - EtherNet/IP™ (FENA-11 or FENA-21 adapter)
 - Modbus/RTU (FSCA-01 adapter)
 - Modbus/TCP (FENA-11 or FENA-21 adapter)
 - POWERLINK (FEPL-02 adapter)
 - PROFIBUS DP (FPBA-01 adapter)
 - PROFINET IO (FENA-11 or FENA-21 adapter).
-

Basics of fieldbus control interface

The cyclic communication between a fieldbus system and the drive consists of 16 and 32-bit input and output data words. The drive supports the use of maximum 12 data words (16 bits) in each direction.

Data transmitted from the drive to the fieldbus controller is defined by parameters [52.01 FBA A data in1](#) ... [52.12 FBA A data in12](#). The data transmitted from the fieldbus controller to the drive is defined by parameters [53.01 FBA A data out1](#) ... [53.12 FBA A data out12](#).



- 1) See also other parameters which can be controlled from fieldbus.
- 2) The maximum number of used data words is protocol-dependent.
- 3) Profile/instance selection parameters. Fieldbus module specific parameters. For more information, see the *User's Manual* of the appropriate fieldbus adapter module.

■ Control word and Status word

The Control word is used for controlling the drive from a fieldbus system. It is sent by the fieldbus master station to the drive through the adapter module. The drive switches between its states according to the bit coded instructions on the Control word, and returns status information to the master in the Status word.

The contents of the Control word and the Status word are detailed on pages [467](#) and [468](#) respectively. The drive states are presented in the state diagram (page [470](#)).

If parameter [50.12 FBA A debug mode](#) is set to *Fast*, the Control word received from the fieldbus is shown by parameter [50.13 FBA A control word](#), and the Status word transmitted to the fieldbus network by [50.16 FBA A status word](#).

■ References


References are 16-bit words containing a sign bit and a 15-bit integer. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference.

ABB drives can receive control information from multiple sources including analog and digital inputs, the drive control panel and a fieldbus adapter module. To control the drive through the fieldbus, the module must be defined as the source for control information, example, Reference.

If parameter [50.12 FBA A debug mode](#) is set to *Fast*, the references received from the fieldbus are displayed by [50.14 FBA A reference 1](#) and [50.15 FBA A reference 2](#).

Scaling of references

The references are scaled as shown below. The values REF_x MIN and REF_x MAX are set by parameters 46.01...46.07 which scaling is in use depends on the setting of [50.04 FBA A ref1 type](#) and [50.05 FBA A ref2 type](#).



The scaled references are shown by parameters [03.05 FB A reference 1](#) and [03.06 FB A reference 2](#).


■ Actual values

Actual values are 16-bit words containing information on the operation of the drive. The types of the monitored signals are selected by parameters [50.07 FBA A actual 1 type](#) and [50.08 FBA A actual 2 type](#).

If parameter [50.12 FBA A debug mode](#) is set to *Fast*, the actual values sent to the fieldbus are displayed by [50.17 FBA A actual value 1](#) and [50.18 FBA A actual value 2](#).


Scaling of actual values

The actual values are scaled as shown below. The values REFx MIN and REFx MAX are set by parameters 46.01...46.04 which scaling is in use depends on the setting of parameters 50.04 and 50.05.



■ Contents of fieldbus Control word

The upper case boldface text refers to the states shown in the state diagram (page 470).

| Bit | Name | Value | STATE/Description |
|-----|--------------|-------|--|
| 0 | Off1 control | 1 | Proceed to READY TO OPERATE . |
| | | 0 | Stop along currently active deceleration ramp. Proceed to OFF1 ACTIVE ; proceed to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active. |
| 1 | Off2 control | 1 | Continue operation (OFF2 inactive). |
| | | 0 | Emergency OFF, coast to a stop. Proceed to OFF2 ACTIVE , proceed to SWITCH-ON INHIBITED . |
| 2 | Off3 control | 1 | Continue operation (OFF3 inactive). |
| | | 0 | Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE ; proceed to SWITCH-ON INHIBITED .  WARNING: Ensure motor and driven machine can be stopped using this stop mode. |
| 3 | Run | 1 | Proceed to OPERATION ENABLED . Note: Run enable signal must be active; see drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal. |
| | | 0 | Inhibit operation. Proceed to OPERATION INHIBITED . |

| Bit | Name | Value | STATE/Description |
|---------|---------------|-------|---|
| 4 | Ramp out zero | 1 | Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT ENABLED . |
| | | 0 | Force Ramp function generator output to zero. The drive immediately decelerates to zero speed (observing the torque limits). |
| 5 | Ramp hold | 1 | Enable ramp function. Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR ENABLED . |
| | | 0 | Halt ramping (Ramp Function Generator output held). |
| 6 | Ramp in zero | 1 | Normal operation. Proceed to OPERATING . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters. |
| | | 0 | Force Ramp function generator input to zero. |
| 7 | Reset | 0=>1 | Fault reset if an active fault exists. Proceed to SWITCH-ON INHIBITED . Note: This bit is effective only if the fieldbus interface is set as the source of the reset signal by drive parameters. |
| | | 0 | Continue normal operation. |
| 8 | Inching 1 | 1 | Accelerate to inching (jogging) setpoint 1. Notes: Bits 4...6 must be 0. See also section <i>Scalar motor control</i> (page 71). |
| | | 0 | Inching (jogging) 1 disabled. |
| 9 | Inching 2 | 1 | Accelerate to inching (jogging) setpoint 2. See notes at bit 8. |
| | | 0 | Inching (jogging) 2 disabled. |
| 10 | Remote cmd | 1 | Fieldbus control enabled. |
| | | 0 | Control word and reference not getting through to the drive, except for bits OFF1, OFF2 and OFF3. |
| 11 | Ext ctrl loc | 1 | Select External Control Location EXT2. Effective if control location is parameterized to be selected from fieldbus. |
| | | 0 | Select External Control Location EXT1. Effective if control location is parameterized to be selected from fieldbus. |
| 12...15 | Reserved. | | |

■ Contents of the fieldbus Status word

The upper case boldface text refers to the states shown in the state diagram (page 470).

| Bit | Name | Value | STATE/Description |
|-----|--------------------|-------|--------------------------------|
| 0 | Ready to switch ON | 1 | READY TO SWITCH ON. |
| | | 0 | NOT READY TO SWITCH ON. |
| 1 | Ready run | 1 | READY TO OPERATE. |
| | | 0 | OFF1 ACTIVE. |
| 2 | Ready ref | 1 | OPERATION ENABLED. |
| | | 0 | OPERATION INHIBITED. |
| 3 | Tripped | 1 | FAULT. |
| | | 0 | No fault. |

| Bit | Name | Value | STATE/Description |
|-----|---------------------|-------|---|
| 4 | Off 2 inactive | 1 | OFF2 inactive. |
| | | 0 | OFF2 ACTIVE. |
| 5 | Off 3 inactive | 1 | OFF3 inactive. |
| | | 0 | OFF3 ACTIVE. |
| 6 | Switch-on inhibited | 1 | SWITCH-ON INHIBITED. |
| | | 0 | – |
| 7 | Warning | 1 | Warning active. |
| | | 0 | No warning active. |
| 8 | At setpoint | 1 | OPERATING Actual value equals reference = is within tolerance limits, i.e. in speed control, speed error is 10% max. of nominal motor speed. |
| | | 0 | Actual value differs from reference = is outside tolerance limits. |
| 9 | Remote | 1 | Drive control location: REMOTE (EXT1 or EXT2). |
| | | 0 | Drive control location: LOCAL. |
| 10 | Above limit | 1 | Actual speed, frequency or torque equals or exceeds supervision limit. Valid in both directions of rotation. The supervision limits are defined by parameters 46.31 ... 46.33 . |
| | | 0 | Actual speed, frequency or torque within supervision limit. |
| 11 | User bit 0 | - | See parameter 06.30 MSW bit 11 sel. |
| 12 | User bit 1 | - | See parameter 06.31 MSW bit 12 sel. |
| 13 | User bit 2 | - | See parameter 06.32 MSW bit 13 sel. |
| 14 | User bit 3 | - | See parameter 06.33 MSW bit 14 sel. |
| 15 | Reserved | | |

Setting up the drive for fieldbus control

Before configuring the drive for fieldbus control, install the adapter module mechanically and electrically according to the instructions given in the *User's manual* of the appropriate fieldbus adapter module.

1. Power up the drive.
2. Enable the communication between the drive and the fieldbus adapter module by setting parameter [50.01 FBA A enable](#) to Enable.
3. With [50.02 FBA A comm loss func](#), select how the drive should react to a fieldbus communication break.
Note: This function monitors both the communication between the fieldbus master and the adapter module and the communication between the adapter module and the drive.
4. With [50.03 FBA A comm loss t out](#), define the time between communication break detection and the selected action.
5. Select application specific values for the rest of the parameters in group [50 Fieldbus adapter \(FBA\)](#), starting from [50.04](#). Examples of appropriate values are shown in the tables below.
6. Set the fieldbus adapter module configuration parameters in group [51 FBA A settings](#). At the minimum, set the required node address and the communication profile.
7. Define the process data transferred to and from the drive in parameter groups [52 FBA A data in](#) and [53 FBA A data out](#).
Note: The adapter module sets the Status word and Control word automatically into parameters [52.01](#) and [53.01](#) respectively.
8. Save the valid parameter values to permanent memory by setting parameter [96.07 Parameter save manually](#) to [Save](#).
9. Validate the settings made in parameter groups 51, 52 and 53 by setting parameter [51.27 FBA A par refresh](#) to [Refresh](#).
10. Set the relevant drive control parameters to control the drive according to the application. Examples of appropriate values are shown in the tables below.

■ Parameter setting example: FPBA (PROFIBUS DP)

This example shows how to configure a basic speed control application that uses the PROFIdrive communication profile with PPO Type 2. The start/stop commands and reference are according to the PROFIdrive profile, speed control mode.

The reference value ± 16384 (4000h) corresponds to parameter [46.01 Speed scaling](#) in the forward and reverse directions.

| Direction | PZD1 | PZD2 | PZD3 | PZD4 | PZD5 | PZD6 |
|-----------|--------------|--------------------|---------------|------------|------|------|
| Out | Control word | Speed reference | Acc time 1 | Dec time 1 | | |
| In | Status word | Speed actual value | Motor current | DC voltage | | |

The table below gives the recommended drive parameter settings.

| Drive parameter | Setting for ACS880 drives | Description |
|---|----------------------------|--|
| 50.01 FBA A enable | 1 = Enable | Enables communication between the drive and the fieldbus adapter module. |
| 50.04 FBA A ref1 type | 4 = Speed | Selects the fieldbus A reference 1 type and scaling. |
| 50.07 FBA A actual 1 type | 0 = Auto | Selects the actual value type and scaling according to the currently active Ref1 mode defined in parameter 50.04 . |
| 51.01 FBA A type | 1 = FPBA ¹⁾ | Displays the type of the fieldbus adapter module. |
| 51.02 Node address | 3 ²⁾ | Defines the PROFIBUS node address of the fieldbus adapter module. |
| 51.03 Baud rate | 12000 ¹⁾ | Displays the current baud rate on the PROFIBUS network in kbit/s. |
| 51.04 MSG type | 1 = PPO1 ¹⁾ | Displays the telegram type selected by the PLC configuration tool. |
| 51.05 Profile | 0 = PROFIdrive | Selects the Control word according to the PROFIdrive profile (speed control mode). |
| 51.07 RPBA mode | 0 = Disabled | Disables the RPBA emulation mode. |
| 52.01 FBA data in1 | 4 = SW 16bit ¹⁾ | Status word |
| 52.02 FBA data in2 | 5 = Act1 16bit | Actual value 1 |
| 52.03 FBA data in3 | 01.07 ²⁾ | Motor current |
| 52.05 FBA data in5 | 01.11 ²⁾ | DC voltage |
| 53.01 FBA data out1 | 1 = CW 16bit ¹⁾ | Control word |
| 53.02 FBA data out2 | 2 = Ref1 16bit | Reference 1 (speed) |
| 53.03 FBA data out3 | 23.12 ²⁾ | Acceleration time 1 |
| 53.05 FBA data out5 | 23.13 ²⁾ | Deceleration time 1 |
| 51.27 FBA A par refresh | 1 = Refresh | Validates the configuration parameter settings. |
| 19.12 Ext1 control mode 1 | 2 = Speed | Selects speed control as the control mode 1 for external control location EXT1. |
| 20.01 Ext1 commands | 12 = Fieldbus A | Selects fieldbus adapter A as the source of the start and stop commands for external control location EXT1. |
| 20.02 Ext1 start trigger type | 1 = Level | Selects a level-triggered start signal for external control location EXT1. |
| 22.11 Speed ref1 source | 4 = FB A ref1 | Selects fieldbus A reference 1 as the source for speed reference 1. |

¹⁾ Read-only or automatically detected/set

²⁾ Example

The start sequence for the parameter example above is given below.

Control word:

- 47Eh (1150 decimal) → READY TO SWITCH ON
- 47Fh (1151 decimal) → OPERATING (Speed mode)

■ Parameter setting example: Using PCP/ESP application through FPBA

This example shows how to configure a PCP/ESP application for Profibus communication using ABB Drives profile with PPO Type 8 telegram type. The start/stop commands are according to the Main control word ([06.01 Main control word](#)). Reference is according to application reference ([74.05 Speed ref source](#)).

Example: Assume that pump maximum speed is 80 Prpm and required speed is 60 Prpm. For ABB Drive profile fieldbus speed reference value 20000 corresponds to maximum motor speed. For gear reduction ratio value 10 ([74.03 Gear reduction ratio](#)) maximum pump speed 80 Prpm corresponds to fieldbus reference value 2000. Fieldbus reference for 60 Prpm can be calculated as: $60 * 2000 / 80 = 1500$.

Speed ref 1 in PZD 2 OUT should be equal to 1500.

If actual value 1 in PZD 2 IN equals 50, then pump speed is 50 Prpm.

The table below gives the recommended drive parameter settings.

| Direction | PZD1 | PZD2 | PZD3 | PZD4 |
|-----------|-------------------|------------|------|------------|
| Out | Main control word | Speed ref1 | | |
| In | Drive status word | Rod speed | | Rod torque |

| Direction | PZD5 | PZD6 | PZD7 | PZD8 |
|-----------|------|------------------|------|------------------|
| Out | | | | |
| In | | Output frequency | | Pump status word |

The table below gives the recommended drive parameter settings.

| Drive parameter | Setting for ACS880 drive | Description |
|-------------------------------------|--------------------------|--|
| 20.01 Ext1 commands | Fieldbus A | Selects the source of start command. |
| 50.01 FBA A enable | Option slot 3 | Enables communication between the drive and the fieldbus adapter module. Fieldbus adapter module must be attached to slot 3. |
| 51.02 Node address | 3 ²⁾ | Defines the PROFIBUS node address of the fieldbus adapter module. |
| 51.03 Baud rate | 12000 ¹⁾ | Displays the current baud rate on the PROFIBUS network in kbit/s. |
| 51.05 Profile | ABB Drives ²⁾ | Selects the Control word according to the ABB Drives profile. |
| 51.27 FBA A par refresh | Refresh | Validates the configuration parameter settings. |

| Drive parameter | Setting for ACS880 drive | Description |
|-----------------------------------|-------------------------------------|--|
| 52.01 FBA data in1 | SW 16bit ²⁾ | Status word of the drive is sent to the master (PLC). |
| 52.02 FBA data in2 | 9.6 Rod speed ²⁾ | Rod speed |
| 53.04 FBA data in4 | 9.1 Rod torque ²⁾ | Rod torque |
| 52.06 FBA data in6 | 1.6 Output frequency ²⁾ | Output frequency of the drive |
| 52.08 FBA data in8 | 9.14 Pump status word ²⁾ | Pump status word (16 bit) |
| 53.01 FBA data out1 | CW 16bit ²⁾ | Command word from master to the drive. |
| 53.02 FBA data out2 | Ref1 16bit ²⁾ | Speed reference from master to the drive. |
| <i>74.01 Pump enable</i> | Enable | Enables the pump related application features. |
| <i>74.03 Gear reduction ratio</i> | 10 ²⁾ | Set 10 as transmission reduction ratio for ESP application. |
| <i>74.05 Speed ref source</i> | FBA1 ref | Set FBA Ref1 as a source for application speed reference. |
| <i>74.07 Minimum rod speed</i> | -10 ²⁾ | Minimum allowed rod speed. |
| <i>74.08 Maximum rod speed</i> | 80 ²⁾ | Maximum allowed rod speed. |
| <i>74.19 Maximum rod torq ref</i> | 12 ²⁾ | Maximum allowed torque reference for ESP. |
| <i>74.10 Rod acc time</i> | 20 ²⁾ | Time period that is required to accelerate from zero to 46.01 Speed scaling. |
| <i>74.11 Rod dec time</i> | 20 ²⁾ | Time period that is required to decelerate from 46.01 Speed scaling to zero speed. |

¹⁾ Read-only or automatically detected/set

²⁾ Example

The start sequence for the parameter example above is given below. Application command word (*06.02 Application control word*):

- 47Eh (1150 decimal) → READY TO SWITCH ON
- 47Fh (1151 decimal) → OPERATING (Speed mode)
- 477h (1143 decimal) → STOP (Coast)




Control chain diagrams


Contents of this chapter

The chapter presents the reference chains of the drive. For a general diagram, see section [Operating modes of the drive](#) (page 53).


Speed reference source selection for application




Speed reference source selection




Speed reference source selection II




Speed reference ramping and shaping




Motor feedback configuration




Load feedback and position counter configuration




Speed error calculation



Speed controller



Frequency reference modification



14

Appendix: ESP with step-up transformer and sine filter

Contents of this chapter


This chapter provides an overview of ESP with step-up transformer and sine filter.

ESP with step-up transformer and sine filter

Sine filters are used to suppress the high frequency components of the drive output. The step up transformer enables the use of a medium-voltage motor with a low-voltage drive.

■ Block diagram

The following block diagram represents the ACS880 drive connected to motor with a step-up transformer and sine filter.



■ Current calculation

For ESP with sine filter and step-up transformer instead of using the motor rating plate data, set parameter [99.07 Motor nominal voltage](#) according to the nominal supply voltage of the drive (example: 690 V). Also set the parameter [99.06 Motor nominal current](#) to

$$\frac{U_2}{U_1} \cdot I_n$$

Where U_1 and U_2 are the primary and secondary voltages of the step-up transformer respectively.

■ Primary and secondary voltage calculation

Required data:

Motor: $U_n, I_n, \cos(\varphi_n), f_n$

Cable: $R_c, L_c, length$

If the cable characteristics are not known, typical values can be used:

$$R_c = 0.27 \frac{\Omega}{km}$$

$$L_c = 0.33 \frac{mH}{km}$$

Motor data:

Nominal impedance,

$$Z_m = \frac{U_n}{I_n \cdot \sqrt{3}}$$

Resistive component,

$$R_m = Z_m \cdot \cos(\varphi_n)$$

Reactive component,

$$X_m = Z_m \cdot \sqrt{1 - \cos^2(\varphi_n)}$$

Cable reactance at frequency f ,

$$X_c = 2\pi f L_c$$

Primary side:


The primary voltage can be assumed to be 10% lower than the supply voltage of the drive because of the voltage drop in the sine filter and the drive.

The primary voltage U_1 is

- $0.85 \times 400 \text{ V} = 340 \text{ V}$ (for 400 V drives)
- $0.87 \times 500 \text{ V} = 435 \text{ V}$ (for 500 V drives)
- $0.9 \times 690 \text{ V} = 620 \text{ V}$ (for 690 V drives)

Secondary side:

The following diagram represents the secondary side of a step-up system.



The impedance of the secondary side is

$$Z_1 = \sqrt{(R_C + R_m)^2 + (X_C + X_m)^2}$$

The system is dimensioned using the nominal current of the motor:

$$I_2 = I_n$$

The minimum voltage for the transformer secondary is

$$U_2 = \sqrt{3} \cdot I_2 \cdot Z_1$$

■ Example

The nominal voltage of the drive in this calculation is 690 V.

Motor

$$U_n = 3300V$$

$$I_n = 106A$$

$$f_n = 50Hz$$

$$\cos(\varphi_n) = 0.82$$

$$Z_m = \frac{3300}{106\sqrt{3}}\Omega \approx 17.97\Omega \Rightarrow R_m = 17.97 \cdot 0.82\Omega \approx 14.74\Omega$$

$$X_m = 17.97 \cdot \sqrt{1 - 0.82^2}\Omega \approx 10.29\Omega$$

Cable

$$\text{Length} = 5km$$

$$R_c = 0.27 \frac{\Omega}{km} \Rightarrow R_c = 5 \cdot 0.27\Omega \approx 1.35\Omega$$

$$L_c = 0.33 \frac{mH}{km} \Rightarrow L_c = 5 \cdot 0.33mH \approx 1.65mH$$

$$X_c = 2\pi fL_c \Rightarrow X_c = 2 \cdot \pi \cdot 50 \cdot 1.65 \cdot 10^{-3} \approx 0.52\Omega$$

Secondary side

$$Z_1 = \sqrt{(1.53 + 14.74)^2 + (0.52 + 10.29)^2} \Omega \approx 10.38 \Omega$$

Secondary side current,

$$I_2 = I_n = 106 \text{ A}$$

The minimum voltage for secondary side,

$$U_s = \sqrt{3} \cdot 106 \text{ A} \cdot 19.38 \Omega \approx 3558 \text{ V}$$

The secondary voltage of the transformer is chosen as,

$$U_{N2} = 3560 \text{ V}$$

Primary side

The primary voltage of the transformer is,

$$U_{N1} = 0.9 \cdot 690 \text{ V} \approx 620 \text{ V}$$

Calculated current,

$$\frac{U_{N2}}{U_{N1}} \cdot I_n = \frac{3560}{620} \cdot 106 \approx 608.6 \text{ A}$$

Set par. [99.06 Motor nominal current](#) to 608.6 A

For more information, see the *Sine Filters User's Manual* (3AFE68389178 [English]).

Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/searchchannels.

Product training

For information on ABB product training, navigate to new.abb.com/service/training.

Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at www.abb.com/drives/documents.

Contact us

www.abb.com/drives

www.abb.com/drivespartners

3AXD50000016186 Rev B (EN) 2015-10-27

Power and productivity
for a better world™

